


TORO®

MODEL NO. 38080-3900001 & UP


**PARTS
CATALOG****824 SNOWTHROWER**

C-0041

AUGER ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	43-7440	Sideplate - Auger Right	1	17	3257-23	Key - Woodruff	2
2	26-6140	Auger - Right	1	18	3231-27	Bolt Carriage	4
*	26-6150	Auger - Left	1	19	56-2450	Chute	1
3	40-8120	Housing - Auger	1	20	54-9770	Wire - Chute	1
5	321-44	Screw - Hex. Hd. Cap	2	21	27-0210	Screw - Special	4
6	66-8010	Spacer	2	22	43-7470	Gear - Chute Swivel	1
7	3242-4	Screw - Set	1	23	40-8150	Retainer - Chute	2
8	3230-1	Bolt - Carriage	3	24	3290-326	Pushnut	2
9	3296-39	Nut - Lock	3	25	3290-340	Washer - Belleville	2
10	32153-2	Nut - Lock	2	26	3296-29	Nut - Lock	15
11	20-4320	Washer - Rubber	2	27		Bearing - Flange Rear	1
12	63-3760	Decal - Discharge	1	28	63-3450	Bearing - Impeller	1
13	20-1410	Handle - Deflector	1	29		Bearing - Flange, Front	1
14	11-9379	Deflector Chute (Incl. Ref.#12)	1	30	26-6400	Positioner - Scraper, Blade	2
15	3-0737	Washer - Thrust	2	31	5-7290	Spring - Scraper, Blade	2
16	20-1310	Pulley - Impeller	1	32	20-0300	Spacer - Scraper Blade	2
				33	3296-42	Nut - Lock	10

*Not Illustrated




C-0041

AUGER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
34	20-0990	Bearing - Flange Auger	2
35	20-0980	Bearing - Auger	2
36	20-1000	Bearing - Flange Auger	2
37	3234-14	Screw - Hex. Hd. Cap	10
38	17-6500	Decal - Auger Side Plate	2
39	321-3	Screw - Hex. Hd. Cap	8
40	3-0750	Washer - Flat	2
41	323-6	Screw - Hex. Hd. Cap	2
42	3234-11	Bolt - Hex. Flange	2
43	20-2840	Skid - Auger	2
44	3290-357	Nut - Flange	4
45	43-7430	Sideplate - Auger L.H.	1
46	25-5140	Standoff - Scraper Blade	2
47	25-5150	Bumper - Scraper Blade	2
48	20-1320	Blade - Scraper	1
49	32128-21	Nut - Lock	2
50	25-5090	Spacer - Auger Hub	2
51	17-7030	Bolt - Auger	2
52	66-6941	Shaft - Impeller	1
53	3257-33	Key - Woodruff	2
54	20-1170	Shaft - Auger	1
55	37-8860	Case - Gear (Incl. Ref. #68 & 69)	1
56	281-1	Plug - Pipe	1

Ref. No.	Part No.	Description	No. Used
57	5-7180	Gear - Worm	1
58	252-71	Bearing - Thrust	2
59	252-78	Washer - Thrust	1
60	252-76	Bearing - Thrust	1
61	3-8664	Washer - Thrust	1
62	32120-72	Ring - Retaining	1
63	256-32	Bushing	1
64	5-7170	Worm	1
65	252-77	Washer - Thrust	1
66	51-0460	Gasket	1
67	37-8850	Gear Case (Incl.ref.#68, 69)	1
68	256-237	Bushing	2
69	7-0045	Seal - Oil	2
70	32144-41	Screw - Thread Forming	8
71	20-3210	Bushing	1
72	237-87	Seal	1
73	53-7670	Decal - Warning Auger	1
74	66-6930	Impeller	1
75	6-8590	Impeller Key	1
76	3242-4	Screw - Sq. Hd. Set	1
*	19-7002	Gear Case Assembly	1
*	20-0690	Drift Breaker Kit (Optional)	1
*	12-8789	Bearing Assembly (Incl. Ref. #27 & 29)	1

* Not Illustrated




C-0042

TRACTION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290-383	Pushnut	1
2	3256-25	Washer - Flat	1
3	20-1420	Side Plate Traction	1
4	20-1160	Spring - Clutch Torsion	1
5	8-9019	Rod - Clutch (Incl. Ref.#66)	1
6	3296-59	Nut - Lock	1
7	32144-15	Screw - Thd. Form	8
8	3-4244	Pulley Idler	1
9	3256-45	Washer - Flat	2
10	323-8	Screw - Hex. Hd. Cap	1
11	32108-94	Screw - Flat Hd.	4
12	20-1620	Bearing - Friction Wheel	2
13	11-4640	Spring - Clutch Control	1
14	20-1580	Pivot Shaft	1
15	32144-70	Screw - Thread Forming	9
16	3245-32	Screw - Set	2
17	3296-29	Nut - Lock	7
18	3256-23	Washer	4
19	36-9990	Bracket - Shaft Support	1
20	322-2	Screw - Hex. Hd. Cap	2
21	322-3	Screw - Hex. Hd. Cap	2

Ref. No.	Part No.	Description	No. Used
22	321-33	Screw - Hex. Hd. Cap	1
23	32121-6	Pin - Roll	1
24	3-0737	Washer - Thrust	5
25	26-6370	Spacer - Drive Shaft	1
26	20-1080	Support - Clutch Shaft	1
27	322-9	Screw - Hex. Hd. Cap	2
28	26-6360	Frame - Center	1
29	20-1760	Bracket - Pivot	1
30	26-6380	Standoff - Drive Shaft	2
31	20-1730	Bearing - Axle	3
32	20-1550	Plate - Friction	1
33	3296-8	Nut - Lock	1
34	36-9980	Bearing - Pillow Block	1
35	5-9820	Sprocket	1
36	3-7384	Spacer	1
37	2710-6	Link - Connecting	1
38	20-1810	Chain	1
39	20-1640	Gear & Bushing Assembly (Incl. Ref. #40)	1
40	3-1506	Bushing - Flanged	2
41	20-1430	Side Plate Traction	1
42	11-8140	Screw - Shoulder	3




C-0042

TRACTION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
43	231-120	Tire	2
44	232-46	Tube	2
45	3290-243	Pin - Klik	2
46	241-128	Wheel	2
47	32144-4	Screw - Thread Forming	4
48	20-1680	Axle & Gear Assembly	1
49	20-1630	Shaft - Friction Wheel	1
50	3-6168	Key - Square	1
51	20-1780	Linkage - Shaft	1
52	20-1770	Plate - Pivot	1
53	32151-36	Ring - Snap	1
54	252-71	Bearing - Thrust	1
55	11-8050	Slider Ring Collar	1
56	11-8080	Ring - Slider	2
57	32121-9	Pin - Roll	1

Ref. No.	Part No.	Description	No. Used
58	32128-12	Nut - Flange	1
59	3290-212	Washer - Lock	2
60	3296-6	Nut	1
61	22-7930	Shaft - Drive	1
62	20-1840	Shield - Lower	1
63	20-3310	Hub - Traction Drive	1
64	40-8170	Wheel - Friction	1
65	3296-47	Nut - Lock	4
66	66-8060	Pad - Brake Moulded	1
67	66-6760	Spring	1
68	66-7560	Bracket - Spring	1
69	32153-2	Nut - Lock	1
70	66-6760	Spring	1
*	12-0179	Loose Parts Kit	1
*	56-2700	Tire Chain Kit (Optional)	1

*Not Illustrated




C-0058

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3255-8	Washer - Lock	3
2	20-1800	Arm - Idler	1
3	52-2670	Fuel Tank Assembly	1
4	40-8490	Spacer	1
5	5-0930	Key	1
6	74-1170	Decal - danger	1
7		Engine	1
8	63-3190	Decal - Throttle	1
9	53-7680	Decal - Warning	1
10	39-3850	Decal - Choke	1
11	32144-4	Screw - Thread Forming	1
12	41-8601	Module - Interlock	1
13	3296-29	Nut - Lock	4
14	289-52	Nipple - Pipe	1
15	288-2	Cap - Pipe	1

Ref. No.	Part No.	Description	No. Used
16	32144-15	Screw - Hex.Thread Form	4
17	37-0320	Plate - Engine Mounting	1
18	322-7	Screw - Hex. Hd. Cap	4
19	17-5530	Retainer - Belt	1
20	3256-23	Washer	3
21	20-1820	V-Belt Traction	1
22	26-9670	V-Belt Auger	1
23	32144-4	Screw - Thread Forming	2
24	20-1830	Guard - Belt	1
25	21-4100	Pulley	1
26	323-8	Screw - Hex. Hd. Cap	1
27	3-4244	Pulley - Idler	1
28	3246-18	Screw - Set	2
29	3296-59	Nut - Lock	1
30	3210-3	Screw - Hex. Hd. Cap	3




C-0059

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	14-5469	Escutcheon Plate (Incl. Ref.#23)	1
2	237-130	Bushing - Snap	1
3	3290-354	Clip	2
4	29-6360	Decal - Safety Interlock	1
5	3290-313	Screw - Pan Hd. Machine	4
6	40-8200	Switch - Micro	2
7	22-7950	Pad - Switch Mounting	1
8	32144-4	Screw - Taptite	1
9	40-9690	Handle - Interlock Switch	1
13	63-8360	Key	2
14	218-461	Nut - Hex.	1
15	3254-5	Washer - Lock	1
16	3296-2	Nut Lock	2
17	3251-5	Screw - Machine	2
18	22-9740	Spacer Interlock	2
19	22-9730	Spring Interlock	1
20	233-21	Knob	2
21	22-9751	Slide Interlock	1
22	40-8241	Switch - On /Off (Incl. Ref. #14 &15)	1
23	74-1390	Decal - Instructions	1
24	3296-42	Nut Lock	4

Ref. No.	Part No.	Description	No. Used
25	43-7450	Clamp - Wire	5
26	3290-257	Washer - Pyramidal	2
27	43-7460	Stud - Mounting	5
28	25-6041	Handle - L.H.	1
29	74-1380	Grip - Handle	2
30	32151-43	Ring - Klip	2
31	321-11	Screw - Hex. Hd. Cap	3
32	321-9	Screw - Hex. Hd. Cap	1
33	63-3510	Decal - Chute Direction	1
34	3290-320	Pushnut	2
35	66-6540	Grip - Chute Control	1
36	40-8311	Rod - Chute Control	1
37	256-249	Nyliner	1
38	3296-29	Nut Lock	2
39	12-7739	Bracket - Chute Control (Incl. Ref. #33 & 37)	1
40	17-5630	Spring - Conical	1
41	323-4	Screw - Hex. Hd. Cap	4
42	3230-22	Bolt - Carriage	1
43	3290-238	Washer - Pyramidal	1
44	40-8280	Bracket - Worm	1
45	40-8250	Gear - Worm, Chute	1




C-0059

HANDLE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
46	3220-3	Nut - Jam	3	60	40-8630	Wire Harness Interlock	1
47	40-8180	Clevis	3	61	322-9	Screw - Hex. Hd. Cap	1
48	3290-398	Retainer - Nut	4	62	3256-25	Washer	2
49	40-8431	Handle R.H.	1	63	3290-213	Washer - Lock	1
50	3272-6	Pin - Cotter	3	64	11-8140	Screw - Shoulder	1
51	283-1	Pin - Clevis	3	65	20-1910	Rod - Pivot	1
52	20-1980	Rod - Speed Control	2	66	28-5660	Spacer - Shift Rod	1
53	237-89	Grommet	1	67	20-1920	Lever	1
54	3256-24	Washer	3	68	66-6580	Decal - Escutcheon	1
55	3272-6	Pin - Cotter	3	69	28-5670	Spacer - Auger Lever	1
56	20-2020	Shift - Lever	1	70	25-9760	Strap - Escutcheon Support	1
57	20-2010	Bracket - Shift	1	71	3290-340	Washer - Belleville	4
58	20-1970	Rod Traction Control	1	*	3290-378	Tie - Wrap	2
59	32152-1	Nut - Lock	1				


*Not Illustrated



ELECTRIC START MOTOR KIT NO. 37-4810

Ref. No.	Part No.	Description	No. Used
1	33842	Ring – Retaining	1
2	33430	Retainer – Spring	1
3	33431	Spring – Anti-drift	1
4	33432	Gear	1
5	33433	Nut – Engagement	1
6	35449	Cap Assembly – Cap End (Incl. Ref. #7)	1
7	35450	"O" Ring	2
8	335541A	Armature	1
9	35451	Housing Assembly	1
10	35452	Card Assembly – Brush	1
13	590500	Washer – Thrust	1

Ref. No.	Part No.	Description	No. Used
14	33441	Screw – Ground	1
15	35453	Cap Assembly Commutator End (Incl. Ref.#7)	1
16	35454	Switch Box Assembly	1
22	35455	Bolt – Case	2
23	35456	Screw – Grounding	1
24	33451	Cover – Dust	1
26	650819	Screw – Self Tapping	2
29	32450A	Cord – Power (10'6")	1
30	30063	Screw – Fil. Hd.	2
31	650820	Screw – Hex.Hd. Shoulder	2




CARBURETOR NO. 632334A

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	631776A	Shaft & Lever Assembly	1	*30	631021	Inlet Needle – Seat & Spring Clip (Incl. Ref. #31)	1
2	631970	Spring – Throttle Return	1	31	631022	Clip – Spring	1
6	631778	Throttle – Shutter	1	32	27136A	Bowl Drain Assembly (Incl. Ref. # 33)	1
7	650506	Screw – Throttle & Choke Shutter	4	33	27554	Gasket – Drain Plunger	1
10	632112	Choke Shaft & Lever Ass'y	1	40	632239	High Speed Mixture Screw Assembly	1
14	632174	Shutter – Choke	1	*41	630740	O–Ring – High Speed Mixture Screw	1
15	630735	Spring – Choke Positioning	1	42	630739	Washer – High Speed Mixture Screw	1
16	632164	Fitting – Fuel	1	43	630738	Tension Spring – High Speed Mixture Screw	1
17	650417	Screw – Idle Speed	1	*44	27110	Washer – Bowl Nut	1
18	630766	Spring – Tension	1	*47	630748	Welch Plug – Idle Mixing Well	1
20	632281	Screw – Idle Mixture	1	*48	631027	Welch Plug – Atmospheric Vent	1
21	630766	Spring – Idle Mixture Screw	1	60	632347	Repair Kit	1
22	630739	Washer – Idle Screw	1				
*23	630740	O–Ring – Idle Screw	1				
25	631951	Bowl – Float (Incl. Ref. #32, & 33)	1				
*27	631024	Shaft – Float	1				
28	632019	Float	1				
*29	631028	O–Ring – Float Bowl to Body	1				

*Included in Carburetor Repair Kit Ref. #60

ENGINE TECUMSEH MODEL HMSK80-155438R



ENGINE TECUMSEH MODEL HMSK80-155483R

Ref. No.	Part No.	Description	No. Used
1	35385	Cylinder (Incl. Ref. #2, 20, & 72)	1
2	27652	Pin - Dowel	2
3	650820	Screw - Hex Hd. Shoulder	2
15	30699C	Rod Ass'y - Governor (Incl. Ref. #15A & 15B)	1
15A	30700	Yoke - Governor	1
15B	650494	Screw - Fil. Hd. Sems	1
16	33454	Lever - Governor	1
17	29916	Clamp - Governor Lever	1
18	650548	Screw - Hex Washer Hd.	1
20	35319	Seal - Oil	1
25	35326	Baffle - Blower Housing	1
26	650561	Screw - Hex Washer Hd. Durluk	2
30	35372	Crankshaft	1
35	29826	Screw - Hex Washer Hd.	1
36	29918	Washer - E.T. Lock	1
37	29216	Nut & Lockwasher Keps	1
37A	30322	Locknut - Hex Keps	1
38	29642	Ring - Retaining	1
40	34552	Piston - Pin & Ring Ass'y Std. (Incl. Ref. #41, 42, & 43)	1
40	34553	Piston - Pin & Ring Ass'y (.010 Oversize) (Incl. Ref. #41, 42, & 43)	1
40	34554	Piston - Pin & Ring Ass'y (.020 Oversize) (Incl. Ref. #42, 42, & 43)	1
41	34329A	Piston & Pin Ass'y (Std.) (Incl. Ref. #43)	1
41	34330A	Piston & Pin Ass'y (.010 Oversize) (Incl. Ref. #43)	1
41	34331A	Piston & Pin Ass'y (.020 Oversize) (Incl. Ref. #43)	1
42	34332	Ring Set - Piston (Std.)	1
42	34333	Ring Set - Piston (.010 Oversize)	1
42	34334	Ring Set - Piston (.020 Oversize)	1
43	27888	Ring - Piston Pin Retaining	2
45	35373A	Rod Ass'y - Connecting (incl. Ref. #46, 47, & 49)	1
46	650908	Bolt - Connecting Rod	1
47	650882	Bolt - Connecting Rod	1
48	34034	Lifter - Valve	2
49	35374	Dipper - Oil	1
50	35375	Camshaft (Mechanical Compression Release)	1
60	33273A	Extension - Blower Housing	1
61	34126	Bracket - Grommet Mounting	1
62	650760	Screw - Pan Hd. Taptite	1
63	28545	Grommet - Plastic	1
65	650128	Screw - Hex Hd. Sems	1
*69	35262	Gasket - Cylinder Cover	1
70	35376	Cover Ass'y - Cylinder (Incl. Ref. #75 & 80)	1

Ref. No.	Part No.	Description	No. Used
71	35377	Bushing - Cylinder Cover	1
72	27642	Plug - Pipe	2
75	35319	Seal - Oil	1
80	31845	Shaft - Governor	1
81	30590A	Washer - Flat	1
82	35378	Gear - Governor (Incl. Ref. #81)	1
83	30588A	Spool - Governor	1
84	29193	Ring - Retaining	1
86	650833	Screw - Hex Washer Hd. Powerlok	7
87	650832	Screw - Hex Washer Hd. Powerlok	1
89	32589	Key - Flywheel	1
90	611091	Flywheel (w/ring gear)	1
92	650880	Washer - Lock	1
93	650881	Nut - Flywheel	1
100	35135	Solid State Ass'y	1
101	610118	Cover - Spark Plug	1
102	650872	Stud - Solid State Mounting	2
103	650814	Screw T-15 Torx Hex Washer Hd. Sems	1
110	35253	Wire - Ground	1
*119	34041A	Gasket - Cylinder Head	1
120	34030	Head - Cylinder	1
125	27878A	Valve - Exhaust (Std.) (Incl. Ref. #151)	1
125	27880A	Valve - Exhaust (1/32" Oversize) (Incl. Ref. #151)	1
126	34035	Valve - Intake (Std.) (Incl. Ref. No. 151)	1
126	34036	Valve - Intake (1/32" Oversize) (Incl. Ref. #151)	1
127	650691	Washer - Flat	2
129	650727	Screw - Special Hex Hd. Tapped	2
130	6021A	Screw - Hex Flange Hd.	7
130A	650802	Screw - Hex Washer Hd. Taptite	1
131A	650713	Screw - Hex Hd.	2
135	35395	Spark Plug (Champion RJ-19LM or equiv.)	1
139	33369	Bracket - Governor Gear	1
140	650836	Screw - Hex Washer Hd. Thread Forming	2
149	27882	Cap - Upper Valve Spring	1
149A	35862	Seal Ass'y - Intake Valve	1
150	27881	Spring - Valve	2
151	32581	Cap - Lower Valve Spring	2
*169	27896A	Gasket - Breather	2
170	28423	Body - Breather	1
171	28424	Element - Breather	1
172	28425	Cover - Breather	1
173	35350	Tube - Breather	1
174	650128	Screw - Hex Hd. Sems	2
178	29752	Nut & Lockwasher	1


*Indicates Parts included in Gasket Set Ref. #400

ENGINE TECUMSEH MODEL HM80-155438R (cont.)

Ref. No.	Part No.	Description	No. Used
182	30088A	Screw - Fil. Hd. Sems	2
183	34587	Bracket - Choke	1
*184	33263	Gasket - Carburetor	1
185	33877	Pipe - Intake	1
186	34667	Link - Governor	1
200	34677	Bracket Ass'y - Control (Incl. Ref. #19, 203, 204, & 206)	1
203	31342	Spring - Compression	1
204	650549	Screw - Fil. Hd.	1
206	610973	Terminal Ass'y	1
207	33878	Link - Governor-to-Throttle	1
209	650821	Screw - Hex Washer Hd. Thread Cutting	2
215	35440	Knob - Control	1
219	34586	Rod - Choke	1
220	35438	Knob - Choke	1
222	28820	Screw - Fil. Hd. Sems	2
223	650378	Screw - T-30 Torx Fil Hd. Sems	2
*224	27915A	Gasket - Intake Pipe	1
260	35447A	Housing - Blower	1
261	650788	Screw - Hex Hd. Spinlock Thread Forming	2
262	29747B	Screw - Hex Hd. Sems	2
265	33272B	Cover - Cylinder Head	1
275	35056	Muffler	1
276	31588	Plate - Lock	1
277	792093	Screw - Flanged Hex Hd.	2
281	33013	Cover - Starter Hole	1
282	650760	Screw - Pan Hd. Taptite	1
285	35985	Hub - Starter	1
286	35446	Screen - Starter	1
287	29752	Nut & Lockwasher	4
290	29774	Line - Fuel (8 1/4")	1
291	30705	Line - Fuel (16")	1
292	26460	Clamp - Fuel Line	4

Ref. No.	Part No.	Description	No. Used
295	35857	Valve - Fuel Shut-Off	1
298	650665	Screw - Hex Washer Hd. Thread Cutting	2
300	34156A	Tank - Fuel (Incl. Ref. #292 & 301)	1
301	35355	Cap - Fuel Tank	1
305	35554	Tube - Oil Fill	1
306	35499	O-Ring	1
308	35540	Clip - Fill Tube	1
310	36205	Dipstick - Oil	1
325	29443	Clip - Spring	1
327	35392	Plug - Starter	1
336	650765	Screw - Hex Washer Hd. Self-Drilling	1
337	35057A	Cover - Carburetor	1
338	28942	Screw - Hex Washer Hd. Sems	2
340	34155	Bracket - Fuel Tank	1
341	34154	Plate - Fuel Tank Mounting	1
342	650561	Screw - Hex Washer Hd. Durluk	1
350	570682	Primer Ass'y	1
351	32180C	Line - Primer	1
355	590574	Starter Handle - Mitten Grip	1
364	33377	Bracket - Carburetor Cover Mounting	1
365	650767	Screw - Hex Washer Hd. Sems Taptite	2
380	632334A	Carburetor (Incl. Ref. #184)	1
390	590672	Starter - Rewind	1
400	33279G	Gasket Set	1
421	730226	SAE5W30 4 Cycle Oil (Quart) RPM Setting: Low Speed 1700, High Speed 3450	1

*Indicates Parts included in Gasket Set Ref. #400



REWIND STARTER NO.590672

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	590599A	Pin – Spring (Incl. Ref.#4)	1	7	590412	Spring – Dog	2
2	590600	Washer	1	8	590682	Pulley & Rewind Spring Assy	1
3	590679	Retainer	1	11	590684	Housing Assembly, Starter	1
4	590601	Washer	1	12	590456	Rope ,Starter	1
5	590678	Spring – Brake	1	13	590574	Handle, Mitten Grip (Not Included With Starter)	1
6	590680	Dog – Starter	2				

[illegible]

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you

MAINTENANCE RECORD

[illegible]