



HD53 Lawn Mower

Model No. 22164TE - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Housing Assembly	 3	Lubrication Equipment Assembly Kawasaki FJ180V-AS28	 15
Housing Assembly No. 108-4750	 4	Cooling Equipment Assembly Kawasaki FJ180V-AS28	 16
Height-of-Cut Assembly	 5	Electric Equipment Assembly Kawasaki FJ180V-AS28	 17
Wheel and Tire Assembly No. 100-2870	 6	Control Equipment Assembly Kawasaki FJ180V-AS28	 18
Transmission Assembly	 7	Carburetor Assembly Kawasaki FJ180V-AS28	 19
Rear Wheel Assembly No. 100-2860	 8	Air Filter and Muffler Assembly Kawasaki FJ180V-AS28	 20
Gear Case Assembly No. 108-8140	 9	Fuel Tank and Fuel Valve Assembly Kawasaki FJ180V-AS28	 21
Engine, Blade and Bag Assembly	 10	Starter Assembly Kawasaki FJ180V-AS28	 22
Handle Assembly	 11	Brake and Cover Assembly Kawasaki FJ180V-AS28	 23
Cylinder and Crankcase Assembly Kawasaki FJ180V-AS28	 12	Decal Assembly Kawasaki FJ180V-AS28	 24
Piston and Crankshaft Assembly Kawasaki FJ180V-AS28	 13		
Valve and Camshaft Assembly Kawasaki FJ180V-AS28	 14		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


❶ Not serviced separately

❷ Obtain from your local Kawasaki dealer




Housing Assembly

Ref	Part No.	Qty.	Description				
1	114-3472	1	Door-Rear				
1:1	114-3470	1	Decal-Warning, Ce				
2	49-2040	10	Screw-HWHTF				
3	3290-337	1	Nut-Speed				
4	107-7493	2	Plate-Support, Door				
5	107-7490	1	Mulch Plug ASM				
6	105-3032	1	Spring-Door, Rear				
7	114-1586	1	Shield-Trailing				
8	107-7497	1	Bracket-Cable, Traction				
9	107-7494	1	Cover-Belt				
10	107-7499	1	Rod-Support, Door				
11	107-3717	1	Discharge Door ASM				
11:2	107-0795	1	Latch-Door				
11:3	107-7456	1	Cap-Door				
11:4	107-7461	1	Screw-Plastite				
12	99-8445	2	Screw-HWH				
13	99-5293	1	Spring-Torsion				
14	99-5291	1	Rod-Cover				
15	112-6416	1	Bracket-Cover				
16	108-3753	1	Chute-Discharge, Side				
18	108-4750	1	Housing ASM				
21	107-7495	1	Tunnel-Discharge				
24	108-3797-03	1	Plate-Cover, Front				




Height-of-Cut Assembly

Ref	Part No.	Qty.	Description				
1	323-12	2	Screw-HH				
2	100-2870	2	Wheel And Tire ASM				
3	114-3467	2	Screw-Shoulder				
4	107-7492	2	Arm-Pivot				
5	107-7491	2	Arm-Spring				
6	110-0549	2	Knob-HOC				
7	603773	4	Nut				
8	49-2040	10	Screw-HWHTF				
10	107-7478	2	Plate-HOC				
13	52-2480	4	Spacer-Wheel				
15	3256-24	2	Washer-Flat				
17	114-3469	1	Decal-Logo				
24	110-4920-03	2	Bracket-Support				



Wheel and Tire Assembly No. 100-2870


Ref	Part No.	Qty.	Description				
1	53-7740	1	Tire				
❶2		1	Wheel ASM				
❶2:1		1	Hub And Bearing ASM				
2:1:1	52-2410	1	Hub-Bearing				
2:1:2	52-2440	1	Spacer-Bearing				
2:1:3	52-2450	2	Bearing-Wheel				
2:2	53-7780-06	2	Plate-Wheel, Half				
2:3	321-2	4	Screw-HH				
2:4	3296-42	4	Nut-Lock, NI				



Transmission Assembly


Ref	Part No.	Qty.	Description
1	323-13	2	Screw-HH
2	100-2860	2	Wheel And Tire ASM
3	65-2720	4	Ring-Clip, Locking
4	65-4740	4	Washer-Thrust, Keyed
5	66-6040	1	Key-Rocking, RH
6	66-6050	1	Key-Rocking, LH
7	65-4710	2	Ring-Friction
8	100-8774	2	Pivot Arm ASM
8:2	47-2900	1	Bushing
8:3	70-9760	1	Bushing
8:4	302-56	1	Fitting-Grease
9	110-0549	2	Knob-HOC
10	42-3520	2	Cap-End
11	49-2040	1	Screw-HWHTF
12	107-7491	2	Arm-Spring
13	603773	2	Nut
14	65-4730	2	Washer-Arm, Pivot
15	65-4760	2	Washer-Clutch
16	65-4750	2	Gear-Pinion
17	65-4720	2	Spring-Compression
18	74-1640	2	Cover-Wheel
19	74-1650	2	Spacer-Cover, Wheel
20	99-1597	1	V-Belt
21	108-8140	1	Gear Case ASM

Ref	Part No.	Qty.	Description
22	107-7483-03	1	Bracket-Gearbox
23	92-1616	1	Screw-HWHTF
24	614673	1	Bushing-Plate, Actuator
25	32144-85	2	Screw-HWH




Rear Wheel Assembly No. 100-2860

Ref	Part No.	Qty.	Description				
1	53-7740	1	Tire				
2		1	Wheel ASM				
2:1		1	Hub And Bearing ASM				
2:1:1	52-2410	1	Hub-Bearing				
2:1:2	52-2440	1	Spacer-Bearing				
2:1:3	52-2450	2	Bearing-Wheel				
2:2	321-2	4	Screw-HH				
2:3	3296-42	4	Nut-Lock, NI				
2:4	53-7780-06	1	Plate-Wheel, Half				
2:5	92-4957-06	1	Wheel Half And Gear ASM				




Gear Case Assembly No. 108-8140

Ref	Part No.	Qty.	Description				
1	104-7619	1	Case-Gear				
2	614668-03	1	Cover-Case, Gear				
3	32144-4	4	Screw-HWH				
4	32151-68	1	Ring-Retaining				
5	3256-24	1	Washer-Flat				
6	3285-19	2	Pin-Groove				
7	3296-5	1	Nut-Lock				
8	36-4780	2	Washer-Plain				
9	36-4791	2	Washer-Thrust				
10	60-8750	2	Bushing				
11	60-8850	2	Bushing				
12	614696	1	Shaft-Intermediate				
13	100-1176	2	Pulley-Half				
14	100-1048	1	Bearing-Ball				
15	62-6660	1	Spacer				
16	104-1005	1	Gear-19T Spur, 37T Bevel				
17	104-7667	1	Gear-Pinion, Bevel				
18	104-1004	1	Gear-30T				
19	108-8141	1	Shaft-Output				



Engine, Blade and Bag Assembly


Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	105-6848-03	1	Accelerator-Blade				
3	106-3987	1	Blade Driver ASM				
4	106-3999	1	Spacer-Driver				
7	114-3471	1	Engine-Kawasaki, Fj180V-As28				
11	107-7489-03	1	Shield-Grass				
12	95-1727	3	Screw-Taptite				
13	108-8110-03	1	Guide-Belt				
15	108-3759-03	1	Blade-Bagging				
16	107-3785-03	1	Bag Frame ASM				
17	107-3789	1	Grass Bag ASM				
18	112-9966	1	Decal				



Handle Assembly

Ref	Part No.	Qty.	Description
1	104-8679-03	1	Bail-Brake
2	104-8678	1	Handle-Control
3	99-1589	1	Lever-Traction
4	99-1588	1	Bar-Control, Traction
5	105-6842	1	Guide-LH
6	106-5750	1	Cable-Brake
7	86-9671	1	Guide-Rope
8	3256-23	1	Washer-Flat
9	105-6841	1	Guide-RH
10	110-4875	1	Decal-Handle
11	95-4453	1	Screw
12	99-5239	1	Anchor-Cable
13	3256-1	1	Washer-Flat
14	3296-42	2	Nut-Lock, NI
15	108-8158	1	Cable-Traction
16	108-8145-03	2	Support-Handle
17	701243	4	Screw-HWHTF
18	27-6600	2	Spacer-Coupling
19	104-8690	1	Spring-Torsion
20	3296-29	6	Nut-Lock, NI
21	55-9670	2	Washer
22	92-4095	6	Screw-Handle
23	114-3492-03	1	Handle-Lower
24	98-4387	1	Decal-Protection, Ear


Ref	Part No.	Qty.	Description
27	110-4874-03	1	Handle-Upper
29	3290-456	2	Washer-Belleville
31	614249	1	Strap-Tie



Cylinder and Crankcase Assembly


Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
211004	11004-7020	1	Gasket-Head				
211008	11008-7025	1	Head-Cylinder				
211022	11022-7005	1	Case-Rocker				
211061	11061-7023	1	Gasket-Case, Rocker				
211061A	11061-7031	1	Gasket-Breather				
211061B	11061-7060	1	Gasket-Cover, Crankcase				
214041	14041-7009	1	Cover				
214091	14091-7010	1	Cover-Breather				
216126	16126-7014	1	Valve-Breather				
249120	49120-7082	1	Crankcase				
292043	92043-7001	2	Pin				
292049	92049-7008	2	Seal-Oil (28-44-9 Tc)				
292153	92153-7043	4	Bolt (6X12)				
292171	92171-7024	2	Clamp				
292191	92191-7025	1	Tube (12X16X49)				
2130	130CA0840	4	Bolt-Flanged (8X40)				
2130A	130G0625	7	Bolt-Flanged (6X25)				
2130B	130G0635	1	Bolt-Flanged (6X35)				
2214	214B0510	5	Screw-Pan (5X10)				
2551	551A0612	2	Pin-Dowel (6X12)				




Piston and Crankshaft Assembly
Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
●13001	13001-7022	1	Piston-Engine				
●13002	13002-7001	1	Pin-Piston				
●13008	13008-7002	1	Piston Ring Set				
●13025	13025-7006	1	Piston Ring Set (L 0.50)				
●13029	13029-7005	1	Piston-Engine (L 0.50)				
●13031	13031-7078	1	Crankshaft				
●13251	13251-7011	1	Connecting Rod ASM				
●92033	92033-7002	2	Ring-Snap				
●92200	92200-7042	1	Washer (28X41.5X2.5)				
●130	130G0630	2	Bolt-Flanged (6X30)				



Valve and Camshaft Assembly
Kawasaki FJ180V-AS28


Ref	Part No.	Qty.	Description				
②12004	12004-7005	1	Valve-Intake				
②12005	12005-7006	1	Valve-Exhaust				
②12009	12009-7001	2	Retainer-Spring, Valve				
②12011	12011-2056	4	Collet				
②12016	12016-7008	2	Arm-Rocker				
②12032	12032-7001	2	Tappet				
②12043	12043-7005	1	Camshaft Valve ASM				
②13042	13042-7006	1	Weight				
②13070	13070-7009	1	Guide				
②13116	13116-7003	2	Rod-Push				
②16154	16154-7004	1	Rotor-Pump				
②21083	21083-7009	1	Arm				
②49078	49078-7001	2	Spring-Valve, Engine				
②92009	92009-2341	2	Screw				
②92015	92015-2253	2	Nut				
②92043	92043-7006	3	Pin				
②92145	92145-7016	1	Spring				
②92153	92153-7019	2	Bolt				



Lubrication Equipment Assembly


Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
②14075	14075-7007	1	Cap ASM				
②14091	14091-7011	1	Cover, Oil Filter				
②16154	16154-7002	1	Rotor-Pump				
②59231	59231-7004	1	Filler				
②92055	92055-2151	1	O-Ring				
②92066	92066-7003	1	Plug				
②92151	92151-7012	2	Bolt (6X12)				
②92153	92153-7007	1	Bolt				
②92153A	92153-7043	1	Bolt (6X12)				
②92170	92170-1577	1	Clamp				
②670	670D2016	2	O-Ring (16Mm)				




Cooling Equipment Assembly Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
②11053	11053-7009	1	Bracket-Fan				
②14037	14037-7017	1	Screen				
②14091	14091-7046	1	Cover				
②59041	59041-7009	1	Fan				
②59066	59066-7016	1	Housing-Fan				
②92153	92153-7008	1	Bolt				
②92153A	92153-7043	1	Bolt (6X12)				




Electric Equipment Assembly
Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
②14090	14090-2108	1	Cover				
②14091	14091-7036	1	Cover				
②16073	16073-2192	1	Insulator				
②21169	21169-2071	1	Terminal				
②21171	21171-7030	1	Ignition Coil ASM				
②21194	21194-7024	1	Flywheel				
②26011	26011-7013	1	Wire-Lead				
②92038	92038-2077	1	Key				
②92070	92070-2088	1	Spark Plug, B P R 5E S (N G K) Solid				
②92153	92153-7007	2	Bolt				
②92153A	92153-7012	1	Bolt (4X16)				
②92153B	92153-7030	1	Bolt (12X30)				
②130	130B0620	2	Bolt-Flanged (6X20)				
②311	311B0400	1	Nut-Hex (4Mm)				
②410	410B0400	1	Washer-Plain, S (4Mm)				



Control Equipment Assembly
Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
②16171	16171-7015	1	Link-Throttle				
②39003	39003-7002	1	Arm-Pivot				
②39129	39129-7007	1	Spring-Governor				
②42036	42036-2051	1	Sleeve				
②49103	49103-7005	1	Arm-Governor				
②49110	49110-7002	1	Governor ASM				
②59226	59226-7014	1	Panel-Control				
②92002	92002-2269	1	Bolt (6X28)				
②92015	92015-1193	1	Nut				
②92145	92145-7025	1	Spring-Throttle				
②92153	92153-7043	2	Bolt (6X12)				
②92200	92200-2029	1	Washer (6.5X11.5X2.0)				
②92200A	92200-2036	1	Washer (6.2X20X0.5)				
②554	554A0600	1	Pin-Snap (1.2X21.2)				




Carburetor Assembly

Kawasaki FJ180V-AS28


Ref	Part No.	Qty.	Description
●11060	11060-2190	1	Gasket
●11061	11061-7010	1	Gasket-Screw
●11061A	11061-7015	2	Gasket-Insulator
●13107	13107-7024	1	Shaft
●15003	15003-7133	1	Carburetor ASM
●16009	16009-2136	1	Needle-Jet
●16014	16014-7008	1	Screw-Air, Pilot
●16020	16020-7005	1	Chamber-Float
●16025	16025-7007	1	Valve-Throttle
●16041	16041-7019	1	Shaft-Carburetor
●16073	16073-7006	1	Insulator
●16183	16183-2002	1	Float ASM
●39076	39076-7001	1	Limiter
●49043	49043-7002	1	Pump-Priming
●49121	49121-7012	1	Nozzle-Main
●92009	92009-2083	1	Screw
●92009A	92009-2349	1	Screw
●92063	92063-7048	1	Jet-Main, No. 76
●92063A	92063-7049	1	Jet-Main, No. 74
●92063B	92063-7061	1	Jet-Main, No. 78
●92081	92081-2234	1	Spring
●92093	92093-2100	1	Seal
●92145	92145-7015	1	Spring
●92172	92172-7023	1	Screw

Ref	Part No.	Qty.	Description
●92192	92192-7074	1	Tube (2.2X7.3X65)
●315	315B1000	1	Nut-Hex, Fine (10Mm)
●463	463H1000	1	Washer-Toothed (10Mm)




Air Filter and Muffler Assembly
Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
②11011	11011-7028	1	Case-Filter, Air				
②11013	11013-7032	1	Element-Filter, Air				
②11029	11029-7021	1	Air Filter Element ASM				
②11061	11061-7012	1	Gasket-Pipe, Intake				
②11061A	11061-7029	1	Gasket-Muffler				
②16060	16060-7012	1	Pipe-Intake				
②49070	49070-7022	1	Muffler				
②49106	49106-7019	1	Cover-Muffler				
②92015	92015-1193	2	Nut				
②92153	92153-7023	1	Bolt (6X10)				
②92210	92210-7019	1	Nut				
②172	172G0680	2	Bolt-Stud (6X80)				
②186	186B0680	2	Bolt-Upset, Wp (6X80)				
②670	670B3032	1	O-Ring (32Mm)				




Fuel Tank and Fuel Valve Assembly Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description				
②11060	11060-2145	1	Gasket				
②32052	32052-7001	1	Bracket-Tank				
②49019	49019-7003	1	Filter-Fuel				
②51004	51004-7001	1	Tank-Fuel				
②51049	51049-7002	1	Cap-Tank				
②92153	92153-7023	2	Bolt (6X10)				
②92170	92170-2009	1	Clamp				
②92170A	92170-2088	1	Clamp				
②92192	92192-7033	1	Tube (6.35X12.7X330)				



Starter Assembly Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description
②46075	46075-7002	1	Grip
②49088	49088-7023	1	Starter-Recoil
②59106	59106-7003	1	Rope (2200Mm)
②92152	92152-7011	1	Collar
②92153	92153-7021	4	Bolt (M6)



Brake and Cover Assembly Kawasaki FJ180V-AS28

Ref	Part No.	Qty.	Description
②13236	13236-7008	1	Lever
②21083	21083-7016	1	Arm
②41035	41035-7005	1	Brake Panel ASM
②92015	92015-1193	1	Nut
②92145	92145-7023	1	Spring
②92145A	92145-7032	1	Spring
②92153	92153-7020	2	Bolt
②92153A	92153-7023	1	Bolt (6X10)

NOTES

NOTES

NOTES

