



Commercial Walk-Behind Mower Floating Deck, T-Bar, Gear Drive with 32in Cutting Unit

Model No. 39092 - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Fuel Tank and Idler Bracket Assembly	 3	Lubrication Equipment Assembly Kawasaki FH430V-AS35	 15
Transmission and Idler Pulley Assembly	 4	Cooling Equipment Assembly Kawasaki FH430V-AS35	 16
Brake, Wheel Pulley and Wheel Assembly	 5	Electric Equipment Assembly Kawasaki FH430V-AS35	 17
Handle and Control Panel Assembly	 6	Control Equipment Assembly Kawasaki FH430V-AS35	 18
Engine Assembly	 7	Carburetor Assembly Kawasaki FH430V-AS35	 19
Carrier Assembly	 8	Air Filter and Muffler Assembly Kawasaki FH430V-AS35	 20
Deck Assembly	 9	Fuel Tank and Valve Assembly Kawasaki FH430V-AS35	 21
Spindle and Blade Assembly	 10	Starter Assembly Kawasaki FH430V-AS35	 22
Decal and Mulcher Cover Assembly	 11	Label Assembly Kawasaki FH430V-AS35	 23
Cylinder and Crankcase Assembly Kawasaki FH430V-AS35	 12	Attachments and Accessories List	 24
Piston and Crankshaft Assembly Kawasaki FH430V-AS35	 13		
Valve and Camshaft Assembly Kawasaki FH430V-AS35	 14		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes

❶ Not serviced separately


❷ Obtain from your local Kawasaki dealer



Fuel Tank and Idler Bracket Assembly


Ref	Part No.	Qty.	Description
1	88-3980	1	Gas Cap ASM
1:3	88-4010	1	Gasket-Cap, Gas
2	106-0730	1	Fuel Tank ASM
2:2	103-2605	1	Fitting-Fuel, Bulkhead
5	3296-39	8	Nut-Lock, NI
6	74-0040	4	Spacer-Pivot, Idler
7	51-4370	1	Spring-Torsion, RH
8	51-4380	1	Spring-Torsion, LH
9	32103-25	2	Nut-Wing
10	3256-23	12	Washer-Flat
11	52-2890	2	Bushing-Nylon
12	3290-307	4	Pin-Hair
13	108-2741-01	1	RH Idler Arm ASM
14	108-2740-01	1	LH Idler Arm ASM
15	74-0521	2	Fitting-Rod
16	283-6	2	Pin-Clevis
17	67-6370-01	1	Bracket-Support, RH
18	67-6380-01	1	Bracket-Support, LH
19	323-16	2	Screw-HH
20	323-6	6	Screw-HH
21	3296-23	2	Nut-Lock, NI
22	95-2800	2	Pulley-Idler
23	95-2801	2	Spacer-Pulley
24	51-4450	2	Screw-Leveler

Ref	Part No.	Qty.	Description
25	68-9690	2	Fitting-Rod
26	237-124	1	Grommet
29	105-4670-01	1	Frame ASM
30	322-4	4	Screw-HH
31	3253-4	2	Washer-Lock
33	95-2814	1	Decal-Shut Off, Fuel
34	106-0649-01	1	Frame-Upper
36	98-0776	1	Decal-Caution
37	104-8121	2	Stud-Threaded
38	1-633349	2	Spring-Tank, Fuel
39	3296-47	2	Nut-Lock, NI



Transmission and Idler Pulley Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	98-3274-03	1	Lever-Shift	26	98-5975	1	Washer-Belleville
2	47-1970	1	Grip	27	1-323379	1	Washer
3	3296-42	4	Nut-Lock, NI	28	32151-62	2	Ring-Retaining
4	32120-64	1	Ring-Snap, External	29	3256-24	1	Washer-Flat
5	1-323252	2	Bearing-Shaft	30	1-323254	2	Flange-Output
6	321-4	4	Screw-HH	31	95-1526	1	Shield-Trailing
7	104-1102	2	Shaft-Output	32	95-1529	1	Rod-Shield
9	3257-5	3	Key-Woodruff	33	1-323387-03	1	Plate-Shift
10	3245-9	2	Screw-Set	34	98-3256	1	Decal-Speed, Ground
11	105-2698	2	Pulley-Transmission	35	3230-1	2	Bolt-CARR
12	51-4220	2	Guard-Coupler	36	1-323389-03	2	Bracket-Plate, Shift
13	1-323680	2	Coupler	37	32128-20	2	Nut-HF
14	302-5	2	Fitting-Grease	38	9264964	4	Screw-HWH, Thread Cut
15	3245-1	1	Screw-Set, HSH				
16	51-4190	1	Pulley-Driven				
17	26-9671	1	Belt V				
18	323-9	1	Screw-HH				
19	51-4810	1	Pulley-Idler				
20	3256-24	1	Washer-Flat				
21	32128-21	1	Nut-HF				
22	322-2	4	Screw-HH				
23	3253-4	4	Washer-Lock				
24	1-323500	1	Transmission				
25	3296-6	1	Nut-Lock				



Brake, Wheel Pulley and Wheel Assembly

Ref	Part No.	Qty.	Description
1	51-4580	2	Rod-Brake
2	3290-307	2	Pin-Hair
3	67-6400-01	1	Arm-Brake, RH
4	67-6420-01	1	Arm-Brake, LH
5	32151-40	2	Ring-Retaining
6	32151-56	2	Ring-Retaining, External
7	51-4660-01	2	Plate-Link, Brake
8	51-4650-01	2	Link-Brake
9	93-1163	2	Wheel And Tire ASM
9:1	231-94	1	Tire-Front
9:2	93-1181	1	Wheel ASM
9:3	92-1746	2	Bearing-Ball
9:4	302-57	1	Fitting-Grease
9:5	232-27	1	Stem-Valve
10	10-8110	8	Washer-Thrust
11	32151-91	2	Ring-Retaining
12	51-4291	2	V-Belt
13	51-4170	8	Spacer-Pulley
14	51-4160-03	4	Pulley-Wheel
15	51-4180-03	2	Drum-Brake
16	3253-4	8	Washer-Lock
17	51-4700	2	Band-Brake
18	322-7	8	Screw-HH
19	51-4230	2	Washer-Wheel


Ref	Part No.	Qty.	Description
20	32151-72	4	Ring-Retaining



Handle and Control Panel Assembly

Ref	Part No.	Qty.	Description
1	82-7690-03	1	Bar-Control
2	82-2290	1	Decal
3	3296-2	5	Nut-Lock
4	82-7680-03	1	Bail ASM
5	32105-1	1	Screw-SHH
6	106-5477-03	1	Control Pivot ASM
7	82-2280	1	Decal
8	3272-11	2	Pin-Cotter
9	105-3158-03	1	Upper Handle ASM
10	112-8712	1	Cable-Choke
11	104-8140	1	Switch-PTO
12	63-8360	2	Key-Ignition
14	3296-42	1	Nut-Lock, NI
16	93-1187-03	1	Panel-Bottom
17	104-8141	1	Module-Delay
18	321-2	1	Screw-HH
19	283-55	2	Pin-Clevis
21	112-8711	1	Cable-Throttle
23	29-5560	1	Switch-On / Off
23:1	218-461	1	Nut-HH
23:2	3254-5	1	Washer-Tooth
24	3290-378	2	Tie-Cable
25	104-8137	1	Harness-Wire
26	2412-120	2	R-Clamp


Ref	Part No.	Qty.	Description
27	32104-76	4	Screw
28	110-4982-03	1	Panel-Control
29	104-7050	1	Housing-Manual
30	32128-21	4	Nut-HF
31	3234-11	4	Screw-HHF
32	32105-14	4	Screw-SHH
33	110-4971	1	Decal-Control Panel
34	105-0884	1	Decal-Danger
35	82-7632	2	Rod-Control
36	218-595	1	Connector-Body
37	51-4850-03	1	Lever-Brake, Parking
38	52-2010	1	Decal-Lever, Parking
39	82-2190	1	Switch-Bail
40	3290-307	2	Pin-Hair
41	237-141	2	Grommet-Rubber
42	98-4387	1	Decal-Protection, Ear
43	104-7048	1	Cap-Housing



Engine Assembly


Ref	Part No.	Qty.	Description
1	21	1	Engine-Kawasaki, FH430V-As35
3	2412-87	1	Clamp-Cable
4	56-6360	1	Filter-Fuel
5	2412-98	4	Clamp
6	33114-016	1	Screw-HH
7	110-4894	1	Hose-Fuel
8	3255-8	1	Washer-Lock
10	3256-23	5	Washer-Flat
12	32128-20	6	Nut-HF
13	1-633543-03	1	Strap-Clutch, Brake
14	94-5847-01	1	Cover-Pulley
15	3212-9	1	Screw-HH
16	107-4136	1	Washer
17	105-2635	1	Clutch / Brake
18	608006	1	Key-Square
19	107-4112	1	Pulley-Drive
20	322-7	4	Screw-HH
24	1-613235	4	Washer
26	103-1966	1	Adapter
27	92-6877	1	Valve-Drain, Oil
29	106-0699	1	Decal-Warning
30	107-0588	1	Hose-Fuel
31	1-603770	1	Valve-Fuel
33	1-633545	2	Spacer

Ref	Part No.	Qty.	Description
34	1-633630	2	Grommet-Brake
36	322-11	1	Screw-HH
37	104-6373	1	Tube-Retainer
38	1-603610	2	Washer-Spring
39	322-9	1	Screw-HH




Carrier Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	74-0080	1	Carrier Frame ASM	22	32128-23	6	Nut-HF
2	94-1291	4	Bushing				
3	74-0330	4	Pad-Rubber				
4	3269-24	16	Rivet				
5	32151-91	2	Ring-Retaining				
6	3-6781	4	Washer-Thrust				
7	93-1166	2	Spacer-Castor				
8	325-18	2	Screw-HH				
9	67-6220	2	Spanner				
10	93-1164-01	2	Fork-Caster ASM				
11	32153-5	2	Nut-Lock, Side				
12	63-8400	2	Caster Wheel ASM				
12:1	62-5580	2	Bearing-Outside				
12:2	63-8580	1	Bearing-Roller				
12:3	302-40	1	Fitting-Grease				
13	67-6570	4	Spacer-Wheel				
14	302-5	2	Fitting-Grease				
15	256-156	2	Bushing-Flange				
16	74-0290	2	Spring				
17	41-8440	2	Washer				
18	3218-5	4	Nut-Jam				
19	74-0310	2	Shaft-Adjusting				
20	3296-45	2	Nut-Lock, NI				
21	3234-6	6	Screw-HHF				




Deck Assembly

Ref	Part No.	Qty.	Description				
❶1		1	Deck ASM				
❶2		1	Spindle ASM				
5	32153-2	1	Nut-Lock, Side				
6	28-8010	1	Spring				
7	44-5930	1	Deflector ASM				
7:2	54-9220	1	Decal-Danger				
8	28-7350	1	Post-Pivot				
9	67-6180	1	Strip-Magnetic				
10	3234-29	2	Screw-HHF				
11	67-6160-01	1	Cover				
12	104-8587	1	Knob				
13	3256-24	1	Washer-Flat				
14	32151-72	1	Ring-Retaining				
15	74-0570	1	Guide-Belt				
16	3290-355	4	Pin-Hair				
17	67-6140	2	Rod-Support				
18	3296-29	24	Nut-Lock, NI				
19	322-4	24	Screw-HH				
20	92-5419-03	4	Ring-Recycler				
21	3290-496	2	Nut-Retainer				
22	80-2630-03	4	Kicker				
23	67-6920	1	V-Belt				




Spindle and Blade Assembly

Ref	Part No.	Qty.	Description				
1	104-6325	2	Bearing				
2	32146-20	1	Nut-Jam				
3	3253-23	1	Washer-Lock/Sp				
4	51-4060	1	Screw-Blade				
5	67-6060-03	1	Housing-Spindle				
6	67-6070	1	Spacer-Bearing				
7	67-6080	1	Spacer				
8	92-6313	1	Cup-Scalp, Anti				
9	106-0776	1	Washer-Pinion				
10	74-0580	1	Pulley ASM				
11	80-4430-03	1	Blade-Recycler				
12	82-4750-03	1	Spacer-Blade				
13	105-4607-03	1	Spindle Shaft ASM				



Decal and Mulcher Cover Assembly


Ref	Part No.	Qty.	Description				
1	66-1340	1	Decal-Danger				
2	67-5360	1	Decal-Danger				
3	105-2625	1	Decal-STD, Safety				
4	68-8340	1	Decal-Torque				
5	93-1159	1	Decal-HOC				
6	106-0719	1	Decal				
7	67-6170	1	Decal				
8	54-0910	1	Decal-Hot				
9	66-6380	1	Decal-Danger				
10	92-5422	1	Mulcher Cover ASM				
10:1	28-8070	1	Lanyard				
10:2	28-8130	1	Pin-Locking, Chute				
10:3	3256-49	1	Washer-Flat				
10:4	3290-282	1	Rivet-Pop				
11	322-11	1	Screw-HH				
12	3256-23	2	Washer-Flat				
13	3296-29	1	Nut-Lock, NI				



Cylinder and Crankcase Assembly


Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
❶11004	11004-7018	2	Gasket-Head				
❶11008	11008-7021	1	Head-Cylinder, No. 2				
❶11008A	11008-7022	1	Head-Cylinder, No. 1				
❶11022	11022-7003	2	Case-Rocker				
❶11060	11060-7001	2	Gasket-Case, Rocker				
❶11061	11061-7007	1	Gasket-Cover, Crankcase				
❶11061A	11061-7008	1	Gasket-Breather				
❶14091	14091-7007	1	Cover				
❶49015	49015-7032	1	Cover-Crankcase				
❶49120	49120-7015	1	Crankcase				
❶59071	59071-2079	1	Joint				
❶92043	92043-7001	6	Pin				
❶92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)				
❶92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)				
❶92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)				
❶92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)				
❶92139	92139-7008	1	Bushing				
❶92153	92153-7043	4	Bolt (6X12)				
❶92153A	92153-7054	17	Bolt (8X50)				
❶130	130B0640	4	Bolt-Flanged (6X40)				
❶130A	130CA0875	2	Bolt-Flanged (8X75)				
❶172	172G0818	4	Bolt-Stud (8X18)				




Piston and Crankshaft Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
②13001	13001-7022	2	Piston-Engine				
②13002	13002-7001	2	Pin-Piston				
②13008	13008-7001	2	Ring Set-Piston				
②13025	13025-7003	1	Ring Set-Piston (L 0.50)				
②13029	13029-7005	1	Piston-Engine (L 0.50)				
②13031	13031-7033	1	Crankshaft				
②13251	13251-7007	2	Connecting Rod ASM				
②13251A	13251-7008	2	Connecting Rod ASM (0.50)				
②92033	92033-7002	4	Ring-Snap				
②130	130G0630	4	Bolt-Flanged (6X30)				




Valve and Camshaft Assembly **Kawasaki FH430V-AS35**

Ref	Part No.	Qty.	Description				
②12004	12004-7005	2	Valve-Intake				
②12005	12005-7006	2	Valve-Exhaust				
②12009	12009-7001	4	Retainer-Spring, Valve				
②12011	12011-2056	8	Collet				
②12016	12016-7008	4	Arm-Rocker				
②12032	12032-7001	4	Tappet				
②13070	13070-7001	2	Guide				
②13070A	13070-7004	1	Guide				
②13116	13116-2057	4	Rod-Push				
②13271	13271-7007	1	Plate				
②13271A	13271-7021	1	Plate-Governor				
②42036	42036-7010	1	Sleeve				
②49078	49078-7001	4	Spring-Valve, Engine				
②49118	49118-7009	1	Camshaft				
②92009	92009-2341	4	Screw				
②92015	92015-2253	4	Nut				
②92033	92033-7001	2	Ring-Snap				
②92140	92140-7002	6	Ball				
②92145	92145-7001	1	Spring				
②92153	92153-7019	4	Bolt				
②92200	92200-7001	1	Washer				




Lubrication Equipment Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
②13107	13107-7009	1	Shaft				
②13271	13271-7017	1	Plate				
②14075	14075-7009	1	Cap ASM				
②16154	16154-2053	1	Rotor-Pump (In)				
②16154A	16154-2054	1	Rotor-Pump (Out)				
②49065	49065-2078	1	Filter-Oil				
②49065A	49065-7004	1	Filter-Oil				
②59051	59051-7011	1	Gear-Spur				
②59231	59231-7003	1	Filler				
②92043	92043-7003	2	Pin				
②92066	92066-7003	2	Plug				
②92140	92140-7003	1	Ball				
②92145	92145-7002	1	Spring				
②92153	92153-7043	3	Bolt (6X12)				
②670	670D2016	3	O-Ring (16Mm)				




Cooling Equipment Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
❶13270	13270-7007	1	Plate				
❶14037	14037-7025-9H	1	Screen				
❶14091	14091-7009	1	Cover				
❶49089	49089-7044	1	Shroud-Engine				
❶49089A	49089-7061	1	Shroud-Engine				
❶59041	59041-7012	1	Fan				
❶59066	59066-7036	1	Housing-Fan				
❶92004	92004-7007	2	Stud				
❶92153	92153-7007	3	Bolt				
❶92153A	92153-7008	1	Bolt				
❶92153B	92153-7043	4	Bolt (6X12)				
❶130	130B0616	2	Bolt-Flanged (6X16)				
❶130A	130B0816	1	Bolt-Flanged (8X16)				
❶311	311F0600	2	Nut-Hex (6Mm)				




Electric Equipment Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
21171	21171-7026	1	Ignition Coil ASM				
21171A	21171-7027	1	Ignition Coil ASM				
21194	21194-7012	1	Flywheel				
26030	26030-7001	1	Harness				
59031	59031-7002	1	Coil-Charging				
92004	92004-7008	2	Stud				
92009	92009-2308	2	Screw				
92066	92066-7002	1	Plug				
92066A	92066-7005	1	Plug				
92070	92070-7003	2	Plug-Spark (R C J 8 Y, Solid)				
92151	92151-2097	1	Bolt (12X30)				
92172	92172-7018	4	Screw (5X20)				
92200	92200-7002	1	Washer				
130	130B0620	2	Bolt-Flanged (6X20)				
311	311F0600	2	Nut-Hex (6Mm)				
510	510A5100	1	Key-Woodruff				



Control Equipment Assembly
Kawasaki FH430V-AS35


Ref	Part No.	Qty.	Description				
213107	13107-7010	1	Shaft				
213271	13271-7032	1	Plate				
216169	16169-7012	1	Link-Choke				
216171	16171-7007	1	Link				
239129	39129-7003	1	Spring-Governor				
249103	49103-7004	1	Arm-Governor				
249113	49113-7024	1	Panel-Control				
292009	92009-7007	1	Screw (4X35)				
292145	92145-7003	1	Spring				
292145A	92145-7005	1	Spring				
292150	92150-2182	2	Bolt (5X18)				
292153	92153-7033	1	Bolt (6X35)				
292153A	92153-7043	2	Bolt (6X12)				
292170	92170-7001	2	Clamp				
2214	214B0408	2	Screw-Pan (4X8)				
2311	311B0600	1	Nut-Hex (6Mm)				
2411	411B0600	1	Washer-Plain (6Mm)				



Carburetor Assembly Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
②11061	11061-7004	1	Gasket-Insulator
②11061A	11061-7009	1	Gasket-Chamber
②11061B	11061-7010	1	Gasket-Screw
②11061C	11061-7018	1	Gasket-Cleaner, Air
②13107	13107-7018	1	Shaft
②15003	15003-7061	1	Carburetor ASM
②16014	16014-7002	1	Screw-Pilot, Air
②16020	16020-7003	1	Chamber-Float
②16025	16025-7006	1	Valve-Throttle
②16030	16030-7003	1	Valve-Float
②16031	16031-7002	1	Float
②16041	16041-7016	1	Shaft-Choke, Carburetor
②16041A	16041-7018	1	Shaft-Throttle, Carburetor
②16186	16186-7002	1	Choke Valve ASM
②39076	39076-7001	1	Limiter
②49121	49121-7001	1	Nozzle-Main
②59076	59076-7005	1	Manifold-Intake
②92009	92009-2083	2	Screw
②92009A	92009-2349	1	Screw
②92055	92055-7007	2	O-Ring (I D 31)
②92063	92063-7026	1	Jet-Main, No. 88
②92063A	92063-7028	1	Jet-Main, No. 85
②92063B	92063-7029	1	Jet-Main, No. 82
②92081	92081-2234	1	Spring


Ref	Part No.	Qty.	Description
②92093	92093-2100	1	Seal
②92093A	92093-7003	1	Seal
②92145	92145-7015	1	Spring
②92153	92153-7009	4	Bolt
②92172	92172-7002	1	Screw



Air Filter and Muffler Assembly Kawasaki FH430V-AS35


Ref	Part No.	Qty.	Description
②11011	11011-7045	1	Case-Filter, Air
②11013	11013-7025	1	Element-Filter, Air
②11013A	11013-7031	1	Element-Filter, Air
②11053	11053-7022	1	Bracket
②11054	11054-7002-9H	1	Bracket
②11060	11060-7021	2	Gasket-Muffler
②13271	13271-7022	1	Plate
②16060	16060-7016	1	Pipe-Intake
②18088	18088-7001	1	Pipe-Exhaust
②32154	32154-7006	1	Pipe
②49070	49070-7021	1	Muffler
②92015	92015-1193	2	Nut
②92026	92026-7001	2	Spacer (6.2X7.9X5)
②92055	92055-7015	1	O-Ring
②92072	92072-7012	1	Band
②92153	92153-7043	2	Bolt (6X12)
②92170	92170-7002	1	Clamp
②92192	92192-7010	1	Tube
②92200	92200-2070	2	Washer
②92210	92210-7004	2	Nut
②92210A	92210-7019	1	Nut
②92210B	92210-7027	4	Nut (M8)
②130	130B0610	1	Bolt-Flanged (6X10)

Ref	Part No.	Qty.	Description
②130A	130B0816	3	Bolt-Flanged (8X16)
②220	220B0614	2	Screw-Pan, Cross (6X14)
②233	233B0416	1	Screw (4X16)
②311	311B0400	1	Nut-Hex (4Mm)
②461	461F0800	4	Washer-Spring (8Mm)
②670	670B2010	1	O-Ring (10Mm)



Fuel Tank and Valve Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
23062	23062-7004-9H	1	Bracket				
42036	42036-7012	1	Sleeve				
49019	49019-7001	1	Filter-Fuel				
49040	49040-7001	1	Pump-Fuel				
92170	92170-2088	4	Clamp				
92191	92191-7002	1	Tube				
92192	92192-7035	1	Tube (6.35X12.7X170)				
92192A	92192-7037	1	Tube (6.35X12.7X160)				
130	130B0620	2	Bolt-Flanged (6X20)				



Starter Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description				
②13165	13165-7001	2	Pawl-Starter, Recoil				
②13271	13271-7003-9H	1	Plate				
②14020	14020-7001	1	Retainer				
②32099	32099-7002	1	Case-Starter, Recoil				
②46075	46075-7001	1	Grip-Starter, Recoil				
②49080	49080-7001	1	Pulley-Starting				
②49088	49088-7013	1	Starter-Recoil				
②59101	59101-7001	1	Reel-Starter, Recoil				
②59106	59106-7005	1	Rope				
②92145	92145-7006	1	Spring				
②92145A	92145-7007	2	Spring				
②92145B	92145-7008	1	Spring				
②92151	92151-7008	1	Bolt				
②92200	92200-7004	1	Washer				
②92200A	92200-7005	1	Washer				
②92210	92210-0003	4	Nut				
②130	130B0608	3	Bolt-Flanged (6X8)				

WARNING

- FOR SAFE OPERATION READ OWNER'S MANUAL.
- GASOLINE IS FLAMMABLE. KEEP AWAY FROM FLAME OR SPARK.
- COGNITIVE AND EMOTIONAL DO NOT USE ENGINE IN AN ENCLOSED AREA.
- TO AVOID INJURY, DO NOT TOUCH HOT SURFACES.



Kawasaki	FH430V改KAI 15.0
-----------------	------------------------

Kawasaki FH430V改 KAI 15.0

Label Assembly

Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
②56033	56033-7001	1	Label-Manual
②56070	56070-7001	1	Label-Warning
②56080	56080-2077	1	Label-Brand
②56080A	56080-7024	1	Label-Brand
②56080B	56080-7057	1	Label-Brand

Attachments and Accessories

For 39092 - Commercial Walk-Behind Mower, Floating Deck, T-Bar, Gear Drive with 32in Cutting Unit

Product Name	Model/Part
Bag Kit	30124

NOTES

NOTES

NOTES

