



Commercial Walk-Behind Mower Fixed Deck, T-Bar, Gear Drive with 40in TURBO FORCE® Cutting Unit

Model No. 39696 - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel Tank Assembly	 3	Lubrication Equipment Assembly Kawasaki	
Transmission Drive Assembly	 4	FH430V-CS25	 17
Drive Wheel and Brake Assembly	 6	Cooling Equipment Assembly Kawasaki	
Handle and Control Assembly	 7	FH430V-CS25	 18
Deck Assembly	 8	Electric Equipment Assembly Kawasaki	
Deck Assembly No. 110-4908	 9	FH430V-CS25	 19
Deflector Assembly No. 110-0790	 10	Control Equipment Assembly Kawasaki	
Sheave, Spindle and Blade Assembly	 11	FH430V-CS25	 20
Idler Assembly	 12	Carburetor Assembly Kawasaki FH430V-CS25	 21
Caster Assembly	 13	Air Filter and Muffler Assembly Kawasaki	
Cylinder and Crankcase Assembly Kawasaki		FH430V-CS25	 22
FH430V-CS25	 14	Fuel Tank and Valve Assembly Kawasaki	
Piston and Crankshaft Assembly Kawasaki		FH430V-CS25	 23
FH430V-CS25	 15	Starter Assembly Kawasaki FH430V-CS25	 24
Valve and Camshaft Assembly Kawasaki		Label Assembly Kawasaki FH430V-CS25	 25
FH430V-CS25	 16	Attachments and Accessories List	 26


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- ❶ Not serviced separately
- ❷ Obtain parts from Peerless Transmissions (model 700-070A)
- ❸ Obtain from your local Kawasaki dealer



Engine and Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	1-633023	2	Stud
2	3256-23	4	Washer-Flat
3	1-633349	2	Spring-Tank, Fuel
4	3296-47	2	Nut-Lock, NI
5	1-303077	4	Clamp
1 99			1 Engine-Kawasaki, FH430V-Cs25
10	106-0699	1	Decal-Warning
11	3290-357	1	Nut-HHF, Whiz
12	323-14	1	Screw-HH
13	322-7	3	Screw-HH
14	1-303334	3	Washer-Spring
15	103-1966	1	Adapter
16	92-6877	1	Valve-Drain, Oil
17	98-5975	2	Washer-Belleville
18	109-0293	1	Hose-Fuel
19	1-603770	1	Valve-Fuel
20	109-0306	1	Hose-Fuel
21	32128-21	1	Nut-HF
22	322-3	2	Screw-HH
24	1-805005	2	Washer-Lock
26	106-0730	1	Fuel Tank ASM
26:2	103-2605	1	Fitting-Fuel, Bulkhead
27	88-3980	1	Gas Cap ASM
27:3	88-4010	1	Gasket-Cap, Gas


Ref	Part No.	Qty.	Description
28	32128-20	5	Nut-HF
30	322-9	1	Screw-HH
31	3254-2	1	Washer-Lock, Internal
34	323-8	8	Screw-HH
35	98-5975	8	Washer-Belleville
36	3290-357	8	Nut-HHF, Whiz
99	103-1964	1	Hose-Drain, Oil



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	103-9897-01	1	Deck-Engine
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	2	Screw-Set
5	103-6511	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513152	1	Switch-Closed, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission
25	302-19	2	Fitting-Grease

Ref	Part No.	Qty.	Description
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	98-3256	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-HWH, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	3	Pin-Hair
41	1-303186	1	Bellcrank
42	32128-21	1	Nut-HF
43	95-2814	1	Decal-Shut Off, Fuel
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission
50	110-0504	1	Pulley Assembly



Transmission Drive Assembly (continued)


Ref	Part No.	Qty.	Description				
56	1-603610	2	Washer-Spring				
57	3212-6	1	Screw-HH				
58	1-633453	1	Spacer-Clutch				
59	1-373034	2	Washer				
62	32128-33	2	Nut-HF				
64	103-1797-01	1	Bracket-Cable, Choke				
65	103-1796	1	Cable-Choke				
67	1-323303	1	Linkage-Arm				
68	110-0749	1	Belt-V				
69	1-808280	1	Pin-Clevis				
70	1-303105	1	Yoke-Adjustable				
71	3219-2	1	Nut-Hex				
72	1-303335	2	Tie-Plastic				



Drive Wheel and Brake Assembly

Ref	Part No.	Qty.	Description
1	98-3273	2	Spring-Extension
2	323-10	2	Screw-HH
3	32151-47	2	Ring-Retaining
4	1-806003	4	Pin-Hair
5	3256-23	2	Washer-Flat
6	110-4925-03	1	RH Idler Arm ASM
7	110-4926-03	1	LH Idler Arm ASM
8	74-0521	2	Fitting-Rod
9	283-6	2	Pin-Clevis
10	1-323296	2	Rod-Brake
11	110-5866	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	10	Nut-HHF, Whiz
14	323-16	4	Screw-HH
16	98-5131-01	2	Shield-Wheel, Drive
17	1-323694	4	Spacer-Shield
18	1-323634	2	Idler-Drive, Wheel
19	302-19	2	Fitting-Grease
21	1-323307	4	Pin-Clevis
22	1-322209-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	4	Nut-Push
25	1-323595	2	Band-Brake
26	1-322212-03	1	Axle ASM


Ref	Part No.	Qty.	Description
27	1-523157	6	Washer-Spacer
27	1-543436	8	Washer-Spacer, 18 GA
28	1-323261	2	Drum-Brake
29	1-323253	4	Sheave-Wheel, Drive
30	1-323719	2	Wheel And Tire ASM
30:1	1-323720	1	Tire-Turfmaster
30:2	1-323328	1	Wheel And Hub ASM
30:2:1	1-323329	2	Bearing-Flanged
30:2:2		1	Rim ASM
30:2:3		1	Fitting-Grease
30:2:4		1	Stem-Valve
34	1-808519	2	Ring-Snap
35	1-323260	8	Spacer-Sheave, Wheel
36	322-6	8	Screw-HH
38	1-323631	2	V-Belt
39	3296-29	2	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleveille
44	323-6	4	Screw-HH
46	1-805005	8	Washer-Lock



Handle and Control Assembly


Ref	Part No.	Qty.	Description
1	98-3282	2	Rod-Control
2	95-5522-03	1	Control Bar ASM
3	3296-2	5	Nut-Lock
4	82-2290	1	Decal
5	32105-1	1	Screw-SHH
6	82-7680-03	1	Bail ASM
7	82-2280	1	Decal
8	3272-11	2	Pin-Cotter
9	99-8501-03	1	Control-Pivot
10	218-595	1	Connector-Body
11	98-3261-03	1	Lever-Brake, Parking
12	98-3266	1	Decal
13	740275	1	Switch-Seat
14	1-806003	3	Pin-Hair
15	237-141	2	Grommet-Rubber
16	98-3267-03	1	Upper Handle ASM
17	283-55	2	Pin-Clevis
18	100-6450	1	Control-Throttle
19	2412-120	2	R-Clamp
20	95-5537	1	Decal-Engage, Deck
21	1-303335	1	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-24	2	Washer-Flat
24	3296-39	1	Nut-Lock, NI

Ref	Part No.	Qty.	Description
25	106-0678	1	Harness-Wire
26	98-3279	1	Linkage-Drive, Blade
27	98-3287-03	1	Lever-Engagement, Blade
28	3234-11	4	Screw-HHF
29	32104-76	2	Screw
30	110-6905	1	Control Panel ASM
30:2	110-6916	1	Decal-Panel, Control
30:3	105-0884	1	Decal-Danger
31	104-7050	1	Housing-Manual
32	32105-14	4	Screw-SHH
33	32128-21	4	Nut-HF
34	99-8509	1	Spacer
35	1-303020	1	Grip-Lever
36	323-10	1	Screw-HH
37	98-4387	1	Decal-Protection, Ear
39	29-5560	1	Switch-On / Off
39:1	218-461	1	Nut-HH
39:2	3254-5	1	Washer-Tooth
40	63-8360	1	Key-Ignition
41	104-7048	1	Cap-Housing




Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	110-4908	1	Deck ASM	21	110-6910-03	1	Baffle ASM
2	110-0795-03	1	Baffle Adjust ASM	22	323-4	3	Screw-HH
3	108-7273-01	1	Baffle-Discharge				
4	108-7282-01	1	Plate-Skid				
5	110-0790	1	Deflector ASM				
6	110-2034-01	1	Cover-Deck				
7	92-1624	5	Screw				
8	3290-357	12	Nut-HHF, Whiz				
9	322-50	1	Screw-HH				
10	105-4622	1	Spacer				
11	104-8554	1	Spring-Torsion				
12	107-1664	1	Lever ASM				
12:1	106-3239	1	Screw-Lock				
12:2	107-1644	1	Cap-Lock				
12:3	106-3241	1	Lever-Lock				
12:4	3296-29	1	Nut-Lock, NI				
13	3296-29	1	Nut-Lock, NI				
14	106-4161	5	Knob-Handle				
15	1-323417	5	Washer				
16	1-303536	3	Stud-Shield, Belt (Long)				
17	1-303537	2	Stud-Shield, Belt (Short)				
18	3231-1	4	Screw-CARR				
19	32128-20	5	Nut-HF				
20	110-6919	1	Decal				



Deflector Assembly No. 110-0790


Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	110-0792-01	1	Deflector				
3	110-0793-03	1	Strap-Discharge				
4	110-0791	1	Deflector-Rubber				
5	107-4164-01	1	Bracket-Mounting, Deflector				
6	3296-39	4	Nut-Lock, NI				



Sheave, Spindle and Blade Assembly


Ref	Part No.	Qty.	Description
1	108-6697	3	Spindle Housing ASM
1:1	110-2118	2	Bearing
1:2	110-2116	1	Spacer-Bearing
1:3	108-6694	1	Housing-Spindle
1:4	32120-8	1	Ring-Snap
2	92-1624	18	Screw
3	3290-357	18	Nut-HHF, Whiz
4	110-4888	3	Washer-Spacer
5	103-2535	3	Spacer-Guard, Bottom
6	1-807267	3	Key
7	1-323529	3	Tube-Spindle, Short
8	1-323539	12	Spacer
9	108-4081-03	3	Blade-14 Inch (High Sail)
10	1-513208	3	Washer-Spring
11	1-800861	3	Screw-Cap, HH
12	103-1330	3	Guard-Bearing, Top
13	1-403183	3	Sheave
14	1-323339	3	Washer-Retainer, Sheave
15	3219-6	3	Nut-Hex
16	1-803310	3	Screw-Set
17	1-403184	2	Bushing-Idler
18	1-403186	1	Idler-Pulley, Flat
19	1-613098	1	Pulley-Idler
20	5-0652	2	Spacer

Ref	Part No.	Qty.	Description
21	98-5975	3	Washer-Belleville
22	1-403188	1	Spacer
23	323-15	1	Screw-HH
24	323-14	2	Screw-HH
25	322-2	1	Screw-HH
26	32128-20	1	Nut-HF
27	3296-39	3	Nut-Lock, NI
28	3256-24	1	Washer-Flat




Idler Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-324372	1	Pad And Spring ASM	24	110-2051	1	Rod-Brake
2	321-4	2	Screw-HH	25	1-323748	1	Ring-Push On
3	3296-42	2	Nut-Lock, NI	26	1-323747	1	Spring-Compression
4	322-10	1	Screw-HH	27	1-323746	1	Spacer-Flanged
5	1-403179	1	Tube-Pivot	28	3296-56	1	Nut-Lock, NI
6	32120-35	1	Ring-Retaining, EXT	29	1-323071	1	Spring-Extension
7	3256-23	1	Washer-Flat	30	1-303334	1	Washer-Spring
8	1-322235	1	Arm-Assist	31	302-19	2	Fitting-Grease
9	3256-3	1	Washer-Flat				
10	3296-29	1	Nut-Lock, NI				
11	1-303238	1	Eyebolt-Thread, RH				
12	32128-20	3	Nut-HF				
13	1-303236	1	Body-Turnbuckle				
14	1-303348	1	Eyebolt-Thread, LH				
15	702809	1	Screw-Cap				
16	98-5975	1	Washer-Belleville				
17	1-603843	1	Pulley-Idler				
18	1-303434	1	Bushing-Engagement				
19	103-3600	1	Idler Arm ASM				
19:2	1-323729	2	Sleeve-Bearing				
20	32151-103	1	Ring-Retaining, EXT				
21	322-6	1	Screw-HH				
22	1-303352	1	Washer-Spindle				
23	1-806003	3	Pin-Hair				



Caster Assembly


Ref	Part No.	Qty.	Description				
1	110-5023	2	Wheel And Tire ASM				
❶1:1		1	Tire				
1:2	1-513809	1	Bearing				
1:3	1-513810	2	Bushing				
1:4	302-61	1	Zerk				
❶1:5		1	Wheel				
2	1-513547	2	Spacer				
3	325-20	2	Screw-HH				
4	1-322145-01	2	Fork				
5	3217-9	2	Nut-HH				
6	3253-7	2	Washer-Lock				
7	1-303314	8	Spacer-Caster				
8	110-2130	2	Support ASM				
8:2	1-303514	2	Bearing-Flanged				
8:3	302-52	1	Fitting-Grease				
9	1-513338	2	Washer-Flat				
10	1-809020	2	Pin				
11	323-6	8	Screw-HH				
12	3290-357	8	Nut-HHF, Whiz				
13	3256-24	8	Washer-Flat				



Cylinder and Crankcase Assembly


Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description				
❶11004A	11004-7018	2	Gasket-Head				
❶11008B	11008-7021	1	Head-Cylinder, No. 2				
❶11008D	11008-7022	1	Head-Cylinder, No. 1				
❶11022	11022-7003	2	Case-Rocker				
❶11060	11060-7001	2	Gasket-Case, Rocker				
❶11061	11061-7007	1	Gasket-Cover, Crankcase				
❶11061A	11061-7008	1	Gasket-Breather				
❶14091	14091-7007	1	Cover				
❶49015	49015-7032	1	Cover-Crankcase				
❶49120	49120-7015	1	Crankcase				
❶59071	59071-2079	1	Joint				
❶92043	92043-7001	6	Pin				
❶92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)				
❶92049B	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)				
❶92049C	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)				
❶92049D	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)				
❶92139A	92139-7008	1	Bushing				
❶130	130B0612	4	Bolt-Flanged (6X12)				
❶130A	130B0640	4	Bolt-Flanged (6X40)				
❶130B	130T0850	17	Bolt-Flanged (8X50)				
❶130C	130T0875	2	Bolt-Flanged (8X75)				
❶172	172G0818	4	Bolt-Stud (8X18)				



Piston and Crankshaft Assembly
Kawasaki FH430V-CS25


Ref	Part No.	Qty.	Description				
13001	13001-7009	2	Piston-Engine				
13002	13002-7001	2	Pin-Piston				
13008	13008-7001	2	Ring Set-Piston				
13025	13025-7003	1	Ring Set-Piston (L 0.50)				
13029	13029-7005	1	Piston-Engine (L 0.50)				
13031	13031-7033	1	Crankshaft				
13251	13251-7007	2	Connecting Rod ASM				
13251A	13251-7008	2	Connecting Rod ASM (0.50)				
92033	92033-7005	4	Ring-Snap				
130	130G0630	4	Bolt-Flanged (6X30)				



Valve and Camshaft Assembly


Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description				
③12004A	12004-7005	2	Valve-Intake				
③12005A	12005-7006	2	Valve-Exhaust				
③12009	12009-7001	4	Retainer-Spring, Valve				
③12011	12011-2056	8	Collet				
③12016B	12016-7008	4	Arm-Rocker				
③12032	12032-7001	4	Tappet				
③13070	13070-7001	2	Guide				
③13070A	13070-7004	1	Guide				
③13116	13116-2057	4	Rod-Push				
③13271	13271-7007	1	Plate				
③13271A	13271-7021	1	Plate-Governor				
③42036B	42036-7010	1	Sleeve				
③49078	49078-7001	4	Spring-Valve, Engine				
③49118	49118-7009	1	Camshaft				
③92009	92009-2341	4	Screw				
③92015	92015-2253	4	Nut				
③92033	92033-7001	2	Ring-Snap				
③92140	92140-7002	6	Ball				
③92145	92145-7001	1	Spring				
③92153	92153-7019	4	Bolt				
③92200	92200-7001	1	Washer				




Lubrication Equipment Assembly
Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description				
13107	13107-7009	1	Shaft				
13271	13271-7017	1	Plate				
14075	14075-7009	1	Cap ASM				
16154	16154-2053	1	Rotor-Pump (In)				
16154A	16154-2054	1	Rotor-Pump (Out)				
49065	49065-2078	1	Filter-Oil				
49065A	49065-7004	1	Filter-Oil				
59051	59051-7011	1	Gear-Spur				
59231	59231-7003	1	Filler				
92043	92043-7003	2	Pin				
92066	92066-7003	2	Plug				
92140	92140-7003	1	Ball				
92145	92145-7002	1	Spring				
130	130B0612	3	Bolt-Flanged (6X12)				
670	670D2016	3	O-Ring (16Mm)				



Cooling Equipment Assembly
Kawasaki FH430V-CS25


Ref	Part No.	Qty.	Description				
❶13270	13270-7007	1	Plate				
❶14037A	14037-7025-9H	1	Screen				
❶14091	14091-7009	1	Cover				
❶49089	49089-7044	1	Shroud-Engine				
❶49089C	49089-7061	1	Shroud-Engine				
❶59041B	59041-7012	1	Fan				
❶59066B	59066-7036	1	Housing-Fan				
❶92004	92004-7007	2	Stud				
❶92153	92153-7007	3	Bolt				
❶92153A	92153-7008	1	Bolt				
❶130	130B0612	4	Bolt-Flanged (6X12)				
❶130A	130B0616	2	Bolt-Flanged (6X16)				
❶130B	130B0816	1	Bolt-Flanged (8X16)				
❶311	311F0600	2	Nut-Hex (6Mm)				



Electric Equipment Assembly


Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description
③21171D	21171-7026	1	Ignition Coil ASM
③21171E	21171-7027	1	Ignition Coil ASM
③21194	21194-7013	1	Flywheel
③26030	26030-7001	1	Harness
③92004	92004-7008	2	Stud
③92009	92009-2308	2	Screw
③92066	92066-7002	1	Plug
③92066A	92066-7005	1	Plug
③92070	92070-7003	2	Plug-Spark (R C J 8 Y, Solid)
③92151	92151-2097	1	Bolt (12X30)
③92200	92200-7002	1	Washer
③130	130B0620	2	Bolt-Flanged (6X20)
③311	311F0600	2	Nut-Hex (6Mm)
③510	510A5100	1	Key-Woodruff



Control Equipment Assembly Kawasaki FH430V-CS25


Ref	Part No.	Qty.	Description				
③13107	13107-7010	1	Shaft				
③13271B	13271-7032	1	Plate				
③16169	16169-7012	1	Link-Choke				
③16171	16171-7007	1	Link				
③39129	39129-7003	1	Spring-Governor				
③49103	49103-7004	1	Arm-Governor				
③49113	49113-7024	1	Panel-Control				
③92009	92009-7007	1	Screw (4X35)				
③92145	92145-7003	1	Spring				
③92145A	92145-7005	1	Spring				
③92150	92150-2182	2	Bolt (5X18)				
③92153A	92153-7033	1	Bolt (6X35)				
③92170	92170-7001	2	Clamp				
③130	130B0612	2	Bolt-Flanged (6X12)				
③214	214B0408	2	Screw-Pan (4X8)				
③311	311B0600	1	Nut-Hex (6Mm)				
③411	411B0600	1	Washer-Plain (6Mm)				



Carburetor Assembly Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description
③11061	11061-7004	1	Gasket-Insulator
③11061A	11061-7009	1	Gasket-Chamber
③11061B	11061-7010	1	Gasket-Screw
③11061C	11061-7018	1	Gasket-Cleaner, Air
③13107	13107-7018	1	Shaft
③15003	15003-7061	1	Carburetor ASM
③16014	16014-7002	1	Screw-Pilot, Air
③16020	16020-7003	1	Chamber-Float
③16025	16025-7006	1	Valve-Throttle
③16030	16030-7003	1	Valve-Float
③16031	16031-7002	1	Float
③16041	16041-7016	1	Shaft-Choke, Carburetor
③16041A	16041-7018	1	Shaft-Throttle, Carburetor
③16186	16186-7002	1	Choke Valve ASM
③39076	39076-7001	1	Limiter
③49121	49121-7001	1	Nozzle-Main
③59076	59076-7005	1	Manifold-Intake
③92009	92009-2083	2	Screw
③92009A	92009-2349	1	Screw
③92055	92055-7007	2	O-Ring (I D 31)
③92063	92063-7026	1	Jet-Main, No. 88
③92063A	92063-7028	1	Jet-Main, No. 85
③92063C	92063-7029	1	Jet-Main, No. 82
③92081	92081-2234	1	Spring


Ref	Part No.	Qty.	Description
③92093	92093-2100	1	Seal
③92093A	92093-7003	1	Seal
③92145	92145-7015	1	Spring
③92153	92153-7009	4	Bolt
③92172	92172-7002	1	Screw



Air Filter and Muffler Assembly
Kawasaki FH430V-CS25


Ref	Part No.	Qty.	Description
❶11011B	11011-7045	1	Case-Filter, Air
❶11013	11013-7025	1	Element-Filter, Air
❶11013A	11013-7031	1	Element-Filter, Air
❶11053	11053-7022	1	Bracket
❶11054	11054-7002-9H	1	Bracket
❶11060	11060-7021	2	Gasket-Muffler
❶13271	13271-7022	1	Plate
❶16060	16060-7016	1	Pipe-Intake
❶18088	18088-7001	1	Pipe-Exhaust
❶32154	32154-7006	1	Pipe
❶49070B	49070-7021	1	Muffler
❶92015	92015-1193	2	Nut
❶92026	92026-7001	2	Spacer (6.2X7.9X5)
❶92055	92055-7015	1	O-Ring
❶92072B	92072-7012	1	Band
❶92170	92170-7002	1	Clamp
❶92192	92192-7010	1	Tube
❶92200	92200-2070	2	Washer
❶92210	92210-7004	2	Nut
❶92210A	92210-7019	1	Nut
❶130	130B0610	1	Bolt-Flanged (6X10)
❶130A	130B0612	2	Bolt-Flanged (6X12)
❶130B	130B0816	3	Bolt-Flanged (8X16)

Ref	Part No.	Qty.	Description
❶220	220B0614	2	Screw-Pan, Cross (6X14)
❶233	233B0416	1	Screw (4X16)
❶311	311B0400	1	Nut-Hex (4Mm)
❶317	317R0800	4	Nut-Hex, Small (8Mm)
❶461	461F0800	4	Washer-Spring (8Mm)
❶670	670B2010	1	O-Ring (10Mm)



Fuel Tank and Valve Assembly
Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description				
③23062	23062-7004-9H	1	Bracket				
③42036	42036-7012	1	Sleeve				
③49019	49019-7001	1	Filter-Fuel				
③49040	49040-7001	1	Pump-Fuel				
③92170B	92170-2088	4	Clamp				
③92191	92191-7002	1	Tube				
③92192	92192-7035	1	Tube (6.35X12.7X170)				
③92192A	92192-7037	1	Tube (6.35X12.7X160)				
③130	130B0620	2	Bolt-Flanged (6X20)				



Starter Assembly
Kawasaki FH430V-CS25

Ref	Part No.	Qty.	Description				
❸13165	13165-7001	2	Pawl-Starter, Recoil				
❸13271	13271-7003-9H	1	Plate				
❸14020	14020-7001	1	Retainer				
❸32099	32099-7002	1	Case-Starter, Recoil				
❸46075	46075-7001	1	Grip-Starter, Recoil				
❸49080	49080-7001	1	Pulley-Starting				
❸49088	49088-7013	1	Starter-Recoil				
❸59101	59101-7001	1	Reel-Starter, Recoil				
❸59106A	59106-7005	1	Rope				
❸92145	92145-7006	1	Spring				
❸92145A	92145-7007	2	Spring				
❸92145B	92145-7008	1	Spring				
❸92151	92151-7008	1	Bolt				
❸92200	92200-7004	1	Washer				
❸92200A	92200-7005	1	Washer				
❸92210	92210-0003	4	Nut				
❸130	130B0608	3	Bolt-Flanged (6X8)				

Attachments and Accessories

For 39696 - Commercial Walk-Behind Mower, Fixed Deck, T-Bar, Gear Drive with 40in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Rotary, 14 Inch (Recycling)	108-4089-03
Blade-Rotary, 14 Inch (Mid Flow)	108-4110-03
Blade-Rotary, 14 Inch (Low Flow)	108-4111-03
Blade-Rotary, 14 Inch (Atomic)	108-4112-03
40 Inch Bagger Enhancement Kit	110-2025
40 Inch Recycler Kit	110-2070
Weight Kit	110-2085
Plate Kit	110-6902
Blade-Recycler, 14 Inch (6-pack)	114-4961
Blade-Low Flow, 14inch (6-pack)	114-4962
Blade-Mid Flow, 14 Inch (6-pack)	114-4963
Blade-High Flow, 14 Inch (6-pack)	114-4964
Blade-Atomic, 14 Inch (6-pack)	114-4965
Soft Bag (3 Bushel)	30104
Sulky	30109

NOTES

