

# 1 inch Replacement Axle Kit

## Zero-Turn-Radius Riding Mower

Model No. 115-5039

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers


Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.



1 inch Replacement Axle Kit Assembly

| Ref | Part No. | Qty. | Description             |  |  |  |  |
|-----|----------|------|-------------------------|--|--|--|--|
| 1   | 105-1895 | 1    | Nut                     |  |  |  |  |
| 2   | 105-1894 | 1    | Hub ASM                 |  |  |  |  |
| 4   | 112-9859 | 1    | Bushing-Axle            |  |  |  |  |
| 5   | 112-9858 | 1    | Shaft-Axle              |  |  |  |  |
| 6   | 115-5094 | 1    | Sleeve-Bushing, Inboard |  |  |  |  |
| 7   | 112-9856 | 1    | Washer                  |  |  |  |  |
| 8   | 112-9855 | 1    | Gear-52T, Bull          |  |  |  |  |
| 10  | 115-5095 | 1    | Seal-Lip                |  |  |  |  |
| 41  | 104-5313 | 1    | Seal-Lip                |  |  |  |  |
| 57  | 104-5309 | 1    | Ring-Retaining          |  |  |  |  |
| 90  | 112-9854 | 1    | Ring-Spiral, Retaining  |  |  |  |  |
| 96  | 112-9860 | 1    | Seal-Lip                |  |  |  |  |