



## Windrow Kit Core Processor

Model No. 09760 - 280000001 and up.

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                 | Page    | Description                | Page    |
|-----------------------------|---------|----------------------------|---------|
| Windrow Assembly            | ..... 3 | Left Hand Windrow Assembly | ..... 5 |
| Right Hand Windrow Assembly | ..... 4 |                            |         |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|             |                                |             |                                  |
|-------------|--------------------------------|-------------|----------------------------------|
| AR. ....    | as required                    | HYD. ....   | hydraulic                        |
| ASM. ....   | assembly                       | LH. ....    | left hand                        |
| BBC. ....   | blade brake clutch             | NI. ....    | nylon insert                     |
| CARR. ....  | carriage                       | NPTF. ....  | national pipe thread fine        |
| DEG. ....   | degrees                        | PFH. ....   | phillips flat head               |
| EXT. ....   | external                       | PPH. ....   | phillips pan head                |
| FH. ....    | flat head                      | PPHTF. .... | phillips pan head thread forming |
| GA. ....    | gauge                          | PRH. ....   | phillips round head              |
| HD. ....    | heavy-duty                     | PTH. ....   | phillips truss head              |
| HF. ....    | hex flange                     | PTO. ....   | power-take-off                   |
| HH. ....    | hex head                       | RH. ....    | right hand                       |
| HHF. ....   | hex head flange                | ROPS. ....  | roll-over protection system      |
| HHFTF. .... | hex head flange thread forming | SFH. ....   | slotted fillister head           |
| HJ. ....    | hex jam                        | SHH. ....   | slotted hex head                 |
| HLH. ....   | hex lag head                   | SHWH. ....  | slotted hex washer head          |
| HOC. ....   | height-of-cut                  | SPH. ....   | slotted pan head                 |
| HSBH. ....  | hex socket button head         | SQH. ....   | square head                      |
| HSFH. ....  | hex socket flat head           | SRH. ....   | slotted round head               |
| HS. ....    | hex socket head                | STD. ....   | standard                         |
| HWH. ....   | hex washer head                | TAP. ....   | self tapping                     |
| HWHTF. .... | hex washer head thread forming | TTH. ....   | torx truss head                  |

## Footnotes


- ❶ Not serviced separately





Right Hand Windrow Assembly

| Ref | Part No.    | Qty. | Description       |  |  |  |  |
|-----|-------------|------|-------------------|--|--|--|--|
| 1   | 115-2916-01 | 1    | Plate-Top         |  |  |  |  |
| 2   | 114-7669-01 | 1    | Mount-Windrow, RH |  |  |  |  |
| 3   | 112-4461-01 | 1    | RH Blade ASM      |  |  |  |  |
| 4   | 80-6990     | 4    | Washer-Hardened   |  |  |  |  |
| 5   | 323-25      | 4    | Screw-HH          |  |  |  |  |
| 6   | 104-8301    | 4    | Nut-Flange, NI    |  |  |  |  |
| 7   | 104-0958    | 2    | Spacer-Windrow    |  |  |  |  |
| 8   | 3256-25     | 4    | Washer-Flat       |  |  |  |  |
| 9   | 324-13      | 2    | Screw-HH          |  |  |  |  |
| 10  | 115-2908-01 | 1    | RH Arm ASM        |  |  |  |  |
| 11  | 302-5       | 2    | Fitting-Grease    |  |  |  |  |
| 12  | 3296-48     | 2    | Nut-Lock, NI      |  |  |  |  |
| 13  | 3254-16     | 2    | Washer-Lock/Int   |  |  |  |  |



Left Hand Windrow Assembly

| Ref | Part No.    | Qty. | Description     |  |  |  |  |
|-----|-------------|------|-----------------|--|--|--|--|
| 1   | 115-2916-01 | 1    | Plate-Top       |  |  |  |  |
| 2   | 110-2742-01 | 1    | Mount-Windrow   |  |  |  |  |
| 3   | 115-2907-01 | 1    | LH Arm ASM      |  |  |  |  |
| 4   | 80-6990     | 4    | Washer-Hardened |  |  |  |  |
| 5   | 323-25      | 4    | Screw-HH        |  |  |  |  |
| 6   | 104-8301    | 4    | Nut-Flange, NI  |  |  |  |  |
| 7   | 104-0958    | 2    | Spacer-Windrow  |  |  |  |  |
| 8   | 3256-25     | 4    | Washer-Flat     |  |  |  |  |
| 9   | 324-13      | 2    | Screw-HH        |  |  |  |  |
| 10  | 3296-48     | 2    | Nut-Lock, NI    |  |  |  |  |
| 11  | 302-5       | 2    | Fitting-Grease  |  |  |  |  |
| 12  | 112-4462-01 | 1    | LH Blade ASM    |  |  |  |  |
| 13  | 3254-16     | 2    | Washer-Lock/Int |  |  |  |  |

## NOTES

## NOTES

