




**MODEL NO. 78410-390001 Thru
790001 & UP**
**PARTS
CATALOG**
PROLINE 38"
Recycler Rotary Cutting Unit


C-0880

BAFFLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-7108	Decal - Danger	1
2	92-5787	Recycler Chute Assembly (Incl. Ref.# 1)	1
3	3256-23	Washer - Flat	3
4	78-0820	Rod - Hinge	1
5	3272-6	Pin - Cotter	2
6	80-4510	Plate - Kicker	1
7	321-3	Screw - Hex Hd. Cap	2
8	32144-97	Screw - Pan Hd.	2
9	3296-42	Nut - Hex	2
10	79-1640	Baffle - Rear	1

Ref. No.	Part No.	Description	No. Used
11	32104-130	Screw - Pan Hd.	6
12	76-2160	Plate - Kicker	3
13	79-3140	Decal - Danger	1
14	79-1311	Decal - Recycler	1
15	3296-29	Nut - Hex	1
16	3230-1	Bolt - Carriage	1
17	323-5	Screw - Hex Hd. Cap	2
18	2844	Washer - Flat	2
19	79-1600	Baffle - Front	1
20	3296-39	Nut - Hex	2




C-0877

DECK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-5786	Deck - Mower (Incl. Ref.# 13, 21 & 26)	1
2	92-5788	Chute - Discharge (Incl. Ref.# 25)	1
3	119730	Rod - Front	1
4	119691	Spring	1
5	119720	Rod - Rear	1
6	9267154	Screw	4
7	120700	Support - Lift	1
8	110846	Bracket - Pivot	1
9	103712	Grip	1
10	79-1030	Lever	1
11	933244	Pin - Spirol	1
12	3296-42	Nut	2


Ref. No.	Part No.	Description	No. Used
13	120691	Quadrant	1
14	321-4	Screw	2
15	3272-21	Pin - Cotter	2
16	118960	Shaft - Roller	2
17	29-4820	Roller	2
18	112730	Clip - Spring	1
19	111655	Decal - Height	1
21	93-1122	Decal - Danger	2
23	78-0290	Stop - Deck	1
24	32144-1	Screw	2
26	66-6380	Decal - Danger	1
27	118730	Lock - Shaft	1
28	323-6	Screw - Hex Hd. Cap	1
29	3296-39	Nut - Hex	1



C-0878

SUSPENSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	117071	Bar — Draft L.H.	1	22	3256-23	Washer	1
2	117072	Bar — Draft R.H.	1	23	322-13	Screw — Hex Hd. Cap	1
3	323-9	Screw — Hex Hd. Cap	2	24	322-3	Screw — Hex Hd. Cap	1
4	3256-27	Washer	2	25	120580	Spring	1
5	3272-22	Pin — Cotter	2	26	116368	Shaft — Counter	1
6	102809	Nut — Flange	4	27	103712	Grip	1
7	120070	Bar — Leveler	2	28	117088	Lever	1
8	116167	Spring	1	29	117090	Link	1
9	3272-6	Pin — Cotter	4	30	9002719	Bolt	1
10	9335044	Cotter — Hairpin	2	31	116621	Bushing	2
11	121010	Rod — Lift	2	32	3296-23	Nut	1
12	79-2790	Trunnion	4	33	2844	Washer	2
13	3296-39	Nut	6	34	4627	Spacer	2
14	3296-29	Nut	2	35	323-7	Screw — Hex Hd. Cap	2
15	115706	Spacer	2	36	3231-25	Bolt	2
16	117086	Strap	1	37	115705	Spacer	2
17	117083	Arm — Idler	1	38	116816	Rod — Hanger	2
18	94-6852	Fitting — Grease	1	39	9791804	Spacer	2
19	114512	Spacer	1	40	302-26	Fitting — Grease	1
21	109859	Bushing	2	41	3256-23	Washer — Flat	2



C-0879

SPINDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	116667	Belt - Spindle	1
3	117137	Decal - Belt Guide	1
4	79-1050	Housing - Spindle	2
5	79-2780	Spacer - Bearing	2
6	80-4390	Spacer	2
7	26-0671	Screw - Blade	2
8	3296-29	Nut	8
9	322-3	Screw - Hex Hd. Cap	8
10	79-3061	Shield - Bearing	2
11	80-4370	Cup	2
12	3219-7	Nut - Lock	2
13	79-3800	Pulley	2
14	80-4352	Spindle Shaft	2
15	3290-465	Washer - Belleville	2

Ref. No.	Part No.	Description	No. Used
16	79-1090	Bearing	4
17	105005	Ring - Retaining	1
18	971015	O-Ring	1
19	109966	Bearing	2
20	116165	Pulley	1
21	302-5	Fitting - Grease	1
22	3296-39	Nut	1
23	3256-24	Washer	1
24	93-1622	Pulley	1
25	323-9	Screw - Hex Hd. Cap	1
26	116666	Belt - Drive	1
27	302-16	Fitting - Grease	2
28	80-0510	Blade Stiffener	2

TORO PART NUMBER INDEX

3317—837

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
2844	Washer	"3" 33 2	79—1640	Baffle — Rear	"1" 10 1
2844	Washer — Flat	"1" 18 2	79—2780	Spacer — Bearing	"4" 5 2
4627	Spacer	"3" 34 2	79—2790	Trunnion	"3" 12 4
102809	Nut — Flange	"3" 6 4	79—3061	Shield — Bearing	"4" 10 2
103712	Grip	"2" 9 1	79—3140	Decal — Danger	"1" 13 1
103712	Grip	"3" 27 1	79—3800	Pulley	"4" 13 2
105005	Ring — Retaining	"4" 17 1	80—0510	Blade Stiffener	"4" 28 2
109859	Bushing	"3" 21 2	80—4352	Spindle Shaft	"4" 14 2
109966	Bearing	"4" 19 2	80—4370	Cup	"4" 11 2
110846	Bracket — Pivot	"2" 8 1	80—4390	Spacer	"4" 6 2
111420	Fitting — Grease	"3" 18 1	80—4510	Plate — Kicker	"1" 6 1
111655	Decal — Height	"2" 19 1	92—5786	Deck — Mower	"2" 1 1
112730	Clip — Spring	"2" 18 1	92—5787	Recycler Chute Assembly	"1" 2 1
114512	Spacer	"3" 19 1	92—5788	Chute — Discharge	"2" 2 1
115705	Spacer	"3" 37 2	93—1122	Decal — Danger	"2" 21 2
115706	Spacer	"3" 15 2	93—1622	Pulley	"4" 24 1
116165	Pulley	"4" 20 1	93—7108	Decal — Danger	"1" 1 1
116167	Spring	"3" 8 1	302—5	Fitting — Grease	"4" 21 1
116368	Shaft — Counter	"3" 26 1	302—16	Fitting — Grease	"4" 27 2
116621	Bushing	"3" 31 2	302—26	Fitting — Grease	"3" 40 1
116666	Belt — Drive	"4" 26 1	321—3	Screw — Hex Hd. Cap	"1" 7 2
116667	Belt — Spindle	"4" 1 1	321—4	Screw	"2" 14 2
116816	Rod — Hanger	"3" 38 2	322—3	Screw — Hex Hd. Cap	"4" 9 8
117071	Bar — Draft L.H.	"3" 1 1	322—3	Screw — Hex Hd. Cap	"3" 24 1
117072	Bar — Draft R.H.	"3" 2 1	322—13	Screw — Hex Hd. Cap	"3" 23 1
117083	Arm — Idler	"3" 17 1	323—5	Screw — Hex Hd. Cap	"1" 17 2
117086	Strap	"3" 16 1	323—6	Screw — Hex Hd. Cap	"2" 28 1
117088	Lever	"3" 28 1	323—7	Screw — Hex Hd. Cap	"3" 35 2
117090	Link	"3" 29 1	323—9	Screw — Hex Hd. Cap	"3" 3 2
117137	Decal — Belt Guide	"4" 3 1	323—9	Screw — Hex Hd. Cap	"4" 25 1
118730	Lock — Shaft	"2" 27 1	3219—7	Nut — Lock	"4" 12 2
118960	Shaft — Roller	"2" 16 2	3230—1	Bolt — Carriage	"1" 16 1
119691	Spring	"2" 4 1	3231—25	Bolt	"3" 36 2
119720	Rod — Rear	"2" 5 1	3256—23	Washer	"3" 22 1
119730	Rod — Front	"2" 3 1	3256—23	Washer — Flat	"1" 3 3
120070	Bar — Leveler	"3" 7 2	3256—23	Washer — Flat	"3" 41 2
120580	Spring	"3" 25 1	3256—24	Washer	"4" 23 1
120691	Quadrant	"2" 13 1	3256—27	Washer	"3" 4 2
120700	Support — Lift	"2" 7 1	3272—6	Pin — Cotter	"1" 5 2
121010	Rod — Lift	"3" 11 2	3272—6	Pin — Cotter	"3" 9 4
900271	Bolt	"3" 30 1	3272—21	Pin — Cotter	"2" 15 2
926715	Screw	"2" 6 4	3272—22	Pin — Cotter	"3" 5 2
933244	Pin — Spirol	"2" 11 1	3290—465	Washer — Belleville	"4" 15 2
933504	Cotter — Hairpin	"3" 10 2	3296—23	Nut	"3" 32 1
971015	O—Ring	"4" 18 1	3296—29	Nut	"4" 8 8
979180	Spacer	"3" 39 2	3296—29	Nut	"3" 14 2
26—0671	Screw — Blade	"4" 7 2	3296—29	Nut — Hex	"1" 15 1
29—4820	Roller	"2" 17 2	3296—39	Nut	"3" 13 6
66—6380	Decal — Danger	"2" 26 1	3296—39	Nut	"4" 22 1
76—2160	Plate — Kicker	"1" 12 3	3296—39	Nut — Hex	"1" 20 2
78—0290	Stop — Deck	"2" 23 1	3296—39	Nut — Hex	"2" 29 1
78—0820	Rod — Hinge	"1" 4 1	3296—42	Nut	"2" 12 2
79—1030	Lever	"2" 10 1	3296—42	Nut — Hex	"1" 9 2
79—1050	Housing — Spindle	"4" 4 2	32104—130	Screw — Pan Hd.	"1" 11 6
79—1090	Bearing	"4" 16 4	32144—1	Screw	"2" 24 2
79—1311	Decal — Recycler	"1" 14 1	32144—97	Screw — Pan Hd.	"1" 8 2
79—1600	Baffle — Front	"1" 19 1			

*Not Illustrated

Maintenance Record

[illegible]

Maintenance Record

[illegible]

Maintenance Record

[illegible]