

LAWN-BOY®

21" REAR BAGGER WALK-BEHIND MOWER

**MODEL NO. 10750-3900001 & UP
SELF-PROPELLED**

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.


To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Housing Assembly	1	Engine Assembly	8-9
Shroud-Fuel/Oil Tank Assembly	2	Starter Assembly	10
Drive Assembly	3	Carburetor Assembly	11-12
Handle Assembly	4-5	Numeric Parts Index	13-14
Transmission Assembly	6-7		




C-1410

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	609807	Screw	2
2	613341	Speednut	1
3	613910	Washer - R.H. Handle	1
4	700748	Bolt	2
5	614522	Anchor - Cable	1
6	39-5770	Decal - Blade Warning	1
7	684366	Switch - Bag Lock	1
8	303724	Screw	1
9	684193	Assembly - Magnet	1
10	613625	Lockwasher	1
11	130450	Nut	1
12	613749	Screw	1
13	613321	Bolt - Handle Mounting	2
14	613340	Speednut	1
15	613339	Screw	1
16	613345	Door - Access	1
17	613322	Shield - Trailing	1
18	610026	Rod - Trailing Shield	1
19	614433	Plate - Height Adjust	2
20	613381	Screw - Plate to Housing	6
21	602315	Nut - Cable Anchor/Hsg.	2
22	613289	Baffle	1
23	610361	Washer	4
24	46-6811	Screw - Baffle to Housing	4
25	613320	Screw	2
26	614430	Shoulder Bolt - Wheel	2

Ref. No.	Part No.	Description	No. Used
27	92-1604	Cap - Hub	2
28	27-6250	Bushing	4
29	684645	Assembly - Wheel & Tire (Incl. Ref. No. 28)	2
30	684220	Assy. - Knob & Spring, L.H.	1
*31	684219	Assy. - Knob & Spring, R.H.	1
32	613917	Arm - Front Height Adj.	2
33	610358	Nut	4
34	677525	Assembly - Collar & Plate	1
35	603164	Nut - Blade	1
36	613944	Blade - 21"	1
37	608311	Locknut - Mtg Plate/Hsg.	3
38	684689	Assembly - Housing (Incl. Ref. No. 3, 6, 13, 22 & 24)	1
39	611380	Grommet	1
40	613532	Cover - Lower Drive	1
41	16-2219	Cover - Upper Drive (Incl. Ref. No. 42)	1
42	92-2939	Decal - Warning	1
43	613122	Decal - Sound Emission	1
44	613121	Decal - Spark Plug	1
45	614328	Housing - Shield	1
46	613924	Baffle - Front	1
47	613925	Screw - Baffle, Front	3

*Not Illustrated




C-1403

SHROUD-FUEL/OIL TANK ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	613378	Cover - Muffler	1	19	684508	Assembly - Fuel/Oil Tank (Incl. Ref. No.10, 24, & 28-29)	1
2	613372	Screw - Muffler Guard	1	20	614173	Bracket - Fuel Tank	1
3	613371	Spacer - Muffler Guard	1	21	614181	Screw - Fuel Tank Mount.	1
4	684157	Assembly - Muffler Guard (Incl. Ref. No.1 & 5)	1	22	613337	Bolt - Bracket To Block	2
5	613329	Pushnut	4	23	700098	Nut	1
6	613281	Screw - Shroud	3	24	684093	Fuel Shut - Off Valve	1
7	614041	Applique	1	25	613489	Clamp - Fuel Line	2
8	684429	Assy. - Shroud (Incl. Ref. No. 7)	1	26	613531	Fuel Line	1
9	613330	Screw - Fuel Tank	3	27	613516	Clamp - Oil Hose	2
10	684376	Switch - Low Oil	1	28	684336	Assembly - Oil Fitting (Incl. Ref. No.29)	1
*	705137	Nut - Oil Switch	1	29	613948	O-Ring	1
11	684105	Assembly - Oil Cap (Incl. Ref. No 12-14)	1	30	611774	Screw - Mtg Plate/Hsg.	3
12	614274	Baffle	1	31	613557	Snubber - Belt	1
13	614272	Cover - Baffle	1	32	613206	Plate - Engine Mounting	1
14	613313	Gasket	1	33	613483	Screw - Mtg Plate To Eng.	3
15	684104	Assembly - Fuel Cap (Incl. Ref. No.16-18)	1	34	613266	Gasket - Exhaust	1
16	609150	Baffle	1	35	684579	Muffler	1
17	614271	Cover - Baffle	1	36	613282	Screw - Muffler	3
18	613311	Gasket	1	37	613576	Screw - Muffler Guard	2
				38	700056	Screw - Muffler Guard	1

*Not Illustrated




C-1404

DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	613842	V-Belt	1	22	70-9760	Bushing	2
2	613770	Nut	1	23	47-2900	Bushing	2
3	613445	Pulley - Transmission	1	24	602480	Screw	2
4	614524	Plate - Actuator	1	25	602315	Locknut	2
5	613387	Screw	3	26	610358	Nut	2
6	613385	Clamp	1	27	614442	Fitting - Grease	2
7	146134	Screw - Plate to Trans.	2	28	65-4730	Washer - Inner Thrust	2
8	614525	Spring	1	29	65-4740	Washer - Keyed	4
9	684617	Transmission	1	30	65-2720	Ring - Retaining	4
10	603773	Nut	1	31	65-4710	Ring - Friction	2
11	614523	Arm - Trans. Engagement	1	32	65-4760	Washer - Clutch	2
12	614526	Guide - Belt	1	*33	66-6040	Key, Rocking - R.H.	1
13	614527	Bolt - Shoulder	1	34	66-6050	Key, Rocking - L.H.	1
14	614529	Spring - Extension	1	35	65-4750	Gear - Pinion 15T	2
15	614316	Arm - Shift	1	36	65-4720	Spring - Compression	2
16	614317	Arm - Clutch	1	37	614427	Cover - Wheel	2
17	611840	Key	1	38	614426	Washer - Stepped	2
18	614443	Ring - Isolator	2	39	684645	Assembly - Wheel (Incl. Ref. No.40)	2
19	614447	Spacer	2	40	27-6250	Bushing	2
20	684618	Assembly - Knob & Spring	2	41	614430	Bolt - Wheel	2
21	684616	Pivot Arm Assy. (Incl. Ref. No. 22-23)	2	42	92-1604	Cap - Hub	2

*Not Illustrated

HANDLE & REAR GRASS CATCHER ASSEMBLY




HANDLE & REAR GRASS CATCHER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	614013	Screw – Set	2
2	684399	Assembly – Knob, Throttle (Incl. Ref. #1)	1
3	614567	Plate	1
4	684427	Assembly – Cover, Upper (Incl. Ref. #3)	1
5	145482	Plug	1
6	684446	Lever – Throttle	1
7	684210	Assembly – Cable, Throttle	1
8	684581	Assembly – Handle & Decal (Incl. Ref. #20 & 34)	1
9	613551	Screw	1
10	613406	Nut	2
11	613409	Pivot – Bail	1
12	613417	Bail – Self-propelled	1
13	613553	Screw	1
14	613412	Block – Bail	1
15	92-2940	Decal – Warning	1
16	613550	Nut – Cable, Self-propelled	1
17	700790	Bumper	1
18	613549	Screw	6
19	684209	Assy. – Cable, Eng. Brake	1
20	614023	Screw – Thread Forming	3
21		Bag – Rear, Grass (Accessory Part #684189)	1

Ref. No.	Part No.	Description	No. Used
22	613401	Screw	1
23	613358	Knob – Mounting, Handle	2
24	684695	Assembly – Shaft, Handle (Incl. Ref. # 23 & 25)	1
25	613406	Nut	2
26	614518	Insert – Handle, Cable Side	1
27	613408	Insert – Handle	1
28	613601	Insert – Handle	1
29	684697	Assy. – Cable, Self-propelled	1
30	602315	Nut	1
31	611499	Screw	1
32	613405	Screw	1
33	613393	Plate – Nut	1
34	684151	Guide – Rope	1
35	613980	Decal – Lawn-Boy	1
36	684130	Frame	1
37	613555	Screw	1
38	613416	Bail – Brake, Engine	1
39	684212	Assy. – Cable, Gear Select	1
40	684445	Lever – Gear, Select	1
41	684400	Assy. – Knob, Gear Select (Incl. Ref. #1)	1
42	614330	Decal – Zone Start	1
43	614331	Decal – Self-Propelled	1


TRANSMISSION ASSEMBLY



TRANSMISSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	684731	Kit – Upper & Lower Case (Incl. Sealant)	1	17	614611	Washer	2
2	614625	Screw – Tapping	1	18	684737	Bushing Set	2
3	614626	Screw – Tapping	5	19	614613	Ring – Snap	2
4	614600	Shaft – Input	1	20	614607	Washer	4
5	611840	Key – Woodruff	1	21	614608	Key – Holder,	1
6	614601	Washer	1	22	614609	Collar – Shift	1
7	614602	Bearing – Lower	1	23	614610	Slider	1
8	614603	Bearing – Upper	1	24	614614	Ring – Snap	1
9	684736	Kit – Shaft, Reduction (Incl. Ref. No. 10–11)	1	25	614615	Ball	2
10	614606	Collar	1	26	614616	Collar – Sliding	1
11	684732	Bushing Set	1	27	614617	Fork – Shift	1
12	614604	Ring Gear	1	28	614316	Arm – Shift	1
13	684733	Gear Set	1	29	614618	Support – Fork	2
14	684734	Gear Set	1	30	684739	Spring & Key – Shift	2
15	684735	Gear Set	1	31	614619	Spring	1
16	684740	Kit – Axle Shaft (Incl. Ref. No. 17–19)	1	32	614620	Plate	1
				33	614621	Fork – Clutch	1
				34	614317	Arm – Clutch	1
				35	614622	Ball	1

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	130743	Nut – Flywheel	1
2	316959	Lockwasher	1
3	684023	Flywheel	1
4	613208	Screw	5
5	684275	Oil Pump Kit w/Oil Lines (Incl. Ref. No. 6)	1
6	613516	Clamp – Oil Line	2
9	684673	Wire Harness	1
10	613182	Oil Seal – Crankshaft	2
11	613183	Ring – Retaining	AR
12	613265	Ring – Retaining	AR
13	684022	Bearing – Crankshaft	2
14	602315	Nut	2
15	613390	Brake Actuator	1
16	614032	Shoulder Bolt	1
17	613360	Shoulder Bolt	1
19	613386	Brake Spring	1
20	684362	Brake & Switch	1
21	300402	Pin – Taper	1
22	613110	Screw	2
23	613111	Screw	4
24	613429	Washer – Governor Shaft	2
25	613328	Ring – Retain. – Gov. Shaft	1
26	613230	Seal – Oil, Governor Shaft	1
27	613274	Rod – Choke	1
28	613277	Rod – Throttle	1
29	613430	Retainer – Throttle Wire	1
30	684437	Kit – Gov. & Oil Pump Lever (Incl. Ref. No. 31)	1
31	613269	Screw	1
32	613628	Spring – Torsion	1
33	613336	Nut	1
34	613276	Rod – Oil Pump Control	1
35	614043	Spring – Governor	1
36	613337	Screw	2

Ref. No.	Part No.	Description	No. Used
37	684090	Assy. – Governor Bracket (Incl. Ref. No. 32)	1
38	613388	Clamp – Throttle Cable	1
39	613387	Screw	1
40	613683	Wire Tie	1
41	613227	Screw – Set, Engine Pulley	1
42	613228	Pulley – Engine	1
43	613747	Shaft – Governor	1
44	684465	Ramp – Governor	1
45	613229	Ball – Governor	4
46	614009	Spark Plug	1
47	683993	Crankshaft & Conn. Rod	1
48	607199	Key	1
49	684272	Assy. – Piston & Ring (Std.) (Incl. Ref. No. 50–52)	1
49	684307	Assy. – Piston & Ring (0.020" Oversize) (Inc 50–52)	1
50	613258	Ring – Retaining	2
51	613148	Pin – Wrist	1
52	684273	Ring Set (Standard)	1
52	684309	Ring Set (0.020" Oversize)	1
53	613233	Screw – Cyl. Head to Block	4
54	613197	Head – Cylinder	1
55	613382	Gasket – Head	1
56	613266	Gasket – Exhaust	1
57	684049	Module – C.D. Ignition (Incl. Ref. No. 58–59)	1
58	684179	High Tension Lead & Cover (Incl. Ref. No. 59)	1
59	684698	Assy. – Cover & Terminal	1
*	684276	Short Block (Incl. Ref. #10–13, 21–26, 41–47 & 49–56)	1

*Not Illustrated



C-1406


STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	614037	Decal	1
2	612429	Hub - Starter	1
3	612825	Handle - Starter	1
4	612824	Insert - Clip, Rope	1
5	684567	Housing - Starter	1
6	683897	Recoil Spring & Keeper	1

Ref. No.	Part No.	Description	No. Used
7	612950	Pulley	1
8	612432	Rope	1
9	683899	Assembly - Dog Kit	1
*	612428	Screw - Sems	4
*	684622	Assembly - Starter (Inc. Ref. No. 5-9)	1

*Not Illustrated

CARBURETOR ASSEMBLY



CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	613180	Gasket – Carb. to Spacer	1
2	613181	Gasket – Spacer to Engine	1
3	613748	Gasket – Air Filter Base	1
*	684280	Kit – Gasket (Incl. Ref. No. 4–5)	1
4	613641	Gasket – Bowl Retainer	1
5	613642	Gasket – Fuel Bowl	1
6	684281	Kit – Float & Needle (Incl. Ref. No. 7)	1
7	684282	Needle and Clip	1
8	684283	Kit – Idle Needle & Spring	1
9	684284	Kit – Idle Speed	1
10	613647	Pilot Jet	1
11	613918	Main Jet	1
12	613649	Nozzle	1
13	613650	Seal – Throttle Shaft	1
14	613651	Seal – Choke Shaft	1
15	613655	Screw – Throttle Valve	2
16	613656	Screw – Choke Valve	2
17	613657	Pivot – Upper Choke Shaft	1
18	613658	Pivot – Lower Choke Shaft	1
19	684478	Kit – Bowl (Incl. Ref. No. 20–21)	1

Ref. No.	Part No.	Description	No. Used
20	614175	Bowl – Fuel	1
21	614176	Screw – Bowl Retainer	1
*	684280	Kit – Gasket	1
22	614239	Hose – Carb Vent	1
23	613531	Gas Line	1
24	613489	Clamp – Hose	1
25	613348	Base – Air Filter	1
26	613353	Bolt	1
27	613327	Screw – Carb. to Engine	2
28	613361	Filter – Air	1
29	684559	Assembly – Cover, Air Filter (Incl. Ref. No. 30–33)	1
30	614245	Pre-Filter	1
31	613329	Pushnut	4
32	613349	Screw	2
33	613379	Cover – Air Box	1
34	613352	Spacer	2
†35	613893	Main Jet – High Altitude (Over 3,500 Feet)	1
36	684080	Assy. – Spacer & Oil Nozzle	1
*	684548	Kit – Carb. & Gasket (Incl. Ref. No. 1–22)	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

3316-113

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
130450	Nut	1	11	1	613345	Door - Access	1	16	1
130743	Nut-Flywheel	9	1	1	613348	Base - Air Filter	12	25	1
145482	Plug	5	5	1	613349	Screw	12	32	2
146134	Screw - Plate to Trans.	3	7	2	613352	Spacer	12	34	2
300402	Pin - Taper	9	21	1	613353	Bolt	12	26	1
303724	Screw	1	8	1	613358	Knob - Mounting, Handle	5	23	2
316959	Lockwasher	9	2	1	613360	Shoulder Bolt	9	17	1
602315	Locknut	3	25	2	613361	Filter - Air	12	28	1
602315	Nut	9	14	2	613371	Spacer - Muffler Guard	2	3	1
602315	Nut	5	30	1	613372	Screw - Muffler Guard	2	2	1
602315	Nut - Cable Anchor/Hsg.	1	21	2	613378	Cover - Muffler	2	1	1
602480	Screw	3	24	2	613379	Cover - Air Box	12	33	1
603164	Nut - Blade	1	35	1	613381	Screw - Plate to Housing	1	20	6
603773	Nut	3	10	1	613382	Gasket - Head	9	55	1
607199	Key	9	48	1	613385	Clamp	3	6	1
608311	Locknut - Mtg Plate/Hsg.	1	37	3	613386	Brake Spring	9	19	1
609150	Baffle	2	16	1	613387	Screw	3	5	3
609807	Screw	1	1	2	613387	Screw	9	39	1
610026	Rod - Trailing Shield	1	18	1	613388	Clamp - Throttle Cable	9	38	1
610358	Nut	3	26	2	613390	Brake Actuator	9	15	1
610358	Nut	1	33	4	613393	Plate - Nut	5	33	1
610361	Washer	1	23	4	613401	Screw	5	22	1
611380	Grommet	1	39	1	613405	Screw	5	32	1
611499	Screw	5	31	1	613406	Nut	5	25	2
611774	Screw - Mtg Plate/Hsg.	2	30	3	613406	Nut	5	10	2
611840	Key	3	17	1	613408	Insert - Handle	5	27	1
611840	Key - Woodruff	7	5	1	613409	Pivot - Bail	5	11	1
612428	Screw-Sems	10	*	4	613412	Block - Bail	5	14	1
612429	Hub - Starter	10	2	1	613416	Bail - Brake, Engine	5	38	1
612432	Rope	10	8	1	613417	Bail - Self-propelled	5	12	1
612824	Insert - Clip, Rope	10	4	1	613429	Washer - Governor Shaft	9	24	2
612825	Handle - Starter	10	3	1	613430	Retainer - Throttle Wire	9	29	1
612950	Pulley	10	7	1	613445	Pulley - Transmission	3	3	1
613110	Screw	9	22	2	613483	Screw - Mtg Plate To Eng.	2	33	3
613111	Screw	9	23	4	613489	Clamp - Fuel Line	2	25	2
613121	Decal - Spark Plug	1	44	1	613489	Clamp - Hose	12	24	1
613122	Decal - Sound Emission	1	43	1	613516	Clamp - Oil Hose	2	27	2
613148	Pin - Wrist	9	51	1	613516	Clamp - Oil Line	9	6	2
613180	Gasket - Carb. to Spacer	12	1	1	613531	Fuel Line	2	26	1
613181	Gasket - Spacer to Engine	12	2	1	613531	Gas Line	12	23	1
613182	Oil Seal - Crankshaft	9	10	2	613532	Cover - Lower Drive	1	40	1
613183	Ring - Retaining	9	11	AR	613549	Screw	5	18	6
613197	Head - Cylinder	9	54	1	613550	Nut - Cable, Self-propelled	5	16	1
613206	Plate - Engine Mounting	2	32	1	613551	Screw	5	9	1
613208	Screw	9	4	5	613553	Screw	5	13	1
613227	Screw - Set, Engine Pulley	9	41	1	613555	Screw	5	37	1
613228	Pulley - Engine	9	42	1	613557	Snubber - Belt	2	31	1
613229	Ball - Governor	9	45	4	613576	Screw - Muffler Guard	2	37	2
613230	Seal - Oil, Governor Shaft	9	26	1	613601	Insert - Handle	5	28	1
613233	Screw - Cyl. Head to Block	9	53	4	613625	Lockwasher	1	10	1
613258	Ring - Retaining	9	50	2	613628	Spring - Torsion	9	32	1
613265	Ring - Retaining	9	12	AR	613641	Gasket - Bowl Retainer	12	4	1
613266	Gasket - Exhaust	2	34	1	613642	Gasket - Fuel Bowl	12	5	1
613266	Gasket - Exhaust	9	56	1	613647	Pilot Jet	12	10	1
613269	Screw	9	31	1	613649	Nozzle	12	12	1
613274	Rod - Choke	9	27	1	613650	Seal - Throttle Shaft	12	13	1
613276	Rod - Oil Pump Control	9	34	1	613651	Seal - Choke Shaft	12	14	1
613277	Rod - Throttle	9	28	1	613655	Screw - Throttle Valve	12	15	2
613281	Screw - Shroud	2	6	3	613656	Screw - Choke Valve	12	16	2
613282	Screw - Muffler	2	36	3	613657	Pivot - Upper Choke Shaft	12	17	1
613289	Baffle	1	22	1	613658	Pivot - Lower Choke Shaft	12	18	1
613311	Gasket	2	18	1	613683	Wire Tie	9	40	1
613313	Gasket	2	14	1	613747	Shaft - Governor	9	43	1
613320	Screw	1	25	2	613748	Gasket - Air Filter Base	12	3	1
613321	Bolt - Handle Mounting	1	13	2	613749	Screw	1	12	1
613322	Shield - Trailing	1	17	1	613770	Nut	3	2	1
613327	Screw - Carb. to Engine	12	27	2	613842	V-Belt	3	1	1
613328	Ring - Retain. - Gov. Shaft	9	25	1	613893	Main Jet - High Altitude	12	35	1
613329	Pushnut	2	5	4	613910	Washer - R.H. Handle	1	3	1
613329	Pushnut	12	31	4	613917	Arm - Front Height Adj.	1	32	2
613330	Screw - Fuel Tank	2	9	3	613918	Main Jet	12	11	1
613336	Nut	9	33	1	613924	Baffle - Front	1	46	1
613337	Bolt - Bracket To Block	2	22	2	613925	Screw - Baffle, Front	1	47	3
613337	Screw	9	36	2	613944	Blade - 21"	1	36	1
613339	Screw	1	15	1	613948	O-Ring	2	29	1
613340	Speednut	1	14	1	613980	Decal - Lawn-Boy	5	35	1
613341	Speednut	1	2	1	614009	Spark Plug	9	46	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
614013	Screw - Set	5 1 2	684210	Assembly - Cable, Throttle	5 7 1
614023	Screw - Thread Forming	5 20 3	684212	Assy. - Cable, Gear Select	5 39 1
614032	Shoulder Bolt	9 16 1	684219	Assy. - Knob & Spring, R.H.	1 *31 1
614037	Decal	10 1 1	684220	Assy. - Knob & Spring, L.H.	1 30 1
614041	Applique	2 7 1	684272	Assy. - Piston & Ring (Std.)	9 49 1
614043	Spring - Governor	9 35 1	684273	Ring Set (Standard)	9 52 1
614173	Bracket - Fuel Tank	2 20 1	684275	Oil Pump Kit w/Oil Lines	9 5 1
614175	Bowl - Fuel	12 20 1	684276	Short Block	9 * 1
614176	Screw - Bowl Retainer	12 21 1	684280	Kit - Gasket	12 * 1
614181	Screw - Fuel Tank Mount.	2 21 1	684280	Kit - Gasket	12 * 1
614239	Hose - Carb Vent	12 22 1	684281	Kit - Float & Needle	12 6 1
614245	Pre-Filter	12 30 1	684282	Needle and Clip	12 7 1
614271	Cover - Baffle	2 17 1	684283	Kit - Idle Needle & Spring	12 8 1
614272	Cover - Baffle	2 13 1	684284	Kit - Idle Speed	12 9 1
614274	Baffle	2 12 1	684307	Assy. - Piston & Ring	9 49 1
614316	Arm - Shift	3 15 1	684309	Ring Set (0.020 Oversize)	9 52 1
614316	Arm - Shift	7 28 1	684336	Assembly - Oil Fitting	2 28 1
614317	Arm - Clutch	3 16 1	684362	Brake & Switch	9 20 1
614317	Arm - Clutch	7 34 1	684366	Switch - Bag Lock	1 7 1
614328	Housing - Shield	1 45 1	684376	Switch - Low Oil	2 10 1
614330	Decal - Zone Start	5 42 1	684399	Assembly - Knob, Throttle	5 2 1
614331	Decal - Self-Propelled	5 43 1	684400	Assy. - Knob, Gear Select	5 41 1
614426	Washer - Stepped	3 38 2	684427	Assembly - Cover, Upper	5 4 1
614427	Cover - Wheel	3 37 2	684429	Assy. - Shroud	2 8 1
614430	Bolt - Wheel	3 41 2	684437	Kit - Gov. & Oil Pump Lever	9 30 1
614430	Shoulder Bolt - Wheel	1 26 2	684445	Lever - Gear, Select	5 40 1
614433	Plate - Height Adjust	1 19 2	684446	Lever - Throttle	5 6 1
614442	Fitting - Grease	3 27 2	684465	Ramp - Governor	9 44 1
614443	Ring - Isolator	3 18 2	684478	Kit - Bowl	12 19 1
614447	Spacer	3 19 2	684508	Assembly - Fuel/Oil Tank	2 19 1
614518	Insert - Handle, Cable Side	5 26 1	684548	Kit - Carb. & Gasket	12 * 1
614522	Anchor - Cable	1 5 1	684559	Assembly - Cover, Air Filter	12 29 1
614523	Arm - Trans. Engagement	3 11 1	684567	Housing - Starter	10 5 1
614524	Plate - Actuator	3 4 1	684579	Muffler	2 35 1
614525	Spring	3 8 1	684581	Assembly - Handle & Decal	5 8 1
614526	Guide - Belt	3 12 1	684616	Pivot Arm Assy.	3 21 2
614527	Bolt - Shoulder	3 13 1	684617	Transmission	3 9 1
614529	Spring - Extension	3 14 1	684618	Assembly - Knob & Spring	3 20 2
614567	Plate	5 3 1	684622	Assembly - Starter	10 * 1
614600	Shaft - Input	7 4 1	684645	Assembly - Wheel & Tire	1 29 2
614601	Washer	7 6 1	684645	Assembly - Wheel	3 39 2
614602	Bearing - Lower	7 7 1	684673	Wire Harness	9 9 1
614603	Bearing - Upper	7 8 1	684689	Assembly - Housing	1 38 1
614604	Ring Gear	7 12 1	684695	Assembly - Shaft, Handle	5 24 1
614606	Collar	7 10 1	684697	Assy. - Cable, Self-propelled	5 29 1
614607	Washer	7 20 4	684698	Assy. - Cover & Terminal	9 59 1
614608	Key - Holder,	7 21 1	684731	Kit - Upper & Lower Case	7 1 1
614609	Collar - Shift	7 22 1	684732	Bushing Set	7 11 1
614610	Slider	7 23 1	684733	Gear Set	7 13 1
614611	Washer	7 17 2	684734	Gear Set	7 14 1
614613	Ring - Snap	7 19 2	684735	Gear Set	7 15 1
614614	Ring - Snap	7 24 1	684736	Kit - Shaft, Reduction	7 9 1
614615	Ball	7 25 2	684737	Bushing Set	7 18 2
614616	Collar - Sliding	7 26 1	684739	Spring & Key - Shift	7 30 2
614617	Fork - Shift	7 27 1	684740	Kit - Axle Shaft	7 16 1
614618	Support - Fork	7 29 2	700056	Screw - Muffler Guard	2 38 1
614619	Spring	7 31 1	700098	Nut	2 23 1
614620	Plate	7 32 1	700748	Bolt	1 4 2
614621	Fork - Clutch	7 33 1	700790	Bumper	5 17 1
614622	Ball	7 35 1	705137	Nut - Oil Switch	2 * 1
614625	Screw - Tapping	7 2 1	16-2219	Cover - Upper Drive	1 41 1
614626	Screw - Tapping	7 3 5	27-6250	Bushing	1 28 4
677525	Assembly - Collar & Plate	1 34 1	27-6250	Bushing	3 40 2
683897	Recoil Spring & Keeper	10 6 1	39-5770	Decal - Blade Warning	1 6 1
683899	Assembly - Dog Kit	10 9 1	46-6811	Screw - Baffle to Housing	1 24 4
683993	Crankshaft & Conn. Rod	9 47 1	47-2900	Bushing	3 23 2
684022	Bearing - Crankshaft	9 13 2	65-2720	Ring - Retaining	3 30 4
684023	Flywheel	9 3 1	65-4710	Ring - Friction	3 31 2
684049	Module - C.D. Ignition	9 57 1	65-4720	Spring - Compression	3 36 2
684080	Assy. - Spacer & Oil Nozzle	12 36 1	65-4730	Washer - Inner Thrust	3 28 2
684090	Assy. - Governor Bracket	9 37 1	65-4740	Washer - Keyed	3 29 4
684093	Fuel Shut - Off Valve	2 24 1	65-4750	Gear - Pinion 15T	3 35 2
684104	Assembly - Fuel Cap	2 15 1	65-4760	Washer - Clutch	3 32 2
684105	Assembly - Oil Cap	2 11 1	66-6040	Key, Rocking - R.H.	3 *33 1
684130	Frame	5 36 1	66-6050	Key, Rocking - L.H.	3 34 1
684151	Guide - Rope	5 34 1	70-9760	Bushing	3 22 2
684157	Assembly - Muffler Guard	2 4 1	92-1604	Cap - Hub	3 42 2
684179	High Tension Lead & Cover	9 58 1	92-1604	Cap - Hub	1 27 2
684193	Assembly - Magnet	1 9 1	92-2939	Decal - Warning	1 42 1
684209	Assy. - Cable, Eng. Brake	5 19 1	92-2940	Decal - Warning	5 15 1