



Blower and Drive Kit

48in E-Z Vac™ for Z Master® G3 Mower

Model No. 78551 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Blower Assembly	 3	Belt, Cover and Pulley Assembly	 5


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	LH.	left hand
BBC.	blade brake clutch	NI.	nylon insert
CARR.	carriage	NPTF.	national pipe thread fine
DEG.	degrees	PFH.	phillips flat head
EXT.	external	PPH.	phillips pan head
FH.	flat head	PPHTF.	phillips pan head thread forming
GA.	gauge	PRH.	phillips round head
HD.	heavy-duty	PTH.	phillips truss head
HF.	hex flange	PTO.	power-take-off
HH.	hex head	RH.	right hand
HHF.	hex head flange	ROPS.	roll-over protection system
HHFTF.	hex head flange thread forming	SFH.	slotted fillister head
HJ.	hex jam	SHH.	slotted hex head
HLH.	hex lag head	SHWH.	slotted hex washer head
HOC.	height-of-cut	SPH.	slotted pan head
HSBH.	hex socket button head	SQH.	square head
HSFH.	hex socket flat head	SRH.	slotted round head
HS.	hex socket head	STD.	standard
HWH.	hex washer head	TAP.	self tapping
HWHTF.	hex washer head thread forming	TTH.	torx truss head


Footnotes

- ❶ Not serviced separately



Blower Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-353054	1	Latch-Catcher, Grass	22	110-0334-03	1	Blower Mount ASM
2	1-513013	4	Housing-Flange	22:1		1	Blower-Mount
3	1-513208	1	Washer-Spring	22:1:2	1-353050	1	Shaft-Catcher, Grass
4	1-513435	1	Washer-Spring	22:1:7	1-806323	1	Pin-Roll
5	112-1771	1	Upper Housing ASM	23	117-0345	1	Idler Arm ASM W/Bushings
5:2	106-3339	1	Decal-Warning	23:2	1-653600	2	Bearing
5:3	98-5954	1	Decal-Cover, Missing	23:3	302-19	1	Fitting-Grease
5:4	112-1770	1	Decal	23:4	1-653558	1	Decal-Hot Sheave
6	1-653322	1	Idler-Inside	24	321-3	8	Screw-HH
7	1-653346	2	Bearing-SPH	25	323-11	2	Screw-HH
8	109-1122-01	1	Bumper	26	323-12	2	Screw-HH
9	1-653365	1	Spacer	27	323-7	1	Screw-HH
10	1-653366	1	Hub	28	323-8	3	Screw-HH
11	1-653596-03	1	Plate-Backing, Blower	29	3219-6	1	Nut-Hex
13	3274-69	2	Screw-HSBH	30	3220-5	1	Nut-Jam
14	103-0130	1	Bushing-Pivot, Idler	31	3229-1	2	Screw-CARR
15	112-2345	1	Pulley	32	3229-11	3	Screw-CARR
16	103-1103	1	Idler-Flat	33	3230-18	6	Screw-CARR
17	112-1772	1	Bearing Cover ASM	34	3256-16	12	Washer-Flat
17:2	103-3508	1	Decal-Warning	35	3256-24	1	Washer-Flat
18	103-3815	1	Impeller	36	3256-3	2	Washer-Flat
19	103-4080	2	Latch-Rubber	37	3256-4	4	Washer-Flat
20	103-4171	1	Chute-Blower, Small	38	3257-32	1	Key-Woodruff
21	112-1761-03	1	Plate-Bottom	39	3274-107	1	Screw-HSBH



Blower Assembly (continued)

Ref	Part No.	Qty.	Description
40	3256-22	2	Washer-Flat
41	3290-357	6	Nut-HHF, Whiz
42	3274-39	12	Screw-HSBH
43	3296-39	2	Nut-Lock, NI
44	3296-47	2	Nut-Lock, NI
45	32128-20	6	Nut-HF
46	32128-33	15	Nut-HF
47	3296-2	8	Nut-Lock NI
48	112-1762-03	1	Plate-Filler, Rear
57	112-1787	1	Latch-Stop
58	104-8426	1	Spacer

NOTES

NOTES

