



## 72in E-Z Vac™ Triple Bagging System Gen II Z Master® Mower

Model No. 78564 - 290000001 and up.

### Parts Catalog

---

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


# Contents

| Description             | Page    | Description           | Page    |
|-------------------------|---------|-----------------------|---------|
| Bagger Mount Assembly   | ..... 3 | Bag and Tube Assembly | ..... 5 |
| Hood and Frame Assembly | ..... 4 | Weight Assembly       | ..... 6 |

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


|  |  |
|--|--|
| AR. .... as required                       | HYD. .... hydraulic                          |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HD. .... heavy-duty                        | PTH. .... phillips truss head                |
| HF. .... hex flange                        | PTO. .... power-take-off                     |
| HH. .... hex head                          | RH. .... right hand                          |
| HHF. .... hex head flange                  | ROPS. .... roll-over protection system       |
| HHFTF. .... hex head flange thread forming | SFH. .... slotted fillister head             |
| HJ. .... hex jam                           | SHH. .... slotted hex head                   |
| HLH. .... hex lag head                     | SHWH. .... slotted hex washer head           |
| HOC. .... height-of-cut                    | SPH. .... slotted pan head                   |
| HSBH. .... hex socket button head          | SQH. .... square head                        |
| HSFH. .... hex socket flat head            | SRH. .... slotted round head                 |
| HSH. .... hex socket head                  | STD. .... standard                           |
| HWH. .... hex washer head                  | TAP. .... self tapping                       |
| HWHTF. .... hex washer head thread forming | TTH. .... torx truss head                    |



## Bagger Mount Assembly

| Ref | Part No.    | Qty. | Description            |
|-----|-------------|------|------------------------|
| 1   | 109-9248    | 1    | Mount-Bagger, Lower    |
| 2   | 3231-28     | 4    | Screw-CARR             |
| 3   | 109-6658    | 12   | Nut-Flange, NI (Split) |
| 4   | 116-0473-03 | 1    | Mount-Bagger, Upper    |
| 5   | 3233-34     | 2    | Screw-CARR             |
| 6   | 116-0057-03 | 1    | Bumper-RH              |
| 7   | 116-0180    | 1    | LH Bumper ASM          |
| 7:2 | 103-2076    | 1    | Decal-Caution          |
| 8   | 3231-28     | 2    | Screw-CARR             |
| 9   | 99-5107     | 2    | Nut-Lock               |

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|--|--|--|--|




## Hood and Frame Assembly

| Ref | Part No.    | Qty. | Description                |
|-----|-------------|------|----------------------------|
| 1   | 109-8706-03 | 1    | Frame-Uv, 3-Bag            |
| 2   | 103-5166    | 2    | Bag Support ASM            |
| 2:1 | 1-523420    | 1    | Bumper                     |
| 2:3 | 1-653404    | 1    | Catch                      |
| 2:4 | 3290-148    | 2    | Nut-HF                     |
| 2:5 | 32128-33    | 1    | Nut-HF                     |
| 2:6 | 3290-500    | 2    | Screw-PPH                  |
| 3   | 3274-55     | 8    | Screw-HSBH                 |
| 4   | 109-8351-03 | 2    | Hinge                      |
| 5   | 1-633545    | 2    | Spacer                     |
| 6   | 3256-2      | 4    | Washer-Flat                |
| 7   | 321-6       | 2    | Screw-HH                   |
| 8   | 3296-42     | 4    | Nut-Lock, NI               |
| 9   | 1-653544    | 4    | Spring-Extension           |
| 10  | 3256-61     | 23   | Washer-Flat                |
| 11  | 112-1760    | 1    | Hood ASM                   |
| 13  | 103-0451    | 1    | Seal-Hinge                 |
| 14  | 103-0452-03 | 1    | Plate-Backing              |
| 15  | 103-0391    | 2    | Reinforcement-Hood, Bagger |
| 16  | 321-4       | 10   | Screw-HH                   |
| 17  | 32128-33    | 10   | Nut-HF                     |
| 18  | 1-653403    | 2    | Latch                      |
| 19  | 321-11      | 2    | Screw-HH                   |
| 20  | 114439      | 46   | Rivet-Pop                  |

| Ref | Part No.    | Qty. | Description                |
|-----|-------------|------|----------------------------|
| 21  | 1-803075    | 6    | Screw-Head, Truss          |
| 22  | 3296-2      | 14   | Nut-Lock, NI               |
| 23  | 103-0439    | 1    | Seal-Tube                  |
| 25  | 3250-27     | 8    | Screw-PPH                  |
| 26  | 116-0458    | 2    | Bagger Mount Pin ASM       |
| 28  | 1-513658    | 2    | Bumper                     |
| 29  | 103-0378    | 2    | Clamp-Seal                 |
| 30  | 103-0382-03 | 1    | Stiffener-Bagger, Top      |
| 31  | 103-0440    | 1    | Screen-Bagger              |
| 32  | 103-0380-03 | 1    | Support-Screen             |
| 33  | 103-0379    | 2    | Bracket-Mount              |
| 34  | 103-0376    | 2    | Plate-Latch, Reinforcement |
| 35  | 67-7310     | 1    | Decal                      |
| 36  | 109-9338    | 1    | Diverter-Exhaust           |
| 37  | 109-6658    | 2    | Nut-Flange, NI (Split)     |
| 38  | 3231-28     | 2    | Screw-CARR                 |





## Weight Assembly

| Ref    | Part No.    | Qty. | Description                  |
|--------|-------------|------|------------------------------|
| 1      | 115-3636    | 2    | 63 Lbs Weight ASM            |
| 1:2    | 106-3339    | 1    | Decal-Warning                |
| 2      | 1-806003    | 2    | Pin-Hair                     |
| 3      | 323-50      | 2    | Bolt-TAP                     |
| 4      | 3217-7      | 2    | Nut-Hex                      |
| 5      | 100-1413    | 2    | Pin-Clevis                   |
| 6      | 3256-4      | 2    | Washer-Flat                  |
| 7      | 323-6       | 2    | Screw-HH                     |
| 8      | 115-3615-01 | 1    | Bracket-Weight Mount         |
| 9      | 104-8300    | 2    | Nut-Flange, NI               |
| 10     | 115-3617    | 1    | Weight ASM                   |
| 10:1   | 115-3618    | 1    | Weight                       |
| 10:1:2 | 106-0871    | 1    | Decal-Warning, Counterweight |
| 10:2   | 115-3616-01 | 1    | Tab-Weight Support           |
| 10:3   | 323-4       | 2    | Screw-HH                     |
| 10:4   | 3253-5      | 2    | Washer-Lock                  |
| 11     | 3230-23     | 2    | Screw-CARR                   |
| 12     | 3253-5      | 2    | Washer-Lock                  |
| 13     | 104-8301    | 1    | Nut-Flange, NI               |

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |

## NOTES

