



48in and 52in E-Z Vac™ DFS Collection System Z Master® G3 Mower

Model No. 78566 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Description	Page	Description	Page
Bagger Mount Assembly 3	Tube and Weight Assembly 5
Hood and Frame Assembly 4	Bagger Mount Assembly 6

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head



Bagger Mount Assembly

Ref	Part No.	Qty.	Description
1	3274-1	1	Screw-HSH
2	103-8835-03	1	Link
3	109-8701-03	1	Frame ASM
5	1-323385	1	Knob-3 Prong
6	322-12	1	Screw-HH
7	3256-23	5	Washer-Flat
8	103-5114-03	1	Bellcrank
9	103-3202	2	Cap
10	3296-29	5	Nut-Lock, NI
11	109-9338	1	Diverter-Exhaust
12	109-6658	12	Nut-Flange, NI (Split)
13	3230-31	1	Screw-CARR
14	117-6164-03	1	Handle ASM
15	103-7115	1	Handle-Grip
16	3231-28	8	Screw-CARR
17	3233-34	2	Screw-CARR
18	1-513658	2	Bumper
19	103-4402	2	Bearing
20	103-4433	1	Shaft-Collar
21	116-0473-03	1	Mount-Bagger, Upper
22	109-9248	1	Mount-Bagger, Lower
24	116-0458	2	Bagger Mount Pin ASM
25	3230-5	4	Screw-CARR
26	116-0057-03	1	Bumper-RH

Ref	Part No.	Qty.	Description
27	116-0180	1	LH Bumper ASM
27:2	103-2076	1	Decal-Caution
28	99-5107	2	Nut-Lock



Bagger Mount Assembly

Ref	Part No.	Qty.	Description
1	103-4819-03	1	Guard-RH
2	103-7829	1	Panel-Bagger, RH
3	114439	14	Rivet-Pop
4	103-5102	1	Panel-Bagger
5	103-4828	1	Screen-Door
6	3256-2	20	Washer-Flat
7	321-4	32	Screw-HH
8	103-4406-03	1	Door-Frame
9	3296-29	12	Nut-Lock, NI
10	3256-23	22	Washer-Flat
11	103-4820-03	2	Plate-Hinge
12	103-6294	2	Pin-Pivot, Hinge
13	103-6295	2	Bearing
14	3256-4	2	Washer-Flat
15	3296-59	2	Nut-Lock, NI
16	3230-22	4	Screw-CARR
17	94-8196	6	Washer-Nylon
18	103-4424	2	Arm-Linkage, Door
19	32151-61	6	Ring-Retaining
20	103-4431	2	Washer
21	3219-5	4	Nut-Hex
22	103-4835	2	Anchor-Spring
23	103-4848	2	Trunnion-Link
24	103-4822	2	Link-Door

Ref	Part No.	Qty.	Description
25	103-4813	2	Spring
26	323-7	2	Screw-HH
27	103-4415	2	Bearing-Linkage, Pivot
29	32128-33	26	Nut-HF
30	322-5	4	Screw-HH
31	3231-4	2	Screw-CARR
32	3256-22	6	Washer-Flat
33	103-4437-03	1	Guard-LH
34	103-5112	1	Link-LH
35	107069	6	Clip
36	103-4408-03	2	Stop-Linkage
37	3296-39	2	Nut-Lock, NI
38	3230-2	4	Bolt-CARR
39	103-5111	1	Link-RH
40	3256-26	2	Washer-Flat
41	1-806003	2	Pin-Hair
42	103-7828	1	Panel-Bagger, LH

NOTES

