

LAWN-BOY®

19" S SERIES WALK-BEHIND MOWER

MODEL NO. 10725-3900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN–BOY owners as quickly as possible, minor changes are incorporated into LAWN–BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN–BOY Distributor or his Authorized LAWN–BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck . In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Engine, Shroud and Muffler Plate	1	Carburetor Assembly	5
Deck, Muffler Cover, Blade & Wheels	2	Engine Assembly	6
Handle	3	Numeric Parts Index	8
Starter	4		

Accessories

Description	Model / Part No.	Description	Model / Part No.
Mulch Plate	89862	Leaf Shredder	681683




C-1441a

ENGINE SHROUD AND MUFFLER PLATE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614265	Applique	1	7	681818	Fuel Shut-Off Assembly	1
2	611395	Screw	5	8	92-1648	Screw - Muffler Plt. to Hsg.	3
3	612428	Screw - Starter Mounting	4	9	613500	Screw - Muffler Plt. to Block	1
4	684570	Starter Base	1	10	607601	Screw - Muffler Plt. to Block	3
5	682755	Fuel Cap (Includes both of the following items)	1	11	92-1054	Plate - Muffler	1
*	607213	Gasket	1	12	609420	Gasket - Exhaust	1
*	609150	Baffle	1	13	611564	Decal - Fuel Shut-Off Assy.	1
6	92-1084	Shroud - Engine	1	14	3256-56	Washer - Muffler Plt. to Hsg.	3

*Not illustrated




C-1442

DECK, MUFFLER COVER, BLADE & WHEELS

Ref. No.	Part No.	Description	No. Used
1	608159	Toe Bar	1
2	604604	Grommet	3
4	607560	Cover Plate	1
5	606452	Screw - Cover Plate	1
6	607809	Screw - Plate Mounting	2
7	39-5770	Decal - Danger (English)	1
8	608160	Rod - Trailing Shield	1
9	16-2289	Housing Assembly (Incl. Ref. # 2, 7, 33 & 35)	1
10	611014	Shield - Trailing	1
11	609891	Screw - Trailing Shield	2
12	608161	Clamp	2
13	602315	Nut	3
14	153444	Knob and Spring Assembly	4
15	610646	Bolt - Shoulder	4
16	682974	Wheel - Rear 8"	2
19	603441	Bolt - Wheel	4
20	603620	Washer	4

Ref. No.	Part No.	Description	No. Used
21	608833	Bracket - Wheel Ht. Adjust	4
22	608834	Washer - Wheel Ht. Adjust	4
23	603773	Nut - Wheel Ht. Adjust	4
25	678636	Wheel - Front 6"	2
26	603164	Nut	1
27	603409	Blade 19"	1
28	677525	Collar and Plate Assembly	1
29	609471	Screw - Muff. to Muff. Plate	3
30	609786	Support - Crankshaft	1
31	682876	Muffler Cover Assembly	1
32	46-6811	Screw	2
33	92-2940	Decal - Warning (English)	1
*	92-5434	Kit - Decal, French	1
34	605256	Washer - Wheel Bolt	4
35	613121	Decal - Spark Plug	1
36	603541	Stiffener - Blade	1
37	605058	Washer	2
38	605255	Washer - Felt	8

*Not Illustrated




C-1443

HANDLE

Ref. No.	Part No.	Description	No. Used
1	153254	Rope Guide Assembly	1
2	611233	Screw – Truss Head	2
3	611799	Screw	2
4	612586	Washer	2
5	612588	Cable – Throttle	1
6	683663	Lever & Knob Assembly	1
7	683041	Control Cable Assembly	1
8	611542	Pin	1
9	611777	Control Case Outer	1
10	611541	Column	1
11	612168	Nut – Acorn	1
12	612564	Pulley	1
13	612633	Case – Throttle, Center	1
14	611543	Screw	2
15	612698	Decal – Throttle	1
16	612634	Case – Throttle, Inner	1
17	611258	Nut	2

Ref. No.	Part No.	Description	No. Used
18	683478	Lever – Control	1
20	614243	Knob	2
21	613363	Handle – Lower	1
22	683925	Bracket – Handle L.H.	1
23	607188	Screw	4
25	614249	Tie Strap	2
26	605546	Nut – Push	1
27	683926	Bracket – Handle R.H.	1
28	605803	Pin – Cotter	2
29	614697	Screw	2
30	612683	Handle Assembly – Top	1
31	602315	Nut – Lock	2
32	602945	Washer	2
33	92-2930	Rope Stop	1
34	611571	Eyebolt	1
35	602315	Nut – Lock	2




C-1337

STARTER

Ref. No.	Part No.	Description	No. Used
*	684622	Starter Assembly (Incl. Ref. #3, 6, 7 & 9)	1
1	614196	Decal - Recoil	1
2	684567	Starter Housing & Shaft	1
3	683897	Spring & Keeper	1
4	612825	Handle - Starter	1

Ref. No.	Part No.	Description	No. Used
5	612824	Clip - Rope	1
6	612432	Rope	1
7	612950	Pulley	1
8	612949	Hub - Starter	1
9	683899	Kit - Dog	1
*	47-2480	Stop - Rope	1

*Not Illustrated




C-1340

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
*	684334	Body - Carburetor (Incl. Ref. #18-34)	1	21		(Incl. Ref. # 21 - 22) Spring - Needle	1
1	612505	Vane - Air	1	22		Needle - Idle	1
2	605522	Screw	1	23	683783	Kit - Float Assembly	1
3	610165	Retainer - Speed Control Lever	1	*	683782	Kit - Bowl (Incl. Ref. #24 &25)	1
4	612502	Lever - Governor Control	1	24		Bowl - Fuel	1
5	612757	Collar	1	25		Screw	1
6	613142	Spring	1	*		Kit - Gasket	1
7	308052	Washer	1	*	683778	Kit - Gasket (Incl. Ref. #26 & 27)	1
8	612504	Base - Air Filter	1	26		Gasket - Bowl Retainer	1
9	612503	Spacer - Filter Base	1	27		Gasket - Bowl	1
10	609493	Element - Air Filter	1	*	683777	Kit - Repair (Incl. Ref. #28-31)	1
11	611377	Cover - Air Filter	1	28		Plug - Welch	2
12	610383	Retainer - Cover	1	29		Shaft - Float	1
13	328712	Nut	1	30		Inlet - Needle Valve	1
14	314576	Screw	1	31		Seat - Valve	1
15	612974	Filter - Fuel	1	*		Kit - Gasket	1
16	614380	Heat Shield & Gasket	1	*	683781	Kit - Choke (Incl. Ref. #32-34)	1
17	612507	Screw	2	32		Valve - Choke	1
*	612783	Line - Fuel	1	33		Spring - Return	1
*	684286	Kit - Throttle (Incl. Ref. #18-20)	1	34		Shaft - Choke	1
18		Shaft - Throttle	1	35	612574	Gasket - Carburetor	2
19		Vane - Throttle	1				
20		Screw	1				
*	684285	Kit - Idle Needle	1				

ENGINE ASSEMBLY



C-1338

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1
2	611509	Actuator – Brake Lever	1
3	611214	Spring – Cable, Return	1
4	683819	Switch Assembly (Incl. ref. #1, 6, 20, 56–58)	1
5	682683	Brake Assembly	1
6	683821	Wire Lead	1
7	613529	Bolt – Shoulder	1
8	608311	Nut	1
9	683581	Brace Assembly	1
10	603014	Bolt	1
11	603093	Washer	1
12	602315	Nut	1
13	612427	Shroud – Base	1
14	611191	"J"Clip	1
15	609947	Screw	3
16	683580	Flywheel Assembly	1
17	316959	Washer – Lock	1
18	130743	Nut – Flywheel	1
19	609808	Screw	2
20	317893	Tie Strap	1
21	681737	Set – Ring	1
22	303712	Ring – Retaining	2
23	606608	Pin – Wrist	1
24	92–4934	Piston & Connecting Rod Assembly (Incl. Ref. #20, 24–27 & 32–33)	1
*	682986	Set – Piston & Ring (Incl. Ref. # 21–23)	1
25	679144	Bearing Assembly	1
26	682678	Connecting Rod Assembly (Incl. Ref. #25, 27, 32 & 33)	1
27	603954	Liner – Split	2
28	607199	Key – Flywheel	1

Ref. No.	Part No.	Description	No. Used
29	611396	Seal – Oil	1
30	681830	Bearing – Main	1
31	610747	Crankshaft	1
32	611393	Screw	2
33	92–4927	Set – Needle Bearing	1
34	607526	Screw	2
35	614008	Spark Plug	1
36	684698	Cover – Terminal	1
37	681678	Wire Lead	1
38	683215	C. D. Ignition Module (Incl. Ref. #36, 37)	1
39	605120	Grommet	2
40	614249	Tie Strap	1
41	613072	Bracket – C. D.	1
42	614343	Screw	2
43	683694	Cylinder & Crankcase Cover Assembly (Incl. Ref. # 46–48, 51 & 58)	1
44	609123	Plug	4
45	609420	Gasket – Exhaust	1
46	612872	Screw	2
47	602587	Plate – Reed	1
48	602588	Reed	1
49	681831	Bearing – Main	1
50	611396	Seal – Oil	1
51	613110	Screw	2
52	611192	Bracket – Brake	1
53	613233	Screw	2
54	611211	Spring – Brake	1
55	683819	Case Assembly	1
56	306407	Washer	1
57	609891	Screw	1
*	609629	Dowel	1
*	92–6350	Short Block	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

3316-129

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
130743	Nut - Flywheel	6 18 1	610747	Crankshaft	6 31 1
153254	Rope Guide Assembly	3 1 1	611014	Shield - Trailing	2 10 1
153444	Knob and Spring Assembly	2 14 4	611191	"J"Clip	6 14 1
303712	Ring - Retaining	6 22 2	611192	Bracket - Brake	6 52 1
306407	Washer	6 56 1	611211	Spring - Brake	6 54 1
308052	Washer	4 7 1	611213	Retainer	6 1 1
314576	Screw	4 14 1	611214	Spring - Cable, Return	6 3 1
316959	Washer - Lock	6 17 1	611233	Screw - Truss Head	3 2 2
317893	Tie Strap	6 20 1	611258	Nut	3 17 2
328712	Nut	4 13 1	611377	Cover - Air Filter	4 11 1
602315	Nut	6 12 1	611393	Screw	6 32 2
602315	Nut	2 13 3	611395	Screw	1 2 5
602315	Nut - Lock	3 31 2	611396	Seal - Oil	6 29 1
602315	Nut - Lock	3 35 2	611396	Seal - Oil	6 50 1
602587	Plate - Reed	6 47 1	611509	Actuator - Brake Lever	6 2 1
602588	Reed	6 48 1	611541	Column	3 10 1
602945	Washer	3 32 2	611542	Pin	3 8 1
603014	Bolt	6 10 1	611543	Screw	3 14 2
603093	Washer	6 11 1	611564	Decal - Fuel Shut-Off Assy.	1 13 1
603164	Nut	2 26 1	611571	Eyebolt	3 34 1
603409	Blade 19"	2 27 1	611777	Control Case Outer	3 9 1
603441	Bolt - Wheel	2 19 4	611799	Screw	3 3 2
603541	Stiffener - Blade	2 36 1	612168	Nut - Acorn	3 11 1
603620	Washer	2 20 4	612427	Shroud - Base	6 13 1
603773	Nut - Wheel Ht. Adjust	2 23 4	612428	Screw - Starter Mounting	1 3 4
603954	Liner - Split	6 27 2	612432	Rope	7 6 1
604604	Grommet	2 2 3	612502	Lever - Governor Control	4 4 1
605058	Washer	2 37 2	612503	Spacer - Filter Base	4 9 1
605120	Grommet	6 39 2	612504	Base - Air Filter	4 8 1
605255	Washer - Felt	2 38 8	612505	Vane - Air	4 1 1
605256	Washer - Wheel Bolt	2 34 4	612507	Screw	4 17 2
605522	Screw	4 2 1	612564	Pulley	3 12 1
605546	Nut - Push	3 26 1	612574	Gasket - Carburetor	4 35 2
605803	Pin - Cotter	3 28 2	612586	Washer	3 4 2
606452	Screw - Cover Plate	2 5 1	612588	Cable - Throttle	3 5 1
606608	Pin - Wrist	6 23 1	612633	Case - Throttle, Center	3 13 1
607188	Screw	3 23 4	612634	Case - Throttle, Inner	3 16 1
607199	Key - Flywheel	6 28 1	612683	Handle Assembly - Top	3 30 1
607213	Gasket	1 1 1	612698	Decal - Throttle	3 15 1
607526	Screw	6 34 2	612757	Collar	4 5 1
607560	Cover Plate	2 4 1	612783	Line - Fuel	4 * 1
607601	Screw - Muffler Plt. to Block	1 10 3	612824	Clip - Rope	7 5 1
607809	Screw - Plate Mounting	2 6 2	612825	Handle - Starter	7 4 1
608159	Toe Bar	2 1 1	612872	Screw	6 46 2
608160	Rod - Trailing Shield	2 8 1	612949	Hub - Starter	7 8 1
608161	Clamp	2 12 2	612950	Pulley	7 7 1
608311	Nut	6 8 1	612974	Filter - Fuel	4 15 1
608311	Nut - Muffler Plt. to Hsg.	2 24 3	613072	Bracket - C. D.	6 41 1
608833	Bracket - Wheel Ht. Adjust	2 21 4	613110	Screw	6 51 2
608834	Washer - Wheel Ht. Adjust	2 22 4	613121	Decal - Spark Plug	2 35 1
609123	Plug	6 44 4	613142	Spring	4 6 1
609150	Baffle	1 1 1	613233	Screw	6 53 2
609420	Gasket - Exhaust	1 12 1	613363	Handle - Lower	3 21 1
609420	Gasket - Exhaust	6 45 1	613500	Screw - Muffler Plt. to Block	1 9 1
609471	Screw - Muff. to Muff. Plate	2 29 3	613529	Bolt - Shoulder	6 7 1
609493	Element - Air Filter	4 10 1	614008	Spark Plug	6 35 1
609629	Dowel	6 58 1	614196	Decal - Recoil	7 1 1
609786	Support - Crankshaft	2 30 1	614243	Knob	3 20 2
609808	Screw	6 19 2	614249	Tie Strap	3 25 2
609891	Screw	6 57 1	614249	Tie Strap	6 40 1
609891	Screw - Trailing Shield	2 11 2	614265	Applique	1 1 1
609947	Screw	6 15 3	614343	Screw	6 42 2
610165	Retainer - Speed	4 3 1	614380	Heat Shield & Gasket	4 16 1
610383	Retainer - Cover	4 12 1	614697	Screw	3 29 2
610646	Bolt - Shoulder	2 15 4	677525	Collar and Plate Assembly	2 28 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

3316-129

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
678636	Wheel - Front 6"	2 25 2	683821	Wire Lead	6 6 1
679144	Bearing Assembly	6 25 1	683897	Spring & Keeper	7 3 1
681678	Wire Lead	6 37 1	683899	Kit - Dog	7 9 1
681737	Set - Ring	6 21 1	683925	Bracket - Handle L.H.	3 22 1
681818	Fuel Shut-Off Assembly	1 7 1	683926	Bracket - Handle R.H.	3 27 1
681830	Bearing - Main	6 30 1	684285	Kit - Idle Need	4 * 1
681831	Bearing - Main	6 49 1	684286	Kit - Throttle	4 * 1
682678	Connecting Rod Assembly	6 26 1	684334	Body - Carburetor	4 * 1
682683	Brake Assembly	6 5 1	684567	Starter Housing & Shaft	7 2 1
682755	Fuel Cap	1 5 1	684570	Starter Base	1 4 1
682876	Muffler Cover Assembly	2 31 1	684622	Starter Assembly	7 * 1
682974	Wheel - Rear 8"	2 16 2	684698	Cover - Terminal	6 36 1
682986	Set - Piston & Ring	6 * 1	16-2289	Housing Assembly	2 9 1
683041	Control Cable Assembly	3 7 1	39-5770	Decal - Danger	2 7 1
683215	C. D. Ignition Module	6 38 1	46-6811	Screw	2 32 2
683478	Lever - Control	3 18 1	47-2480	Stop - Rope	7 * 1
683580	Flywheel Assembly	6 16 1	92-1054	Plate - Muffler	1 11 1
683581	Brace Assembly	6 9 1	92-1084	Shroud - Engine	1 6 1
683663	Lever & Knob Assembly	3 6 1	92-1648	Screw - Muffler Plt. to Hsg.	1 8 3
683694	Cylinder & Crankcase Cover	6 43 1	92-2930	Rope Stop	3 33 1
683777	Kit - Repair	4 * 1	92-2940	Decal - Warning (English)	2 33 1
683778	Kit - Gasket	4 * 1	92-4927	Set - Needle Bearing	6 33 1
683781	Kit - Choke	4 * 1	92-4934	Piston & Connecting Rod	6 24 1
683782	Kit - Bowl	4 * 1	92-5434	Kit - Decal, French	2 * 1
683783	Kit - Float Assembly	4 23 1	92-6350	Short Block	6 * 1
683819	Case Assembly	6 55 1	3256-56	Washer - Muffler Plt. to Hsg.	1 14 3
683819	Switch Assembly	6 4 1			

[illegible]