


TORO®

MODEL NO. 59176-3900001 & UP


**PARTS
CATALOG****EASY-EMPTY GRASS CATCHER**

C-0545

GRASS CATCHER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	47-7210	Duct	1
2	32144-34	Screw - Self Tapping	30
3	28-7760	Ring - Retaining	1
4	28-7770	Seal	1
5	74-3320	Frame	1
6	72-2510	Bag - Front	1
7	72-2640	Seal	1
8	72-2540	Bracket - Hinge	2
9	321-39	Screw - Button Head	4
10	3256-61	Washer - Flat	20
11	235-21	Grip - Handle	1
12	72-2660	Handle - Dump	1
13	3269-4	Rivet - Pop	16
14	55-7270	Decal - Warning	1
15	72-2630	Channel - Dump Handle	1
16	3296-42	Nut - Lock	2
17	28-7840	Screen Bag	1

Ref. No.	Part No.	Description	No. Used
18	2410-70	Plug	6
19	72-2690	Decal	1
20	72-2520	Basket - Grass	1
21	72-2650	Frame - Grass Basket	2
23	3296-42	Nut - Lock	8
24	72-2620	Plate - Backup	2
25	321-10	Bolt	9
26	3290-282	Rivet - Pop	5
27	5-1254	Washer	2
28	3290-415	Rivet	2
29	3256-55	Washer - Flat	5
30	2830-10	Chain	2
31	3290-355	Pin - Cotter	2
32	3296-29	Nut - Lock	2
33	72-2550	Guide - Dump Handle	1
34	321-11	Bolt	1



C-0545

GRASS CATCHER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
35	72-2530	Latch	1
36	72-2560	Bracket - Latch	1
37	63-7270	Spacer	1
38	322-3	Bolt	2
39	33-2090	Bracket - Chute Support	1
41	28-8061	Chute Ass'y. (Incl. Ref.#26, 39, 42-49 & 52)	1
42	28-8050	Bracket - Chute Mounting	1
43	3256-49	Washer	1

Ref. No.	Part No.	Description	No. Used
44	3290-412	Rivet - Pop	4
45	28-8130	Pin - Chute	1
46	28-8070	Lanyard	1
48	32140-64	Screw	1
49	54-9220	Decal - Danger	1
50	82-5690	Retainer - Duct	1
51	22-9741	Spacer	1
52	233-68	Knob	1
54	3290-479	Fastener - Panel	1