





MODEL NO. 73401-3900001 & UP

PARTS  
CATALOG

**WHEEL HORSE<sup>®</sup>**  
314-H Garden Tractor






C-1471

### FRAME

Ref. No.	Part No.	Description	No. Used
1	78-2680	Frame	1
2	3231-25	Bolt - Carriage	3
3	3296-39	Nut	3

Ref. No.	Part No.	Description	No. Used
4	323-5	Bolt	4
5	3253-21	Washer - Lock	4




C-1588

## DRIVE BELT AND PULLEYS

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3253-6	Washer - Lock	3	9	937221	Key - Hi-Pro	1
2	324-5	Bolt	3	10	108501	Belt - Drive	1
3	3256-25	Washer	3	11	7443	Pulley - Engine Drive	1
4	321-3	Bolt	1	12	3246-2	Screw - Set	2
5	103995	Washer - Special	1	13	105453	Key	1
6	108393	Fan	1	14	111242	Guide - Belt, Bottom	1
7	3242-2	Screw - Set	2	15	112841	Cap	1
8	108316	Pulley - Transmission Drive	1				


# TRANSAXLE HYDRAULIC SYSTEM



# TRANSAXLE HYDRAULIC SYSTEM

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	108368	Pump & Motor	1	19	108333	Cam – Speed Control	1
2	109751	Gear 20 Tooth	1	20	100309	Spacer	1
3	108366	Spacer – Drive Gear	1	21	108881	Nut – Lock	2
4	32120-64	Ring – Retaining	1	22	106661	Cam – Eccentric	1
5	108319	Gasket	1	23	322-5	Bolt	1
6	323-25	Bolt	2	24	111217	Tube – Suction	1
7	908040	Bolt	1	25	108364	Fitting (With 973620 O-Ring)	1
8	323-26	Bolt	1	26	79-5020	Tube Assembly	1
9	3296-39	Nut	4	27	108365	Elbow (With 973370 O-Ring)	4
10	108329	Plate – Control	1	28	108323	Base – Oil Filter	1
11	108325	Speed Control	1	29	322-3	Bolt	2
12	3257-24	Key – Woodruff	1	30	3253-4	Washer – Lock	2
13	3296-26	Washer	1	31	281-10	Plug – NPT	1
14	3296-23	Nut	1	32	79-5270	Filter – Oil	1
15	108326	Spacer – Pivot, Long	1	33	5991	Fitting	1
16	108327	Spacer – Friction, Short	1				
17	100365	Washer – Spring Disc	2				
18	100305	Washer – Friction	2				

# HYDRAULIC PUMP AND MOTOR




# HYDRAULIC PUMP AND MOTOR

Ref. No.	Part No.	Description	No. Used
1	112635	Screw	1
2	112636	Bearing – Input	1
3	112604	Seal	2
4	112637	Housing – Pump Assembly (Incl. Ref.# 2)	1
5	112654	Ring – Retaining	2
6	112638	Ring – Seal	1
7	112639	Plate	1
8	112640	Ring – Seal	1
9	112641	Cover Assembly (Incl. Ref. #3, 6, 8,10, 11, 19, 20, 36–39, & 51)	1
10	112595	Button	2
11		Pin – Pivot	1
12	112642	Pin	1
13	112643	Shaft – Input	1
14	112644	Ring – Seal	1
15	112645	Rotor – Pump	1
16	113136	Race – Pump	1
17		Ring – Cam	1
18	113041	Piston	2
19		Ring – Back Up	2
20		"O"Ring	2
21	112608	Pin – Coil	1
22	112646	Pintle Assembly (Inc. Ref. #21, 23–29 &41–44)	1
23	112611	Ring – Retaining	2
24	112610	Ball	2
25	112647	Body – Check Valve	2
26	112648	Ball	1
27	112649	Spring – Relief Valve	1
28	112650	Plug – Relief Valve	1

Ref. No.	Part No.	Description	No. Used
29	112651	Pin	1
30	112652	Shield	1
31	112653	Ring – Retaining	1
32	112654	Ring – Retaining	2
33	112616	Screw	4
34	112656	Roller	6
35	112657	Carrier	1
36	112658	Seal	1
37	112659	Kit – Control Shaft	1
38		Washer	1
39		Dowel	1
40	112660	Insert – Cam Ring	1
41	112661	Spring – Acc. Valve	1
42	112661	Spring – Acc. Valve	1
43	112662	Body – Acc. Valve	2
44	112663	Ball	2
45	112664	Rotor – Motor	1
46	112665	Shaft – Output	1
47	113137	Race – Motor	1
48	112613	Plug – "O"Ring (incl. Ref. #49)	1
49	112614	"O"Ring	1
50	112669	Body Assembly (Incl. Ref. #51, 53 & 54)	1
51		Seal	1
52	112666	Bearing – Output	1
53	112600	Ring – Retaining	2
54	112616	Screw	2
55	112667	Kit – Seal, Overhaul (Incl. Ref.# 3, 6, 8, 14, 19, 20, 36, 49 & 51)	1
56	112668	Ring – Cam	1


# TRANSAXLE



# TRANSAXLE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-7297	Transaxle (Incl.. Ref. # 41)	1	20	101889	Gear – Differential Axle 24 Tooth	2
2	92-7298	Case – Transaxle, RH	1	21	105876	Ring – Retaining	2
3	111201	Case – Transaxle, LH	1	22	109703	Gear Assembly	1
4	111199	Bearing – Ball	2	23	101625	Gear – Pinion 11 Tooth	1
5	9416	Bearing – Needle	2	24	101626	Gear – Pinion 44 Tooth	1
6	1532	Bearing – Needle	2	25	9547	Washer – Thrust	1
7	1538	Bearing – Needle	1	26	109370	Shaft	1
8	1518	Bearing – Needle	1	27	109752	Gear 46 Tooth	1
9	6449	Axle – Seal	2	28	109742	Gear 20 Tooth	1
10	108357	Seal	1	29	937099	Key – Woodruff	1
11	108363	Pin – Dowel	2	30	7956	Washer – Thrust	1
12	111196	Cap – Differential End	2	31	108312	Gasket – Case	1
13	105061	Gear – Differential Ring 43 Tooth	1	32	109367	Bracket – Brake	1
14	101623	Gear – Differential Pinion 11 Tooth	8	33	908040	Bolt	1
15	107374	Washer – Special	4	34	323-7	Bolt	1
16	911423	Bolt	4	35	323-25	Bolt	1
17	108881	Nut	4	36	323-15	Bolt	2
18	108362	Axle – Rear, RH Long 13-1/8 in./33 cm	1	37	3296-39	Nut	3
19	108361	Axle – Rear, LH Short 10-1/8 in./26 cm	1	38	106448	Tube – Filler	1
				39	110768	Dipstick	1
				40	281-10	Plug – Pipe	2
				41	88-2790	Decal – Danger	1

# HYDROSTATIC SYSTEM




# HYDROSTATIC SYSTEM

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	78-5670	Rod - Lift Control	1			Cylinder Repair	1
2	116634	Knob - Hydraulic Lift	1	20	119340	Cylinder - Hydraulic (Incl. Ref.# 18-19)	1
3	321-3	Screw	1	21	107691	Spacer	1
4	116305	Bracket - Control Rod	1	22	1278	Washer - Shim	1
5	3296-29	Nut	1	23	110124	Hose - Valve To Cylinder 14"	1
7	104841	Spring	1	24	86-9290	Tube - Hydraulic (Return)	1
8	321-10	Washer	1	25	108365	Fitting - 90° (Incl. Ref.# 13)	2
9	3296-42	Nut	1	27	321-11	Bolt	2
10	973310	O-Ring	2	28	114000	Valve - Hydraulic (Incl. Ref.# 30-31)	1
11	110125	Hose - Valve To Cylinder 9"	1	*	109081	Kit - Valve Assembly Repair	1
12	102628	Fitting - Straight (Incl. Ref.# 13)	2	29	3296-42	Nut	2
13	973370	O-Ring	4	30	932120	Pin - Clevis	1
14	106267	Grommet - Rubber (Pressure)	1	31	932000	Pin - Cotter	2
15	86-9280	Tube - Hydraulic	1	32	78-5640	Bar - Lift	1
16	3272-11	Pin - Cotter	1	33	933198	Pin - Spirol	1
17	932997	Pin - Clevis	1	34	116302	Arm - Control	1
18	101699	Kit - Service Assembly Cylinder Repair	1	*	100571	Tie - Cable	1
19	109088	Kit - Service Assembly					

\*Not Illustrated

# CLUTCH, BRAKE MOTION CONTROL LINKAGE




# CLUTCH, BRAKE MOTION CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
1	78-5660	Lever - Motion Control	1
2	116635	Knob - Motion Control	1
6	5983	Bushing	2
7	5701	Ring - Retaining	2
8	100304	Spacer	2
10	116407	Rod End	2
11	108904	Rod Control 9" Long	1
13	108496	Rod - Pivot	1
14	926694	Bolt	1
16	100656	Bearing - Cam	1
17	5701	Ring - Retaining	4
20	78-8500	Lever - Parking Brake	1
21	118860	Knob - Parking Brake Lever	1
22	323-9	Bolt	1
23	102025	Spacer	1
24	102809	Nut - Special, Flanged	1
25	1230	Spring	1
26	108716	Plate - Cam	1
27	323-8	Bolt	1
28	3256-4	Washer	2
30	108717	Spacer	1
36	108473	Washer - Wave	2
37	107938	Spring	1
38	321-6	Bolt	1
39	32146-17	Nut	4
40	106368	Rod - Pivot	1
42		Pin - Cotter	1
43	112426	Pulley - Idler	1
45	106193	Bolt - Special	1
50	3256-26	Washer	1
51	7879	Bushing	1
52	3256-24	Washer	1

Ref. No.	Part No.	Description	No. Used
53	911458	Bolt	2
54	3256-22	Washer	2
55	3220-1	Nut	3
57	113454	Control - Cam	1
58	3296-39	Nut	2
59	933135	Pin - Spirol	1
60	118660	Guide - Control	1
61	78-5631	Bracket - Control	1
62	78-1540	Bracket - Control, Lower	1
63	101853	Spring	1
64	116321	Arm - Control	1
65	32312-94	Pin - Spirol	1
66	3296-42	Nut	2
67	321-4	Bolt	2
68	933198	Pin - Spirol	1
69	3296-29	Nut	2
70	322-3	Bolt	2
71	3296-4	Nut	1
72	3296-29	Nut	1
73	322-2	Bolt	1
74	116324	Rod Assembly	1
75	106369	Shaft	1
76	3256-26	Washer	4
77	3255-7	Washer - Lock	1
78	3218-1	Nut	1
79	110769	Spring	1
80	106450	Spacer	1
81	8722	Knob	1
82	8693	Knob	1
83	911747	Screw	1
84	110780	Handle	1

# CLUTCH, BRAKE AND SPEED CONTROL LINKAGE




# CLUTCH, BRAKE AND SPEED CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
1	79-1350	Pedal - Brake/Return To Neutral	1
2	6254	Bushing	2
3	1085	Collar	1
4	3245-32	Screw - Set	1
5	107691	Spacer	1
6	103125	Spring - Brake Return	1
7	109372	Rod - Brake, Front	1
8	3272-11	Pin - Cotter	2
9	3296-39	Nut	1
10	3256-24	Washer	2
11	108680	Spring	1
13	106719	Drum - Brake	1

Ref. No.	Part No.	Description	No. Used
14	2844	Special Washer	1
15	323-23	Bolt	1
16	3235-22	Bolt	1
17	109371	Band - Brake	1
18	109367	Arm - Brake Pivot	1
19	109356	Bushing	1
20	323-9	Bolt	1
21	3296-39	Nut	1
22	3256-4	Washer	1
23	3256-6	Washer	2
24	3272-6	Pin - Cotter	2
25	1278	Washer - Shim	1
26	1030	Fitting - Grease	1

# HYDROSTATIC LIFT LINKAGE




# HYDROSTATIC LIFT LINKAGE

Ref. No.	Part No.	Description	No. Used
1	121100	Lever – Lift	1
2	933507	Pin – Cotter	2
3	3256-30	Washer	3
4	106269	Bushing	2
5	106414	Retainer	2
6	1121	Key – Sq.	1
7	78-1550	Bellcrank	1
8	6739	Trunnion	1
9	933505	Pin – Cotter	1
10	106522	Chain – Lift	1
11	322-5	Bolt	1
12	3256-23	Washer	1

Ref. No.	Part No.	Description	No. Used
13	3296-29	Nut	1
14	113445	Bar – Lift	1
15	6229	Bearing	1
16	5701	Ring – Retaining	1
17	108903	Tube – Clamp	1
18	3235-22	Bolt	2
19	108315	Tube – Rear Lift Cable	1
20	8830	Clamp	1
21	933505	Pin – Cotter	1
22	3256-26	Washer	1
23	3296-39	Nut	1

# FRONT AXLE AND STEERING




# FRONT AXLE AND STEERING

Ref. No.	Part No.	Description	No. Used
1	5638	Axle - Front	1
2	302-5	Fitting - Grease	2
3	1481	Fitting - Grease, 45°	2
4	6216	Pin & Plate	1
5	322-1	Bolt	1
6	3253-4	Washer - Lock	1
7	113381	Spindle - Front, LH	1
*	113382	Spindle - Front, RH	1
8	5618	Ring - Retaining	1
10	78-2900	Tie Rod Assembly (Incl. Ref. # 38 & 39)	2
11	9156934	Nut	4
12	6472	Bearing - Flanged	1
13	323-6	Bolt	2
14	3296-39	Nut - Lock	4
15	78-2880	Shaft	1
16	5210	Washer - Shim	6
17	1278	Washer - Shim	3
18	3272-19	Pin - Cotter	1

Ref. No.	Part No.	Description	No. Used
19	88-2710	Support - Steering	1
20	323-9	Bolt	2
23	6397	Bearing	1
24	109189	Bearing	1
25	92-4987	Steering Shaft Assembly	1
28	113443	Tube - Steering	1
29	7896	Washer - Bowed	1
30	76-1420	Steering Wheel (Incl. Ref. #40)	1
31	32121-111	Pin - Spirol	1
32	109262	Washer - Special	2
34	32120-93	Ring - Retaining	2
37	32136-5	Nut - Slotted	1
38	78-2920	Joint - Ball	1
39	915002	Nut	1
40	78-0370	Insert	1
41	237-69	"O" Ring	1
42	3272-21	Pin - Cotter	1

\*Not Illustrated

# HITCHES




# HITCHES

Ref. No.	Part No.	Description	No. Used
1	101711	Housing – Front Hitch	1
2	105859	Latch – Front Hitch	1
3	101750	Rod	1
4	101751	Rod – Front Hitch Lock	1
5	105797	Ring – Retaining	8
6	101707	Lock	1
7	8616	Spring	2
8	105316	Cap – Lock Rod	2
9	1644	Hitch – Drawbar	1
10	105269	Shaft–Drawbar Hitch	1
11	9791204	Spacer	2

Ref. No.	Part No.	Description	No. Used
12	5618	Ring – Retaining	2
13	106634	Pin – Hitch	1
14	933505	Pin – Cotter	1
15	102644	Plate – Mid Hitch	2
16	117940	Rod – Mid Hitch Lock	1
17	117930	Latch – Mid Hitch	1
18	83-6520	Rod – Lock	1
19	3251-25	Bolt	3
20	3296-39	Nut	5
21	323-7	Bolt	2
22	9038	Grip	1

# HOOD ASSEMBLY




# HOOD ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	88-2782	Hood (Incl. Ref. # 27)	1	14	32146-17	Nut	4
2	117344	Handle Assembly (Incl. Ref. #25)	2	16	117431	Rivet - Pop	4
3	117432	Rivet - Pop	4	17	120590	Stop - Throttle	1
4	78-5610	Console	1	18	112506	Bracket	1
5	9266944	Bolt - Washer Hd	3	19	9201504	Washer - Lock	2
6	105797	Ring - Retaining	2	20	9107622	Screw	2
7	116745	Rod - Pivot	1	21	112415	Stop - PTO	1
8	101850	Rod - Hood Stop	1	22	111757	Edging - Console	1
9	9320004	Pin - Cotter	2	23	111392	J-Clip	1
10	116746	Bracket - RH	1	24	9159604	Nut	2
11	116747	Bracket - LH	1	25	117343	Latch - Hood	2
12	3229-25	Bolt - Carriage	4	26	5979	Bushing - Hood Pivot	2
13	3256-22	Washer	4	27	88-0020	Decal - Danger	1
				28	9107922	Screw	2
				29	9157404	Nut - Lock	2

\*Not Illustrated

# HOOD STAND AND SUPPORTS




# HOOD STAND AND SUPPORTS

Ref. No.	Part No.	Description	No. Used
1	79-4900	Hoodstand	1
3	106261	Bracket - Belt	1
4	9266944	Bolt	1
5	78-3000	Bracket - Battery Support	1
6	117371	Bolt - Carriage	4
7	9151126	Nut	4
9	78-3020	Plate - Front	1
10	9266944	Bolt	1
11	106772	Trim - Edge 4"	1
12	9266944	Bolt	4
*	926696	Bolt	2
13	79-5130	Cover - Side, LH	1
14	9108372	Screw	6

Ref. No.	Part No.	Description	No. Used
15	107069	Nut - Speed	6
16	106250	Cover - Dust	1
17	9266944	Bolt	4
18	104248	Grommet	1
19	92-7296	Plate - Shift Cover (Incl. Ref.#27)	1
20	78-5620	Plate - Hood Stand	1
23	110142	Trim - Edge	1
24	9108372	Screw	1
25	106454	Trim - Edge	1
26	3023	Clip	1
27	79-0370	Decal - Danger	1

\*Not Illustrated


# FENDER AND SUPPORTS



# FENDER AND SUPPORTS

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	107975	Guard – Belt	1	18	79-4990	Bracket – Fender Support	1
2	9108372	Screw	2	19	108464	Support – Fuel Tank, LH	1
3	116000	Bolt – Carriage	1	20	106236	Support – Fuel Tank, RH	1
4	9266944	Bolt	1	21	322-3	Bolt	4
5	106352	Guard – Lower Belt	1	22	110960	Fender	1
6	106222	Footrest – RH	1	23	9266944	Bolt	4
7	106223	Footrest – LH	1	24	920008	Washer	4
8	107069	Clip	3	30	3296-29	Nut	6
9	116000	Bolt – Carriage	6	31	111071	Bumper	2
10	3296-29	Nut	7	32	108457	Nut – Push	1
11	7456	Clamp	4	33	118620	Bolt – Carriage	2
13	110636	Pad – Footrest	2	34	9107944	Screw – Machine	2
14	107951	Bracket – Fender Front	1	35	9157404	Nut	4
15	322-3	Bolt	2	36	117331	Holder – Fuse	1
16	3256-23	Washer	2	37	321-4	Bolt	2
17	109554	Bracket – Belt Guard	1	38	3296-42	Nut	1


\*Not Illustrated



C-1481

### ENGINE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1		Engine - 14HP	1	4	323-6	Bolt	2
2	323-8	Bolt	2	5	3253-21	Washer - Lock	1
3	3296-39	Nut	2				




C-1482

## AIR INTAKE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	KH10576	Nut – Wing	1	7	KH10034	Seal	1
2	KH10299	Cover	1	8	KH10609	Screw	3
3	KH10189	Nut	1	9	KH10297	Base – Air Cleaner	1
4	KH10412	Cover – Air Cleaner Element	1	10	KH10697	Gasket	1
5	KH10235	Element – Precleaner	1	11	KH10625	Screw	1
6	KH10236	Element	1	*	KH10191	Decal – Air Cleaner	1

\*Not Illustrated




C-1483

## CARBURETORS

Ref. No.	Part No.	Description	No. Used
1	92-7252	Carburetor Assembly (Incl. Ref. #2-24)	1
2	KH10110	Screw	4
3	92-7255	Plate - Choke	1
4	KH10128	Ball	1
5	KH10113	Spring	1
7	92-7256	Shaft w/Lever & Seal	1
8	92-7257	Plate - Throttle	1
9	KH10132	Needle - Idle Fuel Adj.	1
10	KH10112	Spring - Idle Fuel	1
13	KH10114	Spring - Adj.	1
14	KH10109	Screw - Idle Speed Adj.	1
15	KH10702	Shaft - Choke	1
16	KH10694	Main - Needle	1
17	KH10094	Gasket	1
18	KH10663	Kit - Float (Incl. Pin)	1
19	KH10117	Bowl - Fuel	1
20	KH10093	Gasket	1
21	KH10116	Screw	1
22	KH10123	Connector 90°	1
23	KH10274	Gasket - Carburetor	1
24	KH10146	Gasket - Carburetor	1
*	KH10696	Kit - Carburetor Repair (Includes	
	KH10009	Gasket - Flange	
	KH10146	Gasket - Carburetor	

Ref. No.	Part No.	Description	No. Used
	KH10733	Gasket	
	KH10093	Gasket - Bowl Screen	
	KH10094	Gasket - Bowl	
	KH10677	Gasket - Air Cleaner	
	KH10697	Gasket	
	KH10274	Gasket - Carburetor	
*	KH10358	Kit - Choke & Throttle Repair	1
*	KH10710	Kit - High Altitude Jet (Includes	
	KH10682	Bushing	
	KH10709	Jet - Main	
*	92-7251	Kit - Carburetor w/Linkage (Includes	1
	KH10682	Bushing &	
	KH10709	Main Jet	
*	KH10693	Kit - Adjustable Jet w/Linkage (Includes	1
	KH10701	Carburetor Linkage	
	KH10682	Bushing - Linkage Natural	
	KH10686	Bushing Linkage Black	
	KH10697	Gasket - Air Cleaner	
	KH10693	Carburetor Assembly	
	KH10146	Gasket	
	KH10274	Gasket	1


\*Not Illustrated



C-1565

## GOVERNOR LINKAGE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	KH10660	Kit – Governor Gear (Incl. Ref.# 24)	1	35	KH10570	Washer	1
3	KH10035	Pin – Governor Stop	1	37	KH10600	Screw	1
8	KH10629	Nut – Pal	1	38	KH10599	Washer – Lock	1
22	KH10070	Bushing	1	39	KH10569	Washer	1
23	KH10585	Spacer	1	40	KH10624	Nut	1
24	KH10087	Washer	1	41	KH10152	Washer	2
25	KH10136	Washer	1	42	KH10293	Lever – Choke Control	1
26	92-7262	Kit – Governor Cross Shaft	1	43	KH10294	Lever – Throttle Control	1
27	KH10295	Lever – Governor	1	44	KH10302	Space	1
28	KH10626	Screw	1	45	KH10605	Screw	1
29	92-7254	Bushing	1	46	KH10695	Washer	1
30	KH10701	Linkage (Governor to Carb.)	1	47	KH10040	Screw	1
31	KH10296	Spring (Governor to Carb.)	1	48	KH10303	Bracket – Clutch Control	1
32	KH10287	Linkage – Choke (Carb. to Choke Shaft)	1	49	KH10308	Clamp	1
33	92-7253	Bushing	1	50	KH10619	Nut	1
34	KH10545	Screw	1	*	92-7263	Choke Lever Assembly (Incl. Ref. #37 thru 44)	1




C-1494

## FUEL SYSTEM

Ref. No.	Part No.	Description	No. Used
17	106234	Tank - Fuel	1
18	55-3570	Cap - Fuel	1
20	926697	Bolt	2
21	3256-4	Washer	2
22	322-2	Bolt	3
23	3253-4	Washer - Lock	1
24	104047	Bushing	1
25	104048	Valve - Fuel Shut-Off	1
26	103787	Line - Fuel 62"	1
27	108898	Clamp	2

Ref. No.	Part No.	Description	No. Used
28	950154	Clamp 1/2" (1.3 cm) Dia.	2
29	KH10319	Pump Assy - Fuel (Incl. Ref.#30 & 31)	1
30	92-7261	Gasket - Fuel Pump	1
31	KH10569	Washer	2
32	KH10552	Screw - Pozidrive	2
33	KH10586	Clamp	2
34	92-7250	Line - Fuel 5" Lg	1
35	KH10123	Connector - 90°	2




C-1559

### BAFFLES AND SHROUDS

Ref. No.	Part No.	Description	No. Used
1	KH10413	Screw - Hex .Hd.	6
2	KH10279	Baffle - Side Air	1
3	KH10231	Baffle - Head	1
4	KH10567	Washer	1
5	KH10289	Screw - Pozidrive T.H.	3

Ref. No.	Part No.	Description	No. Used
6	KH10282	Baffle - Cylinder	1
7	KH10280	Baffle - Inner	1
8	KH10265	Housing - Blower	1
9	92-7281	Decal - HP	1

\*Not Illustrated




C-1485

### BREATHER AND VENT

Ref. No.	Part No.	Description	No. Used
1	KH10058	Gasket	1
2	KH10072	Plate	1
3	KH10057	Reed	1
4	KH10143	Baffle	1
5	KH10275	Filter	1
6	KH10034	Seal	1

Ref. No.	Part No.	Description	No. Used
7	KH10149	Gasket	1
8	KH10298	Cover	1
9	KH10150	Stud	1
10	KH10629	Palnut	1
11	KH10309	Hose	1




C-1561

## CRANKCASE AND CYLINDER HEAD

Ref. No.	Part No.	Description	No. Used
1	92-7279	Short Block (Includes Crankshaft)	1
	92-7280	Miniblock (w/Out Crankshaft)	1
2	92-7258	Shaft - Governor Gear	1
3	KH10067	Ball Bearing	2
4	KH10269	Seal	1
5	KH10562	Plug	1
6	92-7259	Guide - Valve	2
7	KH10029	Insert - Exhaust Valve	1
8	KH10049	Bearing	1
9	KH10272	Gasket	1
10	KH10311	Gasket	1
11	KH10687	Plate - Bearing	1
12	KH10268	Seal	1

Ref. No.	Part No.	Description	No. Used
13	KH10549	Screw	4
14	KH10545	Screw	4
15	KH10661	Cover	1
16	KH10055	Gasket	1
18	KH10081	Shaft - Balance Gear	1
19	KH10261	Head - Cylinder	1
20	KH10700	Gasket	1
21	KH10145	Washer	9
22	KH10144	Screw	8
23	KH10312	Strap - Lifting	1
24	KH10290	Screw	1
*	KH10325	Set - Gasket w/ Seals	1
*	KH10258	Set - Gasket w/o Seals	1




C-1560

## CAMSHAFT, CRANKSHAFT AND VALVES

Ref. No.	Part No.	Description	No. Used
1	KH10259	Camshaft Assy (Incl. Ref.# 2)	1
2	KH10292	Spring	1
3	KH10147	Spacer .005	1
*	KH10148	Spacer .010	1
4	KH10310	Pin - Camshaft	1
5	KH10090	Valve - Exhaust	1
6	KH10071	Valve - Intake	1
7	KH10054	Retainer - Upper Spring	2
10	KH10221	Kit - Retainer	2
11	KH10539	Tappet - Intake Valve	2

Ref. No.	Part No.	Description	No. Used
13	KH10496	Rotator - Valve	2
14	KH10062	Spring	2
15	KH10617	Plug - Cup	1
16	KH10245	Kit - Crankshaft (Includes Flywheel Hdwr.)	1
19	KH10322	Kit - Spacer (Incl. Ref.#20)	2
20	KH10574	Retainer	1
21	KH10228	Gear Assembly (Incl. Ref. #22)	2
22	KH10267	Bearing - Needle	2




C-1563

### PISTON AND RINGS

Ref. No.	Part No.	Description	No. Used
1	92-7273	Set - Ring, Std. & .003	1
*	92-7274	Set - Ring .010	1
*	92-7275	Set - Ring .020	1
*	92-7276	Set - Ring .030	1
2	92-7268	Piston w/Ring Set Std.	1
*	92-7269	Piston w/Ring Set .003	1

Ref. No.	Part No.	Description	No. Used
*	92-7270	Piston w/Ring Set .010	1
*	92-7271	Piston w/Ring Set .020	1
*	92-7272	Piston w/Ring Set .030	1
3	KH10262	Retainer - Piston Pin	2
4	92-7267	Rod - Connecting Std.	1
*	KH10695	Rod - Connecting .010	1




C-1562

## OIL PAN AND DIPSTICK

Ref. No.	Part No.	Description	No. Used
1	KH10270	Dipstick	1
2	KH10201	"O"Ring	1
4	KH10266	Adapter - Oil Fill	1
5	KH10541	Screw	3
6	KH10088	Gasket	1
7	KH10248	Pan - Oil	1
8	KH10059	Gasket	1
9	KH10550	Screw	4

Ref. No.	Part No.	Description	No. Used
10	KH10620	Plug	4
11	92-7278	Kit - Float Switch (Incl. Ref.#12 & Decal)	1
12	KH10134	Sleeve	1
13	KH10345	Connector - Female (5-Contact)	1
*	KH10119	Decal - Float Switch	1




C-1490

## STARTER

Ref. No.	Part No.	Description	No. Used
1	92-7260	Starter Assembly (Incl. Ref. # 9-12)	1
2	KH10244	Brace - Starter Tail	1
3	KH10610	Screw - Hex. Hd.	1
4	KH10607	Screw - Hex. Hd.	1
5	KH10304	Bracket - Starter	1
6	KH10549	Screw	2
7	KH10181	Bolt	2

Ref. No.	Part No.	Description	No. Used
8	KH10210	End Cap Ass'y (Incl. Ref.#9)	1
9	KH10515	Kit - Brush	1
10	KH10247	Armature	1
11	KH10209	Cap - Drive End	1
12	KH10323	Kit - Drive (Incl. Ref. #15)	1
13	KH10324	Kit - Drive Parts	1
*	KH10135	Tag - Caution	1
*	KH10549	Screw	1




C-1564

### FLYWHEEL

Ref. No.	Part No.	Description	No. Used
1	KH10263	Flywheel	1
2	KH10588	Key - Woodruff	1
3	KH10188	Spacer	4
4	KH10124	Fan	1

Ref. No.	Part No.	Description	No. Used
5	KH10107	Screw - Hex. Hd.	4
6	KH10126	Screen	1
7	KH10108	Screw	1
8	KH10666	Washer	1




C-1493

### IGNITION SYSTEM

Ref. No.	Part No.	Description	No. Used
1	KH10321	Module – Ignition	1
2	KH10570	Washer – Flat	1
3	KH10610	Screw	1
4	KH10606	Screw – Hex. Hd.	1
5	KH10618	Clip	1
8	92-7264	Clip	1
9	KH10091	Kit – Stator 15 am (Incl. Ref.#8)	1
10	KH10605	Screw – Pozidrive	4
11	KH10345	Connector	1
12	KH10344	Clip	1

Ref. No.	Part No.	Description	No. Used
13	KH10545	Screw	1
14	KH10673	Regulator – Rectifier	2
15	92-7266	Screw	2
16	KH10082	Connector	1
17	92-7265	Plug – Spark	1
18	KH10010	Clip – Hi-Tension	1
*	KH10313	Lead – Violet, Regulator Rectifier to Connector	1
*	KH10315	Lead – Wire, Module to Connector	1




C-1495

## THROTTLE CHOKE AND EXHAUST

Ref. No.	Part No.	Description	No. Used
1	115854	Control - Throttle	1
2	116454	Knob - Throttle Control	1
3	112214	Choke Control	1
4	109530	Nut - Pal	1
5	910792	Screw	2
6	9157404	Nut	2
7	112213	Muffler	1
8	106858	Clamp	1
9	6876	Spacer	1

Ref. No.	Part No.	Description	No. Used
10	KH10344	Clamp - Cable	1
11	KH10610	Screw - Hex. Hd.	1
12	322-6	Bolt	1
13	3253-4	Washer	1
14	3256-66	Washer	1
15	KH10535	Nut - Lock	1
16	KH10278	Elbow	1
17	KH10570	Washer	1




C-1497

## ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	116796	Test Switch (Incl. Ref. #2-4)	1
2	117217	Button - Switch	1
3	111767	Washer	1
4	111359	Nut - Hex	1
5	9157324	Nut - Lock	2


Ref. No.	Part No.	Description	No. Used
6	112506	Bracket	1
7	116723	Harness - Wiring	1
8	9107562	Screw	2
9	111343	Bushing Assembly & Indicator Lens	5
10	114825	PC Board w/Lights	1

# ELECTRICAL SYSTEM



# ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	116338	Switch – Ignition (Incl. Ref.# 6,7,9,17,44 & 64-66)	1	30	321-4	Bolt	2
2	920160	Washer – Lock	1	31	3256-22	Washer	4
3	101884	Nut – Special	1	32	116497	Nut	4
4	62-7770	Key – Ignition, Padded	1	33	105842	Battery	1
5	78-7020	Harness Assy – Wiring	1	34	106948	Tray – Battery	1
6	104926	Switch – Connector Body Ignition	1		9107944	Screw	1
7	518105	Terminal	1		32146-7	Nut	2
8	115230	Switch – Clutch Interlock, (Incl. Ref # 16)	1	37	113969	Hook – Battery Hold Down	2
9	120930	Body – Fuse, Part of 5	1	38	113010	Hold Down – Battery	1
12	109355	Fuse 15 Amp ATO or ATC	1	39	114720	Tube – Drain	1
	109102	Fuse 25 Amp ATO or ATC	1	40	109910	Cable – Ground	1
	NN10277	Fuse 30 Amp ATO or ATC	1	41	100571	Tie – Cable	1
13	111642	Barrier – Switch Insulator	2	42	3254-2	Washer – Lock	1
14	38-1420	Switch – Seat	1	44	102651	Terminal – Female	8
16	110502	Shield – Dirt	1	45	3253-3	Washer – Lock	4
17	112185	Body – Connector	1	48	920262	Washer – Special	1
18	115411	Support – Switch	1	49	3253-3	Washer – Lock	2
19	926671	Bolt	1	50	3218-1	Nut	2
20	111332	Switch – PTO Interlock	2	51	78-0020	Meter – Hour (Incl. Ref.# 52-54)	1
21	79-0060	Voltmeter	1	52	114017	Clamp – Steel	1
22	78-0080	Clamp – Voltmeter, Back	1	53	920120	Washer – Lock	1
23	5924	Nut	2	54	915962	Nut – Hex	1
24	47-1910	Solenoid	1	55	8830	Clip	1
25	960152	Bolt – Whizlock	2	59	910478	Screw	2
26	111069	Cable – Solenoid To Starter	1	60	915732	Nut	2
27	111074	Cable – Battery, Positive	1	62	116397	Relay	1
28	109553	Cover – Terminal	1	63	519337	Clip – Cable	1
29	111069	Cable – Battery, Negative	1	64	518105	Terminal	1
				65	6921	Terminal	1
				68	518077	Terminal	2




C-1498

## ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	102881	Headlight	2	15	3269-3	Rivet - Pop	4
2	108130	Wire - Headlight Ground	1	16	910808	Screw	4
3	3256-23	Washer	1	17	112564	Lens - Taillight	2
4	3254-2	Washer - Lock	1	18	8043	Bulb - Light, Metal Base	2
5	3296-29	Nut	1	*	109045	Bulb - Light, All Glass	2
6	518104	Terminal	1	19	915551	Nut	4
7	920259	Washer - Special	1	20	926671	Bolt	2
8	102950	Ring - Retaining	1	21	109459	Clamp	2
9	113179	Nut	1	22	8519	Clip - Large	1
10	102138	Switch - Light	1	23	100571	Tie - Cable	1
11	3023	Clip - Small	1	24	8830	Clip	1
12	3256-17	Washer	4	25	109495	Retainer - Headlight LH	1
13	3254-1	Washer - Lock	4	26	109494	Retainer - Headlight RH	1
14	105202	Base - Taillight, w/Bulb	2				

\*Not Illustrated




C-1499

### WHEELS AND TIRES

Ref. No.	Part No.	Description	No. Used
1	114428	Logo - Hub Cap 12"	2
2	7007	Tube - Rear (Opt.)	2
*	100291	Tube - Cleat Tires" (Opt.)	2
3	116744	Tire - Turf Trac, Rear	2
4	7607	Tire - Cleat, Rear" (Opt.)	2
5	83-2720	Bolt - Lug	10
6	111516	Wheel - Rear	2
7	5108	Stem - Valve	4
8	937108	Key - Woodruff	2
9	3243-5	Screw - Set	4
10	3218-3	Nut	4
11	105763	Hub - Rear	2

Ref. No.	Part No.	Description	No. Used
12	109500	Fitting - Grease	2
14	5210	Washer - Shim .015	2
15	1278	Washer - Shim .050	4
16	110513	Bearing - Ball	4
17	78-1660	Wheel Assembly - Front (Incl. Ref.# 7, 12, & 16)	2
18	111952	Washer - Special Hub Cap	2
19	3272-17	Pin - Cotter	2
20	111951	Hubcap	2
21	117127	Tire - Turf Trac, Front	2
22	100079	Tube - Front (Opt.)	2
23	114427	Logo - Hub Cap 8" (Opt.)	2

\*Not Illustrated




C-1500

## PTO CLUTCH AND CONTROL

Ref. No.	Part No.	Description	No. Used
1	111234	Lever - PTO Clutch	1
2	9038	Grip	1
3	106649	Ring - Grip	1
4	3765	Washer - Shim	2
5	5666	Bushing - Nyliner	1
6	5983	Bushing	1
7	3272-10	Pin - Cotter	1
11	111052	Rod - PTO Clutch	1
12	3272-10	Pin - Cotter	2
13	103125	Spring	1
14	110656	Trunnion	1
16	323-7	Bolt	1
17	110669	Plate - PTO	1
18	104859	Spacer	1
19	3296-39	Nut	1
20	933505	Pin - Cotter	1
21	3218-1	Nut	2
22	3256-22	Washer	2
23	110665	Brake Assembly - PTO	1
24	3229-25	Bolt - Carriage	2

Ref. No.	Part No.	Description	No. Used
25	111241	Bracket - Engine	1
28	111314	Pin - Locking	1
29	113107	Clevis	1
30	933274	Pin - Spirol	1
31	113108	Rod - PTO Housing	1
32	933506	Pin - Cotter	1
33	102872	Shaft - Stub	1
34	32120-72	Ring - Snap	2
35	936032	Ring - Snap	1
36	109842	Bearing - Ball	1
37	103478	Housing - Pulley	1
38	106769	Bearing - Needle	1
39	6663	Seal	1
40	6658	Race - Bearing	1
41	321-3	Bolt - Nylok	4
42	6659	Retainer	2
43	114881	Facing - Clutch Plate	1
45	106695	Push-On Ring	1
47	3253-3	Washer - Lock	1
48	3256-27	Washer	1




C-1501

## SEAT

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	110920	Spring - Seat	2	11	114344	Spacer	2
2	3253-4	Washer - Lock	12	12	3256-22	Washer	2
3	3296-29	Nut	6	13	321-8	Bolt	2
4	79-0670	Seat	1	14	114345	Bracket	1
5	913464	Bolt	4	15	3296-42	Nut	2
6	3256-23	Washer	8	16	114343	Spring - Gas	1
7	3296-29	Nut	2	17	111071	Bumper	2
8	322-5	Bolt	4	18	322-4	Bolt	6
9	105524	Bracket - Pivot	2	19	105503	Bushing	2
10	78-2990	Plate - Seat Pivot	1	20	109989	Spacer	4

\*Not Illustrated



C-1502

## DECALS

Ref. No.	Part No.	Description	No. Used
1	79-4460	Decal - Hood RH	1
	79-4450	Decal - Hood LH	1
2	111510	Decal - Parking Brake	1
3	111960	Decal - PTO Clutch	1
4	117760	Decal - Rear Fender	1
5	117509	Decal - Front Hood	1
6	116446	Decal - Do Not Toe	1
7	116445	Decal - Parking Brake	1
8	88-0020	Decal - Rear Hood Danger	1
9	119190	Decal - Lower Dash	1
10	119220	Decal - Switch Plate	1
11	117488	Decal - 314-Hydro	2

Ref. No.	Part No.	Description	No. Used
12	111926	Decal - Electrical System	1
13	104955	Decal - Unidrive	1
14	115197	Decal - Attach-A-Matic	1
15	112168	Decal - Lift	1
16	111534	Decal - Hi-Low Shift	1
17	88-2790	Decal - Danger	1
18	117242	Decal - Made in U.S.A.	1
19	KH10191	Decal - Air Cleaner/Lub	1
20	79-0370	Decal - Danger	1
21	88-3200	Decal - Maintenance	1
*	92-1534	Loose Parts Package	1

# TORO PART NUMBER INDEX

3316-140A

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
	Engine - 14HP	28 1 1	9038	Grip	48 2 1
1030	Fitting - Grease	15 26 1	9038	Grip	21 22 1
1085	Collar	15 3 1	9416	Bearing - Needle	9 5 2
1121	Key - Sq.	17 6 1	9547	Washer - Thrust	9 25 1
1230	Spring	13 25 1	100079	Tube - Front (Opt.)	47 22 2
1278	Washer - Shim	19 17 3	100291	Tube - Cleat Tires (Opt.)	47 * 2
1278	Washer - Shim	11 22 1	100304	Spacer	13 8 2
1278	Washer - Shim	15 25 1	100305	Washer - Friction	5 18 2
1278	Washer - Shim .050	47 15 4	100309	Spacer	5 20 1
1481	Fitting - Grease, 45°	19 3 2	100365	Washer - Spring Disc	5 17 2
1518	Bearing - Needle	9 8 1	100571	Tie - Cable	11 * 1
1532	Bearing - Needle	9 6 2	100571	Tie - Cable	46 23 1
1538	Bearing - Needle	9 7 1	100571	Tie - Cable	45 41 1
1644	Hitch - Drawbar	21 9 1	100656	Bearing - Cam	13 16 1
2844	Special Washer	15 14 1	101623	Gear - Differential Pinion	9 14 8
3023	Clip	25 26 1	101625	Gear - Pinion 11 Tooth	9 23 1
3023	Clip - Small	46 11 1	101626	Gear - Pinion 44 Tooth	9 24 1
3765	Washer - Shim	48 4 2	101699	Kit - Service Assembly	11 18 1
5108	Stem - Valve	47 7 4	101707	Lock	21 6 1
5210	Washer - Shim	19 16 6	101711	Housing - Front Hitch	21 1 1
5210	Washer - Shim .015	47 14 2	101750	Rod	21 3 1
5618	Ring - Retaining	19 8 1	101751	Rod - Front Hitch Lock	21 4 1
5618	Ring - Retaining	21 12 2	101850	Rod - Hood Stop	23 8 1
5638	Axle - Front	19 1 1	101853	Spring	13 63 1
5666	Bushing - Nyliner	48 5 1	101884	Nut - Special	45 3 1
5701	Ring - Retaining	13 7 2	101889	Gear - Differential Axle	9 20 2
5701	Ring - Retaining	17 16 1	102025	Spacer	13 23 1
5701	Ring - Retaining	13 17 4	102138	Switch - Light	46 10 1
5924	Nut	45 23 2	102628	Fitting - Straight	11 12 2
5979	Bushing - Hood Pivot	23 26 2	102644	Plate - Mid Hitch	21 15 2
5983	Bushing	13 6 2	102651	Terminal - Female	45 44 8
5983	Bushing	48 6 1	102809	Nut - Special, Flanged	13 24 1
5991	Fitting	5 33 1	102872	Shaft - Stub	48 33 1
6216	Pin & Plate	19 4 1	102881	Headlight	46 1 2
6229	Bearing	17 15 1	102950	Ring - Retaining	46 8 1
6254	Bushing	15 2 2	103125	Spring	48 13 1
6397	Bearing	19 23 1	103125	Spring - Brake Return	15 6 1
6449	Axle - Seal	9 9 2	103478	Housing - Pulley	48 37 1
6472	Bearing - Flanged	19 12 1	103787	Line - Fuel 62	32 26 1
6658	Race - Bearing	48 40 1	103995	Washer - Special	3 5 1
6659	Retainer	48 42 2	104047	Bushing	32 24 1
6663	Seal	48 39 1	104048	Valve - Fuel Shut-Off	32 25 1
6739	Trunnion	17 8 1	104248	Grommet	25 18 1
6876	Spacer	42 9 1	104841	Spring	11 7 1
6921	Terminal	45 65 1	104859	Spacer	48 18 1
7007	Tube - Rear (Opt.)	47 2 2	104926	Switch - Connector Body	45 6 1
7443	Pulley - Engine Drive	3 11 1	104955	Decal - Unidrive	50 13 1
7456	Clamp	27 11 4	105061	Gear - Differential Ring	9 13 1
7607	Tire - Cleat, Rear (Opt.)	47 4 2	105202	Base - Taillight, w/Bulb	46 14 2
7879	Bushing	13 51 1	105269	Shaft - Drawbar Hitch	21 10 1
7896	Washer - Bowed	19 29 1	105316	Cap - Lock Rod	21 8 2
7956	Washer - Thrust	9 30 1	105453	Key	3 13 1
8043	Bulb - Light, Metal Base	46 18 2	105503	Bushing	49 19 2
8519	Clip - Large	46 22 1	105524	Bracket - Pivot	49 9 2
8616	Spring	21 7 2	105763	Hub - Rear	47 11 2
8693	Knob	13 82 1	105797	Ring - Retaining	21 5 8
8722	Knob	13 81 1	105797	Ring - Retaining	23 6 2
8830	Clamp	17 20 1	105842	Battery	45 33 1
8830	Clip	46 24 1	105859	Latch - Front Hitch	21 2 1
8830	Clip	45 55 1	105876	Ring - Retaining	9 21 2

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
106193	Bolt – Special	13	45	1	108680	Spring	15	11	1
106222	Footrest – RH	27	6	1	108716	Plate – Cam	13	26	1
106223	Footrest – LH	27	7	1	108717	Spacer	13	30	1
106234	Tank – Fuel	32	17	1	108881	Nut	9	17	4
106236	Support – Fuel Tank, RH	27	20	1	108881	Nut – Lock	5	21	2
106250	Cover – Dust	25	16	1	108898	Clamp	32	27	2
106261	Bracket – Belt	25	3	1	108903	Tube – Clamp	17	17	1
106267	Grommet – Rubber	11	14	1	108904	Rod Control 9 Long	13	11	1
106269	Bushing	17	4	2	109045	Bulb – Light, All Glass	46	*	2
106352	Guard – Lower Belt	27	5	1	109081	Kit – Valve Assembly	11	*	1
106368	Rod – Pivot	13	40	1	109088	Kit – Service Assembly	11	19	1
106369	Shaft	13	75	1	109102	Fuse 25 Amp ATO or ATC	45		1
106414	Retainer	17	5	2	109189	Bearing	19	24	1
106448	Tube – Filler	9	38	1	109262	Washer – Special	19	32	2
106450	Spacer	13	80	1	109355	Fuse 15 Amp ATO or ATC	45	12	1
106454	Trim – Edge	25	25	1	109356	Bushing	15	19	1
106522	Chain – Lift	17	10	1	109367	Arm – Brake Pivot	15	18	1
106634	Pin – Hitch	21	13	1	109367	Bracket – Brake	9	32	1
106649	Ring – Grip	48	3	1	109370	Shaft	9	26	1
106661	Cam – Eccentric	5	22	1	109371	Band – Brake	15	17	1
106695	Push-On Ring	48	45	1	109372	Rod – Brake, Front	15	7	1
106719	Drum – Brake	15	13	1	109459	Clamp	46	21	2
106769	Bearing – Needle	48	38	1	109494	Retainer – Headlight RH	46	26	1
106772	Trim – Edge 4	25	11	1	109495	Retainer – Headlight LH	46	25	1
106858	Clamp	42	8	1	109500	Fitting – Grease	47	12	2
106948	Tray – Battery	45	34	1	109530	Nut – Pal	42	4	1
107069	Clip	27	8	3	109553	Cover – Terminal	45	28	1
107069	Nut – Speed	25	15	6	109554	Bracket – Belt Guard	27	17	1
107374	Washer – Special	9	15	4	109703	Gear Assembly	9	22	1
107691	Spacer	15	5	1	109742	Gear 20 Tooth	9	28	1
107691	Spacer	11	21	1	109751	Gear 20 Tooth	5	2	1
107938	Spring	13	37	1	109752	Gear 46 Tooth	9	27	1
107951	Bracket – Fender Front	27	14	1	109842	Bearing – Ball	48	36	1
107975	Guard – Belt	27	1	1	109910	Cable – Ground	45	40	1
108130	Wire – Headlight Ground	46	2	1	109989	Spacer	49	20	4
108312	Gasket – Case	9	31	1	110124	Hose – Valve To	11	23	1
108315	Tube – Rear Lift Cable	17	19	1	110125	Hose – Valve To Cylinder 9	11	11	1
108316	Pulley – Transmission Drive	3	8	1	110142	Trim – Edge	25	23	1
108319	Gasket	5	5	1	110502	Shield – Dirt	45	16	1
108323	Base – Oil Filter	5	28	1	110513	Bearing – Ball	47	16	4
108325	Speed Control	5	11	1	110636	Pad – Footrest	27	13	2
108326	Spacer – Pivot, Long	5	15	1	110656	Trunnion	48	14	1
108327	Spacer – Friction, Short	5	16	1	110665	Brake Assembly – PTO	48	23	1
108329	Plate – Control	5	10	1	110669	Plate – PTO	48	17	1
108333	Cam – Speed Control	5	19	1	110768	Dipstick	9	39	1
108357	Seal	9	10	1	110769	Spring	13	79	1
108361	Axle – Rear, LH Short	9	19	1	110780	Handle	13	84	1
108362	Axle – Rear, RH Long	9	18	1	110920	Spring – Seat	49	1	2
108363	Pin – Dowel	9	11	2	110960	Fender	27	22	1
108364	Fitting	5	25	1	111052	Rod – PTO Clutch	48	11	1
108365	Elbow	5	27	4	111069	Cable – Battery, Negative	45	29	1
108365	Fitting – 90°	11	25	2	111069	Cable – Solenoid To Starter	45	26	1
108366	Spacer – Drive Gear	5	3	1	111071	Bumper	49	17	2
108368	Pump & Motor	5	1	1	111071	Bumper	27	31	2
108393	Fan	3	6	1	111074	Cable – Battery, Positive	45	27	1
108457	Nut – Push	27	32	1	111196	Cap – Differential End	9	12	2
108464	Support – Fuel Tank, LH	27	19	1	111199	Bearing – Ball	9	4	2
108473	Washer – Wave	13	36	2	111201	Case – Transaxle, LH	9	3	1
108496	Rod – Pivot	13	13	1	111217	Tube – Suction	5	24	1
108501	Belt – Drive	3	10	1	111234	Lever – PTO Clutch	48	1	1

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
111241	Bracket – Engine	48	25	1	112659	Kit – Control Shaft	7	37	1
111242	Guide – Belt, Bottom	3	14	1	112660	Insert – Cam Ring	7	40	1
111314	Pin – Locking	48	28	1	112661	Spring – Acc. Valve	7	41	1
111332	Switch – PTO Interlock	45	20	2	112661	Spring – Acc. Valve	7	42	1
111343	Bushing Assembly	43	9	5	112662	Body – Acc. Valve	7	43	2
111359	Nut – Hex	43	4	1	112663	Ball	7	44	2
111392	J-Clip	23	23	1	112664	Rotor – Motor	7	45	1
111510	Decal – Parking Brake	50	2	1	112665	Shaft – Output	7	46	1
111516	Wheel – Rear	47	6	2	112666	Bearing – Output	7	52	1
111534	Decal – Hi-Low Shift	50	16	1	112667	Kit – Seal, Overhaul	7	55	1
111642	Barrier – Switch Insulator	45	13	2	112668	Ring – Cam	7	56	1
111757	Edging – Console	23	22	1	112669	Body Assembly	7	50	1
111767	Washer	43	3	1	112841	Cap	3	15	1
111926	Decal – Electrical System	50	12	1	113010	Hold Down – Battery	45	38	1
111951	Hubcap	47	20	2	113041	Piston	7	18	2
111952	Washer – Special Hub Cap	47	18	2	113107	Clevis	48	29	1
111960	Decal – PTO Clutch	50	3	1	113108	Rod – PTO Housing	48	31	1
112168	Decal – Lift	50	15	1	113136	Race – Pump	7	16	1
112185	Body – Connector	45	17	1	113137	Race – Motor	7	47	1
112213	Muffler	42	7	1	113179	Nut	46	9	1
112214	Choke Control	42	3	1	113381	Spindle – Front, LH	19	7	1
112415	Stop – PTO	23	21	1	113382	Spindle – Front, RH	19	*	1
112426	Pulley – Idler	13	43	1	113443	Tube – Steering	19	28	1
112506	Bracket	43	6	1	113445	Bar – Lift	17	14	1
112506	Bracket	23	18	1	113454	Control – Cam	13	57	1
112564	Lens – Taillight	46	17	2	113969	Hook – Battery Hold Down	45	37	2
112595	Button	7	10	2	114000	Valve – Hydraulic	11	28	1
112600	Ring – Retaining	7	53	2	114017	Clamp – Steel	45	52	1
112604	Seal	7	3	2	114343	Spring – Gas	49	16	1
112608	Pin – Coil	7	21	1	114344	Spacer	49	11	2
112610	Ball	7	24	2	114345	Bracket	49	14	1
112611	Ring – Retaining	7	23	2	114427	Logo – Hub Cap 8 (Opt.)	47	23	2
112613	Plug – "O"Ring	7	48	1	114428	Logo – Hub Cap 12	47	1	2
112614	"O"Ring	7	49	1	114720	Tube – Drain	45	39	1
112616	Screw	7	33	4	114825	PC Board w/Lights	43	10	1
112616	Screw	7	54	2	114881	Facing – Clutch Plate	48	43	1
112635	Screw	7	1	1	115197	Decal – Attach-A-Matic	50	14	1
112636	Bearing – Input	7	2	1	115230	Switch – Clutch Interlock,	45	8	1
112637	Housing – Pump Assembly	7	4	1	115411	Support – Switch	45	18	1
112638	Ring – Seal	7	6	1	115854	Control – Throttle	42	1	1
112639	Plate	7	7	1	116000	Bolt – Carriage	27	3	1
112640	Ring – Seal	7	8	1	116000	Bolt – Carriage	27	9	6
112641	Cover Assembly	7	9	1	116302	Arm – Control	11	34	1
112642	Pin	7	12	1	116305	Bracket – Control Rod	11	4	1
112643	Shaft – Input	7	13	1	116321	Arm – Control	13	64	1
112644	Ring – Seal	7	14	1	116324	Rod Assembly	13	74	1
112645	Rotor – Pump	7	15	1	116338	Switch – Ignition	45	1	1
112646	Pintle Assembly	7	22	1	116397	Relay	45	62	1
112647	Body – Check Valve	7	25	2	116407	Rod End	13	10	2
112648	Ball	7	26	1	116445	Decal – Parking Brake	50	7	1
112649	Spring – Relief Valve	7	27	1	116446	Decal – Do Not Toe	50	6	1
112650	Plug – Relief Valve	7	28	1	116454	Knob – Throttle Control	42	2	1
112651	Pin	7	29	1	116497	Nut	45	32	4
112652	Shield	7	30	1	116634	Knob – Hydraulic Lift	11	2	1
112653	Ring – Retaining	7	31	1	116635	Knob – Motion Control	13	2	1
112654	Ring – Retaining	7	5	2	116723	Harness – Wiring	43	7	1
112654	Ring – Retaining	7	32	2	116744	Tire – Turf Trac, Rear	47	3	2
112656	Roller	7	34	6	116745	Rod – Pivot	23	7	1
112657	Carrier	7	35	1	116746	Bracket – RH	23	10	1
112658	Seal	7	36	1	116747	Bracket – LH	23	11	1

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
116796	Test Switch	43 1 1	933505	Pin - Cotter	21 14 1
117127	Tire - Turf Trac, Front	47 21 2	933505	Pin - Cotter	48 20 1
117217	Button - Switch	43 2 1	933505	Pin - Cotter	17 21 1
117242	Decal - Made in U.S.A.	50 18 1	933506	Pin - Cotter	48 32 1
117331	Holder - Fuse	27 36 1	933507	Pin - Cotter	17 2 2
117343	Latch - Hood	23 25 2	936032	Ring - Snap	48 35 1
117344	Handle Assembly	23 2 2	937099	Key - Woodruff	9 29 1
117371	Bolt - Carriage	25 6 4	937108	Key - Woodruff	47 8 2
117431	Rivet - Pop	23 16 4	937221	Key - Hi-Pro	3 9 1
117432	Rivet - Pop	23 3 4	950154	Clamp 1/2 (1.3 cm) Dia.	32 28 2
117488	Decal - 314-Hydro	50 11 2	960152	Bolt - Whizlock	45 25 2
117509	Decal - Front Hood	50 5 1	973310	O-Ring	11 10 2
117760	Decal - Rear Fender	50 4 1	973370	O-Ring	11 13 4
117930	Latch - Mid Hitch	21 17 1	9107562	Screw	43 8 2
117940	Rod - Mid Hitch Lock	21 16 1	9107622	Screw	23 20 2
118620	Bolt - Carriage	27 33 2	9107922	Screw	23 28 2
118660	Guide - Control	13 60 1	9107944	Screw	45 1
118860	Knob - Parking Brake Lever	13 21 1	9107944	Screw - Machine	27 34 2
119190	Decal - Lower Dash	50 9 1	9108372	Screw	27 2 2
119220	Decal - Switch Plate	50 10 1	9108372	Screw	25 14 6
119340	Cylinder - Hydraulic	11 20 1	9108372	Screw	25 24 1
120590	Stop - Throttle	23 17 1	9151126	Nut	25 7 4
120930	Body - Fuse, Part of 5	45 9 1	9156934	Nut	19 11 4
121100	Lever - Lift	17 1 1	9157324	Nut - Lock	43 5 2
518077	Terminal	45 68 2	9157404	Nut	42 6 2
518104	Terminal	46 6 1	9157404	Nut	27 35 4
518105	Terminal	45 7 1	9157404	Nut - Lock	23 29 2
518105	Terminal	45 64 1	9159604	Nut	23 24 2
519337	Clip - Cable	45 63 1	9201504	Washer - Lock	23 19 2
908040	Bolt	5 7 1	9266944	Bolt	25 4 1
908040	Bolt	9 33 1	9266944	Bolt	25 12 4
910478	Screw	45 59 2	9266944	Bolt	25 17 4
910792	Screw	42 5 2	9266944	Bolt	27 23 4
910808	Screw	46 16 4	9266944	Bolt	27 4 1
911423	Bolt	9 16 4	9266944	Bolt	25 10 1
911458	Bolt	13 53 2	9266944	Bolt - Washer Hd	23 5 3
911747	Screw	13 83 1	9320004	Pin - Cotter	23 9 2
913464	Bolt	49 5 4	9791204	Spacer	21 11 2
915002	Nut	19 39 1	KH10009	Gasket - Flange	30
915551	Nut	46 19 4	KH10010	Clip - Hi-Tension	41 18 1
915732	Nut	45 60 2	KH10029	Insert - Exhaust Valve	35 7 1
915962	Nut - Hex	45 54 1	KH10034	Seal	34 6 1
920008	Washer	27 24 4	KH10034	Seal	29 7 1
920120	Washer - Lock	45 53 1	KH10035	Pin - Governor Stop	31 3 1
920160	Washer - Lock	45 2 1	KH10040	Screw	31 47 1
920259	Washer - Special	46 7 1	KH10049	Bearing	35 8 1
920262	Washer - Special	45 48 1	KH10054	Retainer - Upper Spring	36 7 2
926671	Bolt	45 19 1	KH10055	Gasket	35 16 1
926671	Bolt	46 20 2	KH10057	Reed	34 3 1
926694	Bolt	13 14 1	KH10058	Gasket	34 1 1
926696	Bolt	25 * 2	KH10059	Gasket	38 8 1
926697	Bolt	32 20 2	KH10062	Spring	36 14 2
932000	Pin - Cotter	11 31 2	KH10067	Ball Bearing	35 3 2
932120	Pin - Clevis	11 30 1	KH10070	Bushing	31 22 1
932997	Pin - Clevis	11 17 1	KH10071	Valve - Intake	36 6 1
933135	Pin - Spirol	13 59 1	KH10072	Plate	34 2 1
933198	Pin - Spirol	11 33 1	KH10081	Shaft - Balance Gear	35 18 1
933198	Pin - Spirol	13 68 1	KH10082	Connector	41 16 1
933274	Pin - Spirol	48 30 1	KH10087	Washer	31 24 1
933505	Pin - Cotter	17 9 1	KH10088	Gasket	38 6 1

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
KH10090	Valve – Exhaust	36 5 1	KH10267	Bearing – Needle	36 22 2
KH10091	Kit – Stator 15 am	41 9 1	KH10268	Seal	35 12 1
KH10093	Gasket	30 20 1	KH10269	Seal	35 4 1
KH10093	Gasket – Bowl Screen	30	KH10270	Dipstick	38 1 1
KH10094	Gasket	30 17 1	KH10272	Gasket	35 9 1
KH10094	Gasket– Bowl	30	KH10274	Gasket	30
KH10107	Screw – Hex. Hd.	40 5 4	KH10274	Gasket – Carburetor	30
KH10108	Screw	40 7 1	KH10274	Gasket – Carburetor	30 23 1
KH10109	Screw – Idle Speed Adj.	30 14 1	KH10275	Filter	34 5 1
KH10110	Screw	30 2 4	KH10278	Elbow	42 16 1
KH10112	Spring – Idle Fuel	30 10 1	KH10279	Baffle – Side Air	33 2 1
KH10113	Spring	30 5 1	KH10280	Baffle – Inner	33 7 1
KH10114	Spring – Adj.	30 13 1	KH10282	Baffle – Cylinder	33 6 1
KH10116	Screw	30 21 1	KH10287	Linkage – Choke (Carb. to	31 32 1
KH10117	Bowl – Fuel	30 19 1	KH10289	Screw – Pozidrive T.H.	33 5 3
KH10119	Decal – Float Switch	38 * 1	KH10290	Screw	35 24 1
KH10123	Connector – 90°	32 35 2	KH10292	Spring	36 2 1
KH10123	Connector – 90°	30 22 1	KH10293	Lever – Choke Control	31 42 1
KH10124	Fan	40 4 1	KH10294	Lever – Throttle Control	31 43 1
KH10126	Screen	40 6 1	KH10295	Lever – Governor	31 27 1
KH10128	Ball	30 4 1	KH10296	Spring (Governor to Carb.)	31 31 1
KH10132	Needle – Idle Fuel Adj.	30 9 1	KH10297	Base – Air Cleaner	29 9 1
KH10134	Sleeve	38 12 1	KH10298	Cover	34 8 1
KH10135	Tag – Caution	39 * 1	KH10299	Cover	29 2 1
KH10136	Washer	31 25 1	KH10302	Space	31 44 1
KH10143	Baffle	34 4 1	KH10303	Bracket – Clutch Control	31 48 1
KH10144	Screw	35 22 8	KH10304	Bracket – Starter	39 5 1
KH10145	Washer	35 21 9	KH10308	Clamp	31 49 1
KH10146	Gasket	30	KH10309	Hose	34 11 1
KH10146	Gasket – Carburetor	30	KH10310	Pin – Camshaft	36 4 1
KH10146	Gasket – Carburetor	30 24 1	KH10311	Gasket	35 10 1
KH10147	Spacer .005	36 3 1	KH10312	Strap – Lifting	35 23 1
KH10148	Spacer .010	36 * 1	KH10313	Lead – Violet, Regulator	41 * 1
KH10149	Gasket	34 7 1	KH10315	Lead – Wire, Module to	41 * 1
KH10150	Stud	34 9 1	KH10319	Pump Assy – Fuel	32 29 1
KH10152	Washer	31 41 2	KH10321	Module – Ignition	41 1 1
KH10181	Bolt	39 7 2	KH10322	Kit – Spacer	36 19 2
KH10188	Spacer	40 3 4	KH10323	Kit – Drive	39 12 1
KH10189	Nut	29 3 1	KH10324	Kit – Drive Parts	39 13 1
KH10191	Decal – Air Cleaner	29 * 1	KH10325	Set – Gasket w/ Seals	35 * 1
KH10191	Decal – Air Cleaner/Lub	50 19 1	KH10344	Clamp – Cable	42 10 1
KH10201	"O"Ring	38 2 1	KH10344	Clip	41 12 1
KH10209	Cap – Drive End	39 11 1	KH10345	Connector	41 11 1
KH10210	End Cap Ass'y	39 8 1	KH10345	Connector – Female	38 13 1
KH10221	Kit – Retainer	36 10 2	KH10358	Kit – Choke & Throttle	30 * 1
KH10228	Gear Assembly	36 21 2	KH10412	Cover – Air Cleaner Element	29 4 1
KH10231	Baffle – Head	33 3 1	KH10413	Screw – Hex .Hd.	33 1 6
KH10235	Element – Precleaner	29 5 1	KH10496	Rotator – Valve	36 13 2
KH10236	Element	29 6 1	KH10515	Kit – Brush	39 9 1
KH10244	Brace – Starter Tail	39 2 1	KH10535	Nut – Lock	42 15 1
KH10245	Kit – Crankshaft	36 16 1	KH10539	Tappet – Intake Valve	36 11 2
KH10247	Armature	39 10 1	KH10541	Screw	38 5 3
KH10248	Pan – Oil	38 7 1	KH10545	Screw	41 13 1
KH10258	Set – Gasket w/o Seals	35 * 1	KH10545	Screw	35 14 4
KH10259	Camshaft Assy	36 1 1	KH10545	Screw	31 34 1
KH10261	Head – Cylinder	35 19 1	KH10549	Screw	39 * 1
KH10262	Retainer – Piston Pin	37 3 2	KH10549	Screw	39 6 2
KH10263	Flywheel	40 1 1	KH10549	Screw	35 13 4
KH10265	Housing – Blower	33 8 1	KH10550	Screw	38 9 4
KH10266	Adapter – Oil Fill	38 4 1	KH10552	Screw – Pozidrive	32 32 2

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
KH10562	Plug	35 5 1	38-1420	Switch - Seat	45 14 1
KH10567	Washer	33 4 1	47-1910	Solenoid	45 24 1
KH10569	Washer	32 31 2	55-3570	Cap - Fuel	32 18 1
KH10569	Washer	31 39 1	62-7770	Key - Ignition, Padded	45 4 1
KH10570	Washer	42 17 1	76-1420	Steering Wheel	19 30 1
KH10570	Washer	31 35 1	78-0020	Meter - Hour	45 51 1
KH10570	Washer - Flat	41 2 1	78-0080	Clamp - Voltmeter, Back	45 22 1
KH10574	Retainer	36 20 1	78-0370	Insert	19 40 1
KH10576	Nut - Wing	29 1 1	78-1540	Bracket - Control, Lower	13 62 1
KH10585	Spacer	31 23 1	78-1550	Bellcrank	17 7 1
KH10586	Clamp	32 33 2	78-1660	Wheel Assembly - Front	47 17 2
KH10588	Key - Woodruff	40 2 1	78-2680	Frame	2 1 1
KH10599	Washer - Lock	31 38 1	78-2880	Shaft	19 15 1
KH10600	Screw	31 37 1	78-2900	Tie Rod Assembly	19 10 2
KH10605	Screw	31 45 1	78-2920	Joint - Ball	19 38 1
KH10605	Screw - Pozidrive	41 10 4	78-2990	Plate - Seat Pivot	49 10 1
KH10606	Screw - Hex. Hd.	41 4 1	78-3000	Bracket - Battery Support	25 5 1
KH10607	Screw - Hex. Hd.	39 4 1	78-3020	Plate - Front	25 9 1
KH10609	Screw	29 8 3	78-5610	Console	23 4 1
KH10610	Screw	41 3 1	78-5620	Plate - Hood Stand	25 20 1
KH10610	Screw - Hex. Hd.	39 3 1	78-5631	Bracket - Control	13 61 1
KH10610	Screw - Hex. Hd.	42 11 1	78-5640	Bar - Lift	11 32 1
KH10617	Plug - Cup	36 15 1	78-5660	Lever - Motion Control	13 1 1
KH10618	Clip	41 5 1	78-5670	Rod - Lift Control	11 1 1
KH10619	Nut	31 50 1	78-7020	Harness Assy - Wiring	45 5 1
KH10620	Plug	38 10 4	78-8500	Lever - Parking Brake	13 20 1
KH10624	Nut	31 40 1	79-0060	Voltmeter	45 21 1
KH10625	Screw	29 11 1	79-0370	Decal - Danger	50 20 1
KH10626	Screw	31 28 1	79-0370	Decal - Danger	25 27 1
KH10629	Nut - Pal	31 8 1	79-0670	Seat	49 4 1
KH10629	Palnut	34 10 1	79-1350	Pedal - Brake/Return	15 1 1
KH10660	Kit - Governor Gear	31 1 1	79-4450	Decal - Hood LH	50 1 1
KH10661	Cover	35 15 1	79-4460	Decal - Hood RH	50 1 1
KH10663	Kit - Float	30 18 1	79-4900	Hoodstand	25 1 1
KH10666	Washer	40 8 1	79-4990	Bracket - Fender Support	27 18 1
KH10673	Regulator - Rectifier	41 14 2	79-5020	Tube Assembly	5 26 1
KH10677	Gasket - Air Cleaner	30	79-5130	Cover - Side, LH	25 13 1
KH10682	Bushing &	30	79-5270	Filter - Oil	5 32 1
KH10682	Bushing	30	83-2720	Bolt - Lug	47 5 10
KH10682	Bushing - Linkage Natural	30	83-6520	Rod - Lock	21 18 1
KH10686	Bushing Linkage Black	30	86-9280	Tube - Hydraulic	11 15 1
KH10687	Plate - Bearing	35 11 1	86-9290	Tube - Hydraulic (Return)	11 24 1
KH10693	Carburetor Assembly	30	88-0020	Decal - Danger	23 27 1
KH10693	Kit - Adjustable Jet	30 *	88-0020	Decal - Rear Hood Danger	50 8 1
KH10694	Main - Needle	30 16 1	88-2710	Support - Steering	19 19 1
KH10695	Rod - Connecting .010	37 * 1	88-2782	Hood	23 1 1
KH10695	Washer	31 46 1	88-2790	Decal - Danger	50 17 1
KH10696	Kit - Carburetor Repair	30 *	88-2790	Decal - Danger	9 41 1
KH10697	Gasket	30	88-3200	Decal - Maintenance	50 21 1
KH10697	Gasket	29 10 1	92-1534	Loose Parts Package	50 * 1
KH10697	Gasket - Air Cleaner	30	92-4987	Steering Shaft Assembly	19 25 1
KH10700	Gasket	35 20 1	92-7250	Line - Fuel 5 Lg	32 34 1
KH10701	Carburetor Linkage	30	92-7251	Kit - Carburetor w/Linkage	30 * 1
KH10701	Linkage (Governor to Carb.)	31 30 1	92-7252	Carburetor Assembly	30 1 1
KH10702	Shaft - Choke	30 15 1	92-7253	Bushing	31 33 1
KH10709	Jet - Main	30	92-7254	Bushing	31 29 1
KH10709	Main Jet	30	92-7255	Plate - Choke	30 3 1
KH10710	Kit - High Altitude Jet	30 *	92-7256	Shaft w/Lever & Seal	30 7 1
KH10733	Gasket	30	92-7257	Plate - Throttle	30 8 1
NN10277	Fuse 30 Amp ATO or ATC	45 1	92-7258	Shaft - Governor Gear	35 2 1

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
92-7259	Guide - Valve	35	6	2	323-9	Bolt	19	20	2
92-7260	Starter Assembly	39	1	1	323-9	Bolt	13	22	1
92-7261	Gasket - Fuel Pump	32	30	1	323-15	Bolt	9	36	2
92-7262	Kit - Governor Cross Shaft	31	26	1	323-23	Bolt	15	15	1
92-7263	Choke Lever Assembly	31	*	1	323-25	Bolt	5	6	2
92-7264	Clip	41	8	1	323-25	Bolt	9	35	1
92-7265	Plug - Spark	41	17	1	323-26	Bolt	5	8	1
92-7266	Screw	41	15	2	324-5	Bolt	3	2	3
92-7267	Rod - Connecting Std.	37	4	1	3218-1	Nut	48	21	2
92-7268	Piston w/Ring Set Std.	37	2	1	3218-1	Nut	45	50	2
92-7269	Piston w/Ring Set .003	37	*	1	3218-1	Nut	13	78	1
92-7270	Piston w/Ring Set .010	37	*	1	3218-3	Nut	47	10	4
92-7271	Piston w/Ring Set .020	37	*	1	3220-1	Nut	13	55	3
92-7272	Piston w/Ring Set .030	37	*	1	3229-25	Bolt - Carriage	23	12	4
92-7273	Set - Ring, Std. & .003	37	1	1	3229-25	Bolt - Carriage	48	24	2
92-7274	Set - Ring .010	37	*	1	3231-25	Bolt - Carriage	2	2	3
92-7275	Set - Ring .020	37	*	1	3235-22	Bolt	15	16	1
92-7276	Set - Ring .030	37	*	1	3235-22	Bolt	17	18	2
92-7278	Kit - Float Switch	38	11	1	3242-2	Screw - Set	3	7	2
92-7279	Short Block	35	1	1	3243-5	Screw - Set	47	9	4
92-7280	Miniblock (w/Out Crankshaft)	35		1	3245-32	Screw - Set	15	4	1
92-7281	Decal - HP	33	9	1	3246-2	Screw - Set	3	12	2
92-7296	Plate - Shift Cover	25	19	1	3251-25	Bolt	21	19	3
92-7297	Transaxle	9	1	1	3253-3	Washer - Lock	45	45	4
92-7298	Case - Transaxle, RH	9	2	1	3253-3	Washer - Lock	48	47	1
237-69	"O"Ring	19	41	1	3253-3	Washer - Lock	45	49	2
281-10	Plug - NPT	5	31	1	3253-4	Washer	42	13	1
281-10	Plug - Pipe	9	40	2	3253-4	Washer - Lock	49	2	12
302-5	Fitting - Grease	19	2	2	3253-4	Washer - Lock	19	6	1
321-3	Bolt	3	4	1	3253-4	Washer - Lock	32	23	1
321-3	Bolt - Nylok	48	41	4	3253-4	Washer - Lock	5	30	2
321-3	Screw	11	3	1	3253-21	Washer - Lock	2	5	4
321-4	Bolt	45	30	2	3253-21	Washer - Lock	28	5	1
321-4	Bolt	27	37	2	3254-1	Washer - Lock	46	13	4
321-4	Bolt	13	67	2	3254-2	Washer - Lock	46	4	1
321-6	Bolt	13	38	1	3254-2	Washer - Lock	45	42	1
321-8	Bolt	49	13	2	3255-7	Washer - Lock	13	77	1
321-10	Washer	11	8	1	3256-4	Washer	32	21	2
321-11	Bolt	11	27	2	3256-4	Washer	15	22	1
322-1	Bolt	19	5	1	3256-4	Washer	13	28	2
322-2	Bolt	32	22	3	3256-6	Washer	15	23	2
322-2	Bolt	13	73	1	3253-6	Washer	3	3	1
322-3	Bolt	27	15	2	3256-17	Washer	46	12	4
322-3	Bolt	27	21	4	3256-22	Washer	49	12	2
322-3	Bolt	5	29	2	3256-22	Washer	23	13	4
322-3	Bolt	13	70	2	3256-22	Washer	48	22	2
322-4	Bolt	49	18	6	3256-22	Washer	45	31	4
322-5	Bolt	49	8	4	3256-22	Washer	13	54	2
322-5	Bolt	17	11	1	3256-23	Washer	46	3	1
322-5	Bolt	5	23	1	3256-23	Washer	49	6	8
322-6	Bolt	42	12	1	3256-23	Washer	17	12	1
323-5	Bolt	2	4	4	3256-23	Washer	27	16	2
323-6	Bolt	28	4	2	3256-24	Washer	15	10	2
323-6	Bolt	19	13	2	3256-24	Washer	13	52	1
323-7	Bolt	48	16	1	3256-25	Washer	3	3	3
323-7	Bolt	21	21	2	3256-26	Washer	17	22	1
323-7	Bolt	9	34	1	3256-26	Washer	13	50	1
323-8	Bolt	28	2	2	3256-26	Washer	13	76	4
323-8	Bolt	13	27	1	3256-27	Washer	48	48	1
323-9	Bolt	15	20	1	3256-30	Washer	17	3	3

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3256-66	Washer	42 14 1	3296-39	Nut	28 3 2
3257-24	Key - Woodruff	5 12 1	3296-39	Nut	15 9 1
3269-3	Rivet - Pop	46 15 4	3296-39	Nut	5 9 4
3272-6	Pin - Cotter	15 24 2	3296-39	Nut	48 19 1
3272-10	Pin - Cotter	48 7 1	3296-39	Nut	21 20 5
3272-10	Pin - Cotter	48 12 2	3296-39	Nut	15 21 1
3272-11	Pin - Cotter	15 8 2	3296-39	Nut	17 23 1
3272-11	Pin - Cotter	11 16 1	3296-39	Nut	9 37 3
3272-17	Pin - Cotter	47 19 2	3296-39	Nut	13 58 2
3272-19	Pin - Cotter	19 18 1	3296-39	Nut	19 14 4
3272-21	Pin - Cotter	19 42 1	3296-42	Nut	11 9 1
3296-4	Nut	13 71 1	3296-42	Nut	49 15 2
3296-23	Nut	5 14 1	3296-42	Nut	11 29 2
3296-26	Washer	5 13 1	3296-42	Nut	27 38 1
3296-29	Nut	49 3 6	3296-42	Nut	13 66 2
3296-29	Nut	11 5 1	32120-64	Ring - Retaining	5 4 1
3296-29	Nut	46 5 1	32120-72	Ring - Snap	48 34 2
3296-29	Nut	49 7 2	32120-93	Ring - Retaining	19 34 2
3296-29	Nut	27 10 7	32121-111	Pin - Spirol	19 31 1
3296-29	Nut	17 13 1	32136-5	Nut - Slotted	19 37 1
3296-29	Nut	27 30 6	32146-7	Nut	45 2
3296-29	Nut	13 69 2	32146-17	Nut	23 14 4
3296-29	Nut	13 72 1	32146-17	Nut	13 39 4
3296-39	Nut	2 3 3	32312-94	Pin - Spirol	13 65 1

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

## IDENTIFICATION AND ORDERING

### MODEL AND SERIAL NUMBERS

The two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number .
2. Part number, description, and the quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

## TABLE OF CONTENTS

Description	Page	Description	Page
Frame .....	2	Fuel System .....	32
Drive Belt And Pulleys .....	3	Baffles And Shrouds .....	33
Transaxle Hydrostatic System .....	4	Breather And Vent .....	34
Hydraulic Pump And Motor .....	6	Crankcase And Cylinder Head .....	35
Transaxle .....	8	Camshaft, Crankshaft And Valves .....	36
Hydrostatic System .....	10	Piston And Rings .....	37
Clutch, Brake Motion Control Linkage .....	12	Oil Pan And Dipstick .....	38
Clutch, Brake and Speed Control Linkage .....	14	Starter .....	39
Hydrostatic Lift Linkage .....	16	Flywheel .....	40
Front Axle and Steering .....	18	Ignition System .....	41
Hitches .....	20	Throttle Choke And Exhaust .....	42
Hood Assembly .....	22	Electrical System .....	43-46
Hood Stand And Supports .....	24	Wheel And Tires .....	47
Fender And Supports .....	26	P.T.O. Clutch And Control .....	48
Engine Kohler .....	28	Seat .....	49
Air Intake .....	29	Decals .....	50
Carburetors .....	30	Numerical Parts List .....	51
Governor Linkage .....	31		

## Optional Equipment

Description	Model No.	Description	Model No.
36" Rear Discharge Cutting Unit .....	78305	42" Recycler Cutting Unit .....	78355
42" Rear Discharge Cutting Unit .....	78345	36" Tiller .....	79370
48" Rear Discharge Cutting Unit .....	78360	48" Dozer Blade .....	0648BC
42" Rear Discharge Cutting Unit .....	78350	50" Grader Blade .....	79351

