

LAWN-BOY®

**21" REAR BAGGER, ELECTRIC START
EXPORT – WALK BEHIND MOWER**

**MODEL NO.10760-3900001 & UP
SELF-PROPELLED**

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.


To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Housing – Assembly	1	Engine Assembly	8-9
Shroud – Assembly	2	Carburetor Assembly	10-11
Drive Assembly	3	Starter Assembly	12
Handle Assembly	4-5	Electric Starter	13
Transmission Assembly	6-7	Numeric Parts Index	14-16




C-1513

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	609807	Screw	2	28	27-6250	Bushing	4
2	613341	Speednut	1	29	614430	Bolt - Shoulder	2
3	700748	Screw	2	30	92-1604	Cap - Hub	2
4	39-5770	Decal - Blade Warning	1	31	683179	Assembly - Wheel & Tire	2
5	613121	Decal - Spark Plug	1	32	608834	Washer	2
6	614522	Anchor - Cable	1	33	684220	Assy. - Spring Arm, L.H.	1
9	303724	Screw	1	34	613917	Arm - Front, Height Adjust	2
10	684366	Switch - Lock, Bag	1	35	610358	Nut (Thin)	4
11	684193	Assembly - Magnet	1	36	677525	Assembly - Collar & Plate	1
12	613625	Washer - Lock	1	37	603164	Nut - Blade	1
13	130450	Nut	1	38	613944	Blade - 21"	1
14	613749	Screw	1	40	613925	Screw	3
15	613321	Bolt - Mounting, Handle	2	41	613924	Baffle - Front	1
16	614328	Shield - Housing	1	42	614689	Assembly - Housing (Incl. Ref. #4, 15, 23-24 & following item marked *)	1
17	613322	Shield - Trailing	1	43	613122	Decal - Sound Emission	1
18	684394	Charger - Battery	1	44	608311	Nut - Lock	3
19	610026	Rod - Shield, Trailing	1	46	684219	Assy. - Spring Arm, R.H.	1
20	614433	Plate - Height Adjust	2	47	611380	Grommet	1
21	613381	Screw - Plate to Housing	4	48	613532	Cover - Drive, Lower	1
22	602315	Nut - Anchor, Cable	2	49	92-2839	Decal - Warning	1
23	613289	Baffle	1	50	16-2219	Cover - Drive, Upper (Incl. Ref. #49)	1
24	46-6811	Screw - Baffle to Housing	4	51	613910	Washer - R.H. Handle Mtg.	1
25	610361	Washer	4				
26	613320	Screw	2				
27	684645	Assembly - Wheel & Tire (Incl. Ref. #28)	2				

*Not Illustrated




C-1514

SHROUD, FUEL/OIL TANK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	684376	Switch – Low Oil	1
2	684105	Assembly – Cap, Oil (Incl. Ref. #3–5)	1
3	614274	Filter	1
4	614272	Cover	1
5	613313	Gasket	1
6	684104	Assembly – Cap, Fuel (Incl. Ref. #7–9)	1
7	609150	Baffle	1
8	614271	Cover	1
9	613311	Gasket	1
10	684508	Assy. – Fuel/Oil Tank (Incl. Ref. #1, 26 & 31–32)	1
11	614182	Bracket – Tank, Fuel/Oil	1
12	614181	Screw – Mounting, Tank	2
13	613111	Bolt – Bracket/Starter	2
14	800019	Screw – Bracket to Door	2
15	613339	Screw	1
16	613346	Door – Access	1
17	683637	Pack – Battery (Incl. Ref. #18)	1
19	684562	Harness – Wire, Lower	1
20	612510	Pad – Battery	1
21	613344	Bracket – Battery	1
22	604227	Speednut	2
23	613340	Speednut	1
24	684246	Assembly – Cup, Electronic	1
25	607745	Screw	1

Ref. No.	Part No.	Description	No. Used
26	684093	Valve – Fuel, Shut-Off	1
27	682776	Relay – Starter	1
28	613489	Clamp – Fuel Line	2
30	613531	Fuel Line	1
31	613948	O-Ring	1
32	684336	Assembly – Fitting, Oil	1
33	613516	Clamp – Hose, Oil	2
34	611774	Screw	3
35	613206	Plate – Engine, Mounting	1
36	613483	Screw	3
37	613266	Gasket – Exhaust	1
38	684579	Muffler	1
39	613282	Screw – Muffler	1
40	684157	Assembly – Guard, Muffler (Incl. Ref. #43 & 46)	1
41	700056	Screw – Guard, Muffler	1
42	613576	Screw – Guard, Muffler	1
43	613378	Cover – Muffler	1
44	613372	Screw – Guard, Muffler	1
45	613371	Spacer – Guard, Muffler	1
46	613329	Pushnut	4
47	613281	Screw – Shroud	3
48	614041	Applique	1
49	684429	Assy. – Shroud & Applique (Incl. Ref. #48)	1
50	613330	Screw – Tank, Fuel	3
51	613557	Snubber – Belt	1
52	700098	Nut	1




C-1404

DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	613842	V-Belt	1	22	70-9760	Bushing	2
2	613770	Nut	1	23	47-2900	Bushing	2
3	613445	Pulley - Transmission	1	24	602480	Screw	2
4	614524	Plate - Actuator	1	25	602315	Locknut	2
5	613387	Screw	3	26	610358	Nut	2
6	613385	Clamp	1	27	614442	Fitting - Grease	2
7	146134	Screw - Plate to Trans.	2	28	65-4730	Washer - Inner Thrust	2
8	614525	Spring	1	29	65-4740	Washer - Keyed	4
9	684617	Transmission	1	30	65-2720	Ring - Retaining	4
10	603773	Nut	1	31	65-4710	Ring - Friction	2
11	614523	Arm - Trans. Engagement	1	32	65-4760	Washer - Clutch	2
12	614526	Guide - Belt	1	*33	66-6040	Key, Rocking - R.H.	1
13	614527	Bolt - Shoulder	1	34	66-6050	Key, Rocking - L.H.	1
14	614529	Spring - Extension	1	35	65-4750	Gear - Pinion 15T	2
15	614316	Arm - Shift	1	36	65-4720	Spring - Compression	2
16	614317	Arm - Clutch	1	37	614427	Cover - Wheel	2
17	611840	Key	1	38	614426	Washer - Stepped	2
18	614443	Ring - Isolator	2	39	684645	Assembly - Wheel (Incl. Ref. No.40)	2
19	614447	Spacer	2	40	27-6250	Bushing	2
20	684618	Assembly - Knob & Spring	2	41	614430	Bolt - Wheel	2
21	684616	Pivot Arm Assy. (Incl. Ref. No. 22-23)	2	42	92-1604	Cap - Hub	2

*Not Illustrated

HANDLE & REAR GRASS CATCHER




HANDLE & REAR GRASS CATCHER

Ref. No.	Part No.	Description	No. Used
1	684400	Assy. – Knob, Gear Select (Incl. Ref. #2)	1
2	614013	Screw – Set	2
3	684399	Assembly – Knob, Throttle (Incl. Ref. #2)	1
4	614021	Plate	1
5	684427	Assembly – Cover, Upper (Incl. Ref. #4)	1
6	614333	Decal – Electric Start	1
7	684446	Lever – Throttle	1
8	609269	Key – Ignition	2
9	682727	Assembly – Switch	1
10	684238	Wire Harness	1
11	684210	Assembly – Cable, Throttle	1
12	684581	Assy. – Handle & Decal	1
13	613551	Screw	1
14	613406	Nut	2
15	613409	Pivot – Bail	1
16	614331	Decal – Self Propelled	1
17	613417	Bail – Self-propelled	1
18	613553	Screw	1
19	613412	Block – Bail	1
20	602315	Nut	3
21	613550	Nut – Cable, Self-propelled	1
22	700790	Bumper	1
23	613549	Screw	6

Ref. No.	Part No.	Description	No. Used
24	684209	Assy. – Cable, Eng. Brake	1
25	614023	Screw – Thread Forming	3
26		Bag – Rear, Grass (Accessory Part #684189)	1
27	613401	Screw	2
28	613358	Knob – Mounting, Handle	2
29	684150	Knuckle – Handle (Incl. Ref. #27 & 30)	2
30	613406	Nut	2
31	613552	Insert – Handle, Cable Side	1
32	613408	Insert – Handle	1
33	613601	Insert – Handle	1
34	684697	Assy. – Cable, Self-propelled	1
35	611499	Screw	1
36	613405	Screw	1
37	613393	Plate – Nut	1
38	684151	Guide – Rope	1
39	613980	Decal – Lawn-Boy	1
40	684130	Frame	1
41	613555	Screw	1
42	613416	Bail – Brake, Engine	1
43	614329	Decal – Zone	1
44	684212	Assy. – Cable, Gear Select	1
45	684445	Lever – Gear Select	1
46	92-2940	Decal – Warning	1


TRANSMISSION ASSEMBLY



TRANSMISSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	684731	Kit – Upper & Lower Case (Incl. Sealant)	1	17	614611	Washer	2
2	614625	Screw – Tapping	1	18	684737	Bushing Set	2
3	614626	Screw – Tapping	5	19	614613	Ring – Snap	2
4	614600	Shaft – Input	1	20	614607	Washer	4
5	611840	Key – Woodruff	1	21	614608	Key – Holder,	1
6	614601	Washer	1	22	614609	Collar – Shift	1
7	614602	Bearing – Lower	1	23	614610	Slider	1
8	614603	Bearing – Upper	1	24	614614	Ring – Snap	1
9	684736	Kit – Shaft, Reduction (Incl. Ref. No. 10–11)	1	25	614615	Ball	2
10	614606	Collar	1	26	614616	Collar – Sliding	1
11	684732	Bushing Set	1	27	614617	Fork – Shift	1
12	614604	Ring Gear	1	28	614316	Arm – Shift	1
13	684733	Gear Set	1	29	614618	Support – Fork	2
14	684734	Gear Set	1	30	684739	Spring & Key – Shift	2
15	684735	Gear Set	1	31	614619	Spring	1
16	684740	Kit – Axle Shaft (Incl. Ref. No. 17–19)	1	32	614620	Plate	1
				33	614621	Fork – Clutch	1
				34	614317	Arm – Clutch	1
				35	614622	Ball	1

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	613208	Screw	7	34	683993	Crankshaft & Conn. Rod	1
2	613516	Clamp – Oil Line	2	35	613229	Ball – Governor	4
3	684275	Oil Pump Kit w/Oil Lines (Incl. Ref. No. 2)	1	36	613747	Shaft – Governor	1
4	613182	Oil Seal – Crankshaft	2	37	613227	Screw – Set, Engine Pulley	1
5	613183	Ring – Retaining	AR	38	613228	Pulley – Engine	1
6	613265	Ring – Retaining	AR	39	684561	Wire Harness	1
7	684022	Bearing – Crankshaft	2	40	684465	Ramp – Governor	1
8	613756	Shoulder Bolt	1	41	684272	Assy. – Piston & Ring (Std.) (Incl. Ref. No. 43–45)	1
9	613360	Shoulder Bolt	1	41	684307	Assy. – Piston & Ring (0.020" Oversize) (Incl. Ref. #43–45)	1
10	613529	Shoulder Bolt	1	42	607199	Key	1
11	602315	Nut	2	43	613258	Ring – Retaining	2
12	613390	Brake Actuator	1	44	613148	Pin – Wrist	1
13	613386	Brake Spring	1	45	684273	Ring Set (Standard)	1
14	684365	Brake & Switch	1	45	684309	Ring Set (0.020" Oversize)	1
15	300402	Pin – Taper	1	46	614009	Spark Plug	1
16	613110	Screw	2	47	613233	Screw – Cyl. Head to Block	4
17	613111	Screw	4	48	613197	Head – Cylinder	1
18	684437	Kit – Gov. & Oil Pump Lever (Incl. Ref. No. 19)	1	49	613382	Gasket – Head	1
19	613269	Screw	1	50	613266	Gasket – Exhaust	1
20	613337	Screw	2	51	684115	Alternator	1
21	684090	Assy. – Governor Bracket (Incl. Ref. No. 25)	1	52	613683	Wire Tie	1
22	613387	Screw	1	53	684698	Assy. – Cover & Terminal	1
23	613388	Clamp – Throttle Cable	1	54	684179	High Tension Lead & Cover (Incl. Ref. No. 53)	1
24	613430	Retainer – Throttle Wire	1	55	684049	Module – C.D. Ignition (Incl. Ref. No. 53–54)	1
25	613628	Spring – Torsion	1	56	684023	Flywheel	1
26	614043	Spring – Governor	1	57	316959	Lockwasher	1
27	613274	Rod – Choke	1	58	130743	Nut – Flywheel	1
28	613336	Nut	1	*	684276	Short Block (Incl. Ref. #4–7, 15–17, 31–36, 40–45, & 47–50)	1
29	613277	Rod – Throttle	1				
30	613276	Rod – Oil Pump Control	1				
31	613230	Seal – Oil, Governor Shaft	1				
32	613328	Ring – Retain. – Gov. Shaft	1				
33	613429	Washer – Governor Shaft	2				

*Not Illustrated


CARBURETOR ASSEMBLY



CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	613180	Gasket – Carb. to Spacer	1	20	614175	Bowl – Fuel	1
2	613181	Gasket – Spacer to Engine	1	21	614176	Screw – Bowl Retainer	1
3	613748	Gasket – Air Filter Base	1	*	684280	Kit – Gasket	1
*	684280	Kit – Gasket (Incl. Ref. No. 4–5)	1	22	614239	Hose – Carb Vent	1
4	613641	Gasket – Bowl Retainer	1	23	613531	Gas Line	1
5	613642	Gasket – Fuel Bowl	1	24	613489	Clamp – Hose	1
6	684281	Kit – Float & Needle (Incl. Ref. No. 7)	1	25	613348	Base – Air Filter	1
7	684282	Needle and Clip	1	26	613353	Bolt	1
8	684283	Kit – Idle Needle & Spring	1	27	613327	Screw – Carb. to Engine	2
9	684284	Kit – Idle Speed	1	28	613361	Filter – Air	1
10	613647	Pilot Jet	1	29	684559	Assembly – Cover, Air Filter (Incl. Ref. No. 30–33)	1
11	613918	Main Jet	1	30	614245	Pre-Filter	1
12	613649	Nozzle	1	31	613329	Pushnut	4
13	613650	Seal – Throttle Shaft	1	32	613349	Screw	2
14	613651	Seal – Choke Shaft	1	33	613379	Cover – Air Box	1
15	613655	Screw – Throttle Valve	2	34	613352	Spacer	2
16	613656	Screw – Choke Valve	2	†35	613893	Main Jet – High Altitude (Over 3,500 Feet)	1
17	613657	Pivot – Upper Choke Shaft	1	36	684080	Assy. – Spacer & Oil Nozzle	1
18	613658	Pivot – Lower Choke Shaft	1	*	684548	Kit – Carb. & Gasket (Incl. Ref. No. 1–22)	1
19	684478	Kit – Bowl (Incl. Ref. No. 20–21)	1				

*Not Illustrated




C-1406

STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	614037	Decal	1
2	612429	Hub - Starter	1
3	612825	Handle - Starter	1
4	612824	Insert - Clip, Rope	1
5	684567	Housing - Starter	1
6	683897	Recoil Spring & Keeper	1

Ref. No.	Part No.	Description	No. Used
7	612950	Pulley	1
8	612432	Rope	1
9	683899	Assembly - Dog Kit	1
*	612428	Screw-Sems	4
*	684622	Assembly - Starter (Inc. Ref. No. 5-9)	1

*Not Illustrated



C-1447

ELECTRIC STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	608622	Ring – Retaining	1	8	613292	Gear – Driven	1
2	613451	Washer – Stop	1	9	609568	Washer – Thrust	1
3	610257	Spring – Pinion	1	10	613291	Pinion	1
4	613295	Pinion	1	11	684095	Assy. – Housing & Pin	1
5	684097	Assy. – Clutch (Incl. Ref. #1–4 & 13)	1	12	613290	Stud – Spring, Drag	1
6	609130	Screw	2	13	613297	Spring – Drag	1
7	613517	Plate – Cover, Gear	1	*	684288	Kit – Starter & Spring	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
130450	Nut	1 13 1	613274	Rod - Choke	9 27 1
130743	Nut - Flywheel	9 58 1	613276	Rod - Oil Pump Control	9 30 1
146134	Screw - Plate to Trans.	3 7 2	613277	Rod - Throttle	9 29 1
300402	Pin - Taper	9 15 1	613281	Screw - Shroud	2 47 3
303724	Screw	1 9 1	613282	Screw - Muffler	2 39 1
316959	Lockwasher	9 57 1	613289	Baffle	1 23 1
602315	Locknut	3 25 2	613290	Stud - Spring, Drag	13 12 1
602315	Nut	9 11 2	613291	Pinion	13 10 1
602315	Nut	5 20 3	613292	Gear - Driven	13 8 1
602315	Nut - Anchor, Cable	1 22 2	613295	Pinion	13 4 1
602480	Screw	3 24 2	613297	Spring - Drag	13 13 1
603164	Nut - Blade	1 37 1	613311	Gasket	2 9 1
603773	Nut	3 10 1	613313	Gasket	2 5 1
604227	Speednut	2 22 2	613320	Screw	1 26 2
607199	Key	9 42 1	613321	Bolt - Mounting, Handle	1 15 2
607745	Screw	2 25 1	613322	Shield - Trailing	1 17 1
608311	Nut - Lock	1 44 3	613327	Screw - Carb. to Engine	11 27 2
608622	Ring - Retaining	13 1 1	613328	Ring - Retain. - Gov. Shaft	9 32 1
608834	Washer	1 32 2	613329	Pushnut	11 31 4
609130	Screw	13 6 2	613329	Pushnut	2 46 4
609150	Baffle	2 7 1	613330	Screw - Tank, Fuel	2 50 3
609269	Key - Ignition	5 8 2	613336	Nut	9 28 1
609568	Washer - Thrust	13 9 1	613337	Screw	9 20 2
609807	Screw	1 1 2	613339	Screw	2 15 1
610026	Rod - Shield, Trailing	1 19 1	613340	Speednut	2 23 1
610257	Spring - Pinion	13 3 1	613341	Speednut	1 2 1
610358	Nut	3 26 2	613344	Bracket - Battery	2 21 1
610358	Nut (Thin)	1 35 4	613346	Door - Access	2 16 1
610361	Washer	1 25 4	613348	Base - Air Filter	11 25 1
611380	Grommet	1 47 1	613349	Screw	11 32 2
611499	Screw	5 35 1	613352	Spacer	11 34 2
611774	Screw	2 34 3	613353	Bolt	11 26 1
611840	Key	3 17 1	613358	Knob - Mounting, Handle	5 28 2
611840	Key - Woodruff	7 5 1	613360	Shoulder Bolt	9 9 1
612428	Screw - Sems	12 * 4	613361	Filter - Air	11 28 1
612429	Hub - Starter	12 2 1	613371	Spacer - Guard, Muffler	2 45 1
612432	Rope	12 8 1	613372	Screw - Guard, Muffler	2 44 1
612510	Pad - Battery	2 20 1	613378	Cover - Muffler	2 43 1
612824	Insert - Clip, Rope	12 4 1	613379	Cover - Air Box	11 33 1
612825	Handle - Starter	12 3 1	613381	Screw - Plate to Housing	1 21 4
612950	Pulley	12 7 1	613382	Gasket - Head	9 49 1
613110	Screw	9 16 2	613385	Clamp	3 6 1
613111	Bolt - Bracket/Starter	2 13 2	613386	Brake Spring	9 13 1
613111	Screw	9 17 4	613387	Screw	3 5 3
613121	Decal - Spark Plug	1 5 1	613387	Screw	9 22 1
613122	Decal - Sound Emission	1 43 1	613388	Clamp - Throttle Cable	9 23 1
613148	Pin - Wrist	9 44 1	613390	Brake Actuator	9 12 1
613180	Gasket - Carb. to Spacer	11 1 1	613393	Plate - Nut	5 37 1
613181	Gasket - Spacer to Engine	11 2 1	613401	Screw	5 27 2
613182	Oil Seal - Crankshaft	9 4 2	613405	Screw	5 36 1
613183	Ring - Retaining	9 5 AR	613406	Nut	5 30 2
613197	Head - Cylinder	9 48 1	613406	Nut	5 14 2
613206	Plate - Engine, Mounting	2 35 1	613408	Insert - Handle	5 32 1
613208	Screw	9 1 7	613409	Pivot - Bail	5 15 1
613227	Screw - Set, Engine Pulley	9 37 1	613412	Block - Bail	5 19 1
613228	Pulley - Engine	9 38 1	613416	Bail - Brake, Engine	5 42 1
613229	Ball - Governor	9 35 4	613417	Bail - Self-propelled	5 17 1
613230	Seal - Oil, Governor Shaft	9 31 1	613429	Washer - Governor Shaft	9 33 2
613233	Screw - Cyl. Head to Block	9 47 4	613430	Retainer - Throttle Wire	9 24 1
613258	Ring - Retaining	9 43 2	613445	Pulley - Transmission	3 3 1
613265	Ring - Retaining	9 6 AR	613451	Washer - Stop	13 2 1
613266	Gasket - Exhaust	2 37 1	613483	Screw	2 36 3
613266	Gasket - Exhaust	9 50 1	613489	Clamp - Fuel Line	2 28 2
613269	Screw	9 19 1	613489	Clamp - Hose	11 24 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

3316-147

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
613516	Clamp - Hose, Oil	2 33 2	614328	Shield - Housing	1 16 1
613516	Clamp - Oil Line	9 2 2	614329	Decal - Zone	5 43 1
613517	Plate - Cover, Gear	13 7 1	614331	Decal - Self Propelled	5 16 1
613529	Shoulder Bolt	9 10 1	614333	Decal - Electric Start	5 6 1
613531	Fuel Line	2 30 1	614426	Washer - Stepped	3 38 2
613531	Gas Line	11 23 1	614427	Cover - Wheel	3 37 2
613532	Cover - Drive, Lower	1 48 1	614430	Bolt - Wheel	3 41 2
613549	Screw	5 23 6	614430	Bolt - Shoulder	1 29 2
613550	Nut - Cable, Self-propelled	5 21 1	614433	Plate - Height Adjust	1 20 2
613551	Screw	5 13 1	614442	Fitting - Grease	3 27 2
613552	Insert - Handle, Cable Side	5 31 1	614443	Ring - Isolator	3 18 2
613553	Screw	5 18 1	614447	Spacer	3 19 2
613555	Screw	5 41 1	614522	Anchor - Cable	1 6 1
613557	Snubber - Belt	2 51 1	614523	Arm - Trans. Engagement	3 11 1
613576	Screw - Guard, Muffler	2 42 1	614524	Plate - Actuator	3 4 1
613601	Insert - Handle	5 33 1	614525	Spring	3 8 1
613625	Washer - Lock	1 12 1	614526	Guide - Belt	3 12 1
613628	Spring - Torsion	9 25 1	614527	Bolt - Shoulder	3 13 1
613641	Gasket - Bowl Retainer	11 4 1	614529	Spring - Extension	3 14 1
613642	Gasket - Fuel Bowl	11 5 1	614600	Shaft - Input	7 4 1
613647	Pilot Jet	11 10 1	614601	Washer	7 6 1
613649	Nozzle	11 12 1	614602	Bearing - Lower	7 7 1
613650	Seal - Throttle Shaft	11 13 1	614603	Bearing - Upper	7 8 1
613651	Seal - Choke Shaft	11 14 1	614604	Ring Gear	7 12 1
613655	Screw - Throttle Valve	11 15 2	614606	Collar	7 10 1
613656	Screw - Choke Valve	11 16 2	614607	Washer	7 20 4
613657	Pivot - Upper Choke Shaft	11 17 1	614608	Key - Holder,	7 21 1
613658	Pivot - Lower Choke Shaft	11 18 1	614609	Collar - Shift	7 22 1
613683	Wire Tie	9 52 1	614610	Slider	7 23 1
613747	Shaft - Governor	9 36 1	614611	Washer	7 17 2
613748	Gasket - Air Filter Base	11 3 1	614613	Ring - Snap	7 19 2
613749	Screw	1 14 1	614614	Ring - Snap	7 24 1
613756	Shoulder Bolt	9 8 1	614615	Ball	7 25 2
613770	Nut	3 2 1	614616	Collar - Sliding	7 26 1
613842	V-Belt	3 1 1	614617	Fork - Shift	7 27 1
613893	Main Jet - High Altitude	11 35 1	614618	Support - Fork	7 29 2
613910	Washer - R.H. Handle Mtg.	1 51 1	614619	Spring	7 31 1
613917	Arm - Front, Height Adjust	1 34 2	614620	Plate	7 32 1
613918	Main Jet	11 11 1	614621	Fork - Clutch	7 33 1
613924	Baffle - Front	1 41 1	614622	Ball	7 35 1
613925	Screw	1 40 3	614625	Screw - Tapping	7 2 1
613944	Blade - 21"	1 38 1	614626	Screw - Tapping	7 3 5
613948	O-Ring	2 31 1	614689	Assembly - Housing	1 42 1
613980	Decal - Lawn-Boy	5 39 1	677525	Assembly - Collar & Plate	1 36 1
614009	Spark Plug	9 46 1	682727	Assembly - Switch	5 9 1
614013	Screw - Set	5 2 2	682776	Relay - Starter	2 27 1
614021	Plate	5 4 1	683179	Assembly - Wheel & Tire	1 31 2
614023	Screw - Thread Forming	5 25 3	683637	Pack - Battery	2 17 1
614037	Decal	12 1 1	683897	Recoil Spring & Keeper	12 6 1
614041	Applique	2 48 1	683899	Assembly - Dog Kit	12 9 1
614043	Spring - Governor	9 26 1	683993	Crankshaft & Conn. Rod	9 34 1
614175	Bowl - Fuel	11 20 1	684022	Bearing - Crankshaft	9 7 2
614176	Screw - Bowl Retainer	11 21 1	684023	Flywheel	9 56 1
614181	Screw - Mounting, Tank	2 12 2	684049	Module - C.D. Ignition	9 55 1
614182	Bracket - Tank, Fuel/Oil	2 11 1	684080	Assy. - Spacer & Oil Nozzle	11 36 1
614239	Hose - Carb Vent	11 22 1	684090	Assy. - Governor Bracket	9 21 1
614245	Pre-Filter	11 30 1	684093	Valve - Fuel, Shut-Off	2 26 1
614271	Cover	2 8 1	684095	Assy. - Housing & Pin	13 11 1
614272	Cover	2 4 1	684097	Assy. - Clutch	13 5 1
614274	Filter	2 3 1	684104	Assembly - Cap, Fuel	2 6 1
614316	Arm - Shift	3 15 1	684105	Assembly - Cap, Oil	2 2 1
614316	Arm - Shift	7 28 1	684115	Alternator	9 51 1
614317	Arm - Clutch	3 16 1	684130	Frame	5 40 1
614317	Arm - Clutch	7 34 1	684150	Knuckle - Handle	5 29 2

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
684151	Guide - Rope	5 38 1	684579	Muffler	2 38 1
684157	Assembly - Guard, Muffler	2 40 1	684581	Assy. - Handle & Decal	5 12 1
684179	High Tension Lead & Cover	9 54 1	684616	Pivot Arm Assy.	3 21 2
684193	Assembly - Magnet	1 11 1	684617	Transmission	3 9 1
684209	Assy. - Cable, Eng. Brake	5 24 1	684618	Assembly - Knob & Spring	3 20 2
684210	Assembly - Cable, Throttle	5 11 1	684622	Assembly - Starter	12 * 1
684212	Assy. - Cable, Gear Select	5 44 1	684645	Assembly - Wheel	3 39 2
684219	Assy. - Spring Arm, R.H.	1 46 1	684645	Assembly - Wheel & Tire	1 27 2
684220	Assy. - Spring Arm, L.H.	1 33 1	684697	Assy. - Cable, Self-propelled	5 34 1
684238	Wire Harness	5 10 1	684698	Assy. - Cover & Terminal	9 53 1
684246	Assembly - Cup, Electronic	2 24 1	684731	Kit - Upper & Lower Case	7 1 1
684272	Assy. - Piston & Ring (Std.)	9 41 1	684732	Bushing Set	7 11 1
684273	Ring Set (Standard)	9 45 1	684733	Gear Set	7 13 1
684275	Oil Pump Kit w/Oil Lines	9 3 1	684734	Gear Set	7 14 1
684276	Short Block	9 * 1	684735	Gear Set	7 15 1
684280	Kit - Gasket	11 * 1	684736	Kit - Shaft, Reduction	7 9 1
684280	Kit - Gasket	11 * 1	684737	Bushing Set	7 18 2
684281	Kit - Float & Needle	11 6 1	684739	Spring & Key - Shift	7 30 2
684282	Needle and Clip	11 7 1	684740	Kit - Axle Shaft	7 16 1
684283	Kit - Idle Needle & Spring	11 8 1	700056	Screw - Guard, Muffler	2 41 1
684284	Kit - Idle Speed	11 9 1	700098	Nut	2 52 1
684288	Kit - Starter & Spring	13 * 1	700748	Screw	1 3 2
684307	Assy. - Piston & Ring	9 41 1	700790	Bumper	5 22 1
684309	Ring Set (0.020" Oversize)	9 45 1	800019	Screw - Bracket to Door	2 14 2
684336	Assembly - Fitting, Oil	2 32 1	16-2219	Cover - Drive, Upper	1 50 1
684365	Brake & Switch	9 14 1	27-6250	Bushing	1 28 4
684366	Switch - Lock, Bag	1 10 1	27-6250	Bushing	3 40 2
684376	Switch - Low Oil	2 1 1	39-5770	Decal - Blade Warning	1 4 1
684394	Charger - Battery	1 18 1	46-6811	Screw - Baffle to Housing	1 24 4
684399	Assembly - Knob, Throttle	5 3 1	47-2900	Bushing	3 23 2
684400	Assy. - Knob, Gear Select	5 1 1	65-2720	Ring - Retaining	3 30 4
684427	Assembly - Cover, Upper	5 5 1	65-4710	Ring - Friction	3 31 2
684429	Assy. - Shroud & Applique	2 49 1	65-4720	Spring - Compression	3 36 2
684437	Kit - Gov. & Oil Pump Lever	9 18 1	65-4730	Washer - Inner Thrust	3 28 2
684445	Lever - Gear Select	5 45 1	65-4740	Washer - Keyed	3 29 4
684446	Lever - Throttle	5 7 1	65-4750	Gear - Pinion 15T	3 35 2
684465	Ramp - Governor	9 40 1	65-4760	Washer - Clutch	3 32 2
684478	Kit - Bowl	11 19 1	66-6040	Key, Rocking - R.H.	3*33 1
684508	Assy. - Fuel/Oil Tank	2 10 1	66-6050	Key, Rocking - L.H.	3 34 1
684548	Kit - Carb. & Gasket	11 * 1	70-9760	Bushing	3 22 2
684559	Assembly - Cover, Air Filter	11 29 1	92-1604	Cap - Hub	3 42 2
684561	Wire Harness	9 39 1	92-1604	Cap - Hub	1 30 2
684562	Harness - Wire, Lower	2 19 1	92-2839	Decal - Warning	1 49 1
684567	Housing - Starter	12 5 1	92-2940	Decal - Warning	5 46 1

[illegible]

MAINTENANCE RECORD

[illegible]