

LAWN-BOY®

20" REAR DISCHARGE, ZONE START EXPORT – WALK BEHIND MOWER

**MODEL NO.10735-3900001 & UP
SELF PROPELLED**

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.


To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Housing - Assembly	1	Transmission Assembly	6-7
Shroud - Assembly	2	Engine Assembly	8-9
Starter Assembly	3	Carburetor Assembly	10
Handle Assembly	4-5	Numeric Parts Index	11-12




C-1548

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	684231	Assembly – Height Adj., RH (Incl. the following item)	1	23	612064	Pinion	2
*	603615	Fitting – Grease	1	24	608030	Washer	2
2	602315	Nut – Lock	6	25	146209	Screw	6
3	612233	Clamp	2	26	608311	Nut	6
4	611503	Screw	2	27	612104	Decal – Cutting Height	2
5	609927	Screw	3	28	153444	Assy. – Knob & Spring	2
7	612363	Bracket – Support, Bag	1	29	610646	Bolt – Shoulder	2
8	611602	Clamp – Rod, Shield Pivot	2	31	683179	Wheel – Front	2
9	609892	Screw	3	32	603620	Washer	2
10	611495	Shield – Trailing	1	33	608833	Bracket – Adjustment, Height	2
11	610026	Rod – Shield, Trailing	1	34	608834	Washer – Adjustment, Height	2
12	609975	Pushnut – Rod, Shield	2	37	682876	Cover – Muffler	1
13	684230	Assembly – Height Adj., LH (Incl. the following item)	1	38	609786	Plate – Support, Crankshaft	1
*	603615	Fitting – Grease	1	39	609471	Screw	3
14	605255	Washer – Felt	6	40	677525	Collar & Plate	1
15	613512	Cover – Wheel	2	41	603164	Nut – Lock, Blade	1
16	683626	Wheel – Rear	2	42	683680	Blade – 20"	1
17	605256	Washer – Bolt, Wheel	4	43	603773	Nut	2
18	603441	Wheel – Bolt, Shoulder	4	44	608418	Screw	4
19	612066	Key – Pinion	2	45	611497	Baffle – Floor, Chute	1
20	612067	Spring – Key, Pinion	2	46	613122	Decal – Emission, Sound	1
21	607676	Ring – Retaining	4	47	92-5411	Assembly – Housing (Incl. Ref. #27 & 49)	1
22	612068	Spacer	4	49	39-5770	Decal – Contact, Blade	1
				50	613121	Decal – Plug, Spark	1

*Not Illustrated




C-1547

SHROUD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	612428	Screw – Mount, Starter	4
2	683639	Assembly – Base, Starter	1
3	682755	Assembly – Cap, Fuel (Incl. following 2 items)	1
*	609150	Baffle	1
*	607213	Gasket	1
4	684500	Assembly – Shroud & Tank (Incl. Ref. #5)	1
5	683077	Assy. – Fuel Shut Off	1
6	611566	Decal	1
7	609420	Gasket – Exhaust	1
8	92-1648	Screw – Muffler Plate to Hsg.	3
9	611849	Screw – Hex. Hd.	1
10	612055	Screw	1
11	611491	Spring – Latch	1

Ref. No.	Part No.	Description	No. Used
12	609892	Screw	1
13	611485	Washer	2
14	611484	Spacer – Stepped	1
15	612658	Knob – Latch, Bag	1
16	611486	Latch – Bag	1
17	611480	Spring – Door	1
18	683039	Door	1
19	611493	Rod – Pivot, Door	1
20	611496	Plate – Hinge	1
21	602315	Nut – Lock	1
22	604604	Grommet – Cover, Belt	2
23	684055	Cover – Belt	1
25	607601	Screw	4
26	92-4941	Plate – Muffler	1
27	611395	Screw	4




C-1337

STARTER

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614172	Decal – Recoil	1	7	612950	Pulley	1
2	684567	Starter Housing & Shaft	1	8	612949	Hub – Starter	1
3	683897	Spring & Keeper	1	9	683899	Kit – Dog	1
4	612825	Handle – Starter	1	*	684622	Starter Assembly (Incl. Ref. #2-3, 6-7 & 9)	1
5	612824	Clip – Rope	1				
6	612432	Rope	1				

*Not Illustrated

HANDLE ASSEMBLY




HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	605546	Palnut – Bails to Handle	3
2	609975	Palnut – Cable to Bail	1
3	684016	Bail – Self Propelled	1
4	612168	Nut – Acorn, Cable to Bail	1
5	683478	Bail – Brake, Engine	1
6	611233	Screw	3
7	602315	Nut – Lock	3
8	146084	Anchor – Conduit	1
9	684014	Cable – Control	1
10	613632	Handle – Top	1
11	684754	Assy. – Cable, Control	1
12	608311	Nut – Lock	2
13	614249	Strap – Tie	4
14	146012	Bolt	2
15	145509	Washer – Lock, Ext. Tooth	2
16	607544	Nut – Wing	2
17	613159	Handle – Lower	1
18	611205	Screw	2
19	609739	Washer – Curved	2
20	153254	Guide – Rope	1
21	611258	Nut	2
22	612698	Decal – Control, Throttle	1
23	612634	Case – Control, Inner	1

Ref. No.	Part No.	Description	No. Used
24	612633	Case – Control, Center	1
25	611777	Case – Control, Outer	1
26	612586	Washer – Spring	2
27	683663	Lever & Knob, Throttle	1
28	611542	Pin	1
29	612564	Pulley	1
30	611543	Screw	2
31	612588	Cable – Throttle	1
32	611799	Screw	2
33	611541	Column	1
34	611530	Hanger – Bag	1
35	602315	Nut – Lock	4
36	602945	Washer	4
37	609891	Screw	4
38	611500	Adaptor	1
39	613155	"S" Clip	3
40	684008	Bar – Latch	1
41	684020	Bag – Grass	1
42	602945	Washer	2
43	146258	Washer – Lock	2
44	145505	Decal – Traction	1
*	684007	Assembly – Adaptor, Bag (Incl. Ref. #35-40)	1

*Not Illustrated

TRANSMISSION ASSEMBLY




TRANSMISSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	611835	O-Ring	1	30	603773	Nut	2
2	609892	Screw - Hex. Hd. Cap	3	31	611839	Washer - Pulley, Drive	1
3	611828	Gearcase - Upper	1	32	611838	Washer - Pulley, Drive	4
4	611834	Guide - Seal	1	33	611836	Pulley Half - Upper	1
5	146093	Plug	1	34	611837	Pulley Half - Lower	1
6	602315	Nut - Lock	3	35	612652	V-Belt	1
7	611830	Packing	2	36	684497	Arm - Shift	1
8	683186	Kit - Bearing & Seal	2	37	145935	Spring - Extension	1
9	608030	Washer - Thrust	1	38	316676	Washer	1
10	381791	Bearing - Thrust	1	39	611833	Bolt - Shoulder	1
11	611878	Washer - Thrust	1	40	611847	Bolt - Shoulder, Idler Plate	1
12	611822	Washer - Thrust	1	41	602315	Nut - Lock	3
13	607676	Ring - Retaining	1	42	611840	Key - Drive Pulley to Shaft	1
14	611814	Pin	1	43	683189	Plate - Idler	1
15	612063	Shaft - Drive	1	44	800358	Bolt - Sq. Neck	1
16	611815	Sleeve - Driven	1	45	145875	Washer	1
17	612406	Gearcase - Lower	1	46	608311	Nut	1
18	611821	Sleeve - Driver	1	47	612065	Screw	1
19	611827	Gasket	1	48	306488	Washer - Lock	1
20	683187	Bearing	1	50	613245	Fork - Shift	1
21	683343	Kit - Worm Wheel & Shaft (Incl. Ref. #22)	1	51	612428	Screw - SEMS	1
22	613454	Wheel - Worm	1	52	684683	Kit - Disc Plate	1
23	609892	Screw - Hex. Hd. Cap	1	53	614183	Collar	1
24	609005	Washer	2	54	614167	Washer - Thrust	2
25	609976	Pulley - Engine	1	55	684473	Bearing	1
26	610345	Screw - Set	1	*	684684	Kit - Collar Bearing & Disk (Incl. Ref. #50-55)	1
27	611845	Pulley - Idler	1	*	684490	Assembly - Transmission (Complete)	1
28	611846	Pulley - Idler, V-Belt	1				
29	610358	Nut - Pulley, Idler	2				

*Not Illustrated


ENGINE ASSEMBLY



ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1	31	610747	Crankshaft	1
2	611509	Actuator – Brake Lever	1	32	611393	Screw	2
3	611214	Spring – Cable, Return	1	33	683911	Set – Needle Bearing	1
4	683968	Assembly – Switch (Incl. Ref. #1, 6, 20, & 56–58)	1	34	607526	Screw	2
5	682683	Assembly – Brake	1	35	614009	Spark Plug	1
6	683821	Wire Lead	1	36	580339	Cover – Terminal	1
7	613529	Bolt – Shoulder	1	37	681678	Wire Lead	1
8	608311	Nut	1	38	683215	C. D. Ignition Module (Incl. Ref. #36–37 & below listed item.)	1
9	683581	Assembly – Brace	1	*	318535	Adhesive	1
10	603014	Bolt	1	39	605120	Grommet	2
11	306407	Washer	1	40	614249	Tie Strap	1
12	602315	Nut	1	41	609609	Bracket – C. D.	1
13	612427	Shroud – Base	1	42	614343	Screw	2
14	611191	Clip – "J"	1	43	683702	Assy. – Cyl./Crankcase Cov. (Incl. Ref. # 46–48, 51, 53 & below listed item.)	1
15	609947	Screw	3	*	610372	Sealant	1
16	683580	Assembly – Flywheel	1	44	609123	Plug	4
17	316959	Washer – Lock	1	45	609420	Gasket – Exhaust	1
18	130743	Nut – Flywheel	1	46	612872	Screw	2
19	609808	Screw	2	47	602587	Plate – Reed	1
20	317893	Tie Strap	1	48	602588	Reed	1
21	681737	Set – Ring	1	49	681831	Bearing – Main	1
*	92–4923	Set – Piston & Ring (Incl. Ref. # 21–23)	1	50	611396	Seal – Oil	1
22	303712	Ring – Retaining	2	51	613110	Screw	2
23	606608	Pin – Wrist	1	52	611192	Bracket – Brake	1
24	92–4925	Assy. – Piston & Conn. Rod (Incl. Ref. #24–27, & 32–33)	1	53	613233	Screw	2
25	92–4927	Assembly – Bearing	1	54	611211	Spring – Brake	1
26	92–4921	Assembly – Connecting Rod (Incl. Ref. #25–27 & 32–33)	1	55	683819	Assembly – Case	1
27	677982	Liner – Split	1	56	306407	Washer	1
28	607199	Key – Flywheel	1	57	92–6353	Screw	1
29	611396	Seal – Oil	1	*	683700	Assembly – Short Block (Incl. Ref. No.21–27, 29–33, & 43–51)	1
30	681830	Bearing – Main	1				

*Not Illustrated



C-1340

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	612505	Vane - Air	1
2	605522	Screw	1
3	610165	Retainer - Speed Control Lever	1
4	612502	Lever - Governor Control	1
5	612757	Collar	1
6	613142	Spring	1
7	308052	Washer	1
8	612504	Base - Air Filter	1
9	612503	Spacer - Filter Base	1
10	609493	Element - Air Filter	1
11	611377	Cover - Air Filter	1
12	610383	Retainer - Cover	1
13	328712	Nut	1
14	314576	Screw	1
15	612974	Filter - Fuel	1
16	614380	Heat Shield	1
17	612507	Screw	2
*	612782	Line - Fuel	1
*	684286	Kit - Throttle Shaft (Incl. Ref. #18-20)	1
18		Shaft - Throttle	1
19		Vane - Throttle	1
20		Screw	1
*	684285	Kit - Idle Needle (Incl. Ref. #21-22)	1
21		Spring - Needle	1

Ref. No.	Part No.	Description	No. Used
22		Needle - Idle	1
23	683783	Kit - Float Assembly (Incl. Ref. #24-27)	1
*	683782	Kit - Bowl (Incl. Ref. #24-25)	1
24		Bowl - Fuel	1
25		Screw	1
*	683778	Kit - Gasket (Incl. Ref. #26 & 27)	1
26		Gasket - Bowl Retainer	1
27		Gasket - Bowl	1
*	683777	Kit - Repair (Incl. Ref. #26-31)	1
28		Plug - Welch	2
29		Shaft - Float	1
30		Inlet - Needle Valve	1
31		Seat - Valve	1
*		Kit - Gasket	1
*	683781	Kit - Shaft, Choke (Incl. Ref. #32-34)	1
32		Valve - Choke	1
33		Spring - Return	1
34		Shaft - Choke	1
35	612574	Gasket Carburetor	2
*	684352	Body - Carburetor (Incl. Ref. #18-34)	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

3316-173

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
130743	Nut - Flywheel	9 18 1	609471	Screw	1 39 3
145505	Decal - Traction	5 44 1	609493	Element - Air Filter	10 10 1
145509	Washer - Lock, Ext. Tooth	5 15 2	609609	Bracket - C. D.	9 41 1
145875	Washer	7 45 1	609739	Washer - Curved	5 19 2
145935	Spring - Extension	7 37 1	609786	Plate - Support, Crankshaft	1 38 1
146012	Bolt	5 14 2	609808	Screw	9 19 2
146084	Anchor - Conduit	5 8 1	609891	Screw	5 37 4
146093	Plug	7 5 1	609892	Screw	1 9 3
146209	Screw	1 25 6	609892	Screw	2 12 1
146258	Washer - Lock	5 43 2	609892	Screw - Hex. Hd. Cap	7 2 3
153254	Guide - Rope	5 20 1	609892	Screw - Hex. Hd. Cap	7 23 1
153444	Assy. - Knob & Spring	1 28 2	609927	Screw	1 5 3
303712	Ring - Retaining	9 22 2	609947	Screw	9 15 3
306407	Washer	9 11 1	609975	Palnut - Cable to Bail	5 2 1
306407	Washer	9 56 1	609975	Pushnut - Rod, Shield	1 12 2
306488	Washer - Lock	7 48 1	609976	Pulley - Engine	7 25 1
308052	Washer	10 7 1	610026	Rod - Shield, Trailing	1 11 1
314576	Screw	10 14 1	610165	Retainer - Speed	10 3 1
316676	Washer	7 38 1	610345	Screw - Set	7 26 1
316959	Washer - Lock	9 17 1	610358	Nut - Pulley, Idler	7 29 2
317893	Tie Strap	9 20 1	610372	Sealant	9 * 1
318535	Adhesive	9 * 1	610383	Retainer - Cover	10 12 1
328712	Nut	10 13 1	610646	Bolt - Shoulder	1 29 2
381791	Bearing - Thrust	7 10 1	610747	Crankshaft	9 31 1
580339	Cover - Terminal	9 36 1	611191	Clip - J	9 14 1
602315	Nut	9 12 1	611192	Bracket - Brake	9 52 1
602315	Nut - Lock	1 2 6	611205	Screw	5 18 2
602315	Nut - Lock	7 6 3	611211	Spring - Brake	9 54 1
602315	Nut - Lock	5 7 3	611213	Retainer	9 1 1
602315	Nut - Lock	2 21 1	611214	Spring - Cable, Return	9 3 1
602315	Nut - Lock	5 35 4	611233	Screw	5 6 3
602315	Nut - Lock	7 41 3	611258	Nut	5 21 2
602587	Plate - Reed	9 47 1	611377	Cover - Air Filter	10 11 1
602588	Reed	9 48 1	611393	Screw	9 32 2
602945	Washer	5 36 4	611395	Screw	2 27 4
602945	Washer	5 42 2	611396	Seal - Oil	9 29 1
603014	Bolt	9 10 1	611396	Seal - Oil	9 50 1
603164	Nut - Lock, Blade	1 41 1	611480	Spring - Door	2 17 1
603441	Wheel - Bolt, Shoulder	1 18 4	611484	Spacer - Stepped	2 14 1
603615	Fitting - Grease	1 * 1	611485	Washer	2 13 2
603615	Fitting - Grease	1 * 1	611486	Latch - Bag	2 16 1
603620	Washer	1 32 2	611491	Spring - Latch	2 11 1
603773	Nut	7 30 2	611493	Rod - Pivot, Door	2 19 1
603773	Nut	1 43 2	611495	Shield - Trailing	1 10 1
604604	Grommet - Cover, Belt	2 22 2	611496	Plate - Hinge	2 20 1
605120	Grommet	9 39 2	611497	Baffle - Floor, Chute	1 45 1
605255	Washer - Felt	1 14 6	611500	Adaptor	5 38 1
605256	Washer - Bolt, Wheel	1 17 4	611503	Screw	1 4 2
605522	Screw	10 2 1	611509	Actuator - Brake Lever	9 2 1
605546	Palnut - Bails to Handle	5 1 3	611530	Hanger - Bag	5 34 1
606608	Pin - Wrist	9 23 1	611541	Column	5 33 1
607199	Key - Flywheel	9 28 1	611542	Pin	5 28 1
607213	Gasket	2 * 1	611543	Screw	5 30 2
607526	Screw	9 34 2	611566	Decal	2 6 1
607544	Nut - Wing	5 16 2	611602	Clamp - Rod, Shield Pivot	1 8 2
607601	Screw	2 25 4	611777	Case - Control, Outer	5 25 1
607676	Ring - Retaining	7 13 1	611799	Screw	5 32 2
607676	Ring - Retaining	1 21 4	611814	Pin	7 14 1
608030	Washer	1 24 2	611815	Sleeve - Driven	7 16 1
608030	Washer - Thrust	7 9 1	611821	Sleeve - Driver	7 18 1
608311	Nut	9 8 1	611822	Washer - Thrust	7 12 1
608311	Nut	1 26 6	611827	Gasket	7 19 1
608311	Nut	7 46 1	611828	Gearcase - Upper	7 3 1
608311	Nut - Lock	5 12 2	611830	Packing	7 7 2
608418	Screw	1 44 4	611833	Bolt - Shoulder	7 39 1
608833	Bracket - Adjustment, Height	1 33 2	611834	Guide - Seal	7 4 1
608834	Washer - Adjustment, Height	1 34 2	611835	O-Ring	7 1 1
609005	Washer	7 24 2	611836	Pulley Half - Upper	7 33 1
609123	Plug	9 44 4	611837	Pulley Half - Lower	7 34 1
609150	Baffle	2 * 1	611838	Washer - Pulley, Drive	7 32 4
609420	Gasket - Exhaust	2 7 1	611839	Washer - Pulley, Drive	7 31 1
609420	Gasket - Exhaust	9 45 1	611840	Key - Drive Pulley to Shaft	7 42 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
611845	Pulley - Idler	7 27 1	681678	Wire Lead	9 37 1
611846	Pulley - Idler, V-Belt	7 28 1	681737	Set - Ring	9 21 1
611847	Bolt - Shoulder, Idler Plate	7 40 1	681830	Bearing - Main	9 30 1
611849	Screw - Hex. Hd.	2 9 1	681831	Bearing - Main	9 49 1
611878	Washer - Thrust	7 11 1	682683	Assembly - Brake	9 5 1
612055	Screw	2 10 1	682755	Assembly - Cap, Fuel	2 3 1
612063	Shaft - Drive	7 15 1	682876	Cover - Muffler	1 37 1
612064	Pinion	1 23 2	683039	Door	2 18 1
612065	Screw	7 47 1	683077	Assy. - Fuel Shut Off	2 5 1
612066	Key - Pinion	1 19 2	683179	Wheel - Front	1 31 2
612067	Spring - Key, Pinion	1 20 2	683186	Kit - Bearing & Seal	7 8 2
612068	Spacer	1 22 4	683187	Bearing	7 20 1
612104	Decal - Cutting Height	1 27 2	683189	Plate - Idler	7 43 1
612168	Nut - Acorn, Cable to Bail	5 4 1	683215	C. D. Ignition Module	9 38 1
612233	Clamp	1 3 2	683343	Kit - Worm Wheel & Shaft	7 21 1
612363	Bracket - Support, Bag	1 7 1	683478	Bail - Brake, Engine	5 5 1
612406	Gearcase - Lower	7 17 1	683580	Assembly - Flywheel	9 16 1
612427	Shroud - Base	9 13 1	683581	Assembly - Brace	9 9 1
612428	Screw - Mount, Starter	2 1 4	683626	Wheel - Rear	1 16 2
612428	Screw - SEMS	7 51 1	683639	Assembly - Base, Starter	2 2 1
612432	Rope	3 6 1	683663	Lever & Knob, Throttle	5 27 1
612502	Lever - Governor Control	10 4 1	683680	Blade - 20"	1 42 1
612503	Spacer - Filter Base	10 9 1	683700	Assembly - Short Block	9 * 1
612504	Base - Air Filter	10 8 1	683702	Assy. - Cyl./Crankcase Cov.	9 43 1
612505	Vane - Air	10 1 1	683777	Kit - Repair	10 * 1
612507	Screw	10 17 2	683778	Kit - Gasket	10 * 1
612564	Pulley	5 29 1	683781	Kit - Shaft, Choke	10 * 1
612574	Gasket Carburetor	10 35 2	683782	Kit - Bowl	10 * 1
612586	Washer - Spring	5 26 2	683783	Kit - Float Assembly	10 23 1
612588	Cable - Throttle	5 31 1	683819	Assembly - Case	9 55 1
612633	Case - Control, Center	5 24 1	683821	Wire Lead	9 6 1
612634	Case - Control, Inner	5 23 1	683897	Spring & Keeper	3 3 1
612652	V-Belt	7 35 1	683899	Kit - Dog	3 9 1
612658	Knob - Latch, Bag	2 15 1	683911	Set - Needle Bearing	9 33 1
612698	Decal - Control, Throttle	5 22 1	683968	Assembly - Switch	9 4 1
612757	Collar	10 5 1	684007	Assembly - Adaptor, Bag	5 * 1
612782	Line - Fuel	10 * 1	684008	Bar - Latch	5 40 1
612824	Clip - Rope	3 5 1	684014	Cable - Control	5 9 1
612825	Handle - Starter	3 4 1	684016	Bail - Self Propelled	5 3 1
612872	Screw	9 46 2	684020	Bag - Grass	5 41 1
612949	Hub - Starter	3 8 1	684055	Cover - Belt	2 23 1
612950	Pulley	3 7 1	684230	Assembly - Height Adj., LH	1 13 1
612974	Filter - Fuel	10 15 1	684231	Assembly - Height Adj., RH	1 1 1
613110	Screw	9 51 2	684285	Kit - Idle Needle	10 * 1
613121	Decal - Plug, Spark	1 50 1	684286	Kit - Throttle Shaft	10 * 1
613122	Decal - Emission, Sound	1 46 1	684352	Body - Carburetor	10 * 1
613142	Spring	10 6 1	684473	Bearing	7 55 1
613155	S Clip	5 39 3	684490	Assembly - Transmission	7 * 1
613159	Handle - Lower	5 17 1	684497	Arm - Shift	7 36 1
613233	Screw	9 53 2	684500	Assembly - Shroud & Tank	2 4 1
613245	Fork - Shift	7 50 1	684567	Starter Housing & Shaft	3 2 1
613454	Wheel - Worm	7 22 1	684622	Starter Assembly	3 * 1
613512	Cover - Wheel	1 15 2	684683	Kit - Disc Plate	7 52 1
613529	Bolt - Shoulder	9 7 1	684684	Kit - Collar Bearing & Disk	7 * 1
613632	Handle - Top	5 10 1	684754	Assy. - Cable, Control	5 11 1
614009	Spark Plug	9 35 1	800358	Bolt - Sq. Neck	7 44 1
614167	Washer - Thrust	7 54 2	39-5770	Decal - Contact, Blade	1 49 1
614172	Decal - Recoil	3 1 1	92-1648	Screw - Muffler Plate to Hsg.	2 8 3
614183	Collar	7 53 1	92-4921	Assembly - Connecting Rod	9 26 1
614249	Strap - Tie	5 13 4	92-4923	Set - Piston & Ring	9 * 1
614249	Tie Strap	9 40 1	92-4925	Assy. - Piston & Conn. Rod	9 24 1
614343	Screw	9 42 2	92-4927	Assembly - Bearing	9 25 1
614380	Heat Shield	10 16 1	92-4941	Plate - Muffler	2 26 1
677525	Collar & Plate	1 40 1	92-5411	Assembly - Housing	1 47 1
677982	Liner - Split	9 27 1	92-6353	Screw	9 57 1

[illegible]

MAINTENANCE RECORD

[illegible]