FORM NO. 3316–173

LAWN-BOY®

20" REAR DISCHARGE, ZONE START EXPORT –WALK BEHIND MOWER

MODEL NO.10735–3900001 & UP
SELF PROPELLED

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN–BOY owners as quickly as possible, minor changes are incorporated into LAWN–BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN–BOY Distributor or his Authorized LAWN–BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck . In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:


1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page
Housing – Assembly	1
Shroud – Assembly	2
Starter Assembly	3
Handle Assembly	4–5
Transmission Assembly	6–7
Engine Assembly	8–9
Carburetor Assembly	10
Numeric Parts Index	11–12

©Lawn–Boy, Inc.–1993
All Rights Reserved




C–1548

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	684231	Assembly – Height Adj., RH (Incl. the following item)	1
*	603615	Fitting – Grease	1
2	602315	Nut – Lock	6
3	612233	Clamp	2
4	611503	Screw	2
5	609927	Screw	3
7	612363	Bracket – Support, Bag	1
8	611602	Clamp – Rod, Shield Pivot	2
9	609892	Screw	3
10	611495	Shield – Trailing	1
11	610026	Rod – Shield, Trailing	1
12	609975	Pushnut – Rod, Shield	2
13	684230	Assembly – Height Adj., LH (Incl. the following item)	1
*	603615	Fitting – Grease	1
14	605255	Washer – Felt	6
15	613512	Cover – Wheel	2
16	683626	Wheel – Rear	2
17	605256	Washer – Bolt, Wheel	4
18	603441	Wheel – Bolt, Shoulder	4
19	612066	Key – Pinion	2
20	612067	Spring – Key, Pinion	2
21	607676	Ring – Retaining	4
22	612068	Spacer	4

Ref. No.	Part No.	Description	No. Used
23	612064	Pinion	2
24	608030	Washer	2
25	146209	Screw	6
26	608311	Nut	6
27	612104	Decal – Cutting Height	2
28	153444	Assy. – Knob & Spring	2
29	610646	Bolt – Shoulder	2
31	683179	Wheel – Front	2
32	603620	Washer	2
33	608833	Bracket – Adjustment, Height	2
34	608834	Washer – Adjustment, Height	2
37	682876	Cover – Muffler	1
38	609786	Plate – Support, Crankshaft	1
39	609471	Screw	3
40	677525	Collar & Plate	1
41	603164	Nut – Lock, Blade	1
42	683680	Blade – 20"	1
43	603773	Nut	2
44	608418	Screw	4
45	611497	Baffle – Floor, Chute	1
46	613122	Decal – Emission, Sound	1
47	92–5411	Assembly – Housing (Incl. Ref. #27 & 49)	1
49	39–5770	Decal – Contact, Blade	1
50	613121	Decal – Plug, Spark	1

*Not Illustrated




C–1547

SHROUD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	612428	Screw – Mount, Starter	4
2	683639	Assembly – Base, Starter	1
3	682755	Assembly – Cap, Fuel (Incl. following 2 items)	1
*	609150	Baffle	1
*	607213	Gasket	1
4	684500	Asembly – Shroud & Tank (Incl. Ref. #5)	1
5	683077	Assy. – Fuel Shut Off	1
6	611566	Decal	1
7	609420	Gasket – Exhaust	1
8	92–1648	Screw – Muffler Plate to Hsg.	3
9	611849	Screw – Hex. Hd.	1
10	612055	Screw	1
11	611491	Spring – Latch	1

Ref. No.	Part No.	Description	No. Used
12	609892	Screw	1
13	611485	Washer	2
14	611484	Spacer – Stepped	1
15	612658	Knob – Latch, Bag	1
16	611486	Latch – Bag	1
17	611480	Spring – Door	1
18	683039	Door	1
19	611493	Rod – Pivot, Door	1
20	611496	Plate – Hinge	1
21	602315	Nut – Lock	1
22	604604	Grommet – Cover, Belt	2
23	684055	Cover – Belt	1
25	607601	Screw	4
26	92–4941	Plate – Muffler	1
27	611395	Screw	4



C–1337


STARTER

Ref. No.	Part No.	Description	No. Used
1	614172	Decal – Recoil	1
2	684567	Starter Housing & Shaft	1
3	683897	Spring & Keeper	1
4	612825	Handle – Starter	1
5	612824	Clip – Rope	1
6	612432	Rope	1

Ref. No.	Part No.	Description	No. Used
7	612950	Pulley	1
8	612949	Hub – Starter	1
9	683899	Kit – Dog	1
*	684622	Starter Assembly (Incl. Ref. #2–3, 6–7 & 9)	1

*Not Illustrated

HANDLE ASSEMBLY




C–1545

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	605546	Palnut – Bails to Handle	3
2	609975	Palnut – Cable to Bail	1
3	684016	Bail – Self Propelled	1
4	612168	Nut – Acorn, Cable to Bail	1
5	683478	Bail – Brake, Engine	1
6	611233	Screw	3
7	602315	Nut – Lock	3
8	146084	Anchor – Conduit	1
9	684014	Cable – Control	1
10	613632	Handle – Top	1
11	684754	Assy. – Cable, Control	1
12	608311	Nut – Lock	2
13	614249	Strap – Tie	4
14	146012	Bolt	2
15	145509	Washer – Lock, Ext. Tooth	2
16	607544	Nut – Wing	2
17	613159	Handle – Lower	1
18	611205	Screw	2
19	609739	Washer – Curved	2
20	153254	Guide – Rope	1
21	611258	Nut	2
22	612698	Decal – Control, Throttle	1
23	612634	Case – Control, Inner	1
24	612633	Case – Control, Center	1
25	611777	Case – Control, Outer	1
26	612586	Washer – Spring	2
27	683663	Lever & Knob, Throttle	1
28	611542	Pin	1
29	612564	Pulley	1
30	611543	Screw	2
31	612588	Cable – Throttle	1
32	611799	Screw	2
33	611541	Column	1
34	611530	Hanger – Bag	1
35	602315	Nut – Lock	4
36	602945	Washer	4
37	609891	Screw	4
38	611500	Adaptor	1
39	613155	"S" Clip	3
40	684008	Bar – Latch	1
41	684020	Bag – Grass	1
42	602945	Washer	2
43	146258	Washer – Lock	2
44	145505	Decal – Traction	1
*	684007	Assembly – Adaptor, Bag (Incl. Ref. #35–40)	1

*Not Illustrated

TRANSMISSION ASSEMBLY




C–1546

TRANSMISSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	611835	O–Ring	1
2	609892	Screw – Hex. Hd. Cap	3
3	611828	Gearcase – Upper	1
4	611834	Guide – Seal	1
5	146093	Plug	1
6	602315	Nut – Lock	3
7	611830	Packing	2
8	683186	Kit – Bearing & Seal	2
9	608030	Washer – Thrust	1
10	381791	Bearing – Thrust	1
11	611878	Washer – Thrust	1
12	611822	Washer – Thrust	1
13	607676	Ring – Retaining	1
14	611814	Pin	1
15	612063	Shaft – Drive	1
16	611815	Sleeve – Driven	1
17	612406	Gearcase – Lower	1
18	611821	Sleeve – Driver	1
19	611827	Gasket	1
20	683187	Bearing	1
21	683343	Kit – Worm Wheel & Shaft (Incl. Ref. #22)	1
22	613454	Wheel – Worm	1
23	609892	Screw – Hex. Hd. Cap	1
24	609005	Washer	2
25	609976	Pulley – Engine	1
26	610345	Screw – Set	1
27	611845	Pulley – Idler	1
28	611846	Pulley – Idler, V–Belt	1
29	610358	Nut – Pulley, Idler	2
30	603773	Nut	2
31	611839	Washer – Pulley, Drive	1
32	611838	Washer – Pulley, Drive	4
33	611836	Pulley Half – Upper	1
34	611837	Pulley Half – Lower	1
35	612652	V–Belt	1
36	684497	Arm – Shift	1
37	145935	Spring – Extension	1
38	316676	Washer	1
39	611833	Bolt – Shoulder	1
40	611847	Bolt – Shoulder, Idler Plate	1
41	602315	Nut – Lock	3
42	611840	Key – Drive Pulley to Shaft	1
43	683189	Plate – Idler	1
44	800358	Bolt – Sq. Neck	1
45	145875	Washer	1
46	608311	Nut	1
47	612065	Screw	1
48	306488	Washer – Lock	1
50	613245	Fork – Shift	1
51	612428	Screw – SEMS	1
52	684683	Kit – Disc Plate	1
53	614183	Collar	1
54	614167	Washer – Thrust	2
55	684473	Bearing	1
*	684684	Kit – Collar Bearing & Disk (Incl. Ref. #50–55)	1
*	684490	Assembly – Transmission (Complete)	1

*Not Illustrated

ENGINE ASSEMBLY




C–1338

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1
2	611509	Actuator – Brake Lever	1
3	611214	Spring – Cable, Return	1
4	683968	Assembly – Switch (Incl. Ref. #1, 6, 20, & 56–58)	1
5	682683	Assembly – Brake	1
6	683821	Wire Lead	1
7	613529	Bolt – Shoulder	1
8	608311	Nut	1
9	683581	Assembly – Brace	1
10	603014	Bolt	1
11	306407	Washer	1
12	602315	Nut	1
13	612427	Shroud – Base	1
14	611191	Clip – "J"	1
15	609947	Screw	3
16	683580	Assembly – Flywheel	1
17	316959	Washer – Lock	1
18	130743	Nut – Flywheel	1
19	609808	Screw	2
20	317893	Tie Strap	1
21	681737	Set – Ring	1
*	92–4923	Set – Piston & Ring (Incl. Ref.# 21–23)	1
22	303712	Ring – Retaining	2
23	606608	Pin – Wrist	1
24	92–4925	Assy.– Piston & Conn. Rod (Incl. Ref. #24–27, & 32–33)	1
25	92–4927	Assembly – Bearing	1
26	92–4921	Assembly – Connecting Rod (Incl. Ref. #25–27 & 32–33)	1
27	677982	Liner – Split	1
28	607199	Key – Flywheel	1
29	611396	Seal – Oil	1
30	681830	Bearing – Main	1

Ref. No.	Part No.	Description	No. Used
31	610747	Crankshaft	1
32	611393	Screw	2
33	683911	Set – Needle Bearing	1
34	607526	Screw	2
35	614009	Spark Plug	1
36	580339	Cover – Terminal	1
37	681678	Wire Lead	1
38	683215	C. D. Ignition Module (Incl. Ref. #36–37 & below listed item.)	1
*	318535	Adhesive	1
39	605120	Grommet	2
40	614249	Tie Strap	1
41	609609	Bracket – C. D.	1
42	614343	Screw	2
43	683702	Assy. – Cyl./Crankcase Cov. (Incl. Ref. # 46–48, 51, 53 & below listed item.)	1
*	610372	Sealant	1
44	609123	Plug	4
45	609420	Gasket – Exhaust	1
46	612872	Screw	2
47	602587	Plate – Reed	1
48	602588	Reed	1
49	681831	Bearing – Main	1
50	611396	Seal – Oil	1
51	613110	Screw	2
52	611192	Bracket – Brake	1
53	613233	Screw	2
54	611211	Spring – Brake	1
55	683819	Assembly – Case	1
56	306407	Washer	1
57	92–6353	Screw	1
*	683700	Assembly – Short Block (Incl. Ref. No.21–27, 29–33, & 43–51)	1

*Not Illustrated



C–1340

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	612505	Vane – Air	1
2	605522	Screw	1
3	610165	Retainer – Speed Control Lever	1
4	612502	Lever – Governor Control	1
5	612757	Collar	1
6	613142	Spring	1
7	308052	Washer	1
8	612504	Base – Air Filter	1
9	612503	Spacer – Filter Base	1
10	609493	Element – Air Filter	1
11	611377	Cover – Air Filter	1
12	610383	Retainer – Cover	1
13	328712	Nut	1
14	314576	Screw	1
15	612974	Filter – Fuel	1
16	614380	Heat Shield	1
17	612507	Screw	2
*	612782	Line – Fuel	1
*	684286	Kit – Throttle Shaft (Incl. Ref. #18–20)	1
18		Shaft – Throttle	1
19		Vane – Throttle	1
20		Screw	1
*	684285	Kit – Idle Needle (Incl. Ref. #21–22)	1
21		Spring – Needle	1

Ref. No.	Part No.	Description	No. Used
22		Needle – Idle	1
23	683783	Kit – Float Assembly (Incl. Ref. #24–27)	1
*	683782	Kit – Bowl (Incl. Ref. #24–25)	1
24		Bowl – Fuel	1
25		Screw	1
*	683778	Kit – Gasket (Incl. Ref. #26 & 27)	1
26		Gasket – Bowl Retainer	1
27		Gasket – Bowl	1
*	683777	Kit – Repair (Incl. Ref. #26–31)	1
28		Plug – Welch	2
29		Shaft – Float	1
30		Inlet – Needle Valve	1
31		Seat – Valve	1
*		Kit – Gasket	1
*	683781	Kit – Shaft, Choke (Incl. Ref. #32–34)	1
32		Valve – Choke	1
33		Spring – Return	1
34		Shaft – Choke	1
35	612574	Gasket Carburetor	2
*	684352	Body – Carburetor (Incl. Ref. #18–34)	1

*Not Illustrated

LAWN–BOY PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
130743	Nut – Flywheel	9	18	1
145505	Decal – Traction	5	44	1
145509	Washer – Lock, Ext. Tooth	5	15	2
145875	Washer	7	45	1
145935	Spring – Extension	7	37	1
146012	Bolt	5	14	2
146084	Anchor – Conduit	5	8	1
146093	Plug	7	5	1
146209	Screw	1	25	6
146258	Washer – Lock	5	43	2
153254	Guide – Rope	5	20	1
153444	Assy. – Knob & Spring	1	28	2
303712	Ring – Retaining	9	22	2
306407	Washer	9	11	1
306407	Washer	9	56	1
306488	Washer – Lock	7	48	1
308052	Washer	10	7	1
314576	Screw	10	14	1
316676	Washer	7	38	1
316959	Washer – Lock	9	17	1
317893	Tie Strap	9	20	1
318535	Adhesive	9	*	1
328712	Nut	10	13	1
381791	Bearing – Thrust	7	10	1
580339	Cover – Terminal	9	36	1
602315	Nut	9	12	1
602315	Nut – Lock	1	2	6
602315	Nut – Lock	7	6	3
602315	Nut – Lock	5	7	3
602315	Nut – Lock	2	21	1
602315	Nut – Lock	5	35	4
602315	Nut – Lock	7	41	3
602587	Plate – Reed	9	47	1
602588	Reed	9	48	1
602945	Washer	5	36	4
602945	Washer	5	42	2
603014	Bolt	9	10	1
603164	Nut – Lock, Blade	1	41	1
603441	Wheel – Bolt, Shoulder	1	18	4
603615	Fitting – Grease	1	*	1
603615	Fitting – Grease	1	*	1
603620	Washer	1	32	2
603773	Nut	7	30	2
603773	Nut	1	43	2
604604	Grommet – Cover, Belt	2	22	2
605120	Grommet	9	39	2
605255	Washer – Felt	1	14	6
605256	Washer – Bolt, Wheel	1	17	4
605522	Screw	10	2	1
605546	Palnut – Bails to Handle	5	1	3
606608	Pin – Wrist	9	23	1
607199	Key – Flywheel	9	28	1
607213	Gasket	2	*	1
607526	Screw	9	34	2
607544	Nut – Wing	5	16	2
607601	Screw	2	25	4
607676	Ring – Retaining	7	13	1
607676	Ring – Retaining	1	21	4
608030	Washer	1	24	2
608030	Washer – Thrust	7	9	1
608311	Nut	9	8	1
608311	Nut	1	26	6
608311	Nut	7	46	1
608311	Nut – Lock	5	12	2
608418	Screw	1	44	4
608833	Bracket – Adjustment, Height	1	33	2
608834	Washer – Adjustment, Height	1	34	2
609005	Washer	7	24	2
609123	Plug	9	44	4
609150	Baffle	2	*	1
609420	Gasket – Exhaust	2	7	1
609420	Gasket – Exhaust	9	45	1
609471	Screw	1	39	3
609493	Element – Air Filter	10	10	1
609609	Bracket – C. D.	9	41	1
609739	Washer – Curved	5	19	2
609786	Plate – Support, Crankshaft	1	38	1
609808	Screw	9	19	2
609891	Screw	5	37	4
609892	Screw	1	9	3
609892	Screw	2	12	1
609892	Screw – Hex. Hd. Cap	7	2	3
609892	Screw – Hex. Hd. Cap	7	23	1
609927	Screw	1	5	3
609947	Screw	9	15	3
609975	Palnut – Cable to Bail	5	2	1
609975	Pushnut – Rod, Shield	1	12	2
609976	Pulley – Engine	7	25	1
610026	Rod – Shield, Trailing	1	11	1
610165	Retainer – Speed	10	3	1
610345	Screw – Set	7	26	1
610358	Nut – Pulley, Idler	7	29	2
610372	Sealant	9	*	1
610383	Retainer – Cover	10	12	1
610646	Bolt – Shoulder	1	29	2
610747	Crankshaft	9	31	1
611191	Clip – J	9	14	1
611192	Bracket – Brake	9	52	1
611205	Screw	5	18	2
611211	Spring – Brake	9	54	1
611213	Retainer	9	1	1
611214	Spring – Cable, Return	9	3	1
611233	Screw	5	6	3
611258	Nut	5	21	2
611377	Cover – Air Filter	10	11	1
611393	Screw	9	32	2
611395	Screw	2	27	4
611396	Seal – Oil	9	29	1
611396	Seal – Oil	9	50	1
611480	Spring – Door	2	17	1
611484	Spacer – Stepped	2	14	1
611485	Washer	2	13	2
611486	Latch – Bag	2	16	1
611491	Spring – Latch	2	11	1
611493	Rod – Pivot, Door	2	19	1
611495	Shield – Trailing	1	10	1
611496	Plate – Hinge	2	20	1
611497	Baffle – Floor, Chute	1	45	1
611500	Adaptor	5	38	1
611503	Screw	1	4	2
611509	Actuator – Brake Lever	9	2	1
611530	Hanger – Bag	5	34	1
611541	Column	5	33	1
611542	Pin	5	28	1
611543	Screw	5	30	2
611566	Decal	2	6	1
611602	Clamp – Rod, Shield Pivot	1	8	2
611777	Case – Control, Outer	5	25	1
611799	Screw	5	32	2
611814	Pin	7	14	1
611815	Sleeve – Driven	7	16	1
611821	Sleeve – Driver	7	18	1
611822	Washer – Thrust	7	12	1
611827	Gasket	7	19	1
611828	Gearcase – Upper	7	3	1
611830	Packing	7	7	2
611833	Bolt – Shoulder	7	39	1
611834	Guide – Seal	7	4	1
611835	O–Ring	7	1	1
611836	Pulley Half – Upper	7	33	1
611837	Pulley Half – Lower	7	34	1
611838	Washer – Pulley, Drive	7	32	4
611839	Washer – Pulley, Drive	7	31	1
611840	Key – Drive Pulley to Shaft	7	42	1

*Not Illustrated

LAWN–BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
611845	Pulley – Idler	7	27	1
611846	Pulley – Idler, V–Belt	7	28	1
611847	Bolt – Shoulder, Idler Plate	7	40	1
611849	Screw – Hex. Hd.	2	9	1
611878	Washer – Thrust	7	11	1
612055	Screw	2	10	1
612063	Shaft – Drive	7	15	1
612064	Pinion	1	23	2
612065	Screw	7	47	1
612066	Key – Pinion	1	19	2
612067	Spring – Key, Pinion	1	20	2
612068	Spacer	1	22	4
612104	Decal – Cutting Height	1	27	2
612168	Nut – Acorn, Cable to Bail	5	4	1
612233	Clamp	1	3	2
612363	Bracket – Support, Bag	1	7	1
612406	Gearcase – Lower	7	17	1
612427	Shroud – Base	9	13	1
612428	Screw – Mount, Starter	2	1	4
612428	Screw – SEMS	7	51	1
612432	Rope	3	6	1
612502	Lever – Governor Control	10	4	1
612503	Spacer – Filter Base	10	9	1
612504	Base – Air Filter	10	8	1
612505	Vane – Air	10	1	1
612507	Screw	10	17	2
612564	Pulley	5	29	1
612574	Gasket Carburetor	10	35	2
612586	Washer – Spring	5	26	2
612588	Cable – Throttle	5	31	1
612633	Case – Control, Center	5	24	1
612634	Case – Control, Inner	5	23	1
612652	V–Belt	7	35	1
612658	Knob – Latch, Bag	2	15	1
612698	Decal – Control, Throttle	5	22	1
612757	Collar	10	5	1
612782	Line – Fuel	10	*	1
612824	Clip – Rope	3	5	1
612825	Handle – Starter	3	4	1
612872	Screw	9	46	2
612949	Hub – Starter	3	8	1
612950	Pulley	3	7	1
612974	Filter – Fuel	10	15	1
613110	Screw	9	51	2
613121	Decal – Plug, Spark	1	50	1
613122	Decal – Emission, Sound	1	46	1
613142	Spring	10	6	1
613155	S Clip	5	39	3
613159	Handle – Lower	5	17	1
613233	Screw	9	53	2
613245	Fork – Shift	7	50	1
613454	Wheel – Worm	7	22	1
613512	Cover – Wheel	1	15	2
613529	Bolt – Shoulder	9	7	1
613632	Handle – Top	5	10	1
614009	Spark Plug	9	35	1
614167	Washer – Thrust	7	54	2
614172	Decal – Recoil	3	1	1
614183	Collar	7	53	1
614249	Strap – Tie	5	13	4
614249	Tie Strap	9	40	1
614343	Screw	9	42	2
614380	Heat Shield	10	16	1
677525	Collar & Plate	1	40	1
677982	Liner – Split	9	27	1
681678	Wire Lead	9	37	1
681737	Set – Ring	9	21	1
681830	Bearing – Main	9	30	1
681831	Bearing – Main	9	49	1
682683	Assembly – Brake	9	5	1
682755	Assembly – Cap, Fuel	2	3	1
682876	Cover – Muffler	1	37	1
683039	Door	2	18	1
683077	Assy. – Fuel Shut Off	2	5	1
683179	Wheel – Front	1	31	2
683186	Kit – Bearing & Seal	7	8	2
683187	Bearing	7	20	1
683189	Plate – Idler	7	43	1
683215	C. D. Ignition Module	9	38	1
683343	Kit – Worm Wheel & Shaft	7	21	1
683478	Bail – Brake, Engine	5	5	1
683580	Assembly – Flywheel	9	16	1
683581	Assembly – Brace	9	9	1
683626	Wheel – Rear	1	16	2
683639	Assembly – Base, Starter	2	2	1
683663	Lever & Knob, Throttle	5	27	1
683680	Blade – 20"	1	42	1
683700	Assembly – Short Block	9	*	1
683702	Assy. – Cyl./Crankcase Cov.	9	43	1
683777	Kit – Repair	10	*	1
683778	Kit – Gasket	10	*	1
683781	Kit – Shaft, Choke	10	*	1
683782	Kit – Bowl	10	*	1
683783	Kit – Float Assembly	10	23	1
683819	Assembly – Case	9	55	1
683821	Wire Lead	9	6	1
683897	Spring & Keeper	3	3	1
683899	Kit – Dog	3	9	1
683911	Set – Needle Bearing	9	33	1
683968	Assembly – Switch	9	4	1
684007	Assembly – Adaptor, Bag	5	*	1
684008	Bar – Latch	5	40	1
684014	Cable – Control	5	9	1
684016	Bail – Self Propelled	5	3	1
684020	Bag – Grass	5	41	1
684055	Cover – Belt	2	23	1
684230	Assembly – Height Adj., LH	1	13	1
684231	Assembly – Height Adj., RH	1	1	1
684285	Kit – Idle Needle	10	*	1
684286	Kit – Throttle Shaft	10	*	1
684352	Body – Carburetor	10	*	1
684473	Bearing	7	55	1
684490	Assembly – Transmission	7	*	1
684497	Arm – Shift	7	36	1
684500	Asembly – Shroud & Tank	2	4	1
684567	Starter Housing & Shaft	3	2	1
684622	Starter Assembly	3	*	1
684683	Kit – Disc Plate	7	52	1
684684	Kit – Collar Bearing & Disk	7	*	1
684754	Assy. – Cable, Control	5	11	1
800358	Bolt – Sq. Neck	7	44	1
39–5770	Decal – Contact, Blade	1	49	1
92–1648	Screw – Muffler Plate to Hsg.	2	8	3
92–4921	Assembly – Connecting Rod	9	26	1
92–4923	Set – Piston & Ring	9	*	1
92–4925	Assy.– Piston & Conn. Rod	9	24	1
92–4927	Assembly – Bearing	9	25	1
92–4941	Plate – Muffler	2	26	1
92–5411	Assembly – Housing	1	47	1
92–6353	Screw	9	57	1

*Not Illustrated

MAINTENANCE RECORD

Date								

MAINTENANCE RECORD

Date								