



Titan Z5200 Zero-Turn-Radius Riding Mower

Model No. 74818 - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Seat Assembly	3	Crankcase Assembly Kohler SV830-0014	23
Frame Assembly	4	Oil Pan and Lubrication Assembly Kohler SV830-0014	24
Motion Control and Brake Assembly	6	Head, Valve and Breather Assembly Kohler SV830-0014	25
Fuel Tank Assembly	7	Ignition and Electrical Assembly Kohler SV830-0014	26
Engine Assembly	8	Blower Housing Assembly Kohler SV830-0014	27
Transmission Assembly	9	Starter Assembly Kohler SV830-0014	28
LH Transmission Assembly No. 109-3372	10	Fuel System Assembly Kohler SV830-0014	29
RH Transmission Assembly No. 109-3371	12	Engine Control Assembly Kohler SV830-0014	30
52 Inch Deck Assembly	14	Air Intake and Filtration Assembly Kohler SV830-0014	31
52 Inch Deck Assembly No. 109-6254	15	Decals Kohler SV830-0014	32
52 Inch Deck and Discharge Chute Assembly	16	Attachments and Accessories List	33
Anti-Scalp Roller Assembly No. 109-6388	17		
Cutter Housing Assembly No. 109-8744	18		
Washerout Port Assembly No. 109-6393	19		
Rubber Deflector Assembly No. 114-1651	20		
Electrical Assembly	21		
Crankshaft Assembly Kohler SV830-0014	22		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- ❶ Not illustrated
- ❷ Obtain from your local Kohler dealer

- ❸ Not serviced separately



Seat Assembly


Ref	Part No.	Qty.	Description
1	109-6916	1	Seat Plate ASM
2	109-2628	1	Cable-Stop, Seat
3	321-5	2	Screw-HH
4	104-7201	2	Nut-HF
5	109-6184	1	Seat ASM
5:1	107-1880	1	Seat Track Kit
5:2	109-6381	1	Seat
5:6		1	Armrest Kit
5:6:1	110-6569	1	LH Armrest Kit
5:6:2	110-6570	1	RH Armrest Kit
5:6:3	108-6179	6	Screw-HSBH
6	104-8300	8	Nut-Flange, NI
7	103-9376	2	Bumper-Seat
8	27-0410	2	Screw-Shoulder
9	99-2385	1	Decal
10	109-6016	1	Decal-Service Aid



Frame Assembly

Ref	Part No.	Qty.	Description
1	109-8825	1	Frame ASM
1:2	109-6008	2	Decal-Drive Release
1:3	106-5517	2	Decal-Surface, Hot
1:4	109-8965	1	Decal-Safety
2	109-8845	1	Seat Box ASM
2:2	109-9182	1	Decal-Motion Control
2:3	109-9173	1	Decal-Control Brake
2:4	109-9120	1	Decal-Fuse Block
2:5	109-6014	1	Decal-Belt Routing
2:6	109-6210	1	Decal-Danger
3	32144-70	16	Screw-HWHTF
4	109-3678	4	Bearing-Ball
5	109-6218-01	2	Caster Fork ASM
6	109-3724	2	Washer
7	3234-47	5	Screw-HHF
8	109-6405	2	Caster Wheel ASM
8:1	105-1863	1	Wheel-Caster
8:2	104-3667	1	Spanner-Wheel
8:3	325-20	1	Screw-HH
8:4	92-2651	2	Washer
8:5	3296-45	1	Nut-Lock, NI
9	109-3667	4	Bearing-Flange
10	104-8300	21	Nut-Flange, NI
11	322-5	10	Screw-HH


Ref	Part No.	Qty.	Description
12	109-6045-03	1	Bracket-Tank Mount
13	3230-23	2	Screw-CARR
14	109-6867-03	1	Bracket-Rear Tank, LH
15	109-3406-03	1	Bracket-Rear Console, RH
16	109-3381-03	1	Guard-Engine, LH
17	109-3391-03	1	Guard-Engine, RH
18	109-5444-03	1	Casting-Rear
19	109-5432	1	Panel-Front
20	109-5441	1	Fender-LH
21	109-5442	1	Fender-RH
22	109-8870-03	1	Front Shaft ASM
23	109-8871-03	1	Rear Shaft ASM
24	114-1658-03	1	Guard-Muffler
25	9266714	6	Screw-HWH
26	3234-5	6	Screw-HHF
27	104-8301	4	Nut-Flange, NI
28	3231-9	4	Screw-CARR
29	3256-3	2	Washer-Flat
30	109-8758	1	Height Adjustment ASM
30:2	109-8759	1	Decal-Cut Height
31	109-5819	2	Pin-Clevis
32	3256-26	3	Washer-Flat
33	32120-47	3	Ring-Retaining, External
34	109-8755	1	Stop-Height Adjust



Motion Control and Brake Assembly

Ref	Part No.	Qty.	Description
1	109-6915	1	LH Motion Control Pivot ASM
2	109-6914	1	RH Motion Control Pivot ASM
3	103-9928	4	Bearing
4	52-2900	8	Washer-Plastic
5	109-3689	2	Post-Lever Mount
6	5-0838	4	Washer
7	323-9	4	Screw-HH
8	104-8301	4	Nut-Flange, NI
9	109-7098	1	RH Lever And Grip ASM
9:2	109-5192	1	Grip-Control Lever
10	109-7099	1	LH Lever And Grip ASM
10:2	109-5192	1	Grip-Control Lever
11	98-5975	4	Washer-Belleville
12	323-6	4	Screw-HH
13	109-3414	2	Rod-Steering
14	2411-53	2	Bearing-Rod End, LH
15	322-6	2	Screw-HH
16	104-8300	4	Nut-Flange, NI
17	109-3728	2	Nut-Rod Adjustment
18	37-8771	2	Bolt-Shoulder
19	3220-2	2	Nut-Jam
20	3220-20	2	Nut-Jam
21	109-6220	2	Brake Pivot ASM
22	109-3705	2	Pin-Control Pivot


Ref	Part No.	Qty.	Description
23	3272-10	2	Pin-Cotter
24	32128-20	12	Nut-HF
25	1-403180	4	Screw-HH
26	109-5957	2	Damper-Motion Control
27	109-5825	1	Tube-Brake Pivot
28	109-5918	1	Lever ASM
28:2	1-633268	1	Grip-Lever, Brake
29	107-7581	2	Bushing-Flange, Keyed
30	109-5824	1	Bellcrank ASM
31	701197	4	E-Ring
32	109-5834	1	Spacer
33	109-5868	1	Bolt-CARR
34	104-7201	1	Nut-HF
35	109-5914	1	Spacer
36	109-8765	1	Brake Shaft ASM
37	109-6907	2	Link-Brake Actuation
38	109-5833	1	Arm-Brake
39	99-4958	1	Spacer
40	109-6887	2	Pin-Clevis
41	1-603693	2	Spring-Extension



Fuel Tank Assembly


Ref	Part No.	Qty.	Description
1	109-5510	1	Fuel Tank ASM
1:1	103-2605	1	Fitting-Fuel, Bulkhead
1:2	109-0346	1	Cap-Fuel, Gas
1:3	109-3412	1	Tank-Fuel
2	3230-3	2	Screw-CARR
3	3256-23	2	Washer-Flat
4	1-633349	2	Spring-Tank, Fuel
5	3296-47	2	Nut-Lock, NI
6	3230-16	1	Screw-CARR
7	104-8300	1	Nut-Flange, NI
8	1-303077	4	Clamp
9	105-1853	1	Clamp-Hose
10	109-0304	1	Hose-Fuel
11	1-603770	1	Valve-Fuel
12	109-0286	1	Hose-Fuel

--	--	--	--



Engine Assembly


Ref	Part No.	Qty.	Description
② ③ 1		1	Engine-Kohler, Sv830-0014
2	5-7280	1	Key
3	109-3386	1	Sheave-Split Steel
4	110-6766	1	Clutch-Electric, PTO
5	109-8951	1	Muffler ASM
5:2	110-6697	2	Gasket-Exhaust
6	109-8855-03	1	Anchor-Clutch
7	3274-10	4	Screw-HSH
8	1-603610	2	Washer-Spring
9	3212-11	1	Screw-HH
10	109-9162	1	Idler Arm ASM
10:2	1-513034	2	Sleeve-Bearing
11	109-3397	2	Pulley-Flat Idler
12	1-603384	1	Bushing-Pivot, Idler
13	3231-11	1	Screw-CARR
14	3256-4	1	Washer-Flat
15	3231-5	2	Screw-CARR
16	104-8301	3	Nut-Flange, NI
17	1-603402	1	Spring-Extension
18	82-4201	1	HYD Hose ASM
19	109-3388	1	Belt
20	3253-4	4	Washer-Lock
21	32144-109	4	Screw
22	288-10	1	Cap-Pipe



Transmission Assembly

Ref	Part No.	Qty.	Description
1	109-3372	1	Transmission-LH
2	109-3371	1	Transmission-RH
3	109-6570-03	1	Bracket-Fender Support
4	109-2250	1	Vent-Tank, Hydro
4:1	109-3320	1	Cap-Reservoir, Hydraulic
5	104-7201	2	Nut-HF
6	3256-22	2	Washer-Flat
7	321-6	2	Screw-HH
8	104-8300	8	Nut-Flange, NI
9	3230-9	4	Screw-CARR
10	3256-3	2	Washer-Flat
11	322-12	2	Screw-HH
12	109-3652	2	Spacer-Hydro
13	3230-30	2	Screw-CARR
14	109-3710	1	Tube-Spacer
15	104-8301	1	Nut-Flange, NI
16	3290-357	1	Nut-HHF, Whiz
17	109-3711	1	Rod-Tension
18	109-3322	4	Clamp-Hose
19	109-5395	2	Arm-Hydro Bypass
20	3229-1	2	Screw-CARR
21	108-6402	2	Knob-Handle
22	1-806003	2	Pin-Hair
23	109-5577	1	Hose-Hydraulic


Ref	Part No.	Qty.	Description
24	109-5578	1	Hose-Hydraulic
25	109-2985	1	Trim



LH Transmission Assembly No. 109-3372

Ref	Part No.	Qty.	Description
1	114-8471	1	LH Main Housing Kit
2	114-8472	1	LH Side Cover Kit
3	104-5305	16	Screw-HHF
4	114-1678	1	O-Ring
5	112-9850	1	Plug
6	114-1679	1	Loctite 590-Gasket Material
7	114-1680	1	Plate-Bypass
8	109-3321	1	Element-Oil Filter, HYD
9	114-1682	1	Check Plug
10	114-1683	2	Seal-Plug
11	114-1684	3	Screw-Hfhc
12	106-8676	1	Seal-Lip
13	106-8677	1	Ring-Retaining, EXT
14	114-1685	1	Rod-Bypass
15	106-8679	1	Ring-Retaining, Int
16	107-2490	1	Arm-Bypass
17	106-8681	1	Ring-Retaining, EXT
18	104-5304	1	Swashplate-Trunnion
19	114-1686	1	Arm-Control, RH
20	114-8491	1	Washer
21	107-2488	1	Screw
22	114-1687	1	Shaft-Input
23	103-7441	1	Bearing-Shaft, Input
24	104-5307	1	Ring-Retaining


Ref	Part No.	Qty.	Description
25	104-5308	1	Spacer
26	104-5310	1	Seal-Lip
27	104-5309	1	Ring-Retaining
28	114-1688	1	Bearing-Thrust
29	114-1689	1	Motor Cylinder Block Kit
30	94-6922	1	Bearing-Thrust
31	110-8561	1	Pump Block ASM
32	104-5339	1	Washer-Flat
33	104-5340	1	Ring-Retaining
34	114-1690	1	Gear-14T
35	114-1691	1	Shaft-Motor
36	104-5360	1	Washer-Shaft, Motor
37	94-1933	1	Washer
38	114-1692	1	Gear-45T
39	114-1693	1	Gear-11T
40	104-5329	1	Pin-Jackshaft
41	104-2169	1	Ring-Retaining
42	114-1694	1	Gear-54T
43	114-1695	1	Spacer
44	114-1696	1	Bearing-Ball
45	104-2143	1	Bearing-Ball
46	104-2144	1	Seal
47	105-1895	1	Nut
48	114-1697	1	Pawl-Brake



LH Transmission Assembly No. 109-3372 (continued)

Ref	Part No.	Qty.	Description
49	114-1698	1	Shaft-Inboard Brake
50	114-1699	1	Handle-Brake
51	114-8450	1	Clip-Retaining
52	114-8473	1	Guard-Filter, LH
53	109-3278	1	Adapter-Straight
53:1	1-603921	1	O-Ring
54	114-8453	1	Fan-7.0
55	114-8454	1	Pulley-5.0 Inch
56	105-1875	1	Nut-Lock
57	107-9122	1	Washer-Slotted
58	114-8455	1	Tube-Connecting
59	104-2122	1	Gerotor ASM
60	109-3540	1	O-Ring-Seal
61	114-8457	1	Cover-Charge Pump
62	104-2120	1	Screw
63	114-8458	1	Spacer
64	114-8474	1	Arm-Neutral, Left
65	106-8682	1	Screw-Sh
66	114-8475	1	Rtn Ccw ASM
67	114-8478	1	Washer
68	109-5592	1	Spring-Extension
69	109-3537	1	Complete Seal Kit
70	114-8476	1	LH Center Section Kit
71	114-8464	1	Charge Relief Kit


Ref	Part No.	Qty.	Description
72	114-8465	1	Charge Kit
73	109-5939	1	Hub Kit
73:2		1	Hub W/Studs
74	109-5938	1	Fan And Pulley Kit
74:2		1	Pulley
74:3		1	Locknut,Hex
74:4		1	Washer
75	114-8467	1	Hub-Puller, 4 Bolt
76	114-8468	1	Input Shaft Kit
77	114-8477	1	Rtn Ccw Kit
78	114-8470	1	Axle Shaft Kit



RH Transmission Assembly No. 109-3371

Ref	Part No.	Qty.	Description
1	114-1676	1	RH Main Housing Kit
2	114-1677	1	RH Side Cover Kit
3	104-5305	16	Screw-HHF
4	114-1678	2	O-Ring
5	112-9850	1	Plug
6	114-1679	1	Loctite 590-Gasket Material
7	114-1680	1	Plate-Bypass
8	109-3321	1	Element-Oil Filter, HYD
9	114-1682	1	Check Plug
10	114-1683	2	Seal-Plug
11	114-1684	3	Screw-Hfhc
12	106-8676	1	Seal-Lip
13	106-8677	1	Ring-Retaining, EXT
14	114-1685	1	Rod-Bypass
15	106-8679	1	Ring-Retaining, Int
16	107-2490	1	Arm-Bypass
17	106-8681	1	Ring-Retaining, EXT
18	104-5304	1	Swashplate-Trunnion
19	114-1686	1	Arm-Control, RH
20	114-8491	1	Washer
21	107-2488	1	Screw
22	114-1687	1	Shaft-Input
23	103-7441	1	Bearing-Shaft, Input
24	104-5307	1	Ring-Retaining


Ref	Part No.	Qty.	Description
25	104-5308	1	Spacer
26	104-5310	1	Seal-Lip
27	104-5309	1	Ring-Retaining
28	114-1688	1	Bearing-Thrust
29	114-1689	1	Motor Cylinder Block Kit
30	94-6922	1	Bearing-Thrust
31	110-8561	1	Pump Block ASM
32	104-5339	1	Washer-Flat
33	104-5340	1	Ring-Retaining
34	114-1690	1	Gear-14T
35	114-1691	1	Shaft-Motor
36	104-5360	1	Washer-Shaft, Motor
37	94-1933	2	Washer
38	114-1692	1	Gear-45T
39	114-1693	1	Gear-11T
40	104-5329	1	Pin-Jackshaft
41	104-2169	1	Ring-Retaining
42	114-1694	1	Gear-54T
43	114-1695	1	Spacer
44	114-1696	1	Bearing-Ball
45	104-2143	1	Bearing-Ball
46	104-2144	1	Seal
47	105-1895	1	Nut
48	114-1697	1	Pawl-Brake



RH Transmission Assembly No. 109-3371 (continued)

Ref	Part No.	Qty.	Description
49	114-1698	1	Shaft-Inboard Brake
50	114-1699	1	Handle-Brake
51	114-8450	1	Clip-Retaining
52	114-8451	1	Guard-Filter, RH
53	109-3278	1	Adapter-Straight
①53:1	1-603921	1	O-Ring
54	114-8453	1	Fan-7.0
55	114-8454	1	Pulley-5.0 Inch
56	105-1875	1	Nut-Lock
57	107-9122	1	Washer-Slotted
58	114-8455	2	Tube-Connecting
59	104-2122	1	Gerotor ASM
60	109-3540	1	O-Ring-Seal
61	114-8457	1	Cover-Charge Pump
62	104-2120	2	Screw
63	114-8458	1	Spacer
64	114-8459	1	Arm-Neutral, Right
65	106-8682	1	Screw-Sh
66	114-8460	1	Cw Rtn ASM
67	114-8478	1	Washer
68	109-5592	1	Spring-Extension
①69	109-3537	1	Complete Seal Kit
70	114-8463	1	RH Center Section Kit
71	114-8464	1	Charge Relief Kit


Ref	Part No.	Qty.	Description
72	114-8465	1	Charge Kit
73	109-5939	1	Hub Kit
②73:2		1	Hub W/Studs
74	109-5938	1	Fan And Pulley Kit
②74:2		1	Pulley
②74:3		1	Locknut,Hex
②74:4		1	Washer
75	114-8467	1	Hub-Puller, 4 Bolt
76	114-8468	1	Input Shaft Kit
77	114-8469	1	Rtn Cw Kit
78	114-8470	1	Axle Shaft Kit



52 Inch Deck Assembly

Ref	Part No.	Qty.	Description
1	109-6254	1	52 Inch Deck ASM
2	52-2860	2	Washer
3	109-9158	1	Idler Arm ASM
3:2	1-513034	2	Sleeve-Bearing
4	103-3330	1	Spring-Extension
5	1-603384	1	Bushing-Pivot, Idler
6	3231-11	1	Screw-CARR
7	104-8301	8	Nut-Flange, NI
8	1-413113	1	Bushing-Idler
9	109-8891	2	Sheave And Bearing ASM
10	3231-31	1	Screw-CARR
11	109-6572	2	Bushing-Idler
12	1-603843	1	Pulley-Idler
13	109-6868	2	Bolt-Carriage
14	109-3723-01	1	Strut-Deck
15	109-8788	4	Bushing-Flanged
16	3231-25	4	Screw-CARR
17	109-3449	2	Shield-Belt
18	3230-23	6	Screw-CARR
19	109-5667	4	Ring-Retaining, Bolt
20	104-8300	12	Nut-Flange, NI
21	109-5498-03	1	Baffle-Discharge
22	322-2	6	Screw-HH
25	109-9146	1	Decal-Titan 52 Deck


--	--	--	--



52 Inch Deck and Discharge Chute Assembly


Ref	Part No.	Qty.	Description
1	109-6388	3	Anti-Scalp Roller Kit
2	109-8744	3	Complete Cutter Housing ASM
3	109-6873	3	Blade-Notched
4	109-3671	3	Pulley-Deck
5	109-3410	4	Hanger-Deck
6	109-8788	8	Bushing-Flanged
7	3231-25	8	Screw-CARR
8	104-8301	8	Nut-Flange, NI
9	109-3661	1	Belt
10	109-6393	1	Washout Port Kit
13	109-8854	1	Pin-Chute
14	57-6950	1	Spring
15	114-1651	1	Rubber Deflector ASM

--	--	--	--



Cutter Housing Assembly No. 109-8744


Ref	Part No.	Qty.	Description				
1	109-9380	1	Cutter Housing ASM				
1:1	62-3661	1	Spacer-Bearing				
1:2	109-9379	2	Bearing-Ball				
2	80-4380	1	Spacer				
3	80-4360	1	Shield-Bearing				
4	109-7431	1	Spindle-Hex Pilot				
5	109-7429	1	Washer-Blade Drive				
6	109-7452	1	Bolt-Sems, Blade				
7	3219-6	1	Nut-Hex				
8	32144-41	6	Screw-Taptite				



Electrical Assembly

Ref	Part No.	Qty.	Description
1	109-8786	1	Harness-Wire
1:1	109-9186	1	Diode-Tvs
2	240-3	2	Grommet-Rubber
3	32144-1	3	Screw-Taptite
4	3296-2	4	Nut-Lock
5	1-643275	1	Relay
6	1-513075	1	Switch-Solenoid
6:1	3253-17	2	Washer-Lock
6:2	3253-4	2	Washer-Lock
6:3	3219-14	2	Nut-Hex
6:4	3220-2	2	Nut-Jam
7	3256-22	2	Washer-Flat
8	321-4	2	Screw-HH
9	46-8560	2	Screw-HHF
10	107069	4	Clip
11	109-6398	1	Control Panel ASM
11:2	109-6029	1	Decal-Console
12	3258-166	4	Screw-PRH
13	1-513374	1	Meter-Hour
14	103-5221	1	Switch-PTO
15	103-0206	1	Switch-Starting, Key
15:1	3254-5	1	Washer-Tooth
15:2	218-461	1	Nut-HH
16	103-0498	1	Nut-Switch, Ignition


Ref	Part No.	Qty.	Description
17	109-3987	1	Control-Throttle
18	109-9147	1	Control-Choke
19	1-807513	4	Bolt-CARR
20	104-2491	1	Battery
21	32128-33	2	Nut-HF
22	99-7408	1	Switch-Reverse
23	105-1853	1	Clamp-Hose
25	109-7653	1	Positive Battery Cable ASM
26	103-0705	1	Cable-Ground, Negative
27	109-9415	1	Positive Starter Cable ASM
29	110-6765	2	Switch-Single Pole No
31	103-1311-03	1	Holddown-Battery
33	1-633651	2	Bolt-Holddown
34	1-543792	2	Wingnut
35	82-2190	1	Switch-Bail
36	1-303287	1	Tie-Plastic
37	63-8360	1	Key-Ignition



Crankcase Assembly Kohler SV830-0014

Ref	Part No.	Qty.	Description
❶	32 038 01-S	1	Dipstick ASM (Includes 2)
❷	25 153 03-S	1	O Ring-Dipstick
❸	M-545013-S	1	Screw-Flg, Thd Frm (M5X0.8X13)
❹	12 123 04-S	1	Oil Fill Tube Kit (Includes 5, 6)
❺	12 153 03-S	1	O-Ring (Upper Oil Fill Tube)
❻	12 153 01-S	1	O-Ring (Lower Oil Fill Tube)
❼	24 126 19-S	1	Bracket-Tube, Oil Fill
❽	24 032 01-S	1	Seal-Oil
❾	32 522 03	1	Shortblock
❿	24 018 04-S	1	Retainer-Reed, Breather
⓫	12 402 02-S	1	Reed-Breather
⓬	24 380 16-S	6	Pin-Locating
⓭	24 067 16-S	2	Rod-Connecting (STD)
⓮	25 874 01-S	2	Piston W/Ring Set (STD) (Includes 15, 16)
⓯	24 874 28-S	1	Piston W/Ring Set (.25)
⓰	24 874 27-S	1	Piston W/Ring Set (.08)
⓱	24 018 01-S	4	Retainer-Pin, Piston
⓲	24 108 14-S	2	Ring Set (STD)
⓳	24 108 16-S	1	Ring Set (.25)
⓴	12 422 07-S	1	Shim-Camshaft (White .028)
⓵	12 422 08-S	1	Shim-Camshaft (Blue .03)
⓶	12 422 09-S	1	Shim-Camshaft (Red .032)
⓷	12 422 10-S	1	Shim-Camshaft (Yellow .034)


Ref	Part No.	Qty.	Description
⓸	12 422 11-S	1	Shim-Camshaft (Green .036)
⓹	12 422 12-S	1	Shim-Camshaft (Gray .038)
⓺	12 422 13-S	1	Shim-Camshaft (Black .04)
⓻	32 012 01-S	1	Camshaft Kit (Includes Lubricant 25 357 14-S)
⓼	28 032 09-S	1	Seal-Cross Shaft, Governor
⓽	24 018 09-S	1	Retainer-Ring
⓾	M-931010-S	1	Washer-Flat (9Mm)
⓿	24 468 15-S	1	Washer-Flat (11/32)
⓿	24 144 38-S	1	Shaft-Cross, Governor
⓿	25 357 14-S	1	Lubricant-Camshaft



Head, Valve and Breather Assembly Kohler SV830-0014

Ref	Part No.	Qty.	Description
❶	24 755 141-S	1	Plain Rocker Cover Kit
❷	24 153 30-S	2	O-Ring (Valve Cover)
❸	M-651030-S	8	Screw-Flange (M6X1.0X30)
❹	32 3118 08-S	1	Cylinder Head No.1 ASM (Includes 26 [qty 4] And 20)
❺	12 755 03-S	4	Retainer Kit
❻	12 173 01-S	4	Cap-Spring, Valve
❼	24 089 02-S	4	Spring-Valve
❽	235011-S	4	Retainer-Spring
❾	66 032 05-S	2	Seal-Stem, Valve
❿	24 017 01-S	2	Intake Kit (STD)
⓫	24 016 01-S	2	Valve-Exhaust (STD)
⓬	32 326 06-S	1	Breather Hose Kit (Includes 13 [qty 1])
⓭	25 237 14-S	5	Clamp-Hose, Spring (1/2)
⓮	32 081 02-S	1	Breather Housing Kit (Includes 15, 16)
⓯	M-547050-S	1	Nut-Lock (M5X.8)
⓰	32 468 01-S	1	Washer-Sealing
⓱	32 072 03-S	1	Stud-Cover, Breather
⓲	32 019 01-S	4	Tappet
⓳	32 411 04-S	4	Rod-Push
⓴	24 841 03-S	2	Cylinder Head Gasket Kit
⓵	32 318 06-S	1	Cylinder No.2 Head ASM (Includes 26 [qty 4] And 20)


Ref	Part No.	Qty.	Description
❷	32 186 03-S	4	Arm-Rocker
❸	25 100 33-S	4	Nut (M10X0.75)
❹	25 086 128-S	4	Screw-Set
❺	25 599 01-S	4	Pivot-Arm, Rocker
❻	12 086 16-S	8	Screw-Flange (M10X1.5X90)
❼	32 072 04-S	4	Stud-Rocker
❽	32 096 06-S	1	Breather Valve Cover Kit (Includes 2 [qty 1])
❾	24 445 01-S	1	Strap-Lifting
❿	M-645016-S	1	Screw-Flange, Thread Forming (M6X1.0X16)
⓫	32 096 04-S	1	Breather Cover Kit
⓬	32 041 01-S	1	Gasket-Cover, Breather
⓭	32 050 01-S	1	Filter-Breather
⓮	32 146 09-S	2	Plate-Guide
⓯	24 041 49-S	1	Gasket-Exhaust
⓰	24 153 27-S	1	O-Ring (Intake Port)
⓱	32 755 03-S	2	Cylinder Head Hardware Kit (Services 1 Head-Qtys Listed Are For Both Heads) (Includes 5-11, 19, 22, 25, 34)



Ignition and Electrical Assembly Kohler SV830-0014


Ref	Part No.	Qty.	Description
1	32 162 03-S	1	Screen-Grass
2	12 086 14-S	1	Screw-Flange (M10X1.5X45)
3	12 468 03-S	1	Washer-Flat (13/32)
4	20 146 05-S	1	Plate-Mounting, Fan
5	32 157 01-S	1	Fan
6	32 025 16-S	1	Flywheel ASM (S V710/S V730)
7	X-42-15-S	1	Key (3/16 X 5/8)
8	25 155 41-S	1	Connector (3 Contact)
9	M-545016-S	2	Screw-Flange, Thread Forming (M5X0.8X16)
10	41 403 10-S	1	Rectifier/Regulator
11	237878-S	1	15 Amp Stator Kit (Includes 25 452 01-S)
12	M-548025-S	2	Screw-Thread Forming (M5X0.8X25)
13	25 132 16-S	2	Sparkplug
14	24 584 45-S	2	Ignition Module Kit (C D I Fixed)
15	M-545020-S	4	Screw-Flange, Thread Forming (M5X.8X20)
16	25 454 03-S	2	Tie-Wire
17	32 176 14-S	1	Wire Harness Kit
18	25 454 05-S	1	Tie
19	25 452 01-S	2	Terminal

--	--	--	--



Blower Housing Assembly Kohler SV830-0014


Ref	Part No.	Qty.	Description				
1	32 027 15-S	1	Blower Housing ASM (W/Guard)				
2	32 096 09-S	1	Cover-Cleaner, Air (Black)				
3	M-545016-S	6	Screw-Flange, Thread Forming (M5X0.8X16)				
4	M-645016-S	8	Screw-Flange, Thread Forming (M6X1.0X16)				
5	32 146 05-S	1	Backing Plate Kit				
6	32 063 12-S	1	Baffle-Barrel, Cylinder (No.2 Side)				
7	32 063 02-S	1	Baffle-Valley (No.2 Side)				
8	M-545010-S	2	Screw-Flange, Thread Forming (M5X.8X10)				
9	32 063 03-S	1	Baffle-Valley (No.1 Side)				
10	32 063 10-S	1	Baffle-Barrel, Cylinder (No.1 Side)				
11	24 086 12-S	2	Screw-TAP (M6X1.7X18)				
13	32 113 11-S	1	Decal-Guard, Fixed				
15	41 037 10-S	1	Nameplate-Service				



Starter Assembly Kohler SV830-0014

Ref	Part No.	Qty.	Description
1	M-839080-S	2	Screw-Flg (M8X1.25X80)
2	32 098 01-S	1	Starter ASM
3	12 755 39-S	1	Drive Kit
4	12 755 38-S	1	Drive Part Kit
5	32 141 01-S	1	Ring-Retaining
6	32 211 01-S	2	Bolt-Thru
7	12 243 04-S	1	Commutator-Cap, End
8	32 227 01-S	1	Cap-End, Drive

--	--	--	--



Engine Control Assembly Kohler SV830-0014

Ref	Part No.	Qty.	Description
❶	24 211 03-S	1	Bolt-Sq Neck, Rd HD (M6X1.0X25)
❷	24 090 51-S	1	Lever-Governor
❸	M-641060-S	1	Nut-Flange (M6X1.0)
❹	24 089 01-S	1	Spring-Linkage
❺	25 158 08-S	1	Bushing-Retaining, Linkage
❻	24 079 04-S	1	Linkage-Throttle
❼	25 158 11-S	1	Bushing-Linkage, Throttle
❽	M-545016-S	1	Screw-Flange, Thread Forming (M5X0.8X16)
❾	M-547050-S	1	Nut-Lock (M5X.8)
❿	24 089 03-S	1	Spring-Return, Choke
⓫	24 126 161-S	1	Bracket-Control
⓬	M-645016-S	4	Screw-Flange, Thread Forming (M6X1.0X16)
⓭	12 237 01-S	2	Clamp-Cable
⓮	24 086 43-S	2	Screw-Lbd, Thd Frm (M5X0.8X16)
⓯	24 079 22-S	1	Linkage-Choke
⓰	24 112 27-S	1	Space-Control ASM
⓱	24 090 47-S	1	Lever-Actuator, Throttle
⓲	24 090 13-S	1	Lever-Control, Throttle
⓳	24 468 01-S	1	Washer-Flat (5.5Mm)
⓴	M-545020-S	1	Screw-Flange, Thread Forming (M5X.8X20)
⓵	41 468 03-S	1	Washer-Spring (1/4)

Ref	Part No.	Qty.	Description
⓶	24 090 05-S	1	Lever-Choke
⓷	M-403025-S	1	Screw-Slotted Head (M4X0.7X25)
⓸	M-446030-S	1	Nut (M4X0.7)
⓹	24 468 20-S	1	Washer-Flat (5Mm)
⓺	24 089 55-S	1	Spring-Governor
⓻	24 089 25-S	1	Spring-Governor

Attachments and Accessories

For 74818 - Titan Z5200 Zero-Turn-Radius Riding Mower

Product Name	Model/Part
Hitch Kit	109-6245
52 Inch Bagging Blade Kit	79142
48 Inch and 52 Inch Bagger	79155
52 Inch Mulching Kit	79156
Z Sunshade	79157
Z Light Kit	79158

NOTES

NOTES

