



## 53cm Super Recycler<sup>®</sup> Lawn Mower

Model No. 20793 - 290000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                            | Page    | Description                      | Page     |
|----------------------------------------|---------|----------------------------------|----------|
| Deck Housing Assembly                  | ..... 3 | Engine and Blade Assembly        | ..... 7  |
| Housing Assembly No. 115-2855          | ..... 4 | Upper Handle Assembly            | ..... 8  |
| Front Wheel and Height-of-Cut Assembly | ..... 5 | Brake Bail and Cable Assembly    | ..... 9  |
| Transmission and Rear Wheel Assembly   | ..... 6 | Rear Bag Assembly                | ..... 10 |
|                                        |         | Attachments and Accessories List | ..... 11 |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HYD. .... hydraulic                          |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HD. .... heavy-duty                        | PTH. .... phillips truss head                |
| HF. .... hex flange                        | PTO. .... power-take-off                     |
| HH. .... hex head                          | RH. .... right hand                          |
| HHF. .... hex head flange                  | ROPS. .... roll-over protection system       |
| HHFTF. .... hex head flange thread forming | SFH. .... slotted fillister head             |
| HJ. .... hex jam                           | SHH. .... slotted hex head                   |
| HLH. .... hex lag head                     | SHWH. .... slotted hex washer head           |
| HOC. .... height-of-cut                    | SPH. .... slotted pan head                   |
| HSBH. .... hex socket button head          | SQH. .... square head                        |
| HSFH. .... hex socket flat head            | SRH. .... slotted round head                 |
| HSH. .... hex socket head                  | STD. .... standard                           |
| HWH. .... hex washer head                  | TAP. .... self tapping                       |
| HWHTF. .... hex washer head thread forming | TTH. .... torx truss head                    |

## Footnotes

❶ Not serviced separately


❷ Obtain from your local Briggs & Stratton dealer




## Deck Housing Assembly

| Ref  | Part No. | Qty. | Description             |
|------|----------|------|-------------------------|
| 1    | 115-2856 | 1    | Rear Door ASM           |
| 1:2  | 114-7982 | 1    | Decal-Warning           |
| 1:3  | 104-7908 | 1    | Decal-Warning           |
| 2    | 49-2040  | 6    | Screw-HWHTF             |
| 3    | 94-8196  | 2    | Washer-Nylon            |
| 4    | 115-2859 | 1    | Spring-Torsion          |
| 5    | 115-8413 | 1    | Mulch Plug ASM          |
| 6    | 114-7924 | 1    | Spring-Torsion          |
| 7    | 114-1586 | 1    | Shield-Trailing         |
| 8    | 107-7497 | 1    | Bracket-Cable, Traction |
| 9    | 107-7494 | 1    | Cover-Belt              |
| 10   | 114-2668 | 1    | Chute                   |
| 11   | 107-3717 | 1    | Discharge Door ASM      |
| 11:2 | 107-0795 | 1    | Latch-Door              |
| 11:3 | 107-7456 | 1    | Cap-Door                |
| 11:4 | 107-7461 | 1    | Screw-Plastite          |
| 12   | 99-8445  | 2    | Screw-HWH               |
| 13   | 99-5293  | 1    | Spring-Torsion          |
| 14   | 99-5291  | 1    | Rod-Cover               |
| 15   | 112-6416 | 1    | Bracket-Cover           |
| 16   | 108-3753 | 1    | Chute-Discharge, Side   |
| 17   | 117-1092 | 2    | Screw-PTH               |
| 18   | 115-2855 | 1    | Housing ASM             |
| 21   | 107-7495 | 1    | Tunnel-Discharge        |

| Ref | Part No. | Qty. | Description                 |
|-----|----------|------|-----------------------------|
| 23  | 98-2256  | 1    | Clamp                       |
| 24  | 32144-32 | 1    | Screw                       |
| 25  | 112-6438 | 1    | Washer-Seal, Washout Port   |
| 26  | 112-6400 | 1    | Port-Washout                |
| 27  | 112-6401 | 1    | Coupling-Hose, Washout Port |
| 28  | 3254-5   | 1    | Washer-Tooth                |
| 29  | 3218-6   | 1    | Nut-Jam                     |
| 31  | 112-6437 | 1    | Adapter-Quick Connect       |
| 32  | 62-3720  | 1    | Clamp-Cable                 |


**Housing Assembly No. 115-2855**

| Ref | Part No.    | Qty. | Description        |  |  |  |  |
|-----|-------------|------|--------------------|--|--|--|--|
| 2   | 108-3798    | 2    | Kicker-Housing     |  |  |  |  |
| 3   | 32144-111   | 4    | Screw-PPH          |  |  |  |  |
| 4   | 112-8760    | 1    | Decal-Danger       |  |  |  |  |
| 5   | 63-8590     | 3    | Screw              |  |  |  |  |
| 6   | 105-1316-03 | 1    | Sheet-Lip          |  |  |  |  |
| 7   | 49-2040     | 3    | Screw-HWHTF        |  |  |  |  |
| 8   | 108-3797-03 | 1    | Plate-Cover, Front |  |  |  |  |
| 9   | 112-8867    | 1    | Decal              |  |  |  |  |




Front Wheel and Height-of-Cut Assembly

| Ref | Part No. | Qty. | Description        |  |  |  |  |
|-----|----------|------|--------------------|--|--|--|--|
| 1   | 92-1057  | 2    | Bolt-Shoulder      |  |  |  |  |
| 2   | 51-2751  | 2    | Wheel And Tire ASM |  |  |  |  |
| 2:1 | 27-6250  | 2    | Bushing            |  |  |  |  |
| 3   | 114-3467 | 2    | Screw-Shoulder     |  |  |  |  |
| 4   | 107-7492 | 2    | Arm-Pivot          |  |  |  |  |
| 5   | 107-7491 | 2    | Arm-Spring         |  |  |  |  |
| 6   | 105-3042 | 2    | Knob-Lever, HOC    |  |  |  |  |
| 7   | 603773   | 4    | Nut                |  |  |  |  |
| 8   | 49-2040  | 13   | Screw-HWHTF        |  |  |  |  |
| 10  | 107-7478 | 4    | Plate-HOC          |  |  |  |  |
| 11  | 40-1940  | 2    | Washer             |  |  |  |  |
| 13  | 52-2480  | 2    | Spacer-Wheel       |  |  |  |  |
| 15  | 3256-24  | 2    | Washer-Flat        |  |  |  |  |
| 17  | 114-2608 | 1    | Decal-Housing      |  |  |  |  |



# Transmission and Rear Wheel Assembly


| Ref   | Part No. | Qty. | Description                    | Ref | Part No.    | Qty. | Description          |
|-------|----------|------|--------------------------------|-----|-------------|------|----------------------|
| 1     | 92-1057  | 2    | Bolt-Shoulder                  | 20  | 92-1043     | 1    | V-Belt               |
| 2     | 51-2742  | 2    | Wheel And Tire ASM (With Gear) | 21  | 115-4560    | 1    | Transmission ASM     |
| 1 2:3 |          | 1    | Wheel And Tire ASM             | 22  | 114-7977-03 | 1    | Bracket-Transmission |
| 2:3:1 | 27-6250  | 2    | Bushing                        | 23  | 108-7476    | 3    | Screw-Plastite       |
| 3     | 65-2720  | 4    | Ring-Clip, Locking             | 25  | 100-6351    | 1    | Cover-Wheel          |
| 4     | 65-4740  | 4    | Washer-Thrust, Keyed           | 26  | 100-1519    | 1    | Label-Wheel, Smart   |
| 5     | 66-6040  | 1    | Key-Rocking, RH                |     |             |      |                      |
| 6     | 66-6050  | 1    | Key-Rocking, LH                |     |             |      |                      |
| 7     | 65-4710  | 2    | Ring-Friction                  |     |             |      |                      |
| 8     | 100-8774 | 2    | Pivot Arm ASM                  |     |             |      |                      |
| 8:2   | 47-2900  | 1    | Bushing                        |     |             |      |                      |
| 8:3   | 70-9760  | 1    | Bushing                        |     |             |      |                      |
| 8:4   | 302-56   | 1    | Fitting-Grease                 |     |             |      |                      |
| 9     | 105-3042 | 2    | Knob-Lever, HOC                |     |             |      |                      |
| 10    | 42-3520  | 2    | Cap-End                        |     |             |      |                      |
| 11    | 49-2040  | 2    | Screw-HWHTF                    |     |             |      |                      |
| 12    | 107-7491 | 2    | Arm-Spring                     |     |             |      |                      |
| 13    | 603773   | 2    | Nut                            |     |             |      |                      |
| 14    | 65-4730  | 2    | Washer-Arm, Pivot              |     |             |      |                      |
| 15    | 65-4760  | 2    | Washer-Clutch                  |     |             |      |                      |
| 16    | 65-4750  | 2    | Gear-Pinion                    |     |             |      |                      |
| 17    | 65-4720  | 2    | Spring-Compression             |     |             |      |                      |
| 18    | 74-1660  | 2    | Cover-Wheel                    |     |             |      |                      |
| 19    | 74-1671  | 2    | Spacer-Cover, Wheel            |     |             |      |                      |



## Engine and Blade Assembly


| Ref | Part No.    | Qty. | Description           |
|-----|-------------|------|-----------------------|
| 1   | 3296-42     | 1    | Nut-Lock, NI          |
| 2   | 3256-16     | 1    | Washer-Flat           |
| 3   | 107-0797    | 1    | Bushing               |
| 4   | 107-0761    | 1    | Plate-Anchor          |
| 5   | 108-3792    | 1    | Spring-Tension, Brake |
| 6   | 110-7456    | 1    | Pulley                |
| 7   | 110-1790    | 1    | Belt-BBC              |
| 8   | 3231-25     | 1    | Screw-CARR            |
| 9   | 107-7471    | 1    | Plate-Guide           |
| 10  | 605256      | 1    | Washer                |
| 11  | 107-0758    | 1    | Spacer-Bearing        |
| 12  | 107-0759    | 1    | Bolt-Shoulder         |
| 13  | 49-2040     | 3    | Screw-HWHTF           |
| 14  | 107-7477    | 1    | Brake Arm ASM         |
| 15  | 603773      | 2    | Nut                   |
| 16  | 108-3766-03 | 1    | Support-Blade         |
| 17  | 54-9190     | 2    | Nut-Lock              |
| 18  | 3211-42     | 2    | Screw-HH              |
| 19  | 107-0754    | 1    | Drum                  |
| 20  | 100-1048    | 3    | Bearing-Ball          |
| 21  | 107-7487    | 1    | Support-Blade         |
| 22  | 108-9342    | 1    | Nut-Hex               |
| 23  | 108-3762-03 | 1    | Blade-Recycling       |

| Ref | Part No.    | Qty. | Description                              |
|-----|-------------|------|------------------------------------------|
| 1   | 24          | 1    | Engine-Briggs & Stratton, 126T02-0261-B1 |
| 26  | 104-7577-03 | 1    | Shield-Muffler                           |
| 27  | 32144-1     | 3    | Screw-Taptite                            |
| 28  | 32144-102   | 3    | Screw-HWH                                |
| 29  | 32144-112   | 1    | Screw-HWH                                |
| 32  | 108-3790    | 1    | Retainer-Belt                            |
| 33  | 107-7488    | 1    | Cover                                    |
| 34  | 115-4654    | 1    | Decal-Shroud                             |
| 35  | 108-3787    | 1    | Disc                                     |



Upper Handle Assembly

| Ref  | Part No.    | Qty. | Description           | Ref | Part No. | Qty. | Description            |
|------|-------------|------|-----------------------|-----|----------|------|------------------------|
| 2    | 104-8678    | 1    | Handle-Control        | 23  | 106-6805 | 1    | Guide-Cable            |
| 3    | 99-1589     | 1    | Lever-Traction        | 25  | 115-2884 | 1    | Decal-Instruction      |
| 4    | 99-1588     | 1    | Bar-Control, Traction | 26  | 49-2040  | 2    | Screw-HWHTF            |
| 5    | 105-6842    | 1    | Guide-LH              | 27  | 112-9972 | 2    | Washer-Conical, Spring |
| 7    | 86-9671     | 1    | Guide-Rope            | 99  | 614249   | 3    | Strap-Tie              |
| 8    | 3256-23     | 1    | Washer-Flat           |     |          |      |                        |
| 9    | 105-6841    | 1    | Guide-RH              |     |          |      |                        |
| 10   | 110-7056    | 1    | Decal-Handle          |     |          |      |                        |
| 11   | 321-50      | 1    | Screw-HH              |     |          |      |                        |
| 12   | 99-5239     | 1    | Anchor-Cable          |     |          |      |                        |
| 13   | 3256-1      | 1    | Washer-Flat           |     |          |      |                        |
| 14   | 3296-73     | 2    | Nut-Lock, NI          |     |          |      |                        |
| 15   | 108-8158    | 1    | Cable-Traction        |     |          |      |                        |
| 16   | 115-2860    | 2    | Quick Release ASM     |     |          |      |                        |
| 16:1 | 109-0917    | 1    | Nut-Push              |     |          |      |                        |
| 16:2 | 114-7995    | 1    | Lever                 |     |          |      |                        |
| 16:3 | 114-7996    | 1    | Anchor-Spring         |     |          |      |                        |
| 16:4 | 115-2858    | 1    | Spring-Compression    |     |          |      |                        |
| 17   | 115-1958    | 2    | Bolt-Shoulder         |     |          |      |                        |
| 18   | 32144-11    | 2    | Screw-HWHTF           |     |          |      |                        |
| 19   | 104-8690    | 1    | Spring-Torsion        |     |          |      |                        |
| 20   | 115-1300-05 | 1    | Handle                |     |          |      |                        |
| 21   | 114-2671-03 | 1    | Bracket-Handle, LH    |     |          |      |                        |
| 22   | 114-2672-03 | 1    | Bracket-Handle, RH    |     |          |      |                        |



### Brake Bail and Cable Assembly

| Ref | Part No.    | Qty. | Description        |  |  |  |  |
|-----|-------------|------|--------------------|--|--|--|--|
| 1   | 3290-337    | 1    | Nut-Speed          |  |  |  |  |
| 2   | 32128-17    | 1    | Nut-Lock, Flange   |  |  |  |  |
| 3   | 106-9169    | 1    | Screw              |  |  |  |  |
| 4   | 106-6802    | 1    | Lever              |  |  |  |  |
| 5   | 112-8884    | 1    | Knob-BBC           |  |  |  |  |
| 6   | 107-7462    | 1    | Spring-Torsion     |  |  |  |  |
| 7   | 107-7463    | 1    | Spacer             |  |  |  |  |
| 8   | 108-8161    | 1    | Switch Housing ASM |  |  |  |  |
| 14  | 108-8155    | 1    | Cable ASM          |  |  |  |  |
| 15  | 108-3788-03 | 1    | Bail-Brake         |  |  |  |  |
| 17  | 104-9368    | 1    | Plug-Dome          |  |  |  |  |

## Rear Bag Assembly

| Ref | Part No.    | Qty. | Description   |
|-----|-------------|------|---------------|
| 1   | 114-2664    | 1    | Grass Bag ASM |
| 2   | 114-2679-03 | 1    | Frame-Bag     |

# Attachments and Accessories

For 20793 - 53cm Super Recycler Lawn Mower

| Product Name                         | Model/Part |
|--------------------------------------|------------|
| Traction Assist Handle Kit . . . . . | 108-8120   |
| Toro Walk Mower Cover . . . . .      | 490-7462   |
| Plain Walk Mower Cover . . . . .     | 490-7463   |
| Dethatcher Kit . . . . .             | 59131      |

