



## XL 320 Lawn Tractor

Model No. 71257 - 290000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                 | Page     | Description                                 | Page     |
|-----------------------------|----------|---------------------------------------------|----------|
| Frame and Body Assembly     | ..... 3  | 5 Speed Transaxle Assembly                  | ..... 11 |
| Hood and Tower Assembly     | ..... 4  | 32 Inch Deck Assembly                       | ..... 12 |
| Rear Body and Seat Assembly | ..... 5  | 32 Inch Deck Blade Drive and Brake Assembly | ..... 13 |
| Steering Component Assembly | ..... 6  | Height-of-Cut Assembly                      | ..... 14 |
| Fixed Steering Assembly     | ..... 7  | Electrical Assembly                         | ..... 15 |
| Fuel Tank Assembly          | ..... 8  | Engine and Muffler Assembly                 | ..... 16 |
| Traction Clutch Assembly    | ..... 9  | 32 Inch Deck Component Assembly             | ..... 17 |
| Shifter Assembly            | ..... 10 | Attachments and Accessories List            | ..... 18 |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HYD. .... hydraulic                          |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HD. .... heavy-duty                        | PTH. .... phillips truss head                |
| HF. .... hex flange                        | PTO. .... power-take-off                     |
| HH. .... hex head                          | RH. .... right hand                          |
| HHF. .... hex head flange                  | ROPS. .... roll-over protection system       |
| HHFTF. .... hex head flange thread forming | SFH. .... slotted fillister head             |
| HJ. .... hex jam                           | SHH. .... slotted hex head                   |
| HLH. .... hex lag head                     | SHWH. .... slotted hex washer head           |
| HOC. .... height-of-cut                    | SPH. .... slotted pan head                   |
| HSBH. .... hex socket button head          | SQH. .... square head                        |
| HSFH. .... hex socket flat head            | SRH. .... slotted round head                 |
| HSH. .... hex socket head                  | STD. .... standard                           |
| HWH. .... hex washer head                  | TAP. .... self tapping                       |
| HWHTF. .... hex washer head thread forming | TTH. .... torx truss head                    |

## Footnotes


❶ Not serviced separately

❷ Obtain from your local Briggs & Stratton dealer



## Frame and Body Assembly


| Ref | Part No.    | Qty. | Description                      |  |  |  |  |
|-----|-------------|------|----------------------------------|--|--|--|--|
| 1   | 701178      | 2    | Cap-Protector                    |  |  |  |  |
| 2   | 322-5       | 2    | Screw-HH                         |  |  |  |  |
| 3   | 3256-23     | 4    | Washer-Flat                      |  |  |  |  |
| 4   | 88-6220     | 2    | Spring-Compression               |  |  |  |  |
| 5   | 99-2957-03  | 1    | Support-Seat/Rear Hitch          |  |  |  |  |
| 6   | 3296-29     | 24   | Nut-Lock, NI                     |  |  |  |  |
| 7   | 322-3       | 22   | Screw-HH                         |  |  |  |  |
| 8   | 99-2953-03  | 1    | Plate-Switch                     |  |  |  |  |
| 9   | 95-1653     | 1    | Switch-Pole, Single              |  |  |  |  |
| 10  | 94-1967-03  | 2    | Bracket-Mounting, Transmission   |  |  |  |  |
| 11  | 88-4620-03  | 1    | Bracket-Idler Pivot              |  |  |  |  |
| 12  | 322-3       | 2    | Screw-HH                         |  |  |  |  |
| 13  | 99-2958-03  | 1    | Rail-Frame, LH                   |  |  |  |  |
| 14  | 3296-1      | 2    | Nut-Lock                         |  |  |  |  |
| 15  | 3290-392    | 2    | Screw-SHH                        |  |  |  |  |
| 16  | 3296-29     | 2    | Nut-Lock, NI                     |  |  |  |  |
| 21  | 110-8636-03 | 1    | Support-Axle, Front              |  |  |  |  |
| 24  | 88-4630-03  | 1    | Plate-Mounting, Engine           |  |  |  |  |
| 25  | 99-2959-03  | 1    | Rail-Frame, RH                   |  |  |  |  |
| 28  | 99-2971     | 1    | Rear Body ASM                    |  |  |  |  |
| 33  | 93-6675     | 1    | Decal-Gear                       |  |  |  |  |
| 35  | 105-2498    | 1    | Decal-Rear Fender, Lawn Tractors |  |  |  |  |
| 37  | 3256-23     | 2    | Washer-Flat                      |  |  |  |  |



## Hood and Tower Assembly

| Ref  | Part No.   | Qty. | Description            |
|------|------------|------|------------------------|
| 1    | 99-1947    | 1    | Tower-Steering         |
| 2    | 94-5565    | 1    | Knob-Shift             |
| 3    | 46-8091    | 3    | Screw-HWH              |
| 4    | 3296-42    | 4    | Nut-Lock, NI           |
| 5    | 321-2      | 4    | Screw-HH               |
| 6    | 28-0540    | 2    | Bolt-Shoulder          |
| 7    | 88-6050-03 | 1    | Bracket-Pivot, LH Hood |
| 8    | 3290-496   | 2    | Nut-Retainer           |
| 11   | 94-1984    | 1    | Latch-Pin              |
| 12   | 93-3891    | 1    | Duct-Air, Hood         |
| 13   | 46-8090    | 7    | Screw-Plastite         |
| 14   | 92-8650    | 1    | Hood ASM               |
| 14:1 | 92-5748    | 1    | Decal                  |
| 15   | 92-5782    | 3    | Tape-Foil              |
| 16   | 93-3864-03 | 1    | Shield-Heat            |
| 18   | 88-6040-03 | 1    | Bracket-Pivot, RH Hood |
| 19   | 3290-307   | 2    | Pin-Hair               |
| 20   | 100-7401   | 1    | Rod-Tower, Pivot       |
| 21   | 3256-24    | 2    | Washer-Flat            |
| 22   | 3218-3     | 2    | Nut-Jam                |
| 23   | 100-7402   | 2    | Nut-Cap                |
| 24   | 100-7403   | 2    | Washer-Flat            |
| 25   | 88-5190-03 | 1    | Lever-Deck, Engage     |
| 26   | 3296-29    | 2    | Nut-Lock, NI           |


| Ref | Part No. | Qty. | Description          |
|-----|----------|------|----------------------|
| 27  | 3256-23  | 2    | Washer-Flat          |
| 28  | 322-3    | 2    | Screw-HH             |
| 29  | 108-7802 | 2    | Decal-Tower          |
| 30  | 99-8142  | 1    | Decal-Ignition       |
| 31  | 92-5730  | 1    | Decal-Throttle/Choke |
| 32  | 93-6673  | 1    | Decal-Deck, Engage   |
| 33  | 105-2497 | 1    | Decal-Hood           |
| 34  | 105-2496 | 1    | Decal-Hood           |
| 39  | 94-1980  | 2    | Foam-Hood            |



## Rear Body and Seat Assembly

| Ref  | Part No.   | Qty. | Description         |
|------|------------|------|---------------------|
| 1    | 37-8770    | 4    | Bolt-Shoulder       |
| 2    | 63-8360    | 1    | Key-Ignition        |
| 3    | 106-6437   | 1    | Seat Support ASM    |
| 3:2  | 99-2986    | 1    | Decal-Danger        |
| 3:3  | 99-5340    | 1    | Decal-Switch        |
| 4    | 5-4460     | 2    | Washer-Pivot        |
| 5    | 92-9674    | 2    | Knob                |
| 6    | 3290-479   | 16   | Fastener-Panel      |
| 7    | 93-7657    | 1    | Cover-HOC           |
| 8    | 3290-282   | 2    | Rivet-Pop           |
| 9    | 88-5030-03 | 1    | Gate-HOC            |
| 10   | 322-3      | 4    | Screw-HH            |
| 11   | 88-4820-03 | 2    | Bracket-Pivot, Seat |
| 12   | 3296-29    | 6    | Nut-Lock, NI        |
| 13   | 3269-26    | 2    | Washer-Flat         |
| 14   | 46-5780    | 1    | Starter Switch ASM  |
| 14:1 | 3254-5     | 1    | Washer-Tooth        |
| 14:2 | 218-461    | 1    | Nut-HH              |
| 16   | 88-5240    | 1    | Mat-Foot, LH        |
| 17   | 88-5220    | 1    | Mat-Foot, RH        |
| 18   | 3269-26    | 2    | Washer-Flat         |
| 19   | 88-5020-03 | 1    | Plate-Gate, Shift   |
| 20   | 3290-282   | 2    | Rivet-Pop           |
| 21   | 93-7656    | 1    | Cover-Shift         |


| Ref | Part No. | Qty. | Description    |
|-----|----------|------|----------------|
| 22  | 3290-479 | 4    | Fastener-Panel |
| 24  | 105-2699 | 1    | Decal-Noise    |
| 25  | 106-6439 | 1    | Seat-11 Inch   |



## Steering Component Assembly


| Ref | Part No.   | Qty. | Description            |
|-----|------------|------|------------------------|
| 1   | 3296-29    | 5    | Nut-Lock, NI           |
| 2   | 323-13     | 2    | Screw-HH               |
| 3   | 3231-4     | 1    | Screw-CARR             |
| 4   | 3230-3     | 1    | Screw-CARR             |
| 5   | 88-5130-03 | 1    | Bracket-Rack, Steering |
| 6   | 3230-2     | 4    | Bolt-CARR              |
| 7   | 88-5010    | 1    | Spacer-Rack, Steering  |
| 8   | 302-26     | 1    | Fitting-Grease         |
| 9   | 88-4670    | 1    | Bushing-Eccentric      |
| 10  | 88-5200    | 1    | Rack-Steering          |
| 11  | 52-2891    | 2    | Bushing-Flanged, Nylon |
| 12  | 111419     | 1    | Washer-Bearing         |
| 13  | 3256-25    | 4    | Washer-Flat            |
| 14  | 3272-10    | 4    | Pin-Cotter             |
| 15  | 3296-39    | 3    | Nut-Lock, NI           |
| 16  | 99-2956-03 | 1    | Bracket-Module         |
| 17  | 5-4460     | 1    | Washer-Pivot           |
| 18  | 92-7890-03 | 1    | LH Spindle ASM         |
| 19  | 99-3700    | 1    | Module                 |
| 20  | 3256-24    | 4    | Washer-Flat            |
| 21  | 3-6498     | 4    | Washer-Thrust          |
| 23  | 88-5470    | 2    | Spacer                 |
| 24  | 3-6498     | 2    | Washer-Thrust          |
| 25  | 9266714    | 2    | Screw-HWH              |

| Ref    | Part No.   | Qty. | Description              |
|--------|------------|------|--------------------------|
| 26     | 61-9780    | 2    | Cap-Hub                  |
| 27     | 3272-12    | 2    | Pin-Cotter               |
| 28     | 28-2480    | 2    | Washer-Plain             |
| 29     |            | 2    | Front Wheel And Tire ASM |
| 29:1   | 99-2992    | 1    | Tire                     |
| 29:2   | 88-4360    | 1    | Rim ASM                  |
| 29:2:1 | 232-27     | 1    | Stem-Valve               |
| 29:2:2 | 110513     | 2    | Bearing-Wheel            |
| 29:2:3 | 302-5      | 1    | Fitting-Grease           |
| 29:99  | 232-38     | 1    | Tube                     |
| 30     | 92-7889-03 | 1    | RH Spindle ASM           |
| 31     | 94-1962-03 | 1    | Front Axle ASM           |
| 32     | 88-5380    | 1    | Tie Rod-Steering         |
| 33     | 32151-48   | 2    | E-Ring                   |
| 34     | 88-4830    | 1    | Link-Drag                |
| 35     | 88-5510    | 1    | Rod-Brake, Parking       |
| 36     | 88-5520-03 | 1    | Bracket-Parking Brake    |
| 37     | 88-0890    | 1    | Grip-Brake, Parking      |



## Fixed Steering Assembly


| Ref | Part No.  | Qty. | Description           |  |  |  |  |
|-----|-----------|------|-----------------------|--|--|--|--|
| 1   | 98-1467   | 1    | Steering Wheel ASM    |  |  |  |  |
| 1:1 | 98-1468   | 1    | Cover-Wheel, Steering |  |  |  |  |
| 2   | 32121-111 | 1    | Pin-Roll              |  |  |  |  |
| 4   | 88-4190   | 1    | Bushing-Sliding       |  |  |  |  |
| 6   | 3256-22   | 2    | Washer-Flat           |  |  |  |  |
| 7   | 321-4     | 2    | Screw-HH              |  |  |  |  |
| 9   | 3296-42   | 2    | Nut-Lock, NI          |  |  |  |  |
| 16  | 88-5150   | 1    | Bearing-Flange        |  |  |  |  |
| 17  | 3-6498    | 1    | Washer-Thrust         |  |  |  |  |
| 18  | 32151-48  | 1    | E-Ring                |  |  |  |  |
| 23  | 98-1459   | 1    | Decal                 |  |  |  |  |
| 24  | 88-4150   | 1    | Plug                  |  |  |  |  |
| 25  | 88-6380   | 1    | Shaft-Steering, Long  |  |  |  |  |



Fuel Tank Assembly


| Ref  | Part No.    | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 88-4340     | 1    | Throttle Control ASM |
| 1:1  | 66-0120     | 1    | Knob                 |
| 2    | 27-0220     | 4    | Screw-Special        |
| 3    | 88-3880     | 1    | Gas Tank ASM         |
| 3:1  | 46-6560     | 1    | Bushing              |
| 3:2  | 104048      | 1    | Valve-Fuel           |
| 4    | 107-9297    | 1    | Hose-Fuel            |
| 5    | 2412-98     | 2    | Clamp                |
| 20   | 88-4410     | 1    | Gasket-Exhaust       |
| 21   | 3253-4      | 3    | Washer-Lock          |
| 22   | 3274-10     | 3    | Screw-HSH            |
| 23   | 3255-8      | 1    | Washer-Lock          |
| 26   | 32149-1     | 2    | Nut-Keps             |
| 28   | 94-1952     | 1    | Rod-Tank, Gas        |
| 30   | 88-4350     | 1    | Throttle Cable ASM   |
| 31   | 88-3980     | 1    | Gas Cap ASM          |
| 31:3 | 88-4010     | 1    | Gasket-Cap, Gas      |
| 37   | 93-3809     | 1    | Bracket-Ground       |
| 38   | 9266714     | 1    | Screw-HWH            |
| 39   | 94-1951     | 1    | Latch-Hood           |
| 40   | 32144-112   | 2    | Screw-HWH            |
| 41   | 93-3882     | 1    | Clip-Tinnerman       |
| 42   | 117-3901-03 | 1    | Shield-Muffler       |
| 43   | 9266714     | 2    | Screw-HWH            |

| Ref | Part No.   | Qty. | Description           |
|-----|------------|------|-----------------------|
| 44  | 32104-76   | 2    | Screw                 |
| 45  | 93-8450-03 | 1    | Heat Shield ASM       |
| 48  | 88-4490    | 1    | Reducer-Throttle, Rpm |
| 49  | 3256-23    | 1    | Washer-Flat           |




## Traction Clutch Assembly

| Ref | Part No.   | Qty. | Description               | Ref | Part No. | Qty. | Description         |
|-----|------------|------|---------------------------|-----|----------|------|---------------------|
| 1   | 27-8890    | 1    | Spring-Return             | 26  | 3296-29  | 3    | Nut-Lock, NI        |
| 2   | 94-4295    | 1    | Spring-Brake              | 27  | 3296-29  | 1    | Nut-Lock, NI        |
| 3   | 322-3      | 1    | Screw-HH                  | 28  | 3296-59  | 2    | Nut-Lock, NI        |
| 4   | 322-6      | 1    | Screw-HH                  | 29  | 88-5270  | 1    | Rod-Clutch/Brake    |
| 5   | 5-4460     | 1    | Washer-Pivot              | 30  | 88-6070  | 1    | Arm-Idler           |
| 6   | 94-5433    | 1    | Bracket-Belt, Guide       | 31  | 37-8770  | 1    | Bolt-Shoulder       |
| 7   | 88-6330    | 1    | Spring-Extension          | 32  | 88-5560  | 1    | Guide-Idler, Belt   |
| 8   | 84-5610    | 1    | Guide-Cable               | 33  | 104-4160 | 1    | Pulley-Idler        |
| 9   | 3256-23    | 2    | Washer-Flat               | 34  | 323-10   | 1    | Screw-HH            |
| 10  | 3296-29    | 2    | Nut-Lock, NI              | 35  | 5-4460   | 1    | Washer-Pivot        |
| 11  | 46-5590    | 2    | Tubing-Spacer             | 36  | 94-4926  | 1    | Bracket-Belt, Guide |
| 12  | 322-12     | 2    | Screw-HH                  | 37  | 322-3    | 1    | Screw-HH            |
| 13  | 88-4810    | 1    | Clamp-Pivot, Shift        | 38  | 3296-29  | 1    | Nut-Lock, NI        |
| 14  | 322-3      | 1    | Screw-HH                  |     |          |      |                     |
| 15  | 88-5500    | 1    | Rod-Pivot, Pedal          |     |          |      |                     |
| 17  | 88-4800-03 | 1    | Bellcrank                 |     |          |      |                     |
| 18  | 3256-26    | 3    | Washer-Flat               |     |          |      |                     |
| 19  | 3296-47    | 1    | Nut-Lock, NI              |     |          |      |                     |
| 20  | 65-2920    | 1    | Pad-Pedal                 |     |          |      |                     |
| 21  | 88-5000-03 | 1    | Pedal-Clutch/Brake, Hydro |     |          |      |                     |
| 22  | 322-9      | 1    | Screw-HH                  |     |          |      |                     |
| 23  | 3256-23    | 2    | Washer-Flat               |     |          |      |                     |
| 24  | 3272-10    | 1    | Pin-Cotter                |     |          |      |                     |
| 25  | 99-6836    | 1    | Spacer                    |     |          |      |                     |




Shifter Assembly

| Ref | Part No.   | Qty. | Description          |  |  |  |  |
|-----|------------|------|----------------------|--|--|--|--|
| 1   | 94-1991-03 | 1    | Lever-Shift ASM      |  |  |  |  |
| 2   | 323-10     | 1    | Screw-HH             |  |  |  |  |
| 3   | 3296-29    | 4    | Nut-Lock, NI         |  |  |  |  |
| 4   | 88-4810    | 2    | Clamp-Pivot, Shift   |  |  |  |  |
| 5   | 55-9321    | 1    | Cable-Clutch         |  |  |  |  |
| 6   | 322-3      | 3    | Screw-HH             |  |  |  |  |
| 7   | 3296-3     | 2    | Nut-Lock             |  |  |  |  |
| 8   | 94-1993-03 | 1    | Shift Pivot ASM      |  |  |  |  |
| 9   | 94-5432    | 1    | Link-Shift           |  |  |  |  |
| 10  | 329-23     | 1    | Screw-HH             |  |  |  |  |
| 11  | 3253-3     | 1    | Washer-Lock          |  |  |  |  |
| 12  | 7-5461     | 1    | Spacer               |  |  |  |  |
| 13  | 88-5340    | 1    | Lever-Shift          |  |  |  |  |
| 14  | 3256-23    | 2    | Washer-Flat          |  |  |  |  |
| 16  | 88-5930    | 1    | Keeper-Cable         |  |  |  |  |
| 17  | 3230-3     | 1    | Screw-CARR           |  |  |  |  |
| 18  | 3296-39    | 1    | Nut-Lock, NI         |  |  |  |  |
| 19  | 3256-25    | 1    | Washer-Flat          |  |  |  |  |
| 20  | 94-1968    | 1    | Lever-Pivot, Shift   |  |  |  |  |
| 24  | 94-5565    | 1    | Knob-Shift           |  |  |  |  |
| 25  | 84-5610    | 1    | Guide-Cable          |  |  |  |  |
| 26  | 94-1997    | 1    | Bushing-Shift, Lever |  |  |  |  |




5 Speed Transaxle Assembly

| Ref   | Part No. | Qty. | Description             |  |  |  |  |
|-------|----------|------|-------------------------|--|--|--|--|
| 1     | 3296-29  | 4    | Nut-Lock, NI            |  |  |  |  |
| 2     | 32120-64 | 1    | Ring-Snap, External     |  |  |  |  |
| 3     | 3257-23  | 1    | Key-Woodruff            |  |  |  |  |
| 4     | 88-4840  | 1    | Pulley-Transmission     |  |  |  |  |
| 5     | 94-4291  | 1    | V Belt-Traction         |  |  |  |  |
| 7     | 94-6022  | 1    | Transaxle ASM           |  |  |  |  |
| 9     |          | 2    | Rear Wheel And Tire ASM |  |  |  |  |
| 9:1   | 99-2336  | 1    | Tire                    |  |  |  |  |
| 9:2   | 88-4380  | 1    | Rim ASM                 |  |  |  |  |
| 9:2:1 | 232-27   | 1    | Stem-Valve              |  |  |  |  |
| 9:99  | 231-91   | 1    | Tube                    |  |  |  |  |
| 10    | 3-6498   | 2    | Washer-Thrust           |  |  |  |  |
| 11    | 7-0036   | 2    | Key-Square              |  |  |  |  |
| 12    | 28-2480  | 2    | Washer-Plain            |  |  |  |  |
| 13    | 32151-48 | 2    | E-Ring                  |  |  |  |  |
| 14    | 61-9780  | 2    | Cap-Hub                 |  |  |  |  |
| 15    | 322-12   | 4    | Screw-HH                |  |  |  |  |
| 16    | 3256-23  | 4    | Washer-Flat             |  |  |  |  |
| 17    | 3296-29  | 2    | Nut-Lock, NI            |  |  |  |  |
| 18    | 3256-23  | 4    | Washer-Flat             |  |  |  |  |
| 19    | 94-1969  | 2    | Strap-Torque            |  |  |  |  |
| 20    | 26-6701  | 1    | Spring-Return, Brake    |  |  |  |  |
| 21    | 322-3    | 2    | Screw-HH                |  |  |  |  |
| 22    | 32144-14 | 2    | Screw-HWHTF             |  |  |  |  |



### 32 Inch Deck Assembly


| Ref  | Part No.   | Qty. | Description             | Ref | Part No.   | Qty. | Description            |
|------|------------|------|-------------------------|-----|------------|------|------------------------|
| 1    | 92-2493    | 1    | Spring                  | 15  | 88-6150    | 1    | Rod-Hinge, Deflector   |
| 2    | 322-6      | 1    | Screw-HH                | 16  | 88-6160    | 1    | Spring-Torsion         |
| 3    | 28-7350    | 1    | Post-Pivot              | 17  | 3256-58    | 1    | Washer-Flat            |
| 4    | 95-7483    | 1    | Deck ASM                | 18  | 3296-42    | 1    | Nut-Lock, NI           |
| 4:3  | 93-6674    | 2    | Decal-Warning           | 19  | 88-4540    | 1    | Pivot-Hinge, Deflector |
| 4:4  | 93-7009    | 1    | Decal-Danger, Deflector | 24  | 92-2494-03 | 1    | Ramp-Deflector         |
| 4:5  | 93-7010    | 2    | Decal-Danger            | 27  | 80-2630-03 | 4    | Kicker                 |
| 5    | 3296-29    | 8    | Nut-Lock, NI            | 28  | 322-3      | 7    | Screw-HH               |
| 6    | 80-4490-03 | 4    | Ring-Deck               | 29  | 106-6406   | 1    | Decal-Recycler         |
| 7    | 322-3      | 8    | Screw-HH                |     |            |      |                        |
| 8    | 3296-29    | 8    | Nut-Lock, NI            |     |            |      |                        |
| 10   | 3296-59    | 1    | Nut-Lock, NI            |     |            |      |                        |
| 11   | 82-6151    | 1    | Discharge Cover ASM     |     |            |      |                        |
| 11:1 | 28-8130    | 1    | Pin-Locking, Chute      |     |            |      |                        |
| 11:3 | 28-8070    | 1    | Lanyard                 |     |            |      |                        |
| 11:4 | 3290-282   | 2    | Rivet-Pop               |     |            |      |                        |
| 11:5 | 3256-49    | 1    | Washer-Flat             |     |            |      |                        |
| 11:6 | 83-7010-03 | 1    | Brace                   |     |            |      |                        |
| 12   | 32103-2    | 1    | Nut-Wing                |     |            |      |                        |
| 13   | 92-8916    | 1    | Bolt-Shoulder           |     |            |      |                        |
| 14   | 93-7694    | 1    | 32 Inch Deflector ASM   |     |            |      |                        |
| 14:1 | 93-7010    | 1    | Decal-Danger            |     |            |      |                        |
| 14:3 | 93-7696    | 2    | Kicker                  |     |            |      |                        |
| 14:4 | 93-0231    | 4    | Screw-PPH               |     |            |      |                        |



## 32 Inch Deck Blade Drive and Brake Assembly


| Ref | Part No.   | Qty. | Description            |
|-----|------------|------|------------------------|
| 1   | 3219-7     | 1    | Nut-Hex                |
| 2   | 88-5060    | 1    | Pulley-Deck            |
| 3   | 88-5760    | 2    | Guide-Belt, Deck       |
| 4   | 3296-42    | 1    | Nut-Lock, NI           |
| 5   | 88-6330    | 1    | Spring-Extension       |
| 6   | 322-5      | 2    | Screw-HH               |
| 7   | 5-4460     | 2    | Washer-Pivot           |
| 8   | 3290-496   | 2    | Nut-Retainer           |
| 9   | 3296-29    | 4    | Nut-Lock, NI           |
| 10  | 3290-307   | 1    | Pin-Hair               |
| 11  | 3256-24    | 3    | Washer-Flat            |
| 13  | 88-5370-03 | 1    | Plate-Mounting, Idler  |
| 15  | 322-3      | 2    | Screw-HH               |
| 16  | 26-6700    | 1    | Spring-Return, Brake   |
| 17  | 3234-13    | 2    | Screw-HHF              |
| 18  | 88-5850-03 | 1    | Arm-Idler Wa (Black)   |
| 19  | 3296-39    | 1    | Nut-Lock, NI           |
| 20  | 56-9870    | 1    | Pulley-Idler           |
| 21  | 7-0030     | 1    | Screw-Shoulder, HH     |
| 22  | 47-4990    | 2    | Post-Mounting, Linkage |
| 24  | 88-5980    | 1    | Rod-Engage, Deck       |
| 25  | 88-5690    | 1    | Rod-Brake, Deck        |
| 26  | 3256-23    | 1    | Washer-Flat            |
| 27  | 88-6110    | 1    | Brake Arm ASM          |

| Ref  | Part No. | Qty. | Description       |
|------|----------|------|-------------------|
| 27:1 | 3290-282 | 2    | Rivet-Pop         |
| 27:2 | 56-9830  | 1    | Pad-Brake         |
| 28   | 88-4590  | 1    | Bolt-Shoulder     |
| 29   | 88-6260  | 1    | V-Belt            |
| 30   | 88-6420  | 1    | Cable Spring ASM  |
| 31   | 67-0710  | 1    | Ball-Swivel, Stop |



Height-of-Cut Assembly


| Ref | Part No.   | Qty. | Description         |  |  |  |  |
|-----|------------|------|---------------------|--|--|--|--|
| 1   | 93-3822-03 | 1    | HOC Lever ASM       |  |  |  |  |
| 2   | 322-32     | 1    | Screw-HH            |  |  |  |  |
| 3   | 88-5900    | 1    | Link-HOC            |  |  |  |  |
| 4   | 3290-307   | 7    | Pin-Hair            |  |  |  |  |
| 5   | 3256-24    | 4    | Washer-Flat         |  |  |  |  |
| 6   | 88-5570-03 | 2    | Link-Adjusting, HOC |  |  |  |  |
| 8   | 80-6990    | 4    | Washer-Hardened     |  |  |  |  |
| 11  | 7-0030     | 3    | Screw-Shoulder, HH  |  |  |  |  |
| 12  | 88-5450    | 2    | Rod-Hanger, Rear    |  |  |  |  |
| 13  | 88-4230    | 2    | Trunnion-HOC        |  |  |  |  |
| 14  | 3296-29    | 8    | Nut-Lock, NI        |  |  |  |  |
| 16  | 88-4730    | 2    | Clamp-Pivot, HOC    |  |  |  |  |
| 17  | 88-6460    | 1    | Spring-Extension    |  |  |  |  |
| 19  | 322-3      | 4    | Screw-HH            |  |  |  |  |
| 22  | 88-5110-03 | 1    | Pivot ASM           |  |  |  |  |
| 23  | 65-7210    | 1    | Spacer              |  |  |  |  |
| 24  | 94-5565    | 1    | Knob-Shift          |  |  |  |  |
| 25  | 5-4460     | 2    | Washer-Pivot        |  |  |  |  |



Electrical Assembly


| Ref  | Part No. | Qty. | Description              |
|------|----------|------|--------------------------|
| 1    | 28-8080  | 1    | Boot-Terminal            |
| 2    | 321-4    | 2    | Screw-HH                 |
| 3    | 104-1755 | 1    | Battery                  |
| 4    | 44-8110  | 1    | Wire ASM                 |
| 5    | 100-3524 | 1    | Switch-Seat              |
| 7    | 32149-2  | 1    | Nut-Keps                 |
| 8    | 106-8245 | 1    | Solenoid                 |
| 9    | 9266714  | 3    | Screw-HWH                |
| 12   | 88-3960  | 1    | Lens-Headlight           |
| 13   | 32149-2  | 2    | Nut-Keps                 |
| 14   | 3255-7   | 2    | Washer-Lock/EXT          |
| 15   | 93-0539  | 2    | Screw-HH                 |
| 16   | 3290-354 | 1    | Nut-Speed                |
| 19   | 88-9932  | 1    | Switch-Micro             |
| 22   | 98-7249  | 1    | Relay                    |
| 23   | 106-6434 | 1    | Harness-Wire             |
| 24   | 88-9830  | 1    | Key Switch ASM           |
| 24:1 | 3254-5   | 1    | Washer-Tooth             |
| 24:2 | 218-461  | 1    | Nut-HH                   |
| 25   | 63-8360  | 1    | Key-Ignition             |
| 28   | 32103-22 | 2    | Nut-Wing                 |
| 30   | 88-4040  | 1    | Box-Battery              |
| 31   | 95-4248  | 1    | Decal                    |
| 33   | 93-3190  | 1    | Boot-Insulator, Terminal |

| Ref | Part No. | Qty. | Description         |
|-----|----------|------|---------------------|
| 34  | 95-7652  | 1    | Light-Indicator     |
| 38  | 3274-14  | 2    | Screw-HSH           |
| 39  | 65-7410  | 1    | Switch-Pole, Single |
| 40  | 3296-2   | 2    | Nut-Lock NI         |



Engine and Muffler Assembly

| Ref | Part No. | Qty. | Description                  |  |  |  |  |
|-----|----------|------|------------------------------|--|--|--|--|
| 1   | 3296-29  | 3    | Nut-Lock, NI                 |  |  |  |  |
| 2   | 322-9    | 4    | Screw-HH                     |  |  |  |  |
| 3   | 88-6060  | 1    | Guide-Belt, LH               |  |  |  |  |
| 4   | 76-3820  | 2    | Anchor-Guide, Belt           |  |  |  |  |
| 5   | 88-5490  | 1    | Guide-Belt, RH               |  |  |  |  |
| 6   | 110-8640 | 1    | Muffler-Exhaust              |  |  |  |  |
| 9   | 107-4904 | 1    | Decal-Engine, Intek          |  |  |  |  |
| 10  |          |      | Engine-B & S, 21B907-0159-B1 |  |  |  |  |
| 11  | 88-5050  | 1    | Pulley-Engine                |  |  |  |  |
| 12  | 62-3760  | 1    | Screw-HH                     |  |  |  |  |
| 13  | 3253-22  | 1    | Washer-Lock                  |  |  |  |  |
| 14  | 3256-25  | 1    | Washer-Flat                  |  |  |  |  |



## 32 Inch Deck Component Assembly

| Ref | Part No.   | Qty. | Description           |
|-----|------------|------|-----------------------|
| 1   | 322-3      | 8    | Screw-HH              |
| 2   | 3296-29    | 14   | Nut-Lock, NI          |
| 3   | 251-297    | 2    | Bearing-Ball          |
| 4   | 56-7030    | 1    | Spindle               |
| 5   | 83-7020    | 1    | Spacer-Bearing        |
| 6   | 80-4390    | 1    | Spacer-Hardned        |
| 7   | 80-4370    | 1    | Shield-Bearing        |
| 8   | 80-4350    | 1    | Shaft-Spindle         |
| 9   | 80-4430    | 1    | Blade-Recycler        |
| 10  | 80-4570-03 | 1    | Stiffener             |
| 11  | 3290-465   | 1    | Washer-Belleville     |
| 12  | 26-0671    | 1    | Screw-HH              |
| 13  | 88-4940-03 | 1    | Suspension-Pan, Front |
| 14  | 28-0540    | 2    | Bolt-Shoulder         |
| 16  | 322-6      | 2    | Screw-HH              |
| 17  | 106661     | 2    | Cam                   |
| 18  | 3256-23    | 2    | Washer-Flat           |
| 19  | 88-5640-03 | 1    | Bracket-RH            |
| 20  | 88-5650-03 | 1    | Bracket-LH            |
| 21  | 322-12     | 2    | Screw-HH              |
| 22  | 95-2747    | 1    | Fitting-Washout       |
| 23  | 46-6290    | 1    | O-Ring Seal           |
| 24  | 3229-1     | 2    | Screw-CARR            |
| 25  | 3256-1     | 2    | Washer-Flat           |

| Ref | Part No. | Qty. | Description  |
|-----|----------|------|--------------|
| 26  | 3296-16  | 2    | Nut-Lock, NI |

# Attachments and Accessories

For 71257 - XL 320 Lawn Tractor

| Product Name                               | Model/Part |
|--------------------------------------------|------------|
| Blade .....                                | 33-4750    |
| Tire Chains .....                          | 47-7220    |
| 8 Inch Rear Wheel Weight Kit .....         | 59159      |
| 9.0 cu. ft. Twin Bagger .....              | 79086      |
| 6.0 cu. ft. Easy-Empty Grass Catcher ..... | 79096      |
| 42 Inch Snow Blade .....                   | 79150      |
| Exhaust Deflector .....                    | 94-6872    |

## NOTES

