


TORO®

MODEL NO. 51576-3900001 & UP

**PARTS
CATALOG****SUPERBLOWER™**
Blower & Vacuum

C-1687


BLOWER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	73-7580	Decal - Cover	1
2	73-1341	Cover - Intake	1
3	73-3090	Foam - Center	1
4	73-1351	Ring - Coupling	1
5	32104-121	Screw - Self Tapping	17
6	60-9613	Housing - Blower, R.H.	1
7	73-3473	Cord - Power Supply	1
8	61-8432	Housing - Blower, L.H.	1
9	218-511	Connector - Wire	1
10	57-4270	Washer - Impeller	2

Ref. No.	Part No.	Description	No. Used
11	73-1370	Motor - Blower	1
12	57-1074	Cover - Motor	1
13	73-5780	Switch - 2 Speed	1
14	73-5790	Diode Assembly	1
15	73-3170	Wire	2
16	57-5910	Switch - Interlock	1
17	57-5942	Switch - Cam, 2 Speed	1
18	57-3261	Collar - Output	1
19	73-1330	Impeller	1
20	73-5380	Nut - Cap, Locking	1

BLOWER TUBE ASSEMBLY

Ref. No.	Part No.	Description	No. Used




C-1685

VACUUM TUBES AND BAGGING KIT Model No. 51533

Ref. No.	Part No.	Description	No. Used
1	73-1460	Tube - Vacuum, Lower	1
2	73-1640	Bag - Vacuum	1

Ref. No.	Part No.	Description	No. Used
3	73-1450	Tube - Vacuum, Middle	1
4	73-3990	Tube - Vacuum, Upper	1



C-1698

ELECTRICAL SCHEMATIC

Ref. No.	Part No.	Description	No. Used

Ref. No.	Part No.	Description	No. Used

TORO PART NUMBER INDEX

3316-281

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
57-1074	Cover - Motor	1 12 1	73-7580	Decal - Cover	1 1 1
57-3261	Collar - Output	1 18 1	73-1450	Tube - Vacuum, Middle	3 3 1
57-3270	Tube - Blower	2 2 2	73-1460	Tube - Vacuum, Lower	3 1 1
57-3280	Nozzle - Concentrating	2 1 1	73-1640	Bag - Vacuum	3 2 1
57-4270	Washer - Impeller	1 10 2	73-3090	Foam - Center	1 3 1
57-5910	Switch - Interlock	1 16 1	73-3170	Wire	1 15 2
57-5942	Switch - Cam, 2 Speed	1 17 1	73-3473	Cord - Power Supply	1 7 1
60-9613	Housing - Blower, R.H.	1 6 1	73-3990	Tube - Vacuum, Upper	3 4 1
61-8432	Housing - Blower, L.H.	1 8 1	73-5380	Nut - Cap, Locking	1 20 1
73-1330	Impeller	1 19 1	73-5780	Switch - 2 Speed	1 13 1
73-1341	Cover - Intake	1 2 1	73-5790	Diode Assembly	1 14 1
73-1351	Ring - Coupling	1 4 1	218-511	Connector - Wire	1 9 1
73-1370	Motor - Blower	1 11 1	32104-121	Screw - Self Tapping	1 5 17

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's

service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

[illegible]

MAINTENANCE RECORD

[illegible]