


TORO®

MODEL NO. 38005-4900001 & UP

PARTS CATALOG


1200 POWER CURVE SNOWTHROWER



C-0477

HOUSING & ROTOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	64-9070	Vane - Outer	2	18	61-8841	Pulley - Drive	1
2	64-9150	Mount - Vane	1	19	32144-87	Screw - Hex. Washer Hd.	2
3	32112-1	Nut - Push On	2	20	61-8800	Belt - Drive	1
4	73-5720	Wheel	2	21	73-5750	Retainer - Idler Pulley	1
5	37-6461	Shaft - Axle	1	22	32104-130	Screw - Self Tap. Pan Hd.	5
6	73-0252	Sleeve - Axle	1	23	73-4990	Pulley - Driven	1
7	61-8771	Rod - Vane Adjustment	1	24	73-4980	Cover - Belt Case	1
8	32144-30	Screw - Self Tapping	3	25	32128-25	Nut - Flange Lock	1
9	61-8720	Baffle - Air	1	26	37-8080	Washer - Thrust	1
10	61-4210	Motor	1	27	32151-61	Ring - Retaining	1
11	32104-121	Screw - Self Tap. Pan Hd.	10	28	39-5190	Washer - Thrust	1
12	61-8870	Mount - Motor	1	29	73-3250	Bushing - Rotor	1
13	218-511	Connector - Wire	2	30	64-9030	Rotor	1
14	64-9100	Housing	1	31	73-1650	Scraper	1
15	61-8880	Spring - Compression Idler	1	32	64-9120	Bushing - Rotor	1
16	73-5740	Arm - Idler	1	33	64-9080	Vane - Center	3
17	61-8780	Bearing - Ball	1	34	73-4960	Shaft - Rotor	1




C-0477

HOUSING & ROTOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
35	64-8871	Bracket - Wheel R.H.	1
*	64-8881	Bracket - Wheel L.H.	1

Ref. No.	Part No.	Description	No. Used
36	3256-75	Washer	2
37	32104-118	Screw - Self Tapping	3

* Not Illustrated




C-0478

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	13-7849	Shroud (Incl. Ref. # 2, 20, & 21)	1
2	64-9050	Decal - 1200	1
3	64-9020	Decal - Toro	1
4	73-1600	Wire Harness	1
5	42-0775	Cord Supply	1
6	73-1690	Handle - Upper Control	1
7	36-8340	Switch - Starter	1
8	37-8000	Switch - Lockout	1
9	37-7990	Spring - Compression	1
10	32104-121	Screw - Self Tap. Pan Hd.	11
11	38-8310	Key	1
12	73-1700	Handle - Lower Control	1

Ref. No.	Part No.	Description	No. Used
13	37-8010	Bar - Switch	1
14	56-6520	Tube - Upper	2
15	73-5660	Bolt - Carriage	2
16	3296-42	Nut - Lock	2
17	64-9040	Handle - Middle	1
18	56-6540	Handle - Lower L.H.	1
*	64-8570	Handle - Lower R.H.	1
19	49-2040	Screw	6
20	64-7011	Decal - Danger	1
21		Decal - U.L.	1
*		Loose Parts Assembly (Incl. Ref. #11, 15, & 16)	1
*	64-8910	Insulator - Power Cord	1

* Not Illustrated



C-1721

ELECTRICAL SCHEMATIC

Ref. No.	Part No.	Description	No. Used

Ref. No.	Part No.	Description	No. Used

TORO PART NUMBER INDEX

3316-330

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
13-7849	Shroud	3 1 1	64-9070	Vane - Outer	1 1 2
36-8340	Switch - Starter	3 7 1	64-9080	Vane - Center	1 33 3
37-6461	Shaft - Axle	1 5 1	64-9100	Housing	1 14 1
37-7990	Spring - Compression	3 9 1	64-9120	Bushing - Rotor	1 32 1
37-8000	Switch - Lockout	3 8 1	64-9150	Mount - Vane	1 2 1
37-8010	Bar - Switch	3 13 1	73-0252	Sleeve - Axle	1 6 1
37-8080	Washer - Thrust	1 26 1	73-1600	Wire Harness	3 4 1
38-8310	Key	3 11 1	73-1650	Scraper	1 31 1
39-5190	Washer - Thrust	1 28 1	73-1690	Handle - Upper Control	3 6 1
42-0775	Cord Supply	3 5 1	73-1700	Handle - Lower Control	3 12 1
49-2040	Screw	3 19 6	73-3250	Bushing - Rotor	1 29 1
56-6520	Tube - Upper	3 14 2	73-4960	Shaft - Rotor	1 34 1
56-6540	Handle - Lower L.H.	3 18 1	73-4980	Cover - Belt Case	1 24 1
61-4210	Motor	1 10 1	73-4990	Pulley - Driven	1 23 1
61-8720	Baffle - Air	1 9 1	73-5660	Bolt - Carriage	3 15 2
61-8771	Rod - Vane Adjustment	1 7 1	73-5720	Wheel	1 4 2
61-8780	Bearing - Ball	1 17 1	73-5740	Arm - Idler	1 16 1
61-8800	Belt - Drive	1 20 1	73-5750	Retainer - Idler Pulley	1 21 1
61-8841	Pulley - Drive	1 18 1	218-511	Connector - Wire	1 13 2
61-8870	Mount - Motor	1 12 1	3256-75	Washer	2 36 2
61-8880	Spring - Compression Idler	1 15 1	3296-42	Nut - Lock	3 16 2
64-7011	Decal - Danger	3 20 1	32104-118	Screw - Self Tapping	2 37 3
64-8570	Handle - Lower R.H.	3 * 1	32104-121	Screw - Self Tap. Pan Hd.	3 10 11
64-8871	Bracket - Wheel R.H.	2 35 1	32104-121	Screw - Self Tap. Pan Hd.	1 11 10
64-8881	Bracket - Wheel L.H.	2 * 1	32104-130	Screw - Self Tap. Pan Hd.	1 22 5
64-8910	Insulator - Power Cord	3 * 1	32112-1	Nut - Push On	1 3 2
64-9020	Decal - Toro	3 3 1	32128-25	Nut - Flange Lock	1 25 1
64-9030	Rotor	1 30 1	32144-30	Screw - Self Tapping	1 8 3
64-9040	Handle - Middle	3 17 1	32144-87	Screw - Hex. Washer Hd.	1 19 2
64-9050	Decal - 1200	3 2 1	32151-61	Ring - Retaining	1 27 1

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's

service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

MAINTENANCE RECORD

[illegible]

Litho in U.S.A.