



Boom Mounting Kit Multi-Pro® 1200, 1250 and 5700-D

Model No. 41323 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Multi-Pro 1200 and 1250 Boom Kit Assembly	 3	Left and Right Hand Boom Assembly	 9
Multi-Pro 5700-D Boom Kit Assembly	 4	RH Single Body Turret Assembly No. 108-3726	 10
Right Hand Boom Mount Assembly	 5	LH Single Turret Body Assembly No. 108-3725	 11
Left Hand Boom Mount Assembly	 6	Double Turret Body Assembly No. 108-3727	 12
Center Boom Assembly	 7		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes

❶ Not illustrated

❷ Not serviced separately

3



Multi-Pro 5700-D Boom Kit Assembly


Ref	Part No.	Qty.	Description				
21		1	Boom ASM				
22		1	RH Boom Mount ASM				
23		1	LH Boom Mount ASM				
14	110-5161	1	Harness-Wire, Boom				
4:1	108-3736	2	Breaker-Circuit, 30A				
4:2	108-9493	2	Diode-Tvs				
9	3218-5	2	Nut-Jam				
10	3234-5	2	Screw-HHF				
11	2412-129	4	Clamp-Hose				
12	108-3256	1	Hose-Jumper				
13	108-3711-03	1	Bracket-Support, Valve				
14	108-3712-03	1	Bracket-Valve, Boom				
15	100-8524	1	Strip-Foam				
17	108-3720	2	Hose-Boom, LH				
18	325-4	2	Screw-HH				
20	99-7430	4	Relay				

Right Hand Boom Mount Assembly

Ref	Part No.	Qty.	Description
1	108-3714-03	1	RH Boom Mount ASM
2	107-8638-03	1	Wedge-Tube
3	107-8620	1	Screw-HH
4	32121-41	1	Pin-Roll

Left Hand Boom Mount Assembly


Ref	Part No.	Qty.	Description
1	108-3715-03	1	LH Boom Mount ASM
2	107-8638-03	1	Wedge-Tube
3	107-8620	1	Screw-HH
4	32121-41	1	Pin-Roll



Center Boom Assembly


Ref	Part No.	Qty.	Description
1	108-3489	4	Cap-Tube
2	108-3495	2	Cover-Slide
3	108-3457	2	Spacer
4	108-3476-03	2	Upper Cradle ASM
5	104-8301	12	Nut-Flange, NI
6	108-3472-03	2	Lower Cradle ASM
7	110-5057	4	Capscrew-HHF
8	110-5050	10	Screw-HHF
9	108-3408-03	1	Frame-Mount, Boom (LH)
10	108-3723	1	Grommet
11	108-3745	4	Nut-HF, Whiz
12	108-3409-03	1	Frame-Mount, Boom (RH)
13	108-3744	2	Screw-Shoulder
14	114-9566	2	Clamp-R
15	108-3743	2	Washer
16	104-8300	17	Nut-Flange, NI
17	108-3469-03	1	Plate-Washer
18	108-3726	1	Body-Turret, Single (RH)
19	108-3718	1	Hose-Boom, Center (RH)
20	2412-129	7	Clamp-Hose
21	108-3439	1	Tee
22	108-3717	1	Hose-Boom
23	3296-23	2	Nut-Lock, NI
24	95-9187	6	Cap-Blank

Ref	Part No.	Qty.	Description
24:1	40998	1	Seat-Gasket
25	114-9576	2	Decal-Pinchpoint
26	108-3727	1	Body-Turret, Double
27	95-9186	3	Cap
27:1	40998	1	Seat-Gasket
28	108-3735	1	Hose-Boom, Center (LH)
29	114-9579-03	1	Frame ASM
30	108-3725	1	Body-Turret, Single (LH)
31	107-8775	3	Bracket-Mount, Nozzle
32	110-5053	2	Screw-Flange
33	112-7884	2	Pivot Pin ASM
34	114-9560-03	1	Strap-Clevis
35	108-3436	2	Pin-Clevis
36	3290-468	2	Pin-Cotter
37	3269-18	6	Rivet-Pop
38	108-3438	2	Actuator
39	108-3742	2	Screw-HHF
40	110-5067	2	Screw-CARR
41	110-5070	2	Bumper-Neoprene
42	3256-68	2	Washer-Flat
43	32128-54	2	Nut-HF
44	112-7881	2	Bumper
45	108-3748	8	Screw-HHF
46	112-7872-03	2	Bracket-Hard Stop



Center Boom Assembly (continued)


Ref	Part No.	Qty.	Description
47	105-1763	2	Screw-HHF



Left and Right Hand Boom Assembly


Ref	Part No.	Qty.	Description
1	108-3459	4	Boot-Hinge
2	108-3440	4	Spring-Breakaway, Boom
3	108-3730	4	Tube-Hinge
4	108-3444	4	Retainer-Spring
5	3296-15	4	Nut-Lock, NI
6	108-3738	4	Screw-HH
7	110-5054	4	Washer-Flat
8	302-5	8	Fitting-Grease
9	110-5050	16	Screw-HHF
10	108-3605	8	Plate-Backing
11	104-8300	10	Nut-Flange, NI
14	108-3429	4	Block-Slide
15	108-3746	8	Screw-Plastite
16	108-3524-03	1	RH Boom ASM
17	108-3525-03	1	LH Boom ASM
18	108-3726	2	Body-Turret, Single (RH)
19	108-3725	2	Body-Turret, Single (LH)
20	40506	4	Hose-Jumper
21	2412-129	18	Clamp-Hose
22	108-3727	4	Body-Turret, Double
23	240-3	4	Grommet-Rubber
24	108-3721	2	Hose-Boom
25	104-8301	16	Nut-Flange, NI
26	108-3439	2	Tee

Ref	Part No.	Qty.	Description
27	108-3728	2	Hose-Boom
28	95-9186	8	Cap
28:1	40998	1	Seat-Gasket
30	95-9187	16	Cap-Blank
30:1	40998	1	Seat-Gasket
31	108-3471-03	4	Hinge
32	108-3600-03	2	Bracket-Pivot
33	100-8541	4	Bushing-A Arm
34	108-3748	2	Screw-HHF
35	108-3419	2	Pivot Pin ASM
36	107-8650	2	Conduit-Convoluted
37	3290-378	4	Tie-Cable




RH Single Body Turret Assembly No. 108-3726

Ref	Part No.	Qty.	Description				
1	95-9200	1	Plug				
2	95-9198	1	O-Ring				
3	95-9197	1	E-Clip				
4	95-9199	2	O-Ring				
5	108-3264	1	Seal-Viton				
6	108-3265	1	O-Ring-Viton				
7	95-9196	1	Turret				
8	41003	1	Diaphragm				
9	95-9193	1	Cap-Diaphragm				
10	95-9192	1	Body-Split Eyelet				
11	95-9191	1	O-Ring				
12	99-0811	1	Screw-Clamp				
13	99-0812	1	Clamp-Upper				
14	99-0814	1	Pin-Pivot				
15	95-9201	1	Shank-Hose				
16	322-3	1	Screw-HH				



LH Single Turret Body Assembly No. 108-3725

Ref	Part No.	Qty.	Description				
1	95-9200	1	Plug				
2	95-9198	1	O-Ring				
3	95-9197	1	E-Clip				
4	95-9199	2	O-Ring				
5	108-3264	1	Seal-Viton				
6	108-3265	1	O-Ring-Viton				
7	95-9196	1	Turret				
8	41003	1	Diaphragm				
9	95-9193	1	Cap-Diaphragm				
10	95-9192	1	Body-Split Eyelet				
11	95-9191	1	O-Ring				
12	99-0811	1	Screw-Clamp				
13	99-0812	1	Clamp-Upper				
14	99-0814	1	Pin-Pivot				
15	95-9201	1	Shank-Hose				
16	322-3	1	Screw-HH				



Double Turret Body Assembly No. 108-3727

Ref	Part No.	Qty.	Description				
1	95-9200	1	Plug				
2	95-9198	1	O-Ring				
3	95-9197	1	E-Clip				
4	95-9199	2	O-Ring				
5	108-3264	1	Seal-Viton				
6	108-3265	1	O-Ring-Viton				
7	95-9196	1	Turret				
8	41003	1	Diaphragm				
9	95-9193	1	Cap-Diaphragm				
10	95-9192	1	Body-Split Eyelet				
11	95-9191	1	O-Ring				
12	99-0811	1	Screw-Clamp				
13	99-0812	1	Clamp-Upper				
14	99-0814	1	Pin-Pivot				
15	95-9202	1	Shank-Hose				
16	322-3	1	Screw-HH				

NOTES

NOTES

NOTES

