Form Number 3361-477 Rev A

# 20in Mulching/Rear Bagging Lawn Mower

**Model No. 10644C - 290000001 and up.**

## Parts Catalog

**Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© Lawn-Boy Inc. - 2009
All Rights Reserved

Register your product at www.LawnBoy.co

# Contents


| Description | Page | Description | Page |
|---|---|---|---|
| Housing Assembly | . . . . . 3 | Engine and Blade Assembly | . . . . . 6 |
| Front Axle Assembly | . . . . . 4 | Handle and Control Assembly | . . . . . 7 |
| Rear Axle and Transmission Assembly | . . . . . 5 | Rear Bag Assembly | . . . . . 8 |
| | | Attachments and Accessories List | . . . . . 9 |


# Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

# Footnotes

❶ Not serviced separately


❷ Obtain from your local Briggs & Stratton dealer




# Housing Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 117-4153 | 1 | Housing ASM |
| 1:2 | 94-8072 | 1 | Decal-Danger |
| 1:3 | 117-4131 | 1 | Decal |
| 1:4 | 112-8824-02 | 1 | Baffle-Front |
| 2 | 112-8845 | 1 | Chute-Rear |
| 3 | 112-8821 | 1 | Baffle-Rear |
| 4 | 46-8091 | 5 | Screw-HWH |
| 6 | 117-5923 | 1 | Rear Deflector ASM |
| 7 | 112-8848 | 1 | Spring-Torsion, LH |
| 8 | 112-8849 | 1 | Spring-Torsion, RH |
| 11 | 46-8093 | 3 | Screw-Plastite |

| | | | |
|---|---|---|---|
| | | | |




# Front Axle Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 614650 | 2 | Bolt-Shoulder |
| 2 | 112-1548 | 2 | 7 Inch Front Wheel ASM |
| 3 | 614672 | 2 | Bolt-Shoulder |
| 4 | 40-1940 | 4 | Washer |
| 5 | 107-3877 | 1 | Arm-Pivot, RH |
| 6 | 92-4890 | 2 | Washer |
| 7 | 112-8828 | 2 | Arm-Spring, Front |
| 8 | 105-3042 | 2 | Knob-Lever, HOC |
| 9 | 3296-39 | 2 | Nut-Lock, NI |
| 10 | 108-1044 | 1 | Arm-Pivot, LH |
| 11 | 117-4161 | 1 | Brace-Front |
| 12 | 80-6990 | 2 | Washer-Hardened |




# Rear Axle and Transmission Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 614650 | 2 | Bolt-Shoulder |
| 2 | 107-3906 | 2 | Rear Wheel ASM |
| 3 | 32151-61 | 2 | Ring-Retaining |
| 4 | 110-9417 | 2 | Pinion |
| 5 | 110-1793 | 2 | Wheel Cover ASM |
| 5:2 | 614426 | 1 | Washer-Stepped |
| 6 | 108-9781 | 2 | Arm-Pivot, Rear |
| 7 | 108-9780 | 2 | Arm-Spring |
| 8 | 105-3042 | 2 | Knob-Lever, HOC |
| 9 | 112-8822-03 | 1 | Plate-HOC, LH |
| 10 | 108-9779 | 2 | Retainer-Bushing, HOC |
| 11 | 108-9782 | 2 | Bushing-Sleeve |
| 12 | 104-8699 | 2 | Bearing-Ball |
| 13 | 112-8823-03 | 1 | Plate-HOC, RH |
| 14 | 112-8768 | 1 | Shield-Trailing |
| 15 | 112-8831 | 1 | Transmission ASM |
| 16 | 110-9429 | 1 | V-Belt |
| 17 | 114-7977-03 | 1 | Bracket-Transmission |
| 18 | 108-7476 | 3 | Screw-Plastite |
| 19 | 117-1092 | 2 | Screw-PPH |
| 20 | 322-3 | 4 | Screw-HH |
| 21 | 3296-29 | 4 | Nut-Lock, NI |
| 22 | 110-7191 | 2 | Washer-Thrust |
| 23 | 3229-11 | 2 | Screw-CARR |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 24 | 3296-16 | 2 | Nut-Lock, NI |





# Engine and Blade Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 105-8579 | 1 | Bolt-Blade |
| 2 | 108-3766-03 | 1 | Support-Blade |
| 3 | 112-8841-03 | 1 | Blade-20In |
| 4 | 106-3987 | 1 | Blade Driver ASM |
| 5 | 106-3999 | 1 | Spacer-Driver |
| 6 | 95-1726 | 3 | Screw-Taptite |
| 7 | 105-3030-03 | 1 | Guide-Belt |
| 8 | 112-8829 | 1 | Cover-Belt |
| 9 | 46-8091 | 3 | Screw-HWH |
| 10 | 32144-1 | 3 | Screw-Taptite |
| 11 | 104-7577-03 | 1 | Shield-Muffler |
| ❶❷12 | | 1 | Engine-B&s, 124T02-0222-B1 |
| 13 | 2210-316 | 1 | Stop-Rope |
| 14 | 112-8844 | 1 | Decal |




# Handle and Control Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 112-8833-05 | 1 | Handle |
| 2 | 86-9671 | 1 | Guide-Rope |
| 3 | 3256-1 | 1 | Washer-Flat |
| 4 | 3296-73 | 2 | Nut-Lock, NI |
| 5 | 112-8834-02 | 1 | Bail-Brake, 2-Bail Flat |
| 6 | 92-2270 | 1 | Screw-Handle |
| 7 | 106-6805 | 1 | Guide-Cable |
| 8 | 112-8818 | 1 | Cable-Brake |
| 9 | 108-8162 | 2 | Knob-Locking |
| 10 | 3230-6 | 2 | Screw-CARR |
| 11 | 112-8835-02 | 1 | Bail-Traction, 2-Bail Flat |
| 12 | 112-8817 | 1 | Cable-Traction |




# Rear Bag Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 112-8836 | 1 | Grass Bag ASM |
| 2 | 112-8825-03 | 1 | Frame-Bag |

# Attachments and Accessories

## For 10644C - 20in Mulching/Rear Bagging Lawn Mower

| Product Name | Model/Part |
|---|---|
| Loose Parts Kit | 117-5929 |
| 20in Replacement Blade | 89963 |

# NOTES

# NOTES


LAWN·BOY®