




MODEL NO. 07345-40001 & UP


**PARTS
CATALOG**
POWER PLATFORM


T-1791

FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290-255	Pin - Cotter Hair	1
2	67-5360	Decal - Danger	1
3	92-2792	Mounting Plate Assembly	2
5	32148-9	Insert - Threaded	24
6	83-6620	Decal - Instruction	1
7	92-2785	Platform W/A (Incl. Ref. #2, & 6)	1
8	92-9028	Cover Assembly	1

Ref. No.	Part No.	Description	No. Used
9	92-9026	Wire Harness	1
10	92-9033	Clamp - Arden	1
11	32104-116	Screw - Tapping	1
12	3290-379	Tie - Cable	1
13	92-9027	Wire Harness	1
14	32128-20	Nut - Lock	4
15	3234-17	Screw	4




T-1792

SHIELD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	322-3	Screw - Hex Head	2
2	32148-6	Insert - Threaded	2
3	80-8040	Decal - Caution	1
4	65-5100	Handle - Hood	1
5	74-5950	Swell Latch Ass'y (Incl. Ref. #13, & 14)	2
6	62-7400	Decal - Toro	1
7	92-2786	Shield (Incl. Ref. #2, 3, & 6)	1

Ref. No.	Part No.	Description	No. Used
8	237-84	Grommet	4
9	2412-133	R-Clamp	2
10	3296-47	Nut - Lock	2
11	46-8091	Screw - Tapping	2
12	74-0720	Tube - Manual	1
13		Spacer	2
14		Nut	2




T-1793

IDLER ARM ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32146-2	Nut - Hex Lock	1
2	41353	Pulley - Idler	1
3	3256-24	Washer	2
4	92-9025	Spacer	1
5	92-9020	Idler Arm W/A	1

Ref. No.	Part No.	Description	No. Used
6	323-9	Screw - Hex Head	1
7	256-116	Bushing - Flange	2
8	32151-47	E-Ring	1
9	49-6920	Spring	1




T-1794

PULLEY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296-45	Nut	1
2	92-2651	Washer	1
3	92-9015	Belt - 48"	1
*	92-2783	Belt - 51"	1
4	92-9014	Pulley	1
5	92-2650	Spacer	4
6	251-82	Ball Bearing	2
7	3-6168	Key - Square	2

Ref. No.	Part No.	Description	No. Used
8	92-9032	Shaft	1
9	87-2750	Spacer - Bearing	1
10	32151-83	Ring - Snap	1
11	92-9016	Pulley	1
12	32146-2	Nut - Hex Lock	2
13	92-9011	Bearing Support W/A	1
14	323-12	Screw - Hex Head	2

*Not Illustrated



T-1795

TOOLBOX (Optional)

Ref. No.	Part No.	Description	No. Used
1	92-2775	Latch	1
2	92-2773	Toolbox	1

Ref. No.	Part No.	Description	No. Used
3	92-2796	Key	1

TORO PART NUMBER INDEX

3316-436

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
41353	Pulley – Idler	3 2 1	92-9026	Wire Harness	1 9 1
3-6168	Key – Square	4 7 2	92-9027	Wire Harness	1 13 1
46-8091	Screw – Tapping	2 11 2	92-9028	Cover Assembly	1 8 1
49-6920	Spring	3 9 1	92-9032	Shaft	4 8 1
62-7400	Decal – Toro	2 6 1	92-9033	Clamp – Arden	1 10 1
65-5100	Handle – Hood	2 4 1	237-84	Grommet	2 8 4
67-5360	Decal – Danger	1 2 1	2412-133	R-Clamp	2 9 2
74-0720	Tube – Manual	2 12 1	251-82	Ball Bearing	4 6 2
74-5950	Swell Latch Ass'y	2 5 2	256-116	Bushing – Flange	3 7 2
80-8040	Decal – Caution	2 3 1	322-3	Screw – Hex Head	2 1 2
83-6620	Decal – Instruction	1 6 1	323-9	Screw – Hex Head	3 6 1
87-2750	Spacer – Bearing	4 9 1	323-12	Screw – Hex Head	4 14 2
92-2650	Spacer	4 5 4	3234-17	Screw	1 15 4
92-2651	Washer	4 2 1	3256-24	Washer	3 3 2
92-2773	Toolbox	5 2 1	3290-255	Pin – Cotter Hair	1 1 1
92-2775	Latch	5 1 1	3290-379	Tie – Cable	1 12 1
92-2783	Belt – 51	4 1 1	3296-45	Nut	4 1 1
92-2785	Platform W/A	1 7 1	3296-47	Nut – Lock	2 10 2
92-2786	Shield	2 7 1	32104-116	Screw – Tapping	1 11 1
92-2792	Mounting Plate Assembly	1 3 2	32128-20	Nut – Lock	1 14 4
92-2796	Key	5 3 1	32146-2	Nut – Hex Lock	3 1 1
92-9011	Bearing Support W/A	4 13 1	32146-2	Nut – Hex Lock	4 12 2
92-9014	Pulley	4 4 1	32148-6	Insert – Threaded	2 2 2
92-9015	Belt – 48	4 3 1	32148-9	Insert – Threaded	1 5 24
92-9016	Pulley	4 11 1	32151-47	E-Ring	3 8 1
92-9020	Idler Arm W/A	3 5 1	32151-83	Ring – Snap	4 10 1
92-9025	Spacer	3 4 1			

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's

service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

MAINTENANCE RECORD

[illegible]