Form Number 3361-910 Rev A

Commercial Walk-Behind Mower

Floating Deck T-Bar Gear with 32in Cutting Unit

Model No. 30092 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2009
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page
Fuel Tank and Idler Bracket Assembly	3
Transmission and Idler Pulley Assembly	4
Brake, Wheel Pulley and Wheel Assembly	5
Handle and Control Panel Assembly	6
Engine Assembly	7
Carrier Assembly	8
Deck Assembly	9
Spindle and Blade Assembly	10
Decal and Mulcher Cover Assembly	11
Cylinder and Crankcase Assembly Kawasaki FH430V-AS35	12
Piston and Crankshaft Assembly Kawasaki FH430V-AS35	13
Valve and Camshaft Assembly Kawasaki FH430V-AS35	14
Lubrication Equipment Assembly Kawasaki FH430V-AS35	15
Cooling Equipment Assembly Kawasaki FH430V-AS35	16
Electric Equipment Assembly Kawasaki FH430V-AS35	17
Control Equipment Assembly Kawasaki FH430V-AS35	18
Carburetor Assembly Kawasaki FH430V-AS35	19
Air Filter and Muffler Assembly Kawasaki FH430V-AS35	20
Fuel Tank and Valve Assembly Kawasaki FH430V-AS35	21
Starter Assembly Kawasaki FH430V-AS35	22
Label Assembly Kawasaki FH430V-AS35	23
Attachments and Accessories List	24

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
CCW. . . . . counter clock wise
CW. . . . . clockwise
DEG. . . . . degrees
ECM. . . . . electronic control module
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

Footnotes

❶ Not serviced separately


❷ Obtain parts from www.kawpowerepc.com



Fuel Tank and Idler Bracket Assembly

Ref	Part No.	Qty.	Description
1	88-3980	1	Gas Cap ASM
1:3	88-4010	1	Gasket-Cap, Gas
2	106-0730	1	Fuel Tank ASM
2:2	103-2605	1	Fitting-Fuel, Bulkhead
5	3296-39	8	Nut-Lock, NI
6	74-0040	4	Spacer-Pivot, Idler
7	51-4370	1	Spring-Torsion, RH
8	51-4380	1	Spring-Torsion, LH
9	32103-25	2	Nut-Wing
10	3256-23	12	Washer-Flat
11	52-2890	2	Bushing-Nylon
12	3290-307	4	Pin-Hair
13	108-2741-01	1	RH Idler Arm ASM
14	108-2740-01	1	LH Idler Arm ASM
15	74-0521	2	Fitting-Rod
16	283-6	2	Pin-Clevis
17	67-6370-01	1	Bracket-Support, RH
18	67-6380-01	1	Bracket-Support, LH
19	323-16	2	Screw-HH
20	323-6	6	Screw-HH
21	3296-23	2	Nut-Lock, NI
22	95-2800	2	Pulley-Idler
23	95-2801	2	Spacer-Pulley
24	51-4450	2	Screw-Leveler


Ref	Part No.	Qty.	Description
25	68-9690	2	Fitting-Rod
26	237-124	1	Grommet
29	105-4670-01	1	Frame ASM
30	322-4	4	Screw-HH
31	3253-4	2	Washer-Lock
33	95-2814	1	Decal-Shut Off, Fuel
34	106-0649-01	1	Frame-Upper
36	98-0776	1	Decal-Caution
37	104-8121	2	Stud-Threaded
38	1-633349	2	Spring-Tank, Fuel
39	3296-47	2	Nut-Lock, NI



Transmission and Idler Pulley Assembly

Ref	Part No.	Qty.	Description
1	98-3274-03	1	Lever-Shift
2	47-1970	1	Grip
3	3296-42	4	Nut-Lock, NI
4	32120-64	1	Ring-Snap, External
5	1-323252	2	Bearing-Shaft
6	321-4	4	Screw-HH
7	104-1102	2	Shaft-Output
9	3257-5	3	Key-Woodruff
10	3245-9	2	Screw-Set
11	105-2698	2	Pulley-Transmission
12	51-4220	2	Guard-Coupler
13	1-323680	2	Coupler
14	302-5	2	Fitting-Grease
15	3245-1	1	Screw-Set, HSH
16	51-4190	1	Pulley-Driven
17	26-9671	1	Belt V
18	323-9	1	Screw-HH
19	51-4810	1	Pulley-Idler
20	3256-24	1	Washer-Flat
21	32128-21	1	Nut-HF
22	322-2	4	Screw-HH
23	3253-4	4	Washer-Lock
24	1-323500	1	Transmission
25	3296-6	1	Nut-Lock


Ref	Part No.	Qty.	Description
26	98-5975	1	Washer-Belleville
27	1-323379	1	Washer
28	32151-62	2	Ring-Retaining
29	3256-24	1	Washer-Flat
30	1-323254	2	Flange-Output
31	95-1526	1	Shield-Trailing
32	95-1529	1	Rod-Shield
33	1-323387-03	1	Plate-Shift
34	98-3256	1	Decal-Speed, Ground
35	3230-1	2	Bolt-CARR
36	1-323389-03	2	Bracket-Plate, Shift
37	32128-20	2	Nut-HF
38	9264964	4	Screw-HWH, Thread Cut



Brake, Wheel Pulley and Wheel Assembly

Ref	Part No.	Qty.	Description
1	51-4580	2	Rod-Brake
2	3290-307	2	Pin-Hair
3	67-6400-01	1	Arm-Brake, RH
4	67-6420-01	1	Arm-Brake, LH
5	32151-40	2	Ring-Retaining
6	32151-56	2	Ring-Retaining, External
7	51-4660-01	2	Plate-Link, Brake
8	51-4650-01	2	Link-Brake
9	93-1163	2	Wheel And Tire ASM
9:1	231-94	1	Tire-Front
9:2	93-1181	1	Wheel ASM
9:3	92-1746	2	Bearing-Ball
9:4	302-57	1	Fitting-Grease
9:5	232-27	1	Stem-Valve
10	10-8110	8	Washer-Thrust
11	32151-91	2	Ring-Retaining
12	51-4291	2	V-Belt
13	51-4170	8	Spacer-Pulley
14	51-4160-03	4	Pulley-Wheel
15	51-4180-03	2	Drum-Brake
16	3253-4	8	Washer-Lock
17	51-4700	2	Band-Brake
18	322-7	8	Screw-HH
19	51-4230	2	Washer-Wheel


Ref	Part No.	Qty.	Description
20	32151-72	4	Ring-Retaining



Handle and Control Panel Assembly

Ref	Part No.	Qty.	Description
1	82-7690-03	1	Bar-Control
2	82-2290	1	Decal
3	3296-2	5	Nut-Lock, NI
4	82-7680-03	1	Bail ASM
5	32105-1	1	Screw-SHH
6	106-5477-03	1	Control Pivot ASM
7	82-2280	1	Decal
8	3272-11	2	Pin-Cotter
9	105-3158-03	1	Upper Handle ASM
10	112-8712	1	Cable-Choke
11	104-8140	1	Switch-PTO
12	63-8360	2	Key-Ignition
14	3296-42	1	Nut-Lock, NI
16	93-1187-03	1	Panel-Bottom
17	104-8141	1	Module-Delay
18	321-2	1	Screw-HH
19	283-55	2	Pin-Clevis
21	112-8711	1	Cable-Throttle
23	29-5560	1	Switch-On / Off
23:1	218-461	1	Nut-HH
23:2	3254-5	1	Washer-Tooth
24	3290-378	2	Tie-Cable
25	104-8137	1	Harness-Wire
26	2412-120	2	R-Clamp


Ref	Part No.	Qty.	Description
27	32104-76	4	Screw
28	110-4982-03	1	Panel-Control
29	104-7050	1	Tube-Manual
30	32128-21	4	Nut-HF
31	3234-11	4	Screw-HHF
32	32105-14	4	Screw-SHH
33	110-4971	1	Decal-Control Panel
34	105-0884	1	Decal-Danger
35	82-7632	2	Rod-Control
36	218-595	1	Connector-Body
37	51-4850-03	1	Lever-Brake, Parking
38	52-2010	1	Decal-Lever, Parking
39	82-2190	1	Switch-Bail
40	3290-307	2	Pin-Hair
41	237-141	2	Grommet-Rubber
42	98-4387	1	Decal-Protection, Ear
43	104-7048	1	Cap-Housing
44	114241	1	Fuse-7.5 Amp



Engine Assembly

Ref	Part No.	Qty.	Description
❶❷1		1	Engine-Kawasaki, FH430V-As35
3	2412-87	1	Clamp-Cable
4	56-6360	1	Filter-Fuel
5	2412-98	4	Clamp
6	33114-016	1	Screw-HH
7	110-4894	1	Hose-Fuel
8	3255-8	1	Washer-Lock
10	3256-23	5	Washer-Flat
12	32128-20	6	Nut-HF
13	1-633543-03	1	Strap-Clutch, Brake
14	94-5847-01	1	Cover-Pulley
15	3212-9	1	Screw-HH
16	107-4136	1	Washer
17	105-2635	1	Clutch / Brake
18	608006	1	Key-Square
19	107-4112	1	Pulley-Drive
20	322-7	4	Screw-HH
24	1-613235	4	Washer
26	103-1966	1	Adapter
27	92-6877	1	Valve-Drain, Oil
29	106-0699	1	Decal-Warning
30	107-0588	1	Hose-Fuel
31	1-603770	1	Valve-Fuel
33	1-633545	2	Spacer


Ref	Part No.	Qty.	Description
34	1-633630	2	Grommet-Brake
36	322-11	1	Screw-HH
37	104-6373	1	Tube-Retainer
38	1-603610	2	Washer-Spring
39	322-9	1	Screw-HH
40	115-4150-03	1	Muffler Shield ASM
41	115-4154-03	1	Bracket-Muffler
42	94-2413	4	U-Nut
43	322-3	4	Screw-HH
99	103-1964	1	Hose-Drain, Oil



Carrier Assembly


Ref	Part No.	Qty.	Description
1	74-0080	1	Carrier Frame ASM
2	94-1291	4	Bushing
3	74-0330	4	Pad-Rubber
4	3269-24	16	Rivet
5	32151-91	2	Ring-Retaining
6	3-6781	4	Washer-Thrust
7	93-1166	2	Spacer-Castor
8	325-18	2	Screw-HH
9	67-6220	2	Spanner
10	93-1164-01	2	Fork-Caster ASM
11	32153-5	2	Nut-Lock, Side
12	63-8400	2	Caster Wheel ASM
12:1	62-5580	2	Bearing-Outside
12:2	63-8580	1	Bearing-Roller
12:3	302-40	1	Fitting-Grease
13	67-6570	4	Spacer-Wheel
14	302-5	2	Fitting-Grease
15	256-156	2	Bushing-Flange
16	74-0290	2	Spring
17	41-8440	2	Washer
18	3218-5	4	Nut-Jam
19	74-0310	2	Shaft-Adjusting
20	3296-45	2	Nut-Lock, NI
21	3234-6	6	Screw-HHF

Ref	Part No.	Qty.	Description
22	32128-23	6	Nut-HF




Deck Assembly

Ref	Part No.	Qty.	Description
1	14-5079	1	32 Inch Deck ASM W/ Decals
❶2		1	Spindle ASM
5	32153-2	1	Nut-Lock, Side
6	28-8010	1	Spring
7	44-5930	1	Deflector ASM
7:2	54-9220	1	Decal-Danger
8	28-7350	1	Post-Pivot
9	67-6180	1	Strip-Magnetic
10	3234-29	2	Screw-HHF
11	67-6160-01	1	Cover
12	104-8587	1	Knob
13	3256-24	1	Washer-Flat
14	32151-72	1	Ring-Retaining
15	74-0570	1	Guide-Belt
16	3290-355	4	Pin-Hair
17	67-6140	2	Rod-Support
18	3296-29	24	Nut-Lock, NI
19	322-4	24	Screw-HH
20	92-5419-03	4	Ring-Recycler
21	3290-496	2	Nut-Retainer
22	80-2630-03	4	Kicker
23	67-6920	1	V-Belt




Spindle and Blade Assembly

Ref	Part No.	Qty.	Description
1	104-6325	2	Bearing-Ball
2	32146-20	1	Nut-Jam
3	3253-23	1	Washer-Lock/Sp
4	51-4060	1	Screw-Blade
5	67-6060-03	1	Housing-Spindle
6	67-6070	1	Spacer-Bearing
7	67-6080	1	Spacer
8	92-6313	1	Cup-Scalp, Anti
9	106-0776	1	Washer-Pinion
10	74-0580	1	Pulley ASM
11	80-4430-03	1	Blade-Recycler
12	82-4750-03	1	Spacer-Blade
13	105-4607-03	1	Spindle Shaft ASM




Decal and Mulcher Cover Assembly

Ref	Part No.	Qty.	Description
1	66-1340	1	Decal-Danger, Thrown Object
2	67-5360	1	Decal-Danger
3	105-2625	1	Decal-STD, Safety
4	68-8340	1	Decal-Torque
5	93-1159	1	Decal-HOC
6	106-0719	1	Decal
7	67-6170	1	Decal
8	54-0910	1	Decal-Hot
9	66-6380	1	Decal-Danger
10	92-5422	1	Mulcher Cover ASM
10:1	28-8070	1	Lanyard
10:2	28-8130	1	Pin-Locking, Chute
10:3	3256-49	1	Washer-Flat
10:4	3290-282	1	Rivet-Blind
11	322-11	1	Screw-HH
12	3256-23	2	Washer-Flat
13	3296-29	1	Nut-Lock, NI




Cylinder and Crankcase Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷11004	11004-7018	2	Gasket-Head
❷11008	11008-7021	1	Head-Cylinder, No. 2
❷11008A	11008-7022	1	Head-Cylinder, No. 1
❷11022	11022-7003	2	Case-Rocker
❷11060	11060-7001	2	Gasket-Case, Rocker
❷11061	11061-7007	1	Gasket-Cover, Crankcase
❷11061A	11061-7008	1	Gasket-Breather
❷14091	14091-7007	1	Cover
❷49015	49015-7032	1	Cover-Crankcase
❷49120	49120-7015	1	Crankcase
❷59071	59071-2079	1	Joint
❷92043	92043-7001	6	Pin
❷92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)
❷92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)
❷92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)
❷92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)
❷92139	92139-7008	1	Bushing
❷92153	92153-7043	4	Bolt (6X12)
❷92153A	92153-7054	17	Bolt (8X50)
❷130	130B0640	4	Bolt-Flanged (6X40)
❷130A	130CA0875	2	Bolt-Flanged (8X75)
❷172	172G0818	4	Bolt-Stud (8X18)




Piston and Crankshaft Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷13001	13001-7022	2	Piston-Engine
❷13002	13002-7001	2	Pin-Piston
❷13008	13008-7001	2	Piston Ring Set
❷13025	13025-7003	1	Piston Ring Set (L 0.50)
❷13029	13029-7005	1	Piston-Engine (L 0.50)
❷13031	13031-7033	1	Crankshaft
❷13251	13251-7007	2	Connecting Rod ASM
❷13251A	13251-7008	2	Connecting Rod ASM (0.50)
❷92033	92033-7002	4	Ring-Snap
❷130	130G0630	4	Bolt-Flanged (6X30)




Valve and Camshaft Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷12004	12004-7005	2	Valve-Intake
❷12005	12005-7006	2	Valve-Exhaust
❷12009	12009-7001	4	Retainer-Spring, Valve
❷12011	12011-2056	8	Collet
❷12016	12016-7008	4	Arm-Rocker
❷12032	12032-7001	4	Tappet
❷13070	13070-7001	2	Guide
❷13070A	13070-7004	1	Guide
❷13116	13116-2057	4	Rod-Push
❷13271	13271-7007	1	Plate
❷13271A	13271-7021	1	Plate-Governor
❷42036	42036-7010	1	Sleeve
❷49078	49078-7001	4	Spring-Valve, Engine
❷49118	49118-7009	1	Camshaft
❷92009	92009-2341	4	Screw
❷92015	92015-2253	4	Nut
❷92033	92033-7001	2	Ring-Snap
❷92140	92140-7002	6	Ball
❷92145	92145-7001	1	Spring
❷92153	92153-7019	4	Bolt
❷92200	92200-7001	1	Washer




Lubrication Equipment Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷13107	13107-7009	1	Shaft
❷13271	13271-7017	1	Plate
❷14075	14075-7009	1	Cap ASM
❷16154	16154-2053	1	Rotor-Pump (In)
❷16154A	16154-2054	1	Rotor-Pump (Out)
❷49065	49065-2078	1	Filter-Oil
❷49065A	49065-7004	1	Filter-Oil
❷59051	59051-7011	1	Gear-Spur
❷59231	59231-7003	1	Filler
❷92043	92043-7003	2	Pin
❷92066	92066-7003	2	Plug
❷92140	92140-7003	1	Ball
❷92145	92145-7002	1	Spring
❷92153	92153-7043	3	Bolt (6X12)
❷670	670D2016	3	O-Ring (16Mm)




Cooling Equipment Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷13270	13270-7007	1	Plate
❷14037	14037-7025-9H	1	Screen
❷14091	14091-7009	1	Cover
❷49089	49089-7044	1	Shroud-Engine
❷49089A	49089-7061	1	Shroud-Engine
❷59041	59041-7012	1	Fan
❷59066	59066-7036	1	Housing-Fan
❷92004	92004-7007	2	Stud
❷92153	92153-7007	3	Bolt
❷92153A	92153-7008	1	Bolt
❷92153B	92153-7043	4	Bolt (6X12)
❷130	130B0616	2	Bolt-Flanged (6X16)
❷130A	130B0816	1	Bolt-Flanged (8X16)
❷311	311F0600	2	Nut-Hex (6Mm)




Electric Equipment Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷21171	21171-7026	1	Ignition Coil ASM
❷21171A	21171-7027	1	Ignition Coil ASM
❷21194	21194-7012	1	Flywheel
❷26030	26030-7001	1	Harness
❷59031	59031-7002	1	Coil-Charging
❷92004	92004-7008	2	Stud
❷92009	92009-2308	2	Screw
❷92066	92066-7002	1	Plug
❷92066A	92066-7005	1	Plug
❷92070	92070-7003	2	Spark Plug (R C J 8 Y, Solid)
❷92151	92151-2097	1	Bolt (12X30)
❷92172	92172-7018	4	Screw (5X20)
❷92200	92200-7002	1	Washer
❷130	130B0620	2	Bolt-Flanged (6X20)
❷311	311F0600	2	Nut-Hex (6Mm)
❷510	510A5100	1	Key-Woodruff



Control Equipment Assembly
Kawasaki FH430V-AS35


Ref	Part No.	Qty.	Description
❷13107	13107-7010	1	Shaft
❷13271	13271-7032	1	Plate
❷16169	16169-7012	1	Link-Choke
❷16171	16171-7007	1	Link
❷39129	39129-7003	1	Spring-Governor
❷49103	49103-7004	1	Arm-Governor
❷49113	49113-7024	1	Panel-Control
❷92009	92009-7007	1	Screw (4X35)
❷92145	92145-7003	1	Spring
❷92145A	92145-7005	1	Spring
❷92150	92150-2182	2	Bolt (5X18)
❷92153	92153-7033	1	Bolt (6X35)
❷92153A	92153-7043	2	Bolt (6X12)
❷92170	92170-7001	2	Clamp
❷214	214B0408	2	Screw-Pan (4X8)
❷311	311B0600	1	Nut-Hex (6Mm)
❷411	411B0600	1	Washer-Plain (6Mm)



Carburetor Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷11061	11061-7004	1	Gasket-Insulator
❷11061A	11061-7009	1	Gasket-Chamber
❷11061B	11061-7010	1	Gasket-Screw
❷11061C	11061-7018	1	Gasket-Cleaner, Air
❷13107	13107-7018	1	Shaft
❷15003	15003-7061	1	Carburetor ASM
❷16014	16014-7002	1	Screw-Pilot, Air
❷16020	16020-7003	1	Chamber-Float
❷16025	16025-7006	1	Valve-Throttle
❷16030	16030-7003	1	Valve-Float
❷16031	16031-7002	1	Float
❷16041	16041-7016	1	Shaft-Choke, Carburetor
❷16041A	16041-7018	1	Shaft-Throttle, Carburetor
❷16186	16186-7002	1	Choke Valve ASM
❷39076	39076-7001	1	Limiter
❷49121	49121-7001	1	Nozzle-Main
❷59076	59076-7005	1	Manifold-Intake
❷92009	92009-2083	2	Screw
❷92009A	92009-2349	1	Screw
❷92055	92055-7007	2	O-Ring (I D 31)
❷92063	92063-7026	1	Jet-Main, No. 88
❷92063A	92063-7028	1	Jet-Main, No. 85 (3280 Ft)
❷92063B	92063-7029	1	Jet-Main, No.82 (6560 Ft)
❷92081	92081-2234	1	Spring


Ref	Part No.	Qty.	Description
❷92093	92093-2100	1	Seal
❷92093A	92093-7003	1	Seal
❷92145	92145-7015	1	Spring
❷92153	92153-7009	4	Bolt
❷92172	92172-7002	1	Screw



Air Filter and Muffler Assembly
Kawasaki FH430V-AS35


Ref	Part No.	Qty.	Description
❷11011	11011-7045	1	Case-Filter, Air
❷11013	11013-7025	1	Element-Filter, Air
❷11013A	11013-7031	1	Element-Filter, Air
❷11053	11053-7022	1	Bracket
❷11054	11054-7002-9H	1	Bracket
❷11060	11060-7021	2	Gasket-Muffler
❷13271	13271-7022	1	Plate
❷16060	16060-7016	1	Pipe-Intake
❷18088	18088-7001	1	Pipe-Exhaust
❷32154	32154-7006	1	Pipe
❷49070	49070-7021	1	Muffler
❷92015	92015-1193	2	Nut
❷92026	92026-7001	2	Spacer (6.2X7.9X5)
❷92055	92055-7015	1	O-Ring
❷92072	92072-7012	1	Band
❷92153	92153-7043	2	Bolt (6X12)
❷92170	92170-7002	1	Clamp
❷92192	92192-7010	1	Tube
❷92200	92200-2070	2	Washer
❷92210	92210-7004	2	Nut (M6)
❷92210A	92210-7019	1	Nut
❷92210B	92210-7027	4	Nut (M8)
❷130	130B0610	1	Bolt-Flanged (6X10)

Ref	Part No.	Qty.	Description
❷130A	130B0816	3	Bolt-Flanged (8X16)
❷220	220B0614	2	Screw-Pan, Cross (6X14)
❷233	233B0416	1	Screw (4X16)
❷311	311B0400	1	Nut-Hex (4Mm)
❷461	461F0800	4	Washer-Spring (8Mm)
❷670	670B2010	1	O-Ring (10Mm)




Fuel Tank and Valve Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷23062	23062-7004-9H	1	Bracket
❷42036	42036-7012	1	Sleeve
❷49019	49019-7001	1	Filter-Fuel
❷49040	49040-7001	1	Pump-Fuel
❷92170	92170-2088	4	Clamp
❷92191	92191-7002	1	Tube
❷92192	92192-7035	1	Tube (6.35X12.7X170)
❷92192A	92192-7037	1	Tube (6.35X12.7X160)
❷130	130B0620	2	Bolt-Flanged (6X20)



Starter Assembly
Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷13165	13165-7001	2	Pawl-Starter, Recoil
❷13271	13271-7003-9H	1	Plate
❷14020	14020-7001	1	Retainer
❷32099	32099-7002	1	Case-Starter, Recoil
❷46075	46075-7001	1	Grip-Starter, Recoil
❷49080	49080-7001	1	Pulley-Starting
❷49088	49088-7013	1	Starter-Recoil
❷59101	59101-7001	1	Reel-Starter, Recoil
❷59106	59106-7005	1	Rope
❷92145	92145-7006	1	Spring
❷92145A	92145-7007	2	Spring
❷92145B	92145-7008	1	Spring
❷92151	92151-7008	1	Bolt
❷92200	92200-7004	1	Washer
❷92200A	92200-7005	1	Washer
❷92210	92210-0003	4	Nut
❷130	130B0608	3	Bolt-Flanged (6X8)



Label Assembly Kawasaki FH430V-AS35

Ref	Part No.	Qty.	Description
❷56033	56033-7001	1	Label-Manual
❷56070	56070-7001	1	Label-Warning
❷56080	56080-2077	1	Label-Brand
❷56080A	56080-7024	1	Label-Brand (Part Can Be Used As Substitute On The Product And Is Supplied Until Stock Is Exhausted)
❷56080B	56080-7057	1	Label-Brand

Attachments and Accessories

For 30092 - Commercial Walk-Behind Mower, Floating Deck T-Bar Gear with 32in Cutting Unit

Product Name	Model/Part
Bag Kit	30124

NOTES

NOTES

NOTES


TORO®