



Commercial Walk-Behind Mower Floating Deck T-Bar Gear with 40in TURBO FORCE® Cutting Unit

Model No. 30096 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Clutch Assembly	 3	Piston and Crankshaft Assembly Kawasaki FH430V-ES28	 20
Power-Take-Off Idler and Weight Assembly	 4	Valve and Camshaft Assembly Kawasaki FH430V-ES28	 21
Fuel System Assembly	 5	Lubrication Equipment Assembly Kawasaki FH430V-ES28	 22
Lower Control Assembly	 6	Cooling Equipment Assembly Kawasaki FH430V-ES28	 23
Transmission Drive Assembly	 7	Electric Equipment Assembly Kawasaki FH430V-ES28	 24
Wheel Drive and Brake Assembly	 8	Control Equipment Assembly Kawasaki FH430V-ES28	 25
Upper Handle Assembly	 9	Carburetor Assembly Kawasaki FH430V-ES28	 26
Control Panel Assembly	 10	Air Filter and Muffler Assembly Kawasaki FH430V-ES28	 27
Carrier Frame Assembly	 11	Fuel Tank and Valve Assembly Kawasaki FH430V-ES28	 28
Deck Drive and Baffle Assembly	 12	Starter Assembly Kawasaki FH430V-ES28	 29
Deck Assembly No. 112-7081	 13	Label Assembly Kawasaki FH430V-ES28	 30
Spindle Assembly No. 110-0728	 14	Attachments and Accessories List	 31
Spindle Assembly No. 110-6927	 15		
Lever Assembly No. 107-1664	 16		
Deck Assembly	 17		
Deflector Assembly No. 110-0790	 18		
Cylinder and Crankcase Assembly Kawasaki FH430V-ES28	 19		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HWHTF. hex washer head thread forming
ASM. assembly	HYD. hydraulic
BBC. blade brake clutch	LH. left hand
CARR. carriage	NI. nylon insert
CCW. counter clock wise	NPTF. national pipe thread fine
CW. clockwise	PFH. phillips flat head
DEG. degrees	PPH. phillips pan head
ECM. electronic control module	PPHTF. phillips pan head thread forming
EXT. external	PRH. phillips round head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power-take-off
HD. heavy-duty	RH. right hand
HF. hex flange	ROPS. roll-over protection system
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HSBH. hex socket button head	STD. standard
HSFH. hex socket flat head	TAP. self tapping
HSH. hex socket head	TTH. torx truss head
HWH. hex washer head	

Footnotes

❶ Not serviced separately


❷ Obtain parts from www.kawpowerepc.com



Engine and Clutch Assembly


Ref	Part No.	Qty.	Description
1	56-6360	1	Filter-Fuel
1 2 2		1	Engine-Kawasaki, FH430V-Es28
3	2412-87	1	Clamp-Cable
4	106-0699	1	Decal-Warning
5	2412-72	1	Clip-Closed, Insulated
6	103-1966	1	Adapter
7	92-6877	1	Valve-Drain, Oil
8	104-8137	1	Harness-Wire
10	32128-20	6	Nut-HF
11	3255-8	1	Washer-Lock
12	112-7069	1	Grommet
13	104-6373	1	Tube-Retainer
14	1-613235	4	Washer
15	1-633630	2	Grommet-Brake
16	1-633545	2	Spacer
17	1-633543-03	1	Strap-Clutch, Brake
18	322-11	1	Screw-HH
19	3256-23	5	Washer-Flat
20	322-7	4	Screw-HH
21	2412-134	1	Clamp-R
22	3212-9	1	Screw-HH
23	107-4136	1	Washer
24	105-2635	1	Clutch / Brake
25	107-4112	1	Pulley-Drive

Ref	Part No.	Qty.	Description
26	608006	1	Key-Square
27	94-5847-01	1	Cover-Pulley
30	115-4150-03	1	Muffler Shield ASM
32	115-4154-03	1	Bracket-Muffler
33	322-3	4	Screw-HH
34	94-2413	4	U-Nut
35	12-3270	2	Screw
36	1-603610	2	Washer-Spring
38	322-9	1	Screw-HH
39	3290-378	1	Tie-Cable
40	114241	1	Fuse-7.5 Amp
99	103-1964	1	Hose-Drain, Oil




Power-Take-Off Idler and Weight Assembly

Ref	Part No.	Qty.	Description				
2	3296-39	1	Nut-Lock, NI				
4	52-2860	3	Washer				
5	104-6377	1	Tube-Idler				
6	112-7055	1	Idler Arm ASM				
6:1	1-513034	2	Sleeve-Bearing				
6:2	302-5	1	Fitting-Grease				
7	323-42	1	Screw-HH				
8	323-6	1	Screw-HH				
9	98-5975	1	Washer-Belleville				
10	3256-24	1	Washer-Flat				
11	1-413099	1	Pulley-Idler				
12	105-8443	1	Spring-Extension				
13	323-10	1	Screw-HH				
14	3290-357	1	Nut-HHF, Whiz				
15	32128-21	1	Nut-HF				
16	112-7059-01	1	Weight-Cast				
17	322-9	2	Screw-HH				
18	3256-23	2	Washer-Flat				
19	3296-29	2	Nut-Lock, NI				




Fuel System Assembly

Ref	Part No.	Qty.	Description				
1	88-3980	1	Gas Cap ASM				
1:3	88-4010	1	Gasket-Cap, Gas				
2	106-0730	1	Fuel Tank ASM				
2:2	103-2605	1	Fitting-Fuel, Bulkhead				
3	104-8121	2	Stud-Threaded				
6	3256-23	4	Washer-Flat				
7	1-633349	2	Spring-Tank, Fuel				
8	3296-47	2	Nut-Lock, NI				
9	110-4985-01	1	Gear Frame ASM				
10	2412-98	4	Clamp				
11	110-4894	1	Hose-Fuel				
12	1-603770	1	Valve-Fuel				
14	107-0588	1	Hose-Fuel				
15	322-4	2	Screw-HH				
16	3253-4	2	Washer-Lock				
17	95-2814	1	Decal-Shut Off, Fuel				
18	98-0776	1	Decal-Caution				



Lower Control Assembly


Ref	Part No.	Qty.	Description				
1	32103-25	2	Nut-Wing				
2	3256-23	6	Washer-Flat				
3	3290-307	4	Pin-Hair				
4	52-2890	2	Bushing-Nylon				
5	74-0521	2	Fitting-Rod				
6	283-6	2	Pin-Clevis				
7	74-0040	4	Spacer-Pivot, Idler				
8	108-2725-01	1	Support-Idler, LH				
9	108-2724-01	1	Support-Idler, RH				
10	323-16	2	Screw-HH				
11	323-7	4	Screw-HH				
12	3296-23	2	Nut-Lock, NI				
13	95-2800	2	Pulley-Idler				
14	95-2801	2	Spacer-Pulley				
15	108-2740-01	1	LH Idler Arm ASM				
16	108-2741-01	1	RH Idler Arm ASM				
17	51-4450	2	Screw-Leveler				
18	68-9690	2	Fitting-Rod				
19	51-4380	1	Spring-Torsion, LH				
20	51-4370	1	Spring-Torsion, RH				
21	3296-39	6	Nut-Lock, NI				
31	3234-32	6	Screw-HHF				
32	32128-23	6	Nut-HF				



Transmission Drive Assembly

Ref	Part No.	Qty.	Description
1	47-1970	1	Grip
2	98-3274-03	1	Lever-Shift
3	3296-6	2	Nut-Lock
4	98-5975	1	Washer-Belleville
5	1-323379	1	Washer
6	1-323500	1	Transmission
7	302-5	2	Fitting-Grease
8	1-323680	2	Coupler
9	51-4220	2	Guard-Coupler
10	1-323254	2	Flange-Output
11	321-4	4	Screw-HH
12	3257-5	3	Key-Woodruff
13	3245-9	2	Screw-Set
14	32151-62	2	Ring-Retaining
15	105-2698	2	Pulley-Transmission
16	104-1102	2	Shaft-Output
17	1-323252	2	Bearing-Shaft
18	95-1529	1	Rod-Shield
19	95-1526	1	Shield-Trailing
20	105-5646	1	Pulley-Driven
21	3245-1	1	Screw-Set, HSH
22	32120-64	1	Ring-Snap, External
23	105-5668	1	V-Belt
24	80-6610	1	Spring-Extension


Ref	Part No.	Qty.	Description
25	27-6230	1	Bolt-Wheel
26	323-9	1	Screw-HH
27	16-7509	1	Lever-Idler
27:1	256-155	2	Bushing-Flange
28	62-4540	1	Pulley
29	3296-39	1	Nut-Lock, NI
30	322-2	4	Screw-HH
31	3253-4	4	Washer-Lock
32	3296-42	4	Nut-Lock, NI
33	1-323389-03	2	Bracket-Plate, Shift
34	9264964	4	Screw-HWH, Thread Cut
35	32128-20	2	Nut-HF
36	1-323387-03	1	Plate-Shift
37	3230-1	2	Bolt-CARR
38	98-3256	1	Decal-Speed, Ground



Wheel Drive and Brake Assembly


Ref	Part No.	Qty.	Description
1	32151-72	4	Ring-Retaining
2	32151-56	2	Ring-Retaining, External
3	106-8792	2	Plate-Link, Brake
4	110-5010-01	2	Brake Arm ASM
6	3290-307	2	Pin-Hair
7	108-2730	2	Rod-Brake
8	32151-40	2	Ring-Retaining
9	106-8773	2	Brake Link ASM
10	110-5004	2	Belt-V, Banded
13	1-543509	4	Bearing-Roller, Tapered
14	1-523157	2	Washer-Spacer
15	1-809082	2	Nut-SHH
16	106-0892	2	Wheel And Tire ASM
16:1	104-6322	1	Tire
16:2	106-0893	1	Wheel
16:3	232-27	1	Stem-Valve
17	242-50	8	Nut-Lug
18	241-119	2	Cap-Dust
19	107-4090	2	Wheel Hub ASM
19:2	1-543508	2	Cup-Bearing
19:3	302-5	1	Fitting-Grease
19:4	10-6830	4	Stud-Type, Drive
22	1-323262	2	Band-Brake
24	1-543511	2	Seal-Grease

Ref	Part No.	Qty.	Description
25	110-5006	2	Spacer-Wheel
26	110-4983-01	1	Axle ASM
27	1-806800	2	Pin-Cotter
28	32128-21	6	Nut-HF
29	3234-11	6	Screw-HHF




Upper Handle Assembly

Ref	Part No.	Qty.	Description				
1	105-4677	2	Rod-Control				
2	3272-4	2	Pin-Cotter				
3	237-141	2	Grommet-Rubber				
4	82-2290	1	Decal				
5	82-7680-03	1	Bail ASM				
6	82-7690-03	1	Bar-Control				
7	82-2280	1	Decal				
8	106-5477-03	1	Control Pivot ASM				
9	3272-11	2	Pin-Cotter				
10	105-3158-03	1	Upper Handle ASM				
11	283-55	2	Pin-Clevis				
12	3290-378	2	Tie-Cable				
13	32128-21	4	Nut-HF				
14	3234-11	4	Screw-HHF				
15	98-4387	1	Decal-Protection, Ear				
16	32105-1	1	Screw-SHH				
17	51-4850-03	1	Lever-Brake, Parking				
18	52-2010	1	Decal-Lever, Parking				
19	3296-2	1	Nut-Lock, NI				
20	218-595	1	Connector-Body				
21	82-2190	1	Switch-Bail				




Control Panel Assembly

Ref	Part No.	Qty.	Description				
1	105-0884	1	Decal-Danger				
2	63-8360	1	Key-Ignition				
3	110-4994	1	Cable-Throttle				
4	32104-76	4	Screw				
5	32105-14	4	Screw-SHH				
6	3296-42	1	Nut-Lock, NI				
7	104-8141	1	Module-Delay				
8	93-1187-03	1	Panel-Bottom				
9	321-2	1	Screw-HH				
12	3296-2	4	Nut-Lock, NI				
13	29-5560	1	Switch-On / Off				
13:1	218-461	1	Nut-HH				
13:2	3254-5	1	Washer-Tooth				
14	2412-120	2	R-Clamp				
15	104-7050	1	Tube-Manual				
16	104-8140	1	Switch-PTO				
17	110-4982-03	1	Panel-Control				
18	110-4971	1	Decal-Control Panel				
19	104-7048	1	Cap-Housing				
20	110-4995	1	Cable-Choke				




Carrier Frame Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	110-6965	1	Carrier Frame ASM	20	100-6453	2	Bushing-Spanner
1:2	32148-9	2	Insert-Nut	21	325-19	2	Screw-HH
1:3	94-1291	4	Bushing	22	283-71	2	Pin-Lynch
1:4	302-5	2	Fitting-Grease	23	3-6781	8	Washer-Thrust
2	110-6985	1	Cover-Frame, Carrier				
3	112-9711	1	Decal				
4	1-804254	3	Nut				
5	106-6778	3	Bushing-Latch, Swell				
6	99-3058	3	Washer				
7	106-6777	3	Handle-Latch, Swell				
8	110-6971-01	1	Shield-Belt				
10	104-1105	4	Spacer-Support, Deck				
11	1-513336	2	Bushing-Deck				
12	323-6	2	Screw-HH				
13	3256-24	2	Washer-Flat				
14	32120-33	2	Ring-Retaining				
15	1-323539	4	Spacer				
16	106-0635	2	Decal-HOC				
17	105-3159-01	2	Castor Fork ASM				
18	32153-5	2	Nut-Lock, Side				
19	110-5024	2	Wheel And Tire ASM				
19:2	112-7066	1	Bearing-Roller				
19:3	1-513810	2	Bushing				
19:4	302-61	1	Zerk				




Deck Drive and Baffle Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	112-7081	1	Deck ASM	25	322-6	1	Screw-HH
2	110-6972	1	Belt-V	26	323-14	1	Screw-HH
3	3256-24	3	Washer-Flat	27	110-6927	1	Spindle ASM
4	3231-22	2	Screw-CARR	28	3256-3	1	Washer-Flat
5	98-5980	1	Guide-Belt	29	32128-13	1	Nut-HF
6	110-6975	1	Guide-Belt	30	110-6910-03	1	Baffle ASM
7	105-0850	1	Guide-Belt	31	110-6940-03	1	Adjust Baffle ASM
8	3290-357	29	Nut-HHF, Whiz	32	108-7273-01	1	Baffle-Discharge
9	32128-21	2	Nut-HF	33	108-7282-01	1	Plate-Skid
10	92-1624	22	Screw-HWH	34	3231-1	4	Screw-CARR
12	108-2728	1	Idler Arm ASM	35	107-1664	1	Lever ASM
12:2	302-11	1	Fitting-Lube, 45 DEG	36	32128-19	1	Nut-HF
12:3	256-90	2	Bushing-Flange	37	110-6973	1	Belt-V
13	3296-39	1	Nut-Lock, NI	38	323-4	3	Screw-HH
14	52-2860	2	Washer				
15	93-1622	1	Pulley-Idler				
16	9202414	1	Washer-Spacer				
17	51-3650	1	Spring-Extension				
18	323-9	1	Screw-HH				
19	112-7091	1	Spacer				
20	110-0728	2	Spindle ASM				
21	108-4081-03	3	Blade-14 Inch (High Sail)				
22	51-4060	3	Screw-Blade				
23	103-0865	3	Washer-Blade Bolt, Heavy				




Deck Assembly No. 112-7081

Ref	Part No.	Qty.	Description
2	104-8569	1	Decal-Warning
3	43-8480	1	Decal-Danger
4	104-8186	1	Decal-Routing, Belt
5	98-5954	3	Decal-Cover, Missing
6	68-8340	1	Decal-Torque
7	66-1340	1	Decal-Danger, Thrown Object
8	105-7798	1	Decal-Scalp, Anti
9	110-2068	1	Decal-Adjustment, Baffle
10	110-2067	1	Decal-Setting, Baffle



Spindle Assembly No. 110-0728


Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	104-1181	1	Pulley ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing-Ball				
6	108-6696	1	Housing-Spindle				
7	110-0727	1	Spacer-Bearing				
8	110-0726	1	Shaft-Spindle				



Spindle Assembly No. 110-6927

Ref	Part No.	Qty.	Description				
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer				
3	110-6928	1	Pulley And Hub ASM				
4	106-0873	1	Shield-Bearing				
5	104-6325	2	Bearing-Ball				
6	108-6696	1	Housing-Spindle				
7	110-0727	1	Spacer-Bearing				
8	110-0725	1	Shaft-Spindle				






Deck Assembly


Ref	Part No.	Qty.	Description
1	110-0790	1	Deflector ASM
2	105-4622	1	Spacer
3	104-8554	1	Spring-Torsion
4	3296-29	2	Nut-Lock, NI
5	110-6984	2	Cover-Belt
7	106-6777	2	Handle-Latch, Swell
8	99-3058	2	Washer
9	108-2674	2	Front Pin ASM
10	3220-3	2	Nut-HJ
11	3296-39	5	Nut-Lock, NI
12	1-613204	2	Balljoint
13	104-1156	2	Spacer
14	323-8	2	Screw-HH
15	110-2086	2	Rear Pin ASM
16	3290-256	6	Pin-Hair
17	323-10	2	Screw-HH
18	1-603299	3	Roller-Scalp, Anti
19	98-5967	1	Spacer-Wheel
20	322-50	2	Screw-HH
21	98-7913	1	Tube-Spacer
22	98-7912	1	Tube-Spinner
23	323-23	1	Screw-HH
24	112-7053-01	2	Bracket-Cover
25	112-7054-01	2	Bracket-Cover

Ref	Part No.	Qty.	Description
26	32144-70	2	Screw-HWHTF
27	106-6778	2	Bushing-Latch, Swell
28	1-804254	2	Nut
29	3290-357	4	Nut-HHF, Whiz
30	92-1624	4	Screw-HWH




Cylinder and Crankcase Assembly
Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description				
❶130	130AA0640	4	Bolt-Flanged (6X40)				
❶130A	130CA0875	2	Bolt-Flanged (8X75)				
❶172	172BA0818	4	Bolt-Stud (8X18)				
❶11004	11004-7018	2	Gasket-Head				
❶11008	11008-7021	1	Head-Cylinder, No. 2				
❶11008A	11008-7022	1	Head-Cylinder, No. 1				
❶11022A	11022-7018	2	Case-Rocker				
❶11060	11060-7001	2	Gasket-Case, Rocker				
❶11061	11061-7007	1	Gasket-Cover, Crankcase				
❶11061A	11061-7008	1	Gasket-Breather				
❶14091	14091-7007	1	Cover				
❶49015A	49015-7080	1	Cover-Crankcase				
❶49120	49120-7015	1	Crankcase				
❶59071	59071-2079	1	Joint				
❶92043	92043-7001	6	Pin				
❶92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)				
❶92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)				
❶92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)				
❶92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)				
❶92139	92139-7008	1	Bushing				
❶92153	92153-7043	4	Bolt (6X12)				
❶92153A	92153-7054	17	Bolt (8X50)				




Piston and Crankshaft Assembly
Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description				
② 130	130BA0630	4	Bolt-Flanged (6X30)				
② 13001	13001-7022	2	Piston-Engine				
② 13002	13002-7001	2	Pin-Piston				
② 13008	13008-7001	2	Piston Ring Set				
② 13025	13025-7003	1	Piston Ring Set (L 0.50)				
② 13029	13029-7005	1	Piston-Engine (L 0.50)				
② 13031	13031-7033	1	Crankshaft				
② 13251	13251-7007	2	Connecting Rod ASM				
② 13251A	13251-7008	2	Connecting Rod ASM (0.50)				
② 92033	92033-7002	4	Ring-Snap				




Valve and Camshaft Assembly
Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description				
②12004	12004-7005	2	Valve-Intake				
②12005	12005-7006	2	Valve-Exhaust				
②12009	12009-7001	4	Retainer-Spring, Valve				
②12011	12011-2056	8	Collet				
②12016	12016-7008	4	Arm-Rocker				
②12032	12032-7001	4	Tappet				
②13070	13070-7001	2	Guide				
②13070A	13070-7004	1	Guide				
②13116	13116-2057	4	Rod-Push				
②13271	13271-7007	1	Plate				
②13271A	13271-7021	1	Plate-Governor				
②42036	42036-7010	1	Sleeve				
②49078	49078-7001	4	Spring-Valve, Engine				
②49118	49118-7009	1	Camshaft				
②92009	92009-2341	4	Screw				
②92015	92015-2253	4	Nut				
②92033	92033-7001	2	Ring-Snap				
②92140A	92140-7005	6	Ball				
②92145	92145-7001	1	Spring				
②92153	92153-7019	4	Bolt				
②92200	92200-7001	1	Washer				




Lubrication Equipment Assembly
Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description				
②670	670D2016	3	O-Ring (16Mm)				
②13107	13107-7009	1	Shaft				
②13271	13271-7017	1	Plate				
②14075	14075-7009	1	Cap ASM				
②16154	16154-2053	1	Rotor-Pump (In)				
②16154A	16154-2054	1	Rotor-Pump (Out)				
②49065	49065-2078	1	Filter-Oil				
②49065A	49065-7004	1	Filter-Oil				
②59051	59051-7011	1	Gear-Spur				
②59231	59231-7003	1	Filler				
②92043	92043-7003	2	Pin				
②92066	92066-7003	2	Plug				
②92140	92140-7003	1	Ball				
②92145	92145-7002	1	Spring				
②92153	92153-7043	3	Bolt (6X12)				



Cooling Equipment Assembly
Kawasaki FH430V-ES28


Ref	Part No.	Qty.	Description				
② 130	130AA0616	2	Bolt-Flanged (6X16)				
② 130A	130AA0816	1	Bolt-Flanged (8X16)				
② 311	311AB0600	2	Nut-Hex (6Mm)				
② 13270	13270-7007	1	Plate				
② 14037	14037-7025-9H	1	Screen				
② 14091	14091-7009	1	Cover				
② 49089B	49089-7071	1	Shroud-Engine				
② 49089D	49089-7072	1	Shroud-Engine				
② 59041	59041-7012	1	Fan				
② 59066	59066-7036	1	Housing-Fan				
② 92004	92004-7007	2	Stud				
② 92153	92153-7007	3	Bolt				
② 92153A	92153-7008	1	Bolt				
② 92153B	92153-7043	4	Bolt (6X12)				



Electric Equipment Assembly


Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description				
2130	130AA0620	2	Bolt-Flanged (6X20)				
2311	311F0600	2	Nut-Hex (6Mm)				
2510	510A5100	1	Key-Woodruff				
221171B	21171-7034	1	Ignition Coil ASM				
221171D	21171-7035	1	Coil-Assy-Ignition				
221194	21194-7012	1	Flywheel				
226030	26030-7001	1	Harness				
259031A	59031-7002	1	Coil-Charging (Part Can Be Used As Substitute On The Product And Is Supplied Until Stock Is Exhausted)				
259031B	59031-7011	1	Coil-Charging				
292004	92004-7008	2	Stud				
292009	92009-2308	2	Screw				
292066A	92066-7002	1	Plug (Part Can Be Used As Substitute On The Product And Is Supplied Until Stock Is Exhausted)				
292066B	92066-7005	1	Plug				
292066C	92066-7026	1	Plug				
292070	92070-7003	2	Spark Plug (R C J 8 Y, Solid)				
292151	92151-2097	1	Bolt (12X30)				
292172	92172-7018	4	Screw (5X20)				
292200	92200-7002	1	Washer				



Control Equipment Assembly
Kawasaki FH430V-ES28


Ref	Part No.	Qty.	Description				
2214	214AA0408	2	Screw-Pan +-(4X8)				
2311	311AA0600	1	Nut-Hex (6Mm)				
2411	411AA0600	1	Washer-Plain (6Mm)				
213107	13107-7010	1	Shaft				
213271	13271-7032	1	Plate				
216169	16169-7012	1	Link-Choke				
216171	16171-7007	1	Link				
239129	39129-7003	1	Spring-Governor				
249103	49103-7004	1	Arm-Governor				
249113A	49113-7024	1	Panel-Control (Part Can Be Used As Substitute On The Product And Is Supplied Until Stock Is Exhausted)				
249113B	49113-7054	1	Control Panel ASM				
292009	92009-7007	1	Screw (4X35)				
292145	92145-7003	1	Spring				
292145A	92145-7005	1	Spring				
292150	92150-2182	2	Bolt (5X18)				
292153	92153-7033	1	Bolt (6X35)				
292153A	92153-7043	2	Bolt (6X12)				
292170	92170-7001	2	Clamp				



Carburetor Assembly Kawasaki FH430V-ES28


Ref	Part No.	Qty.	Description
②11061	11061-7004	1	Gasket-Insulator
②11061A	11061-7009	1	Gasket-Chamber
②11061B	11061-7010	1	Gasket-Screw
②11061C	11061-7018	1	Gasket-Cleaner, Air
②13107	13107-7018	1	Shaft
②15003	15003-7061	1	Carburetor ASM
②16014	16014-7002	1	Screw-Pilot, Air
②16020	16020-7003	1	Chamber-Float
②16025	16025-7006	1	Valve-Throttle
②16030	16030-7003	1	Valve-Float
②16031	16031-7002	1	Float
②16041	16041-7016	1	Shaft-Choke, Carburetor
②16041A	16041-7018	1	Shaft-Throttle, Carburetor
②16186	16186-7002	1	Choke Valve ASM
②39076	39076-7001	1	Limiter
②49121	49121-7001	1	Nozzle-Main
②59076	59076-7005	1	Manifold-Intake
②92009	92009-2083	2	Screw
②92009A	92009-2349	1	Screw
②92055	92055-7007	2	O-Ring (I D 31)
②92063	92063-7026	1	Jet-Main, No. 88
②92063A	92063-7028	1	Jet-Main, No. 85 (3280 Ft)
②92063B	92063-7029	1	Jet-Main, No.82 (6560 Ft)
②92081	92081-2234	1	Spring

Ref	Part No.	Qty.	Description
②92093	92093-2100	1	Seal
②92093A	92093-7003	1	Seal
②92145	92145-7015	1	Spring
②92153	92153-7009	4	Bolt
②92172	92172-7002	1	Screw




Air Filter and Muffler Assembly Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
②130	130AA0610	1	Bolt-Flanged (6X10)	②92015B	92015-1367	2	Nut
②130A	130AA0816	3	Bolt-Flanged (8X16)	②92055	92055-7015	1	O-Ring
②233	233AA0416	1	Screw-Pan, Wp +-(4X16)	②92072	92072-7012	1	Band
②311	311AA0400	1	Nut-Hex (4Mm)	②92153	92153-7038	2	Bolt (6X10)
②461	461DA0800	4	Washer-Spring (8Mm)	②92153A	92153-7043	2	Bolt (6X12)
②670	670B2010	1	O-Ring (10Mm)	②92170	92170-7002	1	Clamp
②11011	11011-7045	1	Case-Filter, Air	②92192	92192-7010	1	Tube
②11013	11013-7025	1	Element-Filter, Air	②92210	92210-7004	2	Nut (M6)
②11013A	11013-7031	1	Element-Filter, Air	②92210A	92210-7019	1	Nut
②11053	11053-7022	1	Bracket	②92210B	92210-7027	4	Nut (M8)
②11054	11054-7002-9H	1	Bracket				
②11060	11060-7021	2	Gasket-Muffler				
②13271	13271-7022	1	Plate				
②16060	16060-7016	1	Pipe-Intake				
②18088A	18088-7001	1	Pipe-Exhaust (Part Can Be Used As Substitute On The Product And Is Supplied Until Stock Is Exhausted)				
②18088B	18088-7008	1	Pipe-Exhaust				
②32154	32154-7006	1	Pipe				
②49070	49070-7021	1	Muffler				
②92015A	92015-1193	1	Nut (Part Can Be Used As Substitute On The Product And Is Supplied Until Stock Is Exhausted)				



Fuel Tank and Valve Assembly Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description
②130	130AA0620	2	Bolt-Flanged (6X20)
②23062A	23062-7019-9H	1	Bracket
②42036	42036-7012	1	Sleeve
②49019	49019-7001	1	Filter-Fuel
②49040	49040-7001	1	Pump-Fuel
②92170	92170-2009	4	Clamp
②92191	92191-7002	1	Tube
②92192D	92192-7135	1	Tube (6.35X12.7X160)
②92192F	92192-7136	1	Tube (6.35X12.7X180)



Starter Assembly
Kawasaki FH430V-ES28

Ref	Part No.	Qty.	Description				
②130	130AA0608	3	Bolt-Flanged (6X8)				
②13165	13165-7001	2	Pawl-Starter, Recoil				
②13271	13271-7003-9H	1	Plate				
②14020	14020-7001	1	Retainer				
②32099	32099-7002	1	Case-Starter, Recoil				
②46075	46075-7001	1	Grip-Starter, Recoil				
②49080	49080-7001	1	Pulley-Starting				
②49088	49088-7013	1	Starter-Recoil				
②59101	59101-7001	1	Reel-Starter, Recoil				
②59106	59106-7005	1	Rope				
②92145	92145-7006	1	Spring				
②92145A	92145-7007	2	Spring				
②92145B	92145-7008	1	Spring				
②92151	92151-7008	1	Bolt				
②92200	92200-7004	1	Washer				
②92200A	92200-7005	1	Washer				
②92210	92210-0003	4	Nut				

Attachments and Accessories

For 30096 - Commercial Walk-Behind Mower, Floating Deck T-Bar Gear with 40in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Rotary, 14 Inch (Recycling)	108-4089-03
Blade-Rotary, 14 Inch (Mid Flow)	108-4110-03
Blade-Rotary, 14 Inch (Low Flow)	108-4111-03
Blade-Rotary, 14 Inch (Atomic)	108-4112-03
40 Inch Bagger Enhancement Kit	110-2025
40 Inch Recycler Kit	110-2070
Plate Kit	110-6902
Weight-Cast	112-7059-01
Weight Kit	112-9971
Blade-Recycler, 14 Inch (6-pack)	114-4961
Blade-Low Flow, 14inch (6-pack)	114-4962
Blade-Mid Flow, 14 Inch (6-pack)	114-4963
Blade-High Flow, 14 Inch (6-pack)	114-4964
Blade-Atomic, 14 Inch (6-pack)	114-4965
Operator-Controlled Discharge Chute Kit	115-4190
Soft Bag (3 Bushel)	30104
Tru Trak Sulky	30110

