



Fuel Stop Solenoid Service Kit

for Reelmaster and Groundsmaster Traction Units

Model No. 104-5154

Installation Instructions

This stop solenoid, part no. 104-5154, replaces the solenoid stop 98-9693. Follow the steps below to install the new stop solenoid and harness.

1. Remove the existing stop solenoid and gasket from the engine.
2. Clean the engine mounting surface of any gasket material.
3. Coat the mounting surfaces with a commercially available RTV, such as ThreeBond 1207F.
4. Mount the new solenoid to the engine and tighten the mounting bolts.
5. Connect the two wire jumper harness to the existing solenoid harness and to the solenoid.