



## **Z300 Z Master<sup>®</sup>**

### **With 34in 7-Gauge Side Discharge Mower**

**Model No. 74408CP - 290000001 and up.**

## **Parts Catalog**

### **Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### **Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### **Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### **Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                       | Page     | Description                           | Page     |
|-----------------------------------|----------|---------------------------------------|----------|
| Deck Connection Assembly          | ..... 3  | Caster and Height-of-Cut Assembly     | ..... 12 |
| Deck Assembly                     | ..... 4  | Seat Assembly                         | ..... 13 |
| Deck Decal Assembly No. 114-0503  | ..... 5  | Motion Control Assembly               | ..... 14 |
| Deflector Assembly No. 110-9917   | ..... 6  | Fuel Tank Assembly                    | ..... 15 |
| Idler Assembly No. 112-3787       | ..... 7  | Engine Mounting Assembly              | ..... 16 |
| Spindle Assembly No. 110-9962     | ..... 8  | Hydraulic Drive Assembly              | ..... 17 |
| Brake Linkage Assembly            | ..... 9  | LH Transmission Assembly No. 109-5847 | ..... 18 |
| Front Frame Assembly              | ..... 10 | RH Transmission Assembly No. 109-5846 | ..... 19 |
| Frame Decal Assembly No. 114-3552 | ..... 11 | Electrical Assembly                   | ..... 20 |
|                                   |          | Attachments and Accessories List      | ..... 21 |

## Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HYD. .... hydraulic                          |
| ASM. .... assembly                         | LH. .... left hand                           |
| BBC. .... blade brake clutch               | NI. .... nylon insert                        |
| CARR. .... carriage                        | NPTF. .... national pipe thread fine         |
| DEG. .... degrees                          | PFH. .... phillips flat head                 |
| EXT. .... external                         | PPH. .... phillips pan head                  |
| FH. .... flat head                         | PPHTF. .... phillips pan head thread forming |
| GA. .... gauge                             | PRH. .... phillips round head                |
| HD. .... heavy-duty                        | PTH. .... phillips truss head                |
| HF. .... hex flange                        | PTO. .... power-take-off                     |
| HH. .... hex head                          | RH. .... right hand                          |
| HHF. .... hex head flange                  | ROPS. .... roll-over protection system       |
| HHFTF. .... hex head flange thread forming | SFH. .... slotted fillister head             |
| HJ. .... hex jam                           | SHH. .... slotted hex head                   |
| HLH. .... hex lag head                     | SHWH. .... slotted hex washer head           |
| HOC. .... height-of-cut                    | SPH. .... slotted pan head                   |
| HSBH. .... hex socket button head          | SQH. .... square head                        |
| HSFH. .... hex socket flat head            | SRH. .... slotted round head                 |
| HSH. .... hex socket head                  | STD. .... standard                           |
| HWH. .... hex washer head                  | TAP. .... self tapping                       |
| HWHTF. .... hex washer head thread forming | TTH. .... torx truss head                    |

## Footnotes


- ❶ Not illustrated
- ❷ Obtain from your local Kawasaki dealer

- ❸ Not serviced separately




Deck Connection Assembly

| Ref | Part No. | Qty. | Description      |  |  |  |  |
|-----|----------|------|------------------|--|--|--|--|
| 1   |          | 1    | Deck ASM         |  |  |  |  |
| 2   | 103-9817 | 2    | Deck Chain ASM   |  |  |  |  |
| 2:1 | 1-633447 | 1    | Chain-Lift, Deck |  |  |  |  |
| 2:2 | 103-1898 | 2    | Screw-HH         |  |  |  |  |
| 2:3 | 32128-37 | 2    | Nut-HF           |  |  |  |  |
| 3   | 104-9776 | 2    | Bushing-Flanged  |  |  |  |  |
| 4   | 103-1898 | 2    | Screw-HH         |  |  |  |  |
| 5   | 32128-37 | 8    | Nut-HF           |  |  |  |  |




## Deck Assembly

| Ref | Part No.    | Qty. | Description                   | Ref | Part No. | Qty. | Description   |
|-----|-------------|------|-------------------------------|-----|----------|------|---------------|
| 1   | 1-603299    | 2    | Roller-Scalp, Anti            | 27  | 322-50   | 1    | Screw-HH      |
| 2   | 1-613098    | 1    | Pulley-Idler                  | 28  | 323-23   | 2    | Screw-HH      |
| 3   | 92-1624     | 16   | Screw-HWH                     | 29  | 3231-1   | 11   | Screw-CARR    |
| 4   | 114-0451    | 1    | Belt                          | 31  | 3231-31  | 1    | Screw-CARR    |
| 5   | 98-7912     | 2    | Tube-Spanner                  | 32  | 3256-24  | 1    | Washer-Flat   |
| 6   | 98-7913     | 2    | Tube-Spacer                   | 33  | 3290-357 | 14   | Nut-HHF, Whiz |
| 7   | 51-4060     | 2    | Screw-Blade                   | 34  | 3296-29  | 1    | Nut-Lock, NI  |
| 8   | 103-0865    | 2    | Washer-Blade Bolt, Heavy      | 35  | 3296-39  | 2    | Nut-Lock, NI  |
| 11  | 105-4622    | 1    | Spacer                        | 37  | 32144-70 | 4    | Screw-HWHTF   |
| 12  | 105-7788    | 1    | Spacer                        | 38  | 3256-23  | 4    | Washer-Flat   |
| 13  | 106-3214    | 1    | Mount-Pulley                  |     |          |      |               |
| 14  | 107-8541-01 | 1    | Baffle-Discharge              |     |          |      |               |
| 15  | 108-4052    | 1    | Spring-Torsion                |     |          |      |               |
| 16  | 114-0503    | 1    | Deck Decal ASM                |     |          |      |               |
| 17  | 110-1515-01 | 1    | Baffle                        |     |          |      |               |
| 18  | 110-9915-03 | 2    | Blade-Rotary, 17.50 High Flow |     |          |      |               |
| 19  | 110-9917    | 1    | Deflector ASM                 |     |          |      |               |
| 20  | 110-9926-01 | 1    | Plate-Skid                    |     |          |      |               |
| 21  | 112-3787    | 1    | Idler ASM                     |     |          |      |               |
| 22  | 110-9946-01 | 1    | Plate-Support, Wheel          |     |          |      |               |
| 23  | 110-9949-01 | 1    | Mount-Wheel, RH               |     |          |      |               |
| 24  | 110-9962    | 2    | Spindle ASM                   |     |          |      |               |
| 25  | 110-9959-01 | 1    | Cover-RH                      |     |          |      |               |
| 26  | 110-9968-01 | 1    | Cover-LH                      |     |          |      |               |




# Deck Decal Assembly No. 114-0503

| Ref | Part No. | Qty. | Description          |
|-----|----------|------|----------------------|
| 2   | 1-403005 | 1    | Decal-Danger         |
| 3   | 54-9220  | 1    | Decal-Danger         |
| 5   | 68-8340  | 1    | Decal-Torque         |
| 6   | 98-5954  | 3    | Decal-Cover, Missing |
| 7   | 112-3793 | 1    | Decal                |
| 8   | 112-3858 | 1    | Decal-Anti Scalp     |




# Deflector Assembly No. 110-9917

| Ref | Part No.    | Qty. | Description                 |
|-----|-------------|------|-----------------------------|
| 1   | 3231-4      | 4    | Screw-CARR                  |
| 2   | 110-0792-01 | 1    | Deflector                   |
| 3   | 110-0793-03 | 1    | Strap-Discharge             |
| 4   | 110-0791    | 1    | Deflector-Rubber            |
| 5   | 110-9923-01 | 1    | Bracket-Mounting, Deflector |
| 6   | 3296-39     | 4    | Nut-Lock, NI                |




# Idler Assembly No. 112-3787

| Ref | Part No. | Qty. | Description                |  |  |  |  |
|-----|----------|------|----------------------------|--|--|--|--|
| 1   | 110-9996 | 1    | Arm-Idler                  |  |  |  |  |
| 3   | 108-4056 | 1    | Spring-Extension           |  |  |  |  |
| 4   | 106-2175 | 1    | Pulley-Idler, Flat         |  |  |  |  |
| 5   | 1-413088 | 1    | Bushing-Lever, Lift        |  |  |  |  |
| 6   | 110-9981 | 2    | Washer-Plain               |  |  |  |  |
| 7   | 108-4063 | 2    | Spacer-Rubber              |  |  |  |  |
| 8   | 3256-24  | 1    | Washer-Flat                |  |  |  |  |
| 9   | 3290-357 | 3    | Nut-HHF, Whiz              |  |  |  |  |
| 11  | 3256-4   | 2    | Washer-Flat                |  |  |  |  |
| 12  | 1-603401 | 3    | Spacer-Fender              |  |  |  |  |
| 14  | 3231-6   | 2    | Screw-CARR                 |  |  |  |  |
| 19  | 3231-5   | 1    | Screw-CARR                 |  |  |  |  |
| 20  | 103-9933 | 1    | Nut-Shoulder               |  |  |  |  |
| 21  | 114-0463 | 2    | Washer-Friction, Composite |  |  |  |  |
| 22  | 323-9    | 1    | Screw-HH                   |  |  |  |  |




**Spindle Assembly No. 110-9962**

| Ref | Part No. | Qty. | Description     |  |  |  |  |
|-----|----------|------|-----------------|--|--|--|--|
| 1   | 3219-7   | 1    | Nut-Hex         |  |  |  |  |
| 2   | 7-4150   | 1    | Washer          |  |  |  |  |
| 3   | 110-9932 | 1    | Pulley          |  |  |  |  |
| 4   | 106-3204 | 1    | Shield-Bearing  |  |  |  |  |
| 5   | 104-6325 | 2    | Bearing-Ball    |  |  |  |  |
| 6   | 108-6696 | 1    | Housing-Spindle |  |  |  |  |
| 7   | 107-8502 | 1    | Spacer-Bearing  |  |  |  |  |
| 8   | 110-0726 | 1    | Shaft-Spindle   |  |  |  |  |
| 10  | 10-8110  | 2    | Washer-Thrust   |  |  |  |  |




Brake Linkage Assembly

| Ref | Part No. | Qty. | Description          |  |  |  |  |
|-----|----------|------|----------------------|--|--|--|--|
| 3   | 103-9408 | 1    | Bar-Equalizer        |  |  |  |  |
| 4   | 103-9409 | 1    | Bracket-Pivot, Brake |  |  |  |  |
| 6   | 109-5376 | 1    | Bellcrank-Brake      |  |  |  |  |
| 7   |          | 1    | Brake Link ASM       |  |  |  |  |
| 7:1 | 109-5370 | 1    | Link-Brake           |  |  |  |  |
| 7:2 | 114-0548 | 1    | Clevis-Brake         |  |  |  |  |
| 7:3 | 103-9925 | 1    | Spring-Brake         |  |  |  |  |
| 7:4 | 103-9926 | 1    | Nut-Square           |  |  |  |  |
| 10  | 1-633545 | 1    | Spacer               |  |  |  |  |
| 11  | 109-0223 | 2    | Link-Center, Over    |  |  |  |  |
| 14  | 109-2861 | 1    | Spring-Return, Brake |  |  |  |  |
| 15  | 283-6    | 2    | Pin-Clevis           |  |  |  |  |
| 16  | 283-75   | 1    | Pin-Clevis           |  |  |  |  |
| 17  | 322-12   | 2    | Screw-HH             |  |  |  |  |
| 19  | 3256-3   | 2    | Washer-Flat          |  |  |  |  |
| 20  | 3272-10  | 3    | Pin-Cotter           |  |  |  |  |
| 22  | 32120-35 | 1    | Ring-Retaining, EXT  |  |  |  |  |
| 23  | 104-8300 | 2    | Nut-Flange, NI       |  |  |  |  |
| 24  | 32120-19 | 1    | E-Ring               |  |  |  |  |
| 25  | 3256-23  | 2    | Washer-Flat          |  |  |  |  |




Front Frame Assembly

| Ref  | Part No.    | Qty. | Description             |  |  |  |  |
|------|-------------|------|-------------------------|--|--|--|--|
| 2    | 1-513658    | 5    | Bumper                  |  |  |  |  |
| 6    | 114-3552    | 1    | Frame ASM               |  |  |  |  |
| 7    | 116-0201-03 | 1    | Guard-Muffler           |  |  |  |  |
| 8    | 103-9381-03 | 1    | Plate, Floor            |  |  |  |  |
| 9    | 104-8300    | 19   | Nut-Flange, NI          |  |  |  |  |
| 10   | 114-0543    | 1    | Rear Guard ASM          |  |  |  |  |
| 10:1 | 93-8069     | 1    | Decal-Surface, Hot      |  |  |  |  |
| 11   | 109-0375    | 1    | Grip-Lever, Brake       |  |  |  |  |
| 13   | 109-2421-03 | 1    | Mount-Tank, Fuel (LH)   |  |  |  |  |
| 14   | 109-2422-03 | 1    | Mount-Tank, Fuel (RH)   |  |  |  |  |
| 15   | 109-2429-03 | 2    | Bracket-Fuel Tank, Rear |  |  |  |  |
| 16   | 114-3560-01 | 1    | Bracket-Fuseblock       |  |  |  |  |
| 17   | 3290-500    | 2    | Screw-PPH               |  |  |  |  |
| 18   | 3296-2      | 2    | Nut-Lock, NI            |  |  |  |  |
| 21   | 109-2605    | 2    | Motion Stop             |  |  |  |  |
| 23   | 302-19      | 5    | Fitting-Grease          |  |  |  |  |
| 25   | 3230-23     | 13   | Screw-CARR              |  |  |  |  |
| 27   | 3234-7      | 3    | Screw-HHF               |  |  |  |  |
| 29   | 3230-16     | 4    | Screw-CARR              |  |  |  |  |
| 30   | 1-603727    | 2    | Clip-Loom               |  |  |  |  |
| 31   | 32151-48    | 1    | E-Ring                  |  |  |  |  |
| 44   | 114-0481-03 | 1    | Shield-Heat             |  |  |  |  |
| 45   | 32144-70    | 5    | Screw-HWHTF             |  |  |  |  |




# Frame Decal Assembly No. 114-3552

| Ref | Part No. | Qty. | Description              |
|-----|----------|------|--------------------------|
| 2   | 112-3856 | 1    | Decal-Danger Battery, Ce |
| 3   | 99-8936  | 2    | Decal-Control, Motion    |
| 4   | 112-3854 | 2    | Decal-Transport, Ce      |
| 5   | 112-3850 | 1    | Decal-Danger Slope, Ce   |
| 6   | 114-3556 | 1    | Decal-Console            |
| 7   | 112-3857 | 1    | Decal-Danger, Ce         |
| 8   | 112-3837 | 1    | Decal                    |
| 9   | 93-8069  | 1    | Decal-Surface, Hot       |




## Caster and Height-of-Cut Assembly

| Ref   | Part No.    | Qty. | Description              | Ref | Part No. | Qty. | Description           |
|-------|-------------|------|--------------------------|-----|----------|------|-----------------------|
| 1     | 112-3810    | 2    | Wheel And Bearing ASM    | 19  | 283-6    | 1    | Pin-Clevis            |
| 2     | 112-3810    | 1    | Wheel Bearing ASM        | 20  | 1-806003 | 1    | Pin-Hair              |
| 1:1:1 | 1-633585    | 2    | Bearing-Cone, Taper      | 21  | 109-2416 | 1    | Spring-Adjust, Height |
| 1:1:2 | 103-0063    | 2    | Seal-Caster              | 22  | 109-2620 | 1    | Pawl-Control, Height  |
| 1:1:3 | 103-3051    | 2    | Spacer-Nut               | 24  | 323-6    | 2    | Screw-HH              |
| 1:1:4 | 103-3157    | 1    | Axle-Caster              | 28  | 109-2410 | 1    | Bar-Adjust, Height    |
| 1:1:5 | 110-9965    | 1    | Wheel And Tire ASM       | 29  | 103-9934 | 1    | Bushing               |
| 1:2   | 103-2768    | 2    | Guard-Seal               | 30  | 104-8301 | 1    | Nut-Flange, NI        |
| 1:3   | 3296-45     | 1    | Nut-Lock, NI             | 31  | 3289-19  | 1    | Screw-FH              |
| 1:4   | 325-20      | 1    | Screw-HH                 | 32  | 3230-23  | 2    | Screw-CARR            |
| 3     | 103-8618-01 | 2    | Fork-Caster              | 33  | 104-8300 | 2    | Nut-Flange, NI        |
| 7     | 1-543511    | 2    | Seal-Grease              | 34  | 1-811010 | 2    | Plug                  |
| 8     | 1-543509    | 4    | Bearing-Roller, Tapered  |     |          |      |                       |
| 9     | 1-543508    | 4    | Cup-Bearing              |     |          |      |                       |
| 10    | 1-633508    | 6    | Washer-Bellville         |     |          |      |                       |
| 11    | 3296-51     | 2    | Nut-Lock, NI             |     |          |      |                       |
| 12    | 103-4882    | 2    | Cap-Grease               |     |          |      |                       |
| 13    | 103-9933    | 2    | Nut-Shoulder             |     |          |      |                       |
| 14    | 63-8410     | 5    | Washer                   |     |          |      |                       |
| 15    | 103-9932    | 1    | Link-Control, Deck       |     |          |      |                       |
| 16    | 109-3544    | 1    | Height Adjust ASM        |     |          |      |                       |
| 16:2  | 109-2463    | 1    | Decal-Height, Deck       |     |          |      |                       |
| 17    | 1-303334    | 2    | Washer-Spring            |     |          |      |                       |
| 18    | 109-3323    | 1    | Height Pin W/Lanyard ASM |     |          |      |                       |



## Seat Assembly

| Ref   | Part No.    | Qty. | Description           | Ref | Part No. | Qty. | Description      |
|-------|-------------|------|-----------------------|-----|----------|------|------------------|
| 1     | 27-0410     | 2    | Screw-Shoulder        | 22  | 3290-321 | 1    | Screw-HWH        |
| 2     | 63-8410     | 4    | Washer                | 26  | 109-2628 | 1    | Cable-Stop, Seat |
| 3     | 82-2190     | 1    | Switch-Bail           |     |          |      |                  |
| 4     | 94-2579     | 1    | Decal                 |     |          |      |                  |
| 5     | 103-9376    | 2    | Bumper-Seat           |     |          |      |                  |
| 6     | 104-8300    | 4    | Nut-Flange, NI        |     |          |      |                  |
| 7     | 112-3845    | 1    | Seat (With Arm Rests) |     |          |      |                  |
| 7:1   | 112-3846    | 1    | Seat                  |     |          |      |                  |
| 7:2   | 108-6163    | 1    | Armrest Kit           |     |          |      |                  |
| 7:2:1 | 110-6569    | 1    | LH Armrest Kit        |     |          |      |                  |
| 7:2:2 | 110-6570    | 1    | RH Armrest Kit        |     |          |      |                  |
| 7:2:3 | 108-6179    | 6    | Screw-HSBH            |     |          |      |                  |
| 8     | 109-2427-03 | 1    | Bar-Stop, Seat        |     |          |      |                  |
| 9     | 112-3836    | 1    | Decal-Service         |     |          |      |                  |
| 10    | 109-2607-03 | 1    | Bracket-Seat          |     |          |      |                  |
| 11    | 109-2608    | 4    | Spacer                |     |          |      |                  |
| 12    | 114-0507    | 1    | Bracket-Seat Holdown  |     |          |      |                  |
| 13    | 321-6       | 2    | Screw-HH              |     |          |      |                  |
| 14    | 322-10      | 4    | Screw-HH              |     |          |      |                  |
| 17    | 32144-4     | 2    | Screw-HWH             |     |          |      |                  |
| 18    | 104-7048    | 1    | Cap-Housing           |     |          |      |                  |
| 19    | 104-7050    | 1    | Housing-Manual        |     |          |      |                  |
| 20    | 2412-120    | 1    | R-Clamp               |     |          |      |                  |
| 21    | 3296-2      | 1    | Nut-Lock, NI          |     |          |      |                  |




Motion Control Assembly

| Ref | Part No. | Qty. | Description            |
|-----|----------|------|------------------------|
| 1   |          | 2    | Steering Rod ASM       |
| 1:1 | 1-543017 | 1    | Balljoint-RH           |
| 1:2 | 103-9407 | 1    | Rod-Steering, LH       |
| 1:3 | 103-9373 | 1    | Trunnion               |
| 1:4 | 3220-2   | 3    | Nut-Jam                |
| 1:5 | 3296-4   | 1    | Nut-Lock               |
| 3   | 1-633181 | 2    | Plate-Tapped           |
| 5   | 1-809057 | 4    | Screw-HSH              |
| 6   | 65-7410  | 2    | Switch-Pole, Single    |
| 7   | 98-5975  | 4    | Washer-Belleville      |
| 8   | 112-3814 | 1    | RH Control Lever ASM   |
| 8:2 | 108-5213 | 1    | Grip-Foam              |
| 9   | 112-3815 | 1    | LH Control Lever ASM   |
| 9:2 | 108-5213 | 1    | Grip-Foam              |
| 12  | 103-9411 | 1    | Control-Steering, RH   |
| 13  | 103-9413 | 1    | Control-Steering, LH   |
| 14  | 103-9414 | 2    | Mount-Post, Lever      |
| 15  | 103-9928 | 4    | Bearing                |
| 16  | 104-7201 | 4    | Nut-HF                 |
| 17  | 104-8300 | 2    | Nut-Flange, NI         |
| 18  | 104-8301 | 2    | Nut-Flange, NI         |
| 19  | 109-2339 | 2    | Damper-Control, Motion |
| 20  | 109-2423 | 2    | Shaft-Pivot, Control   |
| 21  | 109-2428 | 2    | Bracket-Damper         |

| Ref | Part No. | Qty. | Description    |
|-----|----------|------|----------------|
| 22  | 1-633545 | 4    | Spacer         |
| 23  | 322-6    | 2    | Screw-HH       |
| 24  | 323-6    | 4    | Screw-HH       |
| 25  | 323-9    | 2    | Screw-HH       |
| 27  | 3229-4   | 4    | Screw-CARR     |
| 28  | 3234-7   | 4    | Screw-HHF      |
| 29  | 3256-24  | 2    | Washer-Flat    |
| 31  | 3272-10  | 2    | Pin-Cotter     |
| 32  | 3290-500 | 4    | Screw-PPH      |
| 33  | 104-8300 | 2    | Nut-Flange, NI |
| 34  | 32128-20 | 4    | Nut-HF         |
| 35  | 32128-33 | 4    | Nut-HF         |




| Ref    | Part No. | Qty. | Description                      |
|--------|----------|------|----------------------------------|
| ②1     |          | 1    | Fuel Line ASM                    |
| 1:1    | 1-303077 | 12   | Clamp                            |
| 1:2    | 1-603770 | 1    | Valve-Fuel                       |
| 1:3    | 99-5000  | 2    | Valve-Check, Fuel                |
| 1:4    | 99-5005  | 1    | Fitting-Tee, Barbed              |
| 1:5    | 107-7684 | 1    | Hose-Fuel                        |
| 1:6    | 108-4582 | 1    | Hose-Fuel                        |
| 1:7    | 109-0293 | 1    | Hose-Fuel                        |
| 1:8    | 109-0304 | 3    | Hose-Fuel                        |
| 4      | 1-633349 | 4    | Spring-Tank, Fuel                |
| 13     | 112-3780 | 1    | LH Tank ASM (W/Studs)            |
| ②13:1  |          | 1    | LH Tank ASM                      |
| 13:1:2 | 104-7789 | 1    | Bushing                          |
| 13:1:3 | 109-0346 | 1    | Cap-Fuel, Gas                    |
| 13:1:4 | 109-2420 | 1    | Fitting-Fuel (W/Line And Screen) |
| 13:2   | 1-633023 | 2    | Stud                             |
| 14     | 112-3783 | 1    | RH Tank ASM (W/Studs)            |
| ②14:1  |          | 1    | RH Tank ASM                      |
| 14:1:2 | 104-7789 | 1    | Bushing                          |
| 14:1:3 | 109-0346 | 1    | Cap-Fuel, Gas                    |
| 14:1:4 | 109-2420 | 1    | Fitting-Fuel (W/Line And Screen) |
| 14:2   | 1-633023 | 2    | Stud                             |
| 16     | 322-3    | 2    | Screw-HH                         |
| 17     | 3256-23  | 6    | Washer-Flat                      |



Engine Mounting Assembly


| Ref  | Part No.    | Qty. | Description           | Ref | Part No. | Qty. | Description             |
|------|-------------|------|-----------------------|-----|----------|------|-------------------------|
| 1    | 1-303334    | 4    | Washer-Spring         | 25  | 323-8    | 1    | Screw-HH                |
| 3    | 1-513592    | 1    | Knob-Ball             | 26  | 3212-10  | 1    | Screw-HH                |
| 4    | 1-513593    | 1    | Knob-Ball, Black      | 27  | 3231-10  | 1    | Screw-CARR              |
| 5    | 1-603384    | 1    | Bushing-Pivot, Idler  | 28  | 3256-4   | 2    | Washer-Flat             |
| 6    | 108-4056    | 1    | Spring-Extension      | 29  | 3296-2   | 4    | Nut-Lock, NI            |
| 7    | 1-603610    | 2    | Washer-Spring         | 30  | 109-3765 | 1    | Engine-Kawasaki, FH580V |
| 8    | 1-807513    | 4    | Bolt-CARR             | 31  |          | 1    | Bumper                  |
| 9    | 13-2840     | 1    | Key-Square            |     |          |      |                         |
| 10   | 92-6877     | 1    | Valve-Drain, Oil      |     |          |      |                         |
| 11   | 3296-29     | 4    | Nut-Lock, NI          |     |          |      |                         |
| 12   | 103-1966    | 1    | Adapter               |     |          |      |                         |
| 13   | 103-9356-03 | 1    | Rotation-Stop, Clutch |     |          |      |                         |
| 14   | 112-3799    | 1    | Belt-V                |     |          |      |                         |
| 15   | 103-9401    | 1    | Idler                 |     |          |      |                         |
| 16   | 103-9946    | 2    | Throttle Control ASM  |     |          |      |                         |
| 17   | 103-9950    | 1    | Clutch                |     |          |      |                         |
| 18   | 104-8301    | 1    | Nut-Flange, NI        |     |          |      |                         |
| 19   | 106-7022    | 1    | Tube-Drain, Oil       |     |          |      |                         |
| 20   | 109-0393    | 1    | Pulley-Engine         |     |          |      |                         |
| 21   | 3296-59     | 1    | Nut-Lock, NI          |     |          |      |                         |
| 22   | 109-3119    | 1    | Idler Hydro ASM       |     |          |      |                         |
| 22:2 | 1-513034    | 2    | Sleeve-Bearing        |     |          |      |                         |
| 22:3 | 302-40      | 1    | Fitting-Grease        |     |          |      |                         |
| 24   | 322-9       | 4    | Screw-HH              |     |          |      |                         |



## Hydraulic Drive Assembly


| Ref  | Part No.    | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 103-9397    | 2    | Spacer-Hydro             |
| 2    | 103-9380    | 2    | Rod-Bypass, Hydro        |
| 3    | 103-9398    | 1    | Spacer-Axle              |
| 4    | 104-8300    | 6    | Nut-Flange, NI           |
| 5    | 242-50      | 8    | Nut-Lug                  |
| 6    | 109-5846    | 1    | Transmission-RH          |
| 7    | 109-5847    | 1    | Transmission-LH          |
| 8    | 109-2250    | 1    | Vent-Tank, Hydro         |
| 8:1  | 109-3320    | 1    | Cap-Reservoir, Hydraulic |
| 9    | 98-5975     | 2    | Washer-Belleville        |
| 10   | 3230-9      | 4    | Screw-CARR               |
| 11   | 32144-4     | 2    | Screw-HWH                |
| 12   | 104-7201    | 2    | Nut-HF                   |
| 13   | 3256-22     | 2    | Washer-Flat              |
| 14   | 321-4       | 2    | Screw-HH                 |
| 15   | 1-800286    | 2    | Screw-HH                 |
| 16   | 1-806003    | 2    | Pin-Hair                 |
| 17   | 323-11      | 2    | Screw-HH                 |
| 18   | 109-3459    | 1    | Hose-HYD                 |
| 19   | 103-9350-03 | 1    | Plate-Mount, Tank        |
| 20   | 109-3322    | 3    | Clamp-Hose               |
| 21   | 112-3794    | 2    | Wheel And Tire ASM       |
| 21:2 | 112-3797    | 1    | Tire                     |
| 21:3 | 232-27      | 1    | Stem-Valve               |

| Ref   | Part No.    | Qty. | Description            |
|-------|-------------|------|------------------------|
| 21:99 | 107-2491    | 1    | Tube-Tire              |
| 23    | 109-3319    | 1    | Hose-HYD               |
| 24    | 109-2631    | 2    | Spring-Return, Neutral |
| 25    | 114-0469-03 | 2    | Guard-Transmission     |
| 26    | 323-8       | 2    | Screw-HH               |
| 27    | 3290-357    | 2    | Nut-HHF, Whiz          |
| 28    | 109-6801    | 1    | Clamp-Hose             |




# LH Transmission Assembly No. 109-5847

| Ref | Part No. | Qty. | Description             |  |  |  |  |
|-----|----------|------|-------------------------|--|--|--|--|
| 1   | 109-3321 | 1    | Element-Oil Filter, HYD |  |  |  |  |
| ①2  | 109-3537 | 1    | Complete Seal Kit       |  |  |  |  |
| 3   | 109-3538 | 1    | Hub-Kit                 |  |  |  |  |
| 4   | 109-3536 | 1    | Nut-Hub                 |  |  |  |  |
| 5   | 109-3540 | 1    | O-Ring-Seal             |  |  |  |  |
| 6   | 109-3541 | 1    | Fan And Pulley Kit      |  |  |  |  |
| 7   | 109-3542 | 1    | Fan                     |  |  |  |  |
| 9   | 109-3278 | 1    | Adapter-Straight        |  |  |  |  |
| 9:1 | 1-603921 | 1    | O-Ring                  |  |  |  |  |



# RH Transmission Assembly No. 109-5846

| Ref | Part No. | Qty. | Description             |  |  |  |  |
|-----|----------|------|-------------------------|--|--|--|--|
| 1   | 109-3321 | 1    | Element-Oil Filter, HYD |  |  |  |  |
| ①2  | 109-3537 | 1    | Complete Seal Kit       |  |  |  |  |
| 3   | 109-3538 | 1    | Hub-Kit                 |  |  |  |  |
| 4   | 109-3536 | 1    | Nut-Hub                 |  |  |  |  |
| 5   | 109-3540 | 1    | O-Ring-Seal             |  |  |  |  |
| 6   | 109-3541 | 1    | Fan And Pulley Kit      |  |  |  |  |
| 7   | 109-3542 | 1    | Fan                     |  |  |  |  |
| 9   | 109-3278 | 1    | Adapter-Straight        |  |  |  |  |
| 9:1 | 1-603921 | 1    | O-Ring                  |  |  |  |  |



# Electrical Assembly

| Ref  | Part No.    | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 109-7653    | 1    | Positive Battery Cable ASM |
| 1:1  | 109-2407    | 1    | Insulator-Battery          |
| 1:2  | 1-543393    | 1    | Insulator-Solenoid         |
| 2    | 1-513075    | 1    | Switch-Solenoid            |
| 2:1  | 3253-17     | 2    | Washer-Lock                |
| 2:2  | 3253-4      | 2    | Washer-Lock                |
| 2:3  | 3219-14     | 2    | Nut-Hex                    |
| 2:4  | 3220-2      | 2    | Nut-Jam                    |
| 3    | 112-8650    | 1    | Hour Meter ASM             |
| 7    | 1-543792    | 2    | Wingnut                    |
| 8    | 1-633111    | 1    | Switch                     |
| 9    | 1-633181    | 1    | Plate-Tapped               |
| 10   | 109-7620    | 1    | Positive Starter Cable ASM |
| 10:1 | 1-543393    | 2    | Insulator-Solenoid         |
| 11   | 1-633651    | 2    | Bolt-Holddown              |
| 12   | 105-1692    | 1    | Battery                    |
| 12:1 | 104-4163    | 1    | Decal-Battery              |
| 12:2 | 104-4164    | 1    | Decal-Battery              |
| 15   | 116-0229    | 1    | Switch-Ignition            |
| 18   | 103-5221    | 1    | Switch-PTO                 |
| 19   | 103-8355    | 1    | Cable-Battery, Negative    |
| 20   | 103-9944-03 | 1    | Angle-Battery              |
| 21   | 32144-4     | 2    | Screw-HWH                  |
| 22   | 114-3515    | 1    | Harness-Wire               |

| Ref  | Part No. | Qty. | Description  |
|------|----------|------|--------------|
| 22:1 | 109103   | 1    | Fuse-30 Amp  |
| 22:2 | 109102   | 2    | Fuse-25 Amp  |
| 22:3 | 218-578  | 1    | Fuse-10 Amp  |
| 23   | 63-8360  | 1    | Key-Ignition |
| 24   | 321-4    | 2    | Screw-HH     |
| 25   | 3290-500 | 2    | Screw-PPH    |
| 26   | 3296-2   | 2    | Nut-Lock, NI |
| 27   | 32128-33 | 2    | Nut-HF       |
| 29   | 1-807533 | 2    | Bolt-CARR    |

## Attachments and Accessories

For 74408CP - Z300 Z Master, With 34in 7-Gauge Side Discharge Mower

| Product Name                                 | Model/Part |
|----------------------------------------------|------------|
| Recycler Kit . . . . .                       | 110-9960   |
| 17.5 Inch Recycling Blade (6-Pack) . . . . . | 114-4956   |
| 17.5 Low Flow Blade (6-Pack) . . . . .       | 114-4957   |
| 17.5 Med Flow Blade (6-Pack) . . . . .       | 114-4958   |
| 17.5 High Flow Blade (6-Pack) . . . . .      | 114-4959   |
| 17.5 Atomic Blade (6-Pack) . . . . .         | 114-4960   |
| Chute Gate Kit . . . . .                     | 78520      |

## NOTES

## NOTES

