



ProCore[®] SR70 Aerator

Model No. 09924 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Drive Assembly	 3	Idler Assembly	 8
Frame and Roller Assembly	 4	Connecting Rod Assembly	 9
LH Crankshaft Assembly	 5	Hinge and Rear Spool Assembly	 10
Center Crankshaft Assembly	 6	Linkage Arm Assembly	 11
RH Crankshaft Assembly	 7	Head and Spring Assembly	 12
		Screen and Hood Assembly	 13

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes

❶ Not illustrated


❷ Not serviced separately



Drive Assembly

Ref	Part No.	Qty.	Description
1	SG504000-03	1	Gearbox ASM
2	80-6140	2	Key-Square
3	SG517026	2	Gearbox-Sprocket
4	SG527054	2	Sprocket-Hub
4:1	3246-4	1	Screw-Set
5	5-1470	6	Capscrew
6	3253-4	6	Washer-Lock
7	48-9590	4	Washer-Lock
8	33115-020	4	Screw-HH
9	3253-8	4	Washer-Lock
10	33118-030	4	Screw-HH
11	SG580154	2	Chain-60 H, O-Ring
11:1	SG581083	1	Link-Master
12	SG528070	1	PTO #5
13	SG4170401	1	Cone-Shaft
14	3256-24	8	Washer-Flat
15	SG562562	8	Screw-HH
16	99-4371	8	Nut-Lock
17	117-7081-03	2	Angle-Mounting
18	117-7139-03	1	Stand-Storage, LH
19	117-7138-03	1	Stand-Storage, RH
20	323-6	4	Screw-HH
21	3253-21	2	Washer-Lock


Ref	Part No.	Qty.	Description
22	3296-39	2	Nut-Lock, NI



Frame and Roller Assembly


Ref	Part No.	Qty.	Description
1	117-7103	1	Frame ASM
1:2	117-7052	1	Decal-No Oil
1:3	100-3612	2	Decal-Warning
1:4	110-4668	1	Decal-Warning, PTO
2	SG637070-03	2	Bearing-Roller
2:1		1	Bearing-Flange
2:1:1	3245-35	2	Screw-Set
2:1:2	302-19	1	Fitting-Grease
4	SG627070-03	1	Roller-Main, Large
5	SG715875	2	Pin-Hitch
6	SG271517	4	Screw-HH
7	SG639072-01	2	Boot-Roller, Single
8	SG999018	1	Canister-Manual, Operators
9	3253-7	2	Washer-Lock
10	325-6	2	Screw-HH
11	328-26	2	Screw-HH
12	322-3	2	Screw-HH
13	3253-9	2	Washer-Lock
14	SG678970-03	1	Angle-Scraper
15	321-4	2	Screw-HH
16	3253-3	2	Washer-Lock

Ref	Part No.	Qty.	Description
17	3256-22	2	Washer-Flat
18	100-5389	1	Pin-Lynch
19	92-1298	2	Pin-Lynch
20	SG715450	1	Pin-Link, Top
23	3296-23	4	Nut-Lock, NI
27	SG715010	1	HYD Cylinder ASM
27:1	SG555013	2	Bushing
27:3		1	Cylinder-Hydraulic
27:3:1	117-7175	1	Seal Kit
28	SG795250	1	Hose ASM (Long)
29	SG795245	1	Hose ASM (Short)
35	SG795554-03	1	Extension-Adapter 3.50"
36	SG795551-03	1	Extension-Adapter 5.50"
37	117-7124-03	1	Mount-Adapter, 90 DEG




LH Crankshaft Assembly

Ref	Part No.	Qty.	Description				
1	SG204577	3	Bearing ASM				
② 1:1		1	Bearing-Ball				
1:1:1	99-0195	2	Screw-Set, HSH				
1:3	SG427540	2	Ring-Snap				
2	105-1041	6	Pin-Spring				
3	3296-53	6	Nut-Lock, NI				
4	327-14	4	Screw-HH				
5	SG217557	1	Shaft-Stub, Outside				
6	SG267200	8	Nut-Hex				
7	SG247540	3	Washer-Clipped				
8	SG207054	1	Arm-Crank				
9	SG257054	3	Pin-Crank				
10	SG217054	4	Arm-Crank				
11	SG217354	2	Crankshaft				
12	SG217026	1	Sprocket-Crank				
13	SG267500	4	Spacer				
14	3253-7	4	Washer-Lock				
15	SG271517	4	Screw-HH				
17	327-16	2	Screw-HH				




Center Crankshaft Assembly

Ref	Part No.	Qty.	Description				
1	SG204577	3	Bearing ASM				
2	1:1:1	1	Bearing-Ball				
1:1:1	99-0195	2	Screw-Set, HSH				
1:3	SG427540	2	Ring-Snap				
2	105-1041	6	Pin-Spring				
3	3296-53	6	Nut-Lock, NI				
4	327-14	6	Screw-HH				
6	SG267200	8	Nut-Hex				
7	SG247540	2	Washer-Clipped				
9	SG257054	2	Pin-Crank				
10	SG217054	5	Arm-Crank				
11	SG217354	3	Crankshaft				
16	SG217554	1	Arm-Crank				




RH Crankshaft Assembly

Ref	Part No.	Qty.	Description				
1	SG204577	3	Bearing ASM				
2 1:1		1	Bearing-Ball				
1:1:1	99-0195	2	Screw-Set, HSH				
1:3	SG427540	2	Ring-Snap				
2	105-1041	6	Pin-Spring				
3	3296-53	6	Nut-Lock, NI				
4	327-14	4	Screw-HH				
5	SG217557	1	Shaft-Stub, Outside				
6	SG267200	8	Nut-Hex				
7	SG247540	3	Washer-Clipped				
8	SG207054	1	Arm-Crank				
9	SG257054	3	Pin-Crank				
10	SG217054	4	Arm-Crank				
11	SG217354	2	Crankshaft				
12	SG217026	1	Sprocket-Crank				
13	SG267500	4	Spacer				
14	3253-7	4	Washer-Lock				
15	SG271517	4	Screw-HH				
17	327-16	2	Screw-HH				




Idler Assembly

Ref	Part No.	Qty.	Description				
1	SG587054-03	1	Bracket-Idler				
2	SG597054-03	1	Bracket-Idler				
3	SG587202	2	Rod-Idler				
5	3296-23	2	Nut-Lock, NI				
6	SG537500	2	Spacer-Offset				
7	SG517054	2	Sprocket-Idler				
8	327-9	2	Screw-HH				




Connecting Rod Assembly

Ref	Part No.	Qty.	Description				
1	SG337100	16	Bushing-Outer				
4	SG135154	8	Connecting Rod ASM				
24:1		1	Rod-Connecting				
4:2	SG337010	1	Bushing-Inner				
4:3	SG337075	4	Bearing-Ball				
4:4	SG337590	4	Bearing-Ball				
4:5	SG427541	2	Ring-Retaining, Internal				
4:6	SG427625	2	Ring-Retaining, Internal				
5	SG337050	16	Bushing-Outer				




Hinge and Rear Spool Assembly

Ref	Part No.	Qty.	Description				
1	327-14	16	Screw-HH				
5	SG337050	16	Bushing-Outer				
6	SG136354	8	Rear Spool ASM				
6:2	SG337010	1	Bushing-Inner				
6:3	SG337075	4	Bearing-Ball				
6:4	SG427625	2	Ring-Retaining, Internal				
7	SG487001-03	8	Bracket-Spring, Rear				
8	3296-53	16	Nut-Lock, NI				
9	SG449125-03	8	Spool-Spring, Rear				
10	323-16	8	Screw-HH				
11	3296-39	8	Nut-Lock, NI				



Linkage Arm Assembly

Ref	Part No.	Qty.	Description				
1	SG387054-03	16	Arm-Linkage				
2	328-12	24	Screw-HH				
3	3296-51	24	Nut-Lock, NI				
4	SG437125	16	Bushing-Outer				
5	SG337075	16	Bearing-Ball				
6	3296-39	16	Nut-Lock, NI				
7	323-21	16	Screw-HH				
8	SG337300	8	Spacer-Linkage				
9	SG487125	8	Bumper-Rubber				
10	SG486312	8	Spacer-Arm, Linkage				
11	SG487126	8	Bumper-Rubber				



Head and Spring Assembly

Ref	Part No.	Qty.	Description				
1	SG407054-03	8	Head-Tine				
2	323-15	16	Screw-HH				
3	SG477125	40	Screw-Set, SQH				
4	SG487200	8	Bumper-Head				
5	3296-39	16	Nut-Lock, NI				
6	SG447080	16	Bushing-Flanged				
7	SG437100-03	8	Spacer-Head				
8	SG447054-03	8	Spool-Head				
② 11		8	3 Wire Spring ASM				
11:1	SG481512	1	Spring-Compression				
11:2	SG487255	3	Wire-Draw Bar				

NOTES

NOTES

