



Insight[®] Lawn Mower

Model No. 10662 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Deck Housing, Front Wheel and Tunnel Assembly	 3	Engine and Blade Assembly	 6
Side Discharge Chute Assembly	 4	Rear Bag Assembly	 7
Rear Axle and Transmission Assembly	 5	Handle Assembly	 8
		Attachments and Accessories List	 9

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


❶ Not serviced separately

❷ Obtain from your local Briggs & Stratton dealer




Deck Housing, Front Wheel and Tunnel Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	114-2804	1	Housing ASM	28	80-6990	2	Washer-Hardened
1:2	94-8072	1	Decal-Danger	29	108-1044	1	Arm-Pivot, LH
1:3	108-7450	1	Decal-HOC, RH	30	108-7453	1	Decal
1:4	108-7451	1	Decal-HOC, LH	39	110-9468	1	Mulch Plug ASM
1:5	107-3889	1	Decal-Safety	39:1	110-9446	1	Plug-Mulch, LH
3	614650	2	Bolt-Shoulder	39:2	110-9448	1	Latch-Plug, Mulch
4	112-1548	2	7 Inch Front Wheel ASM	39:3	110-9447	1	Plug-Mulch, RH
5	614672	2	Bolt-Shoulder	39:4	108-7476	3	Screw-Plastite
6	40-1940	2	Washer	39:5	110-9458	1	Spring-Extension
7	107-3877	1	Arm-Pivot, RH	39:6	110-9457	1	Decal-Plug, Mulch
8	92-4890	2	Washer				
9	107-3878	2	Arm-Spring				
10	110-0549	2	Knob-HOC				
11	107-3926	1	Cover-Front				
12	108-7476	8	Screw-Plastite				
13	3296-39	2	Nut-Lock, NI				
14	115-3177	1	Cover-Rear				
14:2	114-2820	1	Decal-Warning				
15	110-9455	1	Tunnel				
19	108-7475	2	Screw-Plastite				
20	108-0993	1	Module-Switch				
21	94-1610	2	Nut-Clip				
23	108-0965	2	Screw-PTH				
24	105-6849	2	Screw-Thread Forming				




Side Discharge Chute Assembly

Ref	Part No.	Qty.	Description				
14	99-8445	2	Screw-HWH				
15	99-5293	1	Spring-Torsion				
16	112-6416	1	Bracket-Cover				
17	99-5291	1	Rod-Cover				
18	105-3028	1	Chute-Discharge, Side				
19	106-8376	1	Discharge Door ASM				
19:2	107-0795	1	Latch-Door				
19:3	107-7456	1	Cap-Door				
19:4	107-7461	1	Screw-Plastite				



Rear Axle and Transmission Assembly

Ref	Part No.	Qty.	Description				
1	614650	2	Bolt-Shoulder				
2	107-3906	2	Rear Wheel ASM				
4	110-9417	2	Pinion				
7	110-1793	2	Wheel Cover ASM				
7:2	614426	1	Washer-Stepped				
8	32151-36	2	Ring-Retaining				
9	108-9344	1	Arm-Rear Pivot, LH				
10	110-9445	2	Arm-Spring, Rear				
11	110-0549	2	Knob-HOC				
12	104-8698	2	Retainer-Bearing, HOC				
13	104-8699	2	Bearing-Ball				
14	36-4780	3	Washer-Plain				
16	110-9479	1	Transmission ASM				
18	114-7977-03	1	Bracket-Transmission				
19	108-7476	3	Screw-Plastite				
22	110-9429	1	V-Belt				
25	112-8768	1	Shield-Trailing				
28	108-9343	1	Arm-Rear Pivot, RH				
29	32151-61	2	Ring-Retaining				
30	117-1092	2	Screw-PTH				




Engine and Blade Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	108-3766-03	1	Support-Blade				
3	108-0954-03	1	Blade-21 Inch				
4	106-3987	1	Blade Driver ASM				
5	106-3999	1	Spacer-Driver				
6	92-1624	3	Screw-HWH				
7	105-3030-03	1	Guide-Belt				
8	110-1832	1	Cover-Belt				
9	46-8091	3	Screw-HWH				
10	2210-316	1	Stop-Rope				
11		1	Engine-Briggs & Stratton, 126T02-4181-B1				
12	104-7577-03	1	Shield-Muffler				
13	32144-1	3	Screw-Taptite				
17	98-1394	1	Screw-HWH				
20	110-1778	1	Handle-Recoil				
21	114-2830	1	Decal-Engine				

Rear Bag Assembly

Ref	Part No.	Qty.	Description
1	107-3911	1	Bag-Grass
2	112-8750-03	1	Frame-Bag



Handle Assembly

Ref	Part No.	Qty.	Description				
1	104-8677	1	Cable-Brake				
2	106-4161	4	Knob-Handle				
3	104-8680-05	1	Handle-Upper				
4	106-8330	1	Guide-Rope				
5	3256-1	2	Washer-Flat				
6	3296-73	2	Nut-Lock, NI				
7	107-0757	1	Stop-Pivot				
8	105-6800-03	1	Bail-Brake				
9	105-1837-03	1	Bail-Control				
10	104-8682	1	Stop-Pivot				
11	95-4453	1	Screw				
12	92-7729	1	Anchor-Cable, Upper				
13	110-1834	1	Cable-Traction				
14	112-8876	2	Screw-Handle				
15	110-1828-05	1	Handle-Lower				
16	106-6805	1	Guide-Cable				
17	614249	1	Strap-Tie				
18	115-3157	2	Handle Mount ASM				
20	49-2040	4	Screw-HWHTF				
21	2412-113	3	Clamp				
22	108-0994	1	Guide-Rope, Lower				

Attachments and Accessories

For 10662 - Insight Lawn Mower

Product Name	Model/Part
Replacement Air Filter	104-7944
Lawn Boy Paint	110-8800
Replacement Bag	89815
Rear Bag Kit	89913
21 Inch Blade	89914
Cruise Control Kit	89919

NOTES

NOTES

