



## Cab Kit Workman<sup>®</sup> HD/HDX/HDX-D Utility Vehicle

Model No. 07339

### Parts Catalog

---

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


# Contents

Description	Page	Description	Page
Cab Frame, Roof and Rear Window Assembly	..... 3	Windshield Assembly No. 117-5012	..... 6
Rear Window Assembly No. 117-5019	..... 4	Door Striker Assembly	..... 7
Windshield and Wiper Assembly	..... 5	Overhead Console Assembly	..... 8
		Mounting Hardware Assembly	..... 9

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. .... as required	HYD. .... hydraulic
ASM. .... assembly	LH. .... left hand
BBC. .... blade brake clutch	NI. .... nylon insert
CARR. .... carriage	NPTF. .... national pipe thread fine
DEG. .... degrees	PFH. .... phillips flat head
EXT. .... external	PPH. .... phillips pan head
FH. .... flat head	PPHTF. .... phillips pan head thread forming
GA. .... gauge	PRH. .... phillips round head
HD. .... heavy-duty	PTH. .... phillips truss head
HF. .... hex flange	PTO. .... power-take-off
HH. .... hex head	RH. .... right hand
HHF. .... hex head flange	ROPS. .... roll-over protection system
HHFTF. .... hex head flange thread forming	SFH. .... slotted fillister head
HJ. .... hex jam	SHH. .... slotted hex head
HLH. .... hex lag head	SHWH. .... slotted hex washer head
HOC. .... height-of-cut	SPH. .... slotted pan head
HSBH. .... hex socket button head	SQH. .... square head
HSFH. .... hex socket flat head	SRH. .... slotted round head
HSH. .... hex socket head	STD. .... standard
HWH. .... hex washer head	TAP. .... self tapping
HWHTF. .... hex washer head thread forming	TTH. .... torx truss head




### Cab Frame, Roof and Rear Window Assembly

Ref	Part No.	Qty.	Description
2	117-5008	1	Trim-Roof
3	117-5010	1	Seal-Cab, Bottom
4	115-5586	10	Nut-Panel, Deep
5	115-5570	12	Bushing-Thin
6	117-5009	1	Roof
7	115-5581	6	Washer-Flat
8	117-5011	6	Screw
9	117-5019	1	Rear Window Kit
10	117-4955	2	Decal-Danger, ROPS (Ce)
11	117-5028	1	Wire Harness ASM

--	--	--	--






## Windshield and Wiper Assembly

Ref	Part No.	Qty.	Description
2	115-7689	1	RH Hinge ASM
2:3	115-7696	1	Washer-Hinge, Brass
3	117-5012	1	Windshield Kit
4	115-7692	2	Mount-Window Slider, Front
5	3230-2	2	Bolt-CARR
6	3256-23	2	Washer-Flat
7	115-7693	4	Sleeve-Slide, Window
8	115-1794	2	Screw-HHF
9	104-8300	2	Nut-Flange, NI
10	115-7694	1	Slider-Window, LH
11	115-7695	1	Slider-Window, RH
12	3296-29	2	Nut-Lock, NI
13	115-7935	1	Cover-Motor, Wiper
14	115-7934	1	Bushing-Mount, Windshield
15	115-7933	1	Plate-Mount, Wiper
16	115-8831	1	Motor-Wiper
17	3253-3	2	Washer-Lock
18	329-6	2	Screw-HH
19	115-7686	1	Arm-Radial
20	115-7691	1	Blade-Wiper
21	115-7688	1	LH Hinge ASM
21:3	115-7696	1	Washer-Hinge, Brass






## Overhead Console Assembly

Ref	Part No.	Qty.	Description
1	117-5015	1	Headliner
2	3274-65	4	Screw-HSBH
3	115-7952	4	Nut-Panel
4	117-5016	1	Switch Plate
5	115-7953	1	Fuse Block ASM
6	104-2408	4	Screw-HSBH
7	115-5505	2	Nut-Panel, Spring
8	115-7957	1	Cover-Access, Fuse
9	115-5506	2	Knob
10	115-7955	1	Switch-Momentary
11	117-5017	1	Decal-Plate, Switch
12	117-5018	1	Decal-Cover, Access (Fuse)
13	115-7946	1	Light-Dome
14	115-5594	2	Screw-HSBH
15	117-5022	2	Screw-Pan, Sq
16	3290-148	2	Nut-HF
17	117-5023	1	Seal-Bulb, Headliner

--	--	--	--



### Mounting Hardware Assembly

Ref	Part No.	Qty.	Description				
1	117-5003	1	Mount-Rear, LH				
2	117-5004	1	Mount-Rear, RH				
3	117-4807	2	Support-Floor				
4	117-5005	4	Isolator				
5	117-5006	4	Washer-Rubber				
6	117-5007	4	Washer				
7	325-12	4	Screw-HH				
8	99-5107	4	Nut-Lock				
9	3256-4	4	Washer-Flat				
11	323-6	4	Screw-HH				
12	104-8301	6	Nut-Flange, NI				
13	115-7959	2	Button-Plug				
15	108-3074	2	Spring-Variable				
16	109101	1	Fuse-20 Amp				

## NOTES

# NOTES

