


TORO®

MODEL NO. 30136-491037 & UP

**PARTS
CATALOG****36" SIDE DISCHARGE CUTTING UNIT
for ProLine Wide Area Mower**

T-0216


CUTTING UNIT ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	54-9220	Decal - Caution	2	15	3256-2	Washer - Flat	A/R
2	13-3879	Deflector - Grass (Incl. Ref.#1)	1	16	3211-5	Screw - Hex. Hd. Cap	1
3	3296-5	Nut - Lock	3	17	51-3660	Idler - Flat	1
4	40-6230	Spring - Torsion	2	18	323-12	Screw - Hex. Hd. Cap	1
5	29-5590	Bracket - Pivot, Deflector	2	19	3256-24	Washer - Flat	A/R
6	62-6520	Knob	2	20	56-4341	Arm - Idler	1
7	3231-22	Bolt - Carriage	13	21	51-3641	Sleeve - Pivot Idler	1
8	51-3650	Spring - Idler	1	22	3230-22	Bolt - Carriage	2
9	32151-72	Ring - Retaining	2	23	52-4780	Rod - Belt	2
10	82-5460	Cover - Deck	1	24	32128-21	Nut - Lock	14
11	51-3730	Decal - 36"	1	25	36-1740	Roller - Deck	1
12	74-2080	Decal - Proline	1	26	40-6400	Shaft - Roller	2
13	3296-29	Nut - Lock	2	27	3272-11	Pin - Cotter	3
14	56-4360	Rod - Spring	1	28	68-8340	Decal - Blade Torque	1
				29	27-7680	Ring - Deck Support	2

© The TORO Company -1994

TPS

All Rights Reserved




T-0216

CUTTING UNIT ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
30	43-8480	Decal - Danger	1	37	51-3530	Belt - Deck Drive	1
31	14-2369	Deck Assembly (Incl. Ref.#28,30,42 & 46)	1	38	29-4820	Roller - Deck	2
32	56-2390	Blade - High Sail (Std.)	2	39	57-0690	Pin - Special	1
*	27-0990	Blade - Low Sail (Optional)	2	40	3230-18	Bolt - Carriage	4
33	54-7781	Spindle Assembly - Drive	1	41	27-0870	Spindle Assembly	1
34	72-9361	Cup - Scalp	2	42	66-1340	Decal - Caution	1
35	3253-27	Washer - Lock	2	44	32152-1	Nut	4
36	44-2200	Screw - Blade Bolt	2	45	3211-15	Screw - Hex. Hd.	2
				46	67-5360	Decal - Danger	1

*Not Illustrated




T-0111

DRIVE SPINDLE NO. 27-0870

Ref. No.	Part No.	Description	No. Used
1	302-2	Fitting - Grease	1
2	32146-20	Nut - Lock	1
3	7-4150	Washer	1
4	27-0970	Pulley & Hub Assembly	1
5	253-139	Seal - Wave	2

Ref. No.	Part No.	Description	No. Used
6	46-8530	Bearing Assembly	1
7	61-4160	Spindle Housing	1
8	27-0950	Spacer - Spindle Bearing	1
9	27-0920	Shaft - Spindle	1


* Not Illustrated.



T-0218

DRIVE SPINDLE NO. 54-7781

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	302-2	Fitting - Grease	1	6	61-4160	Housing - Spindle	1
2	32146-20	Nut - Lock	1	7	253-139	Seal - Wave	2
3	7-4150	Washer	1	8	27-0950	Spacer - Spindle Bearing	1
4	55-7610	Pulley Assembly	1	9	51-3551	Spindle - Shaft	1
5	46-8530	Bearing Assembly	1	10	54-2750	"V" Belt - Engine to Deck	1



T-0219

CARRIER FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3290-355	Pin - Cotter	4	19	3217-6	Nut	8
2	74-0350	Cushion - Rubber	4	20	3253-4	Washer - Lock	8
3	74-0130	Frame - Carrier (Incl. Ref. #32)	1	21	68-8930	Wheel Half - Male	2
4	283-55	Pin - Clevis	4	22	68-8960	Tire	2
5	68-8360	Decal - H.O.C., L.H. 1-4"	1	23	68-8920	Wheel Half - Female	2
*	85-7450	Decal - H.O.C., L.H. 2-5"	1	24	68-8940	Hub - Center	2
6	32128-23	Nut - Lock	6	25	302-61	Fitting - Grease	2
7	3234-6	Screw - Flange Lock	6	26	3256-6	Washer	4
8	3296-45	Nut - Lock	2	27	32153-5	Nut - Lock	2
9	74-0310	Shaft - Adjusting	2	28	74-0251	Castor - Fork	2
10	3218-5	Nut	4	29	3-6781	Washer - Thrust	8
11	41-8440	Washer	2	30	302-5	Fitting - Grease	2
12	74-0290	Spring - Compression	2	31	32151-91	Ring - Retaining	2
13	256-156	Bushing	2	32	28-9290	Bushing - Special	4
14	325-19	Screw - Hex. Hd. Cap	2	33	74-0940	Decal - H.O.C., R.H. 1-4"	1
15	62-5580	Bushing	4	*	85-7460	Decal - H.O.C., R.H. 2-5"	1
16	68-8950	Tube w/Valve	2	34	93-1167	Spacer - Castor	2
17	68-8980	Spanner - Bushing	2	*	13-3869	Castor Wheel Assembly (2 Per Carton)	1
18	62-5570	Bearing - Roller	2				

*Not Illustrated

TORO PART NUMBER INDEX

3316-755

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3-6781	Washer - Thrust	5 29 8	68-8950	Tube w/Valve	5 16 2
7-4150	Washer	3 3 1	68-8960	Tire	5 22 2
7-4150	Washer	4 3 1	68-8980	Spanner - Bushing	5 17 2
12-4099	Spindle Assembly	2 41 1	72-9361	Cup - Scalp	2 34 2
12-4109	Spindle Assembly - Drive	2 33 1	74-0130	Frame - Carrier	5 3 1
13-3869	Castor Wheel Assembly	5 * 1	74-0251	Castor - Fork	5 28 2
13-3879	Deflector - Grass	1 2 1	74-0290	Spring - Compression	5 12 2
14-2369	Deck Assembly	2 31 1	74-0310	Shaft - Adjusting	5 9 2
27-0920	Shaft - Spindle	3 9 1	74-0350	Cushion - Rubber	5 2 4
27-0950	Spacer - Spindle Bearing	3 8 1	74-0940	Decal - H.O.C., R.H. 1-4"	5 33 1
27-0950	Spacer - Spindle Bearing	4 8 1	74-2080	Decal - Proline	1 12 1
27-0970	Pulley & Hub Assembly	3 4 1	82-5460	Cover - Deck	1 10 1
27-0990	Blade - Low Sail (Optional)	2 * 2	85-7450	Decal - H.O.C., L.H. 2-5"	5 * 1
27-7680	Ring - Deck Support	1 29 2	85-7460	Decal - H.O.C., R.H. 2-5"	5 * 1
28-9290	Bushing - Special	5 32 4	93-1167	Spacer - Castor	5 34 2
29-4820	Roller - Deck	2 38 2	253-139	Seal - Wave	3 5 2
29-5590	Bracket - Pivot, Deflector	1 5 2	253-139	Seal - Wave	4 7 2
36-1740	Roller - Deck	1 25 1	256-156	Bushing	5 13 2
40-6230	Spring - Torsion	1 4 2	283-55	Pin - Clevis	5 4 4
40-6400	Shaft - Roller	1 26 2	302-2	Fitting - Grease	3 1 1
41-8440	Washer	5 11 2	302-2	Fitting - Grease	4 1 1
43-8480	Decal - Danger	2 30 1	302-5	Fitting - Grease	5 30 2
44-2200	Screw - Blade Bolt	2 36 2	302-61	Fitting - Grease	5 25 2
46-8530	Bearing Assembly	4 5 1	323-12	Screw - Hex. Hd. Cap	1 18 1
46-8530	Bearing Assembly	3 6 1	325-19	Screw - Hex. Hd. Cap	5 14 2
51-3530	Belt - Deck Drive	2 37 1	3211-5	Screw - Hex. Hd. Cap	1 16 1
51-3551	Spindle - Shaft	4 9 1	3211-15	Screw - Hex. Hd.	2 45 2
51-3641	Sleeve - Pivot Idler	1 21 1	3217-6	Nut	5 19 8
51-3650	Spring - Idler	1 8 1	3218-5	Nut	5 10 4
51-3660	Idler - Flat	1 17 1	3230-18	Bolt - Carriage	2 40 4
51-3730	Decal - 36	1 11 1	3230-22	Bolt - Carriage	1 22 2
52-4780	Rod - Belt	1 23 2	3231-22	Bolt - Carriage	1 7 13
54-2750	VBelt - Engine to Deck	4 10 1	3234-6	Screw - Flange Lock	5 7 6
54-9220	Decal - Caution	1 1 2	3253-4	Washer - Lock	5 20 8
55-7610	Pulley Assembly	4 4 1	3253-27	Washer - Lock	2 35 2
56-2390	Blade - High Sail (Std.)	2 32 2	3256-2	Washer - Flat	1 15A/R
56-4341	Arm - Idler	1 20 1	3256-6	Washer	5 26 4
56-4360	Rod - Spring	1 14 1	3256-24	Washer - Flat	1 19A/R
57-0690	Pin - Special	2 39 1	3272-11	Pin - Cotter	1 27 3
61-4160	Housing - Spindle	4 6 1	3290-355	Pin - Cotter	5 1 4
61-4160	Spindle Housing	3 7 1	3296-5	Nut - Lock	1 3 3
62-5570	Bearing - Roller	5 18 2	3296-29	Nut - Lock	1 13 2
62-5580	Bushing	5 15 4	3296-45	Nut - Lock	5 8 2
62-6520	Knob	1 6 2	32128-21	Nut - Lock	1 24 14
66-1340	Decal - Caution	2 42 1	32128-23	Nut - Lock	5 6 6
67-5360	Decal - Danger	2 46 1	32146-20	Nut - Lock	3 2 1
68-8340	Decal - Blade Torque	1 28 1	32146-20	Nut - Lock	4 2 1
68-8360	Decal - H.O.C., L.H. 1-4"	5 5 1	32151-72	Ring - Retaining	1 9 2
68-8920	Wheel Half - Female	5 23 2	32151-91	Ring - Retaining	5 31 2
68-8930	Wheel Half - Male	5 21 2	32152-1	Nut	2 44 4
68-8940	Hub - Center	5 24 2	32153-5	Nut - Lock	5 27 2

*Not Illustrated