



**TORO®****MODEL NO. 20907B-4900001 & UP****PARTS  
CATALOG****48cm REAR BAGGING MOWER**

C-1515A

**HOUSING ASSEMBLY**

| Ref. No. | Part No. | Description                       | No. Used | Ref. No. | Part No. | Description                               | No. Used |
|----------|----------|-----------------------------------|----------|----------|----------|-------------------------------------------|----------|
| 1        | 71-9860  | Decal - 48cm                      | 1        | 17       | 322-29   | Screw - Cap Hex. Hd.                      | 2        |
| 2        | 16-1669  | Housing - 48cm<br>(Incl. Ref. #4) | 1        | 18       | 71-9840  | Spring - Door                             | 2        |
| 3        | 71-7920  | Cover - Belt                      | 1        | 19       | 66-0680  | Decal - French Regulation                 | 1        |
| 4        | 92-9077  | Decal - Danger                    | 1        | 20       | 71-8580  | Spacer - Door                             | 2        |
| 5        | 32144-70 | Screw - Hex. Flange Hd.           | 1        | 21       | 71-7890  | Guide - Belt Rear                         | 1        |
| 6        | 71-7870  | Grip - Lower                      | 1        | 22       | 71-7990  | Ramp - Discharge                          | 1        |
| 7        | 71-7930  | Trigger - H.O.C.                  | 1        | 23       | 32112-11 | Nut - Push                                | 1        |
| 8        | 3284-5   | Pin - Roll                        | 1        | 24       | 71-8830  | Retainer - Shaft                          | 2        |
| 10       | 32144-4  | Screw - Thread Forming            | 10       | 25       | 71-7820  | Pivot - Front                             | 1        |
| 11       | 71-7910  | Cap - Hinge Bolt R.H.             | 1        | 26       | 3296-5   | Nut - Lock                                | 2        |
| 12       | 65-5210  | Screw - Thread Forming            | 2        | 27       | 40-1940  | Washer - Wheel                            | 2        |
| 13       | 71-7860  | Grip - Upper                      | 1        | 28       | 27-6250  | Bushing - Wheel                           | 4        |
| 14       | 32144-97 | Screw - Thread Forming            | 2        | 29       | 46-1113  | Wheel & Tire Assembly<br>(Incl. Ref. #28) | 2        |
| 15       | 71-9800  | Door - Discharge                  | 1        | 30       | 27-6230  | Bolt - Wheel                              | 2        |
| 16       | 71-7900  | Cap - Hinge Bolt L.H.             | 1        |          |          |                                           |          |




C-1516

## ENGINE ASSEMBLY

| Ref. No. | Part No.  | Description           | No. Used |
|----------|-----------|-----------------------|----------|
| 1        |           | Engine – B&S Quantum  | 1        |
| 2        | 71-8460   | Decal – Engine        | 1        |
| 3        | 82-8550   | Shield – Muffler      | 1        |
| 4        | 3290-378  | Tie – Cable           | 1        |
| 5        | 32144-73  | Screw – Muffler       | 3        |
| 6        | 32144-102 | Screw – Engine Mount  | 3        |
| 7        | 32144-4   | Screw – Thr'd Forming | 2        |
| 8        | 71-7940   | Retainer – Blade      | 1        |

| Ref. No. | Part No. | Description         | No. Used |
|----------|----------|---------------------|----------|
| 9        | 71-8210  | Blade – 48cm        | 1        |
| 10       | 80-2770  | Cup – Anti-Scalp    | 1        |
| 11       | 3253-22  | Washer – Lock       | 1        |
| 12       | 26-0672  | Bolt – Blade        | 1        |
| 13       | 71-7960  | Guide – Engine Belt | 1        |
| 14       | 62-7550  | Pulley – Driver     | 1        |
| 15       | 86-7990  | Screw – Clamp       | 1        |
| 16       | 2210-249 | Clamp – Cable       | 1        |




C-1517

## S. P. REAR AXLE ASSEMBLY

| Ref. No. | Part No. | Description                                            | No. Used | Ref. No. | Part No. | Description                                  | No. Used |
|----------|----------|--------------------------------------------------------|----------|----------|----------|----------------------------------------------|----------|
| 1        | 71-9820  | Rear Pivot Assembly R.H.<br>(Incl. Ref. #2, 4, 5 & 14) | 1        | 19       | 65-4750  | Gear - Pinion                                | 2        |
| 2        | 302-26   | Fitting - Grease                                       | 2        | 20       | 65-4720  | Spring - Compression                         | 2        |
| 3        | 71-9850  | Retainer - Belt                                        | 1        | 21       | 74-1660  | Cover - Wheel                                | 2        |
| 4        | 47-2890  | Bushing - Sleeve                                       | 2        | 22       | 14-9959  | Wheel, Tire & Gear Assy.<br>(Incl. Ref. #24) | 2        |
| 5        | 47-6730  | Seal - Grease                                          | 2        | 23       | 27-6230  | Bolt - Wheel                                 | 2        |
| 6        | 71-9810  | Rear Pivot Assembly L.H.<br>(Incl. Ref. #2, 4, 5 & 14) | 1        | 24       | 27-6250  | Bushing - Wheel                              | 4        |
| 7        | 3296-5   | Nut - Lock                                             | 2        | 25       | 74-1670  | Spacer - Wheel                               | 2        |
| 8        | 71-7840  | Rod - Trigger                                          | 1        | 26       | 65-4760  | Washer - Clutch                              | 2        |
| 9        | 32144-31 | Screw - Thread Forming                                 | 1        | 27       | 71-7770  | Plate - Rear Securing                        | 2        |
| 10       | 71-8060  | Spring - Trigger Return                                | 2        | 28       | 32144-4  | Screw - Thread Forming                       | 6        |
| 11       | 71-8080  | Saddle - H.O.C.                                        | 1        | 29       | 32151-93 | Ring - Grip                                  | 1        |
| 12       | 63-8590  | Screw - Thread Forming                                 | 2        | 30       | 71-7970  | Rod - Link                                   | 1        |
| 13       | 32112-13 | Nut - Push                                             | 1        | 31       | 71-7740  | Spring - Counterbalance                      | 1        |
| 14       | 48-2060  | Bearing - Needle                                       | 2        | 32       | 71-8450  | Cover - Spring                               | 1        |
| 15       | 65-4710  | Washer - Friction                                      | 2        | 33       | 71-7980  | Indicator - H.O.C.                           | 1        |
| 16       | 65-4740  | Washer - Keyed Thrust                                  | 4        | 34       | 71-9450  | V-Belt                                       | 1        |
| 17       | 65-2720  | Ring - Retaining                                       | 4        | 35       | 71-9600  | Gearcase Assembly<br>(Incl. Ref. #36)        | 1        |
| 18       | 66-6050  | Key - Rocking L.H.                                     | 1        | 36       | 71-9630  | Bracket - Traction                           | 1        |
| *        | 66-6040  | Key - Rocking R.H.                                     | 1        |          |          |                                              |          |

\*Not Illustrated




C-1292a

## GEAR CASE ASSEMBLY

| Ref. No. | Part No. | Description          | No. Used |
|----------|----------|----------------------|----------|
| 1        | 49-2040  | Screw - Tapite       | 4        |
| 2        | 614668   | Cover - Gear Case    | 1        |
| 3        | 55-3760  | Pinion - 15 Tooth    | 1        |
| 4        | 614696   | Shaft - Intermediate | 1        |
| 5        | 36-4791  | Washer               | 2        |
| 6        | 60-8750  | Bushing              | 2        |
| 7        | 71-9620  | Shaft - Output       | 1        |
| 8        | 32121-63 | Pin - Groove         | 2        |
| 9        | 60-8850  | Bushing - Output     | 2        |
| 10       | 614578   | Gearcase             | 1        |

| Ref. No. | Part No. | Description              | No. Used |
|----------|----------|--------------------------|----------|
| 11       | 62-6660  | Spacer                   | 1        |
| 12       | 71-9610  | Pulley - Half            | 2        |
| 13       | 3256-24  | Washer                   | 1        |
| 14       | 3296-5   | Nut                      | 1        |
| 15       | 38-7820  | Bearing - Ball           | 1        |
| 16       | 60-8890  | Gear - Bevel Pinion      | 1        |
| 17       | 36-4780  | Washer - Thrust          | 3        |
| 18       | 614596   | Gear 34 Tooth            | 1        |
| *        | 71-9600  | Gear Case Ass'y Complete | 1        |

\*Not Illustrated




C-0367

## S. P. HANDLE ASSEMBLY

| Ref. No. | Part No. | Description                                                              | No. Used | Ref. No. | Part No.  | Description            | No. Used |
|----------|----------|--------------------------------------------------------------------------|----------|----------|-----------|------------------------|----------|
| 1        | 71-9020  | Handle                                                                   | 1        | 13       | 321-3     | Screw - Cap Hex. Hd.   | 1        |
| 2        | 17-9426  | Screw - Handle                                                           | 2        | 14       | 32144-97  | Screw - Thread Forming | 5        |
| 3        | 16-1689  | Panel - Control<br>(Incl. Ref. #4 & 5)                                   | 1        | 15       | 32104-121 | Screw - Thread Forming | 1        |
| 4        | 71-9861  | Decal - TORO 4 Cyc.                                                      | 1        | 16       | 71-7680   | Cover - Throttle Lower | 1        |
| 5        | 71-9865  | Decal - Danger                                                           | 1        | 17       | 71-7630   | Cap - Throttle Lower   | 1        |
| 6        | 66-0235  | Control - Throttle<br>Bend Type #1<br>Sheath Lg. 55.50<br>Wire Lg. 2 1/2 | 1        | 18       | 32144-99  | Screw - Thread Forming | 2        |
| 7        | 46-9900  | Bar - Control                                                            | 1        | 19       | 71-8110   | Cable - Traction       | 1        |
| 8        | 3296-29  | Nut - Flange Lock                                                        | 2        | 20       | 71-8310   | Spring - Compression   | 1        |
| 9        | 3296-42  | Nut - Lock                                                               | 1        | 21       | 3290-378  | Tie - Cable            | 2        |
| 10       | 46-8800  | Lever - Control                                                          | 1        | 22       | 32144-98  | Screw - Thread Forming | 4        |
| 11       | 46-5520  | Lever - Traction                                                         | 1        | 23       | 71-8040   | Plate - Throttle       | 1        |
| 12       | 66-0330  | Support - Spacer                                                         | 2        | 24       | 71-8130   | Bracket - Panel        | 1        |
|          |          |                                                                          |          | 25       | 19-4050   | Knob - Handle          | 2        |
|          |          |                                                                          |          | 26       | 71-8100   | Mount - Handle R.H.    | 1        |
|          |          |                                                                          |          | *        | 71-8090   | Mount - Handle L.H.    | 1        |

\*Not Illustrated




C-1509

**GRASS BAG ASSEMBLY**

| Ref. No. | Part No.  | Description        | No. Used |
|----------|-----------|--------------------|----------|
| 1        | 32144-111 | Screw - Thr'd Form | 5        |
| 2        | 71-9480   | Handle - Door      | 1        |
| 3        | 71-9470   | Door - Bag         | 1        |

| Ref. No. | Part No. | Description | No. Used |
|----------|----------|-------------|----------|
| 4        | 71-9900  | Frame - Bag | 1        |
| 5        | 71-9460  | Bag - Grass | 1        |



1019 LABEL KIT


★ REQUIRES SPECIAL TOOLS  
TO INSTALL. SEE REPAIR  
INSTRUCTION MANUAL.

## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                                    | No. Used |
|----------|----------|------------------------------------------------|----------|
| 1        | 493260   | Cylinder Assembly                              | 1        |
| 2        | 293708   | Bushing-Cylinder                               | 1        |
|          |          | Note: Requires Special Tools for Installation. | 1        |
| ★3       | 393862   | Seal-Oil                                       | 1        |
| 5        | 213861   | Head-Cylinder                                  | 1        |
| ★7       | 272200   | Gasket-Cylinder Hd.                            | 1        |
| 8        | 399717   | Breather-Vlv. Chamber                          | 1        |
| ★9       | 271904   | Gasket-Valve Cover                             | 1        |
| ★9A      | 272238   | Gasket-Baffle Plate                            | 1        |
| 10       | 94222    | Screw-Breather Mtg.                            | 1        |
| 11       | 231685   | Tube-Breather                                  | 1        |
| 13       | 94547    | Screw-Cylinder Hd.                             | 1        |
| ★52      | 272199   | Gasket-Intake Elbow                            | 1        |
| 54       | 94526    | Screw-Intake Elbow Mtg.                        | 1        |
| 284      | 94511    | Screw-Hex. Head                                | 1        |
| 307      | 94515    | Screw-Hex. Head                                | 1        |
| 337      | 802592   | Plug-Spark                                     | 1        |
| 383      | 89838    | Wrench-Spark Plug                              | 1        |

| Ref. No. | Part No. | Description                        | No. Used |
|----------|----------|------------------------------------|----------|
| 523      | 493950   | Cap with Dipstick-Oil Filler       | 1        |
| 524      | 280393   | Seal-Filler Tube                   | 1        |
| 525      | 493952   | Tube-Oil Filler                    | 1        |
| 572      | 224328   | Baffle-Cylinder                    | 1        |
| 625      | 492717   | Tube-Fuel Intake                   | 1        |
| 635      | 66538    | Elbow-Spark Plug                   | 1        |
| 842      | 280966   | Seal-O-Ring                        | 1        |
| 847      | 493459   | Dipstick and Tube Assy.-Oil Filler | 1        |
| 869      | 213512   | Seat-Intake Valve (Std.)           | 1        |
| 870      | 213513   | Seat-Exhaust Valve (Std.)          | 1        |
| 871      | 262001   | Guide-Exhaust Valve                | 1        |
|          |          | Note: 63709 Guide-Intake Valve     |          |
|          |          | See Repair Instruction Manual.     | 1        |
| 1019     | 494256   | Label Kit                          | 1        |

★ Included in Gasket Set-Part No. 493263.




## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                            | No. Used |
|----------|----------|----------------------------------------|----------|
| ★12      | 272198   | Gasket—Crankcase                       | 1        |
| 15       | 93418    | Plug—Oil Drain                         | 1        |
| 16       | 494547   | Crankshaft                             | 1        |
|          |          | Note: Order 94388 For Timing Gear Key. | 1        |
| 18       | 493279   | Sump—Engine                            | 1        |
| ★20      | 399781   | Seal—Oil                               | 1        |
| 22       | 94220    | Screw—Sump Mtg. Sem                    | 1        |
|          |          | Note: 94612 Screw—Sump Mtg.            |          |
|          |          | One Used in Hole Nearest Breather.     | 1        |
| 24       | 222698   | Key—Flywheel                           | 1        |
| 25       | 493262   | Piston Assy. (Standard)                | 1        |
|          | 493385   | Piston Assy. (.010" O.S.)              | 1        |
|          | 493386   | Piston Assy. (.020" O.S.)              | 1        |
|          | 493387   | Piston Assy. (.030" O.S.)              | 1        |
|          |          | PISTON RING SETS:                      |          |
| 26       | 493261   | Ring Set—Piston (Std.)                 | 1        |
|          | 493388   | Ring Set—Piston (.010" O.S.)           | 1        |
|          | 493389   | Ring Set—Piston (.020" O.S.)           | 1        |
|          | 493390   | Ring Set—Piston (.030" O.S.)           | 1        |

| Ref. No. | Part No. | Description                                            | No. Used |
|----------|----------|--------------------------------------------------------|----------|
| 27       | 26026    | Lock—Piston Pin                                        | 1        |
| 28       | 298909   | Pin Assembly—Piston (Std.)                             | 1        |
| 29       | 490566   | Rod Assembly— Connecting                               | 1        |
|          |          | Note: For Connecting Rod with .020" Undersize Crankpin |          |
|          |          | Bearing—Order No. 490743.                              | 1        |
| 32       | 94405    | Screw—Connecting Rod                                   | 1        |
| 33       | 262651   | Valve—Exhaust                                          | 1        |
| 34       | 262652   | Valve—Intake                                           | 1        |
| 35       | 262224   | Spring—Valve                                           | 1        |
| 40       | 93312    | Retainer—Valve Spring                                  | 1        |
| 45       | 262204   | Tappet—Valve                                           | 1        |
| 46       | 492828   | Gear—Cam                                               | 1        |
| 47       | 493737   | Oil Slinger Gear and Bracket                           | 1        |
| 227      | 492349   | Lever Assembly—Gov.                                    | 1        |
| 230      | 67072    | Washer—Gov. Crank                                      | 1        |
| 562      | 92613    | Bolt—Governor Lever                                    | 1        |
| 592      | 231082   | Nut—Hex                                                | 1        |
| 615      | 94474    | Pushnut (Governor Crank)                               | 1        |
| 616      | 262578   | Crank—Governor                                         | 1        |
| 741      | 262598   | Gear—Timing                                            | 1        |

★ Included in Gasket Set—Part No. 493263.




## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                           | No. Used |
|----------|----------|---------------------------------------|----------|
| 98A      | 493280   | Screw Assy. - Speed Adj.              | 1        |
| ★163     | 272296   | Gasket - Air Cleaner                  | 1        |
| 188A     | 94644    | Screw - Hex. Head                     | 1        |
| 201      | 262579   | Link - Governor                       | 1        |
| 209      | 262661   | Spring - Governor                     | 1        |
| 529      | 280943   | Grommet - Breather                    | 1        |
| 618      | 262749   | Spring - Choke Return                 | 1        |
| 620      | 493894   | Bracket Assembly - Carburetor Control | 1        |
| 621      | 396847   | Switch - Stop                         | 1        |

| Ref. No. | Part No. | Description                              | No. Used |
|----------|----------|------------------------------------------|----------|
| 670A     | 493823   | Spacer - Carburetor Brkt. (Includes 2)   | 1        |
| 966      | 492363   | Base - Air Cleaner                       | 1        |
| 967      | 491588   | Filter - Air                             | 1        |
| 968      | 280937   | Cover - Air Cleaner                      | 1        |
| 969      | 94120    | Screw - Cover Mtg.                       | 1        |
| 971      | 94269    | Screw - Air Cleaner                      | 1        |
| 971A     | 94121    | Screw - Air Cleaner (Base to Carburetor) | 1        |

★ Included in Gasket Set - Part No. 493263.




## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                        | No. Used |
|----------|----------|------------------------------------|----------|
| 95       | 94098    | Screw—Throttle Valve Mounting      | 1        |
| 98       | 398185   | Screw—Idle Adjustment              | 1        |
| •104     | 231371   | Pin—Float Hinge                    | 1        |
| 108      | 223471   | Valve—Choke                        | 1        |
| ♦♦116    |          | Gasket—Sealing (Sold in Kit Only). | 1        |
| •117     |          | Jet (Sold in Kit Only).            | 1        |
| 118      | 493765   | Valve and Spring—Needle            | 1        |
| 124      | 94525    | Screw—Carburetor Mtg.              | 1        |
| 125      | 494216   | Carburetor Assembly                | 1        |
| •127     |          | Plug—Welch (Sold in Kit Only).     | 1        |

| Ref. No. | Part No. | Description                      | No. Used |
|----------|----------|----------------------------------|----------|
| 130      | 223470   | Valve—Throttle                   | 1        |
| 131      | 493267   | Shaft and Lever—Throttle         | 1        |
| 133      | 398187   | Float Assy.—Carburetor           | 1        |
| •134     | 398188   | Valve—Inlet (Includes Seat)      | 1        |
| ♦♦137    |          | Gasket—Bowl (Sold in Kit Only).  | 1        |
| 141      | 494218   | Shaft—Choke                      | 1        |
| ♦♦617    | 270344   | Seal—Fuel Intake Tube            | 1        |
| ♦♦634    |          | Washer—Shaft (Sold in Kit Only). | 1        |
| 955      | 493763   | Screw—Fuel Bowl                  | 1        |
| 975      | 493640   | Bowl—Carburetor                  | 1        |

• Included in Carburetor Overhaul Kit—Part No. 493762.


♦ Included in Carburetor Gasket Set—Part No. 490937.



## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description        | No. Used |
|----------|----------|--------------------|----------|
| 23       | 492177   | Flywheel Assembly  | 1        |
| 304      | 493294   | Housing—Blower     | 1        |
| 305      | 94513    | Screw—Hex Head Sem | 1        |
| 332      | 92284    | Nut—Flywheel       | 1        |
| 333      | 802574   | Armature—Magnet    | 1        |


| Ref. No. | Part No. | Description             | No. Used |
|----------|----------|-------------------------|----------|
| 334      | 93381    | Screw—Armature Mounting | 1        |
| 356      | 398808   | Wire—Ground             | 1        |
| 363      | 19069    | Puller—Flywheel         | 1        |
| 455      | 224250   | Cup—Starter             | 1        |
| 851      | 221798   | Terminal—Ignition Cable | 1        |



## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                             | No. Used |
|----------|----------|-----------------------------------------|----------|
| 55       | 492831   | Housing—Rewind Starter                  | 1        |
| 56       | 492832   | Pulley—Rewind Starter                   | 1        |
| 57       | 262594   | Spring—Rewind Starter                   | 1        |
| 58       | 280399   | Rope—Rewind Starter<br>(Cut to 88-5/8") | 1        |
| 60       | 393152   | Handle—Rewind Starter                   | 1        |
| 69       | 280973   | Washer—Rewind Starter                   | 1        |
| 69A      | 224322   | Washer—Rewind Starter                   | 1        |
| 456      | 224321   | Retainer—Rewind Starter                 | 1        |




| Ref. No. | Part No. | Description                                                                 | No. Used |
|----------|----------|-----------------------------------------------------------------------------|----------|
| 459      | 492833   | Pawl—Starter                                                                | 1        |
| 461      | 262626   | Pin—Starter                                                                 | 1        |
| 515      | 262556   | Spring—Pawl                                                                 | 1        |
| 515A     | 262625   | Spring—Torsion                                                              | 1        |
| 608      | 493295   | Starter Assy.—Rewind<br>Includes:<br>94128 Screw—Hex. Hd.<br>92987 Nut—Hex. | 1        |
| 1016     | 224278   | Cover—Rewind Starter                                                        | 1        |



## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                             | No. Used |
|----------|----------|-----------------------------------------|----------|
| 81       | 223664   | Lock - Muffler Screw                    | 1        |
| 187      | 492790   | Hose - Fuel                             | 1        |
| 188      | 398540   | Screw - Tank Mounting (Includes Washer) | 1        |
| 265      | 221535   | Clamp - Casing                          | 1        |
| 267      | 94204    | Screw - Clamp Mtg.                      | 1        |
| 284      | 94511    | Screw - Hex Head                        | 1        |
| 300      | 490547   | Muffler - Exhaust                       | 1        |

| Ref. No. | Part No. | Description          | No. Used |
|----------|----------|----------------------|----------|
| 346      | 94602    | Screw - Hex. Head    | 1        |
| 601      | 93807    | Clamp - Hose         | 1        |
| 613      | 94231    | Screw - Muffler Mtg. | 1        |
| 670      | 280512   | Spacer - Fuel Tank   | 1        |
| 832      | 494224   | Guard - Muffler      | 1        |
| 949      | 281136   | Guard - Finger       | 1        |
| 957      | 397974   | Cap Assembly - Fuel  | 1        |
| 972      | 494528   | Tank Assembly - Fuel | 1        |



## ENGINE BRIGGS & STRATTON MODEL 122702-0182-01

| Ref. No. | Part No. | Description                           | No. Used |
|----------|----------|---------------------------------------|----------|
| ★3       | 393862   | Seal—Oil                              | 1        |
| ★7       | 272200   | Gasket—Cylinder Hd.                   | 1        |
| ★9       | 271904   | Gasket—Valve Cover                    | 1        |
| ★9A      | 272238   | Gasket—Baffle Plate                   | 1        |
| ★12      | 272198   | Gasket—Crankcase                      | 1        |
| ★20      | 399781   | Seal—Oil                              | 1        |
| ★52      | 272199   | Gasket—Intake Elbow                   | 1        |
| ●104     | 231371   | Pin—Float Hinge                       | 1        |
| ●●116    |          | Gasket—Sealing<br>(Sold in Kit Only). | 1        |
| ●117     |          | Jet<br>(Sold in Kit Only).            | 1        |

| Ref. No. | Part No. | Description                         | No. Used |
|----------|----------|-------------------------------------|----------|
| 121      | 493762   | Carburetor Overhaul Kit             | 1        |
| ●127     |          | Plug—Welch<br>(Sold in Kit Only).   | 1        |
| ●134     | 398188   | Valve—Inlet (Includes Seat)         | 1        |
| ●●137    |          | Gasket—Bowl<br>(Sold in Kit Only).  | 1        |
| ★163     | 272296   | Gasket—Air Cleaner                  | 1        |
| 358      | 493263   | Gasket Set                          | 1        |
| ●●617    | 270344   | Seal—Fuel Intake Tube               | 1        |
| ●●634    |          | Washer—Shaft<br>(Sold in Kit Only). | 1        |
| 977      | 490937   | Gasket Set—Carburetor               | 1        |

● Included in Carburetor Overhaul Kit—Part No. 493762.

●● Included in Carburetor Gasket Set—Part No. 490937.

★ Included in Gasket Set—Part No. 493263.

# TORO PART NUMBER INDEX

3316-858

| Part No. | Description               | Pg. Ref.<br>No. No. Qty. | Part No.  | Description              | Pg. Ref.<br>No. No. Qty. |
|----------|---------------------------|--------------------------|-----------|--------------------------|--------------------------|
|          | Engine - B & S Quantum    | 2 1 1                    | 71-8090   | Mount - Handle L.H.      | 5 * 1                    |
| 614578   | Gearcase                  | 4 10 1                   | 71-8100   | Mount - Handle R.H.      | 5 26 1                   |
| 614596   | Gear 34 Tooth             | 4 18 1                   | 71-8110   | Cable - Traction         | 5 19 1                   |
| 614668   | Cover - Gear Case         | 4 2 1                    | 71-8130   | Bracket - Panel          | 5 24 1                   |
| 614696   | Shaft - Intermediate      | 4 4 1                    | 71-8210   | Blade - 48cm             | 2 9 1                    |
| 14-9959  | Wheel, Tire & Gear Assy.  | 3 22 2                   | 71-8310   | Spring - Compression     | 5 20 1                   |
| 16-1669  | Housing - 48cm            | 1 2 1                    | 71-8450   | Cover - Spring           | 3 32 1                   |
| 16-1689  | Panel - Control           | 5 3 1                    | 71-8460   | Decal - Engine           | 2 2 1                    |
| 17-9426  | Screw - Handle            | 5 2 2                    | 71-8580   | Spacer - Door            | 1 20 2                   |
| 19-4050  | Knob - Handle             | 5 25 2                   | 71-8830   | Retainer - Shaft         | 1 24 2                   |
| 26-0672  | Bolt - Blade              | 2 12 1                   | 71-9020   | Handle                   | 5 1 1                    |
| 27-6230  | Bolt - Wheel              | 3 23 2                   | 71-9450   | V-Belt                   | 3 34 1                   |
| 27-6230  | Bolt - Wheel              | 1 30 2                   | 71-9460   | Bag - Grass              | 6 5 1                    |
| 27-6250  | Bushing - Wheel           | 3 24 4                   | 71-9470   | Door - Bag               | 6 3 1                    |
| 27-6250  | Bushing - Wheel           | 1 28 4                   | 71-9480   | Handle - Door            | 6 2 1                    |
| 36-4780  | Washer - Thrust           | 4 17 3                   | 71-9600   | Gear Case Ass'y Complete | 4 * 1                    |
| 36-4791  | Washer                    | 4 5 2                    | 71-9600   | Gearcase Assembly        | 3 35 1                   |
| 38-7820  | Bearing - Ball            | 4 15 1                   | 71-9610   | Pulley - Half            | 4 12 2                   |
| 40-1940  | Washer - Wheel            | 1 27 2                   | 71-9620   | Shaft - Output           | 4 7 1                    |
| 46-1113  | Wheel & Tire Assembly     | 1 29 2                   | 71-9630   | Bracket - Traction       | 3 36 1                   |
| 46-5520  | Lever - Traction          | 5 11 1                   | 71-9800   | Door - Discharge         | 1 15 1                   |
| 46-8800  | Lever - Control           | 5 10 1                   | 71-9810   | Rear Pivot Assembly L.H. | 3 6 1                    |
| 46-9900  | Bar - Control             | 5 7 1                    | 71-9820   | Rear Pivot Assembly R.H. | 3 1 1                    |
| 47-2890  | Bushing - Sleeve          | 3 4 2                    | 71-9840   | Spring - Door            | 1 18 2                   |
| 47-6730  | Seal - Grease             | 3 5 2                    | 71-9850   | Retainer - Belt          | 3 3 1                    |
| 48-2060  | Bearing - Needle          | 3 14 2                   | 71-9860   | Decal - 48cm             | 1 1 1                    |
| 49-2040  | Screw - Tapitite          | 4 1 4                    | 71-9861   | Decal - TORO 4 Cyc.      | 5 4 1                    |
| 55-3760  | Pinion - 15 Tooth         | 4 3 1                    | 71-9865   | Decal - Danger           | 5 5 1                    |
| 60-8750  | Bushing                   | 4 6 2                    | 71-9900   | Frame - Bag              | 6 4 1                    |
| 60-8850  | Bushing - Output          | 4 9 2                    | 74-1660   | Cover - Wheel            | 3 21 2                   |
| 60-8890  | Gear - Bevel Pinion       | 4 16 1                   | 74-1670   | Spacer - Wheel           | 3 25 2                   |
| 62-6660  | Spacer                    | 4 11 1                   | 80-2770   | Cup - Anti-Scalp         | 2 10 1                   |
| 62-7550  | Pulley - Driver           | 2 14 1                   | 82-8550   | Shield - Muffler         | 2 3 1                    |
| 63-8590  | Screw - Thread Forming    | 3 12 2                   | 86-7990   | Screw - Clamp            | 2 15 1                   |
| 65-2720  | Ring - Retaining          | 3 17 4                   | 92-9077   | Decal - Danger           | 1 4 1                    |
| 65-4710  | Washer - Friction         | 3 15 2                   | 2210-249  | Clamp - Cable            | 2 16 1                   |
| 65-4720  | Spring - Compression      | 3 20 2                   | 302-26    | Fitting - Grease         | 3 2 2                    |
| 65-4740  | Washer - Keyed Thrust     | 3 16 4                   | 321-3     | Screw - Cap Hex. Hd.     | 5 13 1                   |
| 65-4750  | Gear - Pinion             | 3 19 2                   | 322-29    | Screw - Cap Hex. Hd.     | 1 17 2                   |
| 65-4760  | Washer - Clutch           | 3 26 2                   | 3253-22   | Washer - Lock            | 2 11 1                   |
| 65-5210  | Screw - Thread Forming    | 1 12 2                   | 3256-24   | Washer                   | 4 13 1                   |
| 66-0235  | Control - Throttle        | 5 6 1                    | 3284-5    | Pin - Roll               | 1 8 1                    |
| 66-0330  | Support - Spacer          | 5 12 2                   | 3290-378  | Tie - Cable              | 2 4 1                    |
| 66-0680  | Decal - French Regulation | 1 19 1                   | 3290-378  | Tie - Cable              | 5 21 2                   |
| 66-6040  | Key - Rocking R.H.        | 3 * 1                    | 3296-5    | Nut                      | 4 14 1                   |
| 66-6050  | Key - Rocking L.H.        | 3 18 1                   | 3296-5    | Nut - Lock               | 3 7 2                    |
| 71-7630  | Cap - Throttle Lower      | 5 17 1                   | 3296-5    | Nut - Lock               | 1 26 2                   |
| 71-7680  | Cover - Throttle Lower    | 5 16 1                   | 3296-29   | Nut - Flange Lock        | 5 8 2                    |
| 71-7740  | Spring - Counterbalance   | 3 31 1                   | 3296-42   | Nut - Lock               | 5 9 1                    |
| 71-7770  | Plate - Rear Securing     | 3 27 2                   | 32104-121 | Screw - Thread Forming   | 5 15 1                   |
| 71-7820  | Pivot - Front             | 1 25 1                   | 32112-11  | Nut - Push               | 1 23 1                   |
| 71-7840  | Rod - Trigger             | 3 8 1                    | 32112-13  | Nut - Push               | 3 13 1                   |
| 71-7860  | Grip - Upper              | 1 13 1                   | 32121-63  | Pin - Groove             | 4 8 2                    |
| 71-7870  | Grip - Lower              | 1 6 1                    | 32144-4   | Screw - Thr'd Forming    | 2 7 2                    |
| 71-7890  | Guide - Belt Rear         | 1 21 1                   | 32144-4   | Screw - Thread Forming   | 1 10 10                  |
| 71-7900  | Cap - Hinge Bolt L.H.     | 1 16 1                   | 32144-4   | Screw - Thread Forming   | 3 28 6                   |
| 71-7910  | Cap - Hinge Bolt R.H.     | 1 11 1                   | 32144-31  | Screw - Thread Forming   | 3 9 1                    |
| 71-7920  | Cover - Belt              | 1 3 1                    | 32144-70  | Screw - Hex. Flange Hd.  | 1 5 1                    |
| 71-7930  | Trigger - H.O.C.          | 1 7 1                    | 32144-73  | Screw - Muffler          | 2 5 3                    |
| 71-7940  | Retainer - Blade          | 2 8 1                    | 32144-97  | Screw - Thread Forming   | 1 14 2                   |
| 71-7960  | Guide - Engine Belt       | 2 13 1                   | 32144-97  | Screw - Thread Forming   | 5 14 5                   |
| 71-7970  | Rod - Link                | 3 30 1                   | 32144-98  | Screw - Thread Forming   | 5 22 4                   |
| 71-7980  | Indicator - H.O.C.        | 3 33 1                   | 32144-99  | Screw - Thread Forming   | 5 18 2                   |
| 71-7990  | Ramp - Discharge          | 1 22 1                   | 32144-102 | Screw - Engine Mount     | 2 6 3                    |
| 71-8040  | Plate - Throttle          | 5 23 1                   | 32144-111 | Screw - Thr'd Form       | 6 1 5                    |
| 71-8060  | Spring - Trigger Return   | 3 10 2                   | 32151-93  | Ring - Grip              | 3 29 1                   |
| 71-8080  | Saddle - H.O.C.           | 3 11 1                   |           |                          |                          |

\*Not Illustrated

## PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

## COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's

service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

## MAINTENANCE RECORD

[illegible]