



## TimeCutter™ Z4200 Riding Mower

Model No. 74360 - 290000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                         | Page     | Description                                  | Page     |
|-------------------------------------|----------|----------------------------------------------|----------|
| Frame Assembly                      | ..... 3  | Engine, Muffler and Clutch Assembly          | ..... 12 |
| Deck Lift and Seat Support Assembly | ..... 4  | Styling and Fuel System Assembly             | ..... 13 |
| Seat Assembly                       | ..... 5  | 42 Inch Deck Assembly                        | ..... 14 |
| Control Assembly                    | ..... 6  | 42 Inch Deck Assembly No. 117-1290           | ..... 15 |
| Hydro Drive Assembly                | ..... 7  | 42 Inch Deck Spindle and Belt Drive Assembly | ..... 16 |
| RH Hydro Assembly No. 110-6771      | ..... 8  | Electrical Assembly                          | ..... 17 |
| LH Hydro Assembly No. 110-6770      | ..... 10 | Attachments and Accessories List             | ..... 18 |


## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HWHTF. .... hex washer head thread forming   |
| ASM. .... assembly                         | HYD. .... hydraulic                          |
| BBC. .... blade brake clutch               | LH. .... left hand                           |
| CARR. .... carriage                        | NI. .... nylon insert                        |
| CCW. .... counter clock wise               | NPTF. .... national pipe thread fine         |
| CW. .... clockwise                         | PFH. .... phillips flat head                 |
| DEG. .... degrees                          | PPH. .... phillips pan head                  |
| ECM. .... electronic control module        | PPHTF. .... phillips pan head thread forming |
| EXT. .... external                         | PRH. .... phillips round head                |
| FH. .... flat head                         | PTH. .... phillips truss head                |
| GA. .... gauge                             | PTO. .... power-take-off                     |
| HD. .... heavy-duty                        | RH. .... right hand                          |
| HF. .... hex flange                        | ROPS. .... roll-over protection system       |
| HH. .... hex head                          | SFH. .... slotted fillister head             |
| HHF. .... hex head flange                  | SHH. .... slotted hex head                   |
| HHFTF. .... hex head flange thread forming | SHWH. .... slotted hex washer head           |
| HJ. .... hex jam                           | SPH. .... slotted pan head                   |
| HLH. .... hex lag head                     | SQH. .... square head                        |
| HOC. .... height-of-cut                    | SRH. .... slotted round head                 |
| HSBH. .... hex socket button head          | STD. .... standard                           |
| HSFH. .... hex socket flat head            | TAP. .... self tapping                       |
| HSH. .... hex socket head                  | TTH. .... torx truss head                    |
| HWH. .... hex washer head                  |                                              |

## Footnotes


- |                                                                                |                           |
|--------------------------------------------------------------------------------|---------------------------|
| ❶ Not illustrated                                                              | ❷ Not serviced separately |
| ❸ Obtain parts from <a href="http://www.kohlerplus.com">www.kohlerplus.com</a> |                           |



## Frame Assembly


| Ref  | Part No.    | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 115-2464-01 | 1    | Frame                    |
| 2    | 110-6899-03 | 1    | Bumper-Rear              |
| 3    | 115-5041-03 | 1    | Seat Pivot/Control ASM   |
| 4    | 108-7882-01 | 1    | Front Axle ASM           |
| 5    | 105-3471    | 2    | Front Wheel And Tire ASM |
| 5:1  | 105-1943    | 1    | Tire                     |
| 5:2  | 302-5       | 1    | Fitting-Grease           |
| 5:3  | 232-27      | 1    | Stem-Valve               |
| 5:5  | 114-1640    | 2    | Bushing-Flange           |
| 5:99 | 93-4244     | 1    | Tube-Inner (W/Valve)     |
| 6    | 104-3667    | 2    | Spanner-Wheel            |
| 7    | 325-22      | 2    | Screw-HH                 |
| 8    | 3296-45     | 2    | Nut-Lock, NI             |
| 9    | 108-7851-01 | 2    | Caster Fork ASM          |
| 10   | 110-6767    | 2    | Washer-Thrust            |
| 11   | 1-303514    | 4    | Bearing-Flanged          |
| 12   | 104-8076    | 2    | Washer                   |
| 13   | 32151-103   | 2    | Ring-Retaining, EXT      |
| 14   | 61-9780     | 2    | Cap-Hub                  |
| 15   | 3234-47     | 7    | Screw-HHF                |
| 16   | 108-7855-03 | 1    | Footrest                 |
| 17   | 3296-29     | 7    | Nut-Lock, NI             |
| 18   | 32104-32    | 2    | Screw-HWH                |
| 19   | 302-5       | 2    | Fitting-Grease           |

| Ref | Part No. | Qty. | Description     |
|-----|----------|------|-----------------|
| 20  | 323-8    | 4    | Screw-HH        |
| 21  | 80-6990  | 2    | Washer-Hardened |
| 22  | 3296-39  | 8    | Nut-Lock, NI    |
| 23  | 323-13   | 4    | Screw-HH        |
| 24  | 99-2385  | 1    | Decal           |
| 25  | 3256-24  | 10   | Washer-Flat     |




Deck Lift and Seat Support Assembly

| Ref | Part No.    | Qty. | Description       |  |  |  |  |
|-----|-------------|------|-------------------|--|--|--|--|
| 1   | 112-4027-03 | 1    | Sector-HOC        |  |  |  |  |
| 2   | 322-10      | 2    | Screw-HH          |  |  |  |  |
| 3   | 322-6       | 3    | Screw-HH          |  |  |  |  |
| 4   | 112-3960-03 | 1    | Lift Arm ASM      |  |  |  |  |
| 5   | 108-7841-03 | 1    | Lift Lever ASM    |  |  |  |  |
| 6   | 110-6800-03 | 1    | Plate-Lift        |  |  |  |  |
| 7   | 110-6805-03 | 1    | Bracket-Seat/Pods |  |  |  |  |
| 8   | 110-1937-03 | 1    | Tray-Battery      |  |  |  |  |
| 9   | 3296-29     | 8    | Nut-Lock, NI      |  |  |  |  |
| 10  | 108-7840    | 1    | Link-Lift         |  |  |  |  |
| 11  | 108-7839    | 1    | Arm-Lift, Rear    |  |  |  |  |
| 12  | 108-7845    | 2    | Block-Pivot       |  |  |  |  |
| 13  | 112-9802    | 1    | Decal-HOC         |  |  |  |  |
| 14  | 105-3450    | 1    | Grip-Lever, Lift  |  |  |  |  |
| 15  | 3272-10     | 1    | Pin-Cotter        |  |  |  |  |
| 16  | 3256-26     | 1    | Washer-Flat       |  |  |  |  |
| 17  | 104-8300    | 3    | Nut-Flange, NI    |  |  |  |  |
| 18  | 3234-47     | 6    | Screw-HHF         |  |  |  |  |
| 19  | 3256-23     | 3    | Washer-Flat       |  |  |  |  |
| 20  | 106-8743    | 1    | Decal             |  |  |  |  |
| 21  | 32104-32    | 1    | Screw-HWH         |  |  |  |  |



## Seat Assembly


| Ref | Part No.    | Qty. | Description        |  |  |  |  |
|-----|-------------|------|--------------------|--|--|--|--|
| 1   | 115-2465-03 | 1    | Base-Seat          |  |  |  |  |
| 2   | 117-1225    | 1    | Seat-15 Inch       |  |  |  |  |
| 3   | 701178      | 2    | Cap-Protector      |  |  |  |  |
| 4   | 3234-47     | 2    | Screw-HHF          |  |  |  |  |
| 6   | 92-7054     | 2    | Spring-Compression |  |  |  |  |
| 7   | 104-8300    | 2    | Nut-Flange, NI     |  |  |  |  |
| 8   | 5-4460      | 1    | Washer-Pivot       |  |  |  |  |
| 9   | 92-9674     | 1    | Knob               |  |  |  |  |
| 10  | 94-7582     | 2    | Bolt-Shoulder      |  |  |  |  |
| 11  | 32128-21    | 2    | Nut-HF             |  |  |  |  |
| 12  | 37-8771     | 4    | Bolt-Shoulder      |  |  |  |  |
| 13  | 115-2469    | 1    | Decal-Danger       |  |  |  |  |
| 14  | 115-2450    | 1    | Decal              |  |  |  |  |
| 15  | 99-4693     | 1    | Decal              |  |  |  |  |
| 16  | 106-8717    | 1    | Decal-Service      |  |  |  |  |
| 17  | 109-2628    | 1    | Cable-Stop, Seat   |  |  |  |  |
| 18  | 60-1730     | 1    | Pin-Clevis         |  |  |  |  |
| 19  | 1-806003    | 1    | Pin-Cotter, Hair   |  |  |  |  |
| 20  | 321-5       | 1    | Screw-HH           |  |  |  |  |
| 21  | 104-7201    | 1    | Nut-HF             |  |  |  |  |



## Control Assembly


| Ref  | Part No.    | Qty. | Description            |
|------|-------------|------|------------------------|
| ❶1   | 110-6814    | 1    | RH Handle ASM          |
| ❶1:1 | 108-6187    | 1    | Grip                   |
| 2    | 110-6815    | 1    | LH Handle ASM          |
| 2:1  | 108-6187    | 1    | Grip                   |
| 3    | 3256-24     | 4    | Washer-Flat            |
| 4    | 323-6       | 4    | Screw-HH               |
| 5    | 112-4004    | 2    | Screw-Shoulder         |
| 6    | 110-6828    | 2    | Activator Arm ASM      |
| 6:2  | 105-3455    | 2    | Bushing                |
| 7    | 110-6810    | 2    | Stud-Damper            |
| 8    | 103-2913    | 2    | Damper-Control, Motion |
| 9    | 3296-42     | 6    | Nut-Lock, NI           |
| 10   | 46-8560     | 2    | Screw-HHF              |
| 11   | 3296-48     | 2    | Nut-Lock, NI           |
| 12   | 3256-22     | 4    | Washer-Flat            |
| 13   | 32128-23    | 2    | Nut-HF                 |
| 14   | 3256-5      | 2    | Washer-Flat            |
| 15   | 110-6693    | 2    | Link-Hydro             |
| 16   | 1-303105    | 2    | Yoke-Adjustable        |
| 17   | 1-808280    | 2    | Pin-Clevis             |
| 18   | 1-806003    | 2    | Pin-Cotter, Hair       |
| 19   | 3220-2      | 2    | Nut-Jam                |
| 20   | 110-6845    | 2    | Gear-Control           |
| 21   | 110-6783-03 | 1    | Arm-Actuator, LH       |

| Ref | Part No.    | Qty. | Description             |
|-----|-------------|------|-------------------------|
| ❶22 | 110-6782-03 | 1    | Arm-Actuator, RH        |
| 23  | 115-5023    | 2    | Tab-Stop                |
| 24  | 110-6873    | 2    | Eccentric               |
| 25  | 110-6874    | 2    | Screw-Eccentric         |
| 26  | 110-6875    | 2    | Bolt-Shoulder           |
| 27  | 110-6858    | 2    | Cable-Brake, Parking    |
| 28  | 110-6751    | 2    | Bracket-Return          |
| 29  | 110-6750    | 2    | Plate-Return            |
| 30  | 110-6752    | 2    | Spring                  |
| 31  | 110-6894    | 8    | Washer-Pivot            |
| 33  | 323-4       | 2    | Screw-HH                |
| 34  | 110-0863    | 2    | Screw-Torx              |
| 35  | 110-6784    | 2    | Bolt-Shoulder           |
| 36  | 112-9750    | 1    | Decal-Control Lever, LH |
| 37  | 112-9751    | 1    | Decal-Control Lever, RH |
| 38  | 37-8771     | 2    | Bolt-Shoulder           |
| 39  | 104-8300    | 2    | Nut-Flange, NI          |
| 40  | 112-9771    | 2    | Washer-Teflon           |



## Hydro Drive Assembly


| Ref   | Part No.    | Qty. | Description        | Ref | Part No. | Qty. | Description         |
|-------|-------------|------|--------------------|-----|----------|------|---------------------|
| 1     | 110-6771    | 1    | Hydro-RH           | 22  | 110-6787 | 2    | Rod-Bypass          |
| 2     | 110-6770    | 1    | Hydro-LH           | 23  | 1-806003 | 2    | Pin-Cotter, Hair    |
| 3     | 322-4       | 2    | Screw-HH           | 24  | 3256-22  | 2    | Washer-Flat         |
| 4     | 322-11      | 2    | Screw-HH           | 25  | 324-8    | 4    | Screw-HH            |
| 5     | 3230-9      | 4    | Screw-CARR         | 26  | 3296-48  | 2    | Nut-Lock, NI        |
| 6     | 104-8300    | 17   | Nut-Flange, NI     | 27  | 112-3979 | 2    | Hub ASM             |
| 7     | 322-6       | 1    | Screw-HH           | 28  | 112-3982 | 2    | Nut-Lock            |
| 8     | 322-7       | 1    | Screw-HH           | 29  | 114-8532 | 1    | Decal-Transport, LH |
| 9     | 110-6677    | 2    | Clip-Spring        | 30  | 114-8531 | 1    | Decal-Transport, RH |
| 10    | 110-6774    | 1    | V-Belt             | 31  | 3234-47  | 8    | Screw-HHF           |
| 11    | 63-1590     | 1    | Spring-Idler       |     |          |      |                     |
| 12    | 110-6775    | 2    | Pulley-Idler       |     |          |      |                     |
| 13    | 5-4460      | 3    | Washer-Pivot       |     |          |      |                     |
| 14    | 110-1925    | 1    | Arm-Idler          |     |          |      |                     |
| 15    | 37-8771     | 1    | Bolt-Shoulder      |     |          |      |                     |
| 16    | 110-6881    | 2    | Wheel And Tire ASM |     |          |      |                     |
| 16:2  | 110-6885    | 1    | Tire               |     |          |      |                     |
| 16:3  | 232-27      | 1    | Stem-Valve         |     |          |      |                     |
| 16:99 | 107-2491    | 1    | Tube-Tire          |     |          |      |                     |
| 17    | 242-50      | 8    | Nut-Lug            |     |          |      |                     |
| 18    | 110-6807    | 1    | Shaft-Cross        |     |          |      |                     |
| 19    | 110-1926    | 1    | Plate-Pivot        |     |          |      |                     |
| 20    | 110-6806-03 | 2    | Strap-Torque       |     |          |      |                     |
| 21    | 110-6878-03 | 2    | Support-Hydro      |     |          |      |                     |



## RH Hydro Assembly No. 110-6771

| Ref | Part No. | Qty. | Description           | Ref | Part No. | Qty. | Description                  |
|-----|----------|------|-----------------------|-----|----------|------|------------------------------|
| 1   | 114-1630 | 1    | RH Main Housing ASM   | 39  | 94-1933  | 2    | Washer                       |
| 2   | 114-1631 | 1    | RH Side ASM           | 40  | 104-5317 | 1    | Gear                         |
| 4   | 110-8561 | 1    | Pump Block ASM        | 41  | 104-5318 | 1    | Gear-Jackshaft, 10T          |
| 6   | 104-2189 | 1    | Plug-Thread, Straight | 42  | 104-5329 | 1    | Pin-Jackshaft                |
| 7   | 103-2666 | 1    | Cylinder Block Kit    | 44  | 112-9855 | 1    | Gear-52T, Bull               |
| 8   | 104-5305 | 16   | Screw-HHF             | 45  | 112-9856 | 1    | Washer                       |
| 13  | 106-8678 | 1    | Rod-Bypass            | 46  | 112-9857 | 1    | Bearing-Sleeve               |
| 17  | 104-5304 | 1    | Swashplate-Trunnion   | 47  | 112-9858 | 1    | Shaft-Axle                   |
| 19  | 104-2116 | 1    | Stud                  | 48  | 112-9859 | 1    | Bushing-Axle                 |
| 20  | 112-9853 | 1    | Puck-Friction         | 50  | 106-8686 | 1    | Seal Kit                     |
| 21  | 106-8747 | 1    | Arm-Control           | 51  | 106-8697 | 1    | RH Expansion Plate Kit       |
| 22  | 5-4460   | 1    | Washer-Pivot          | 52  | 106-8698 | 1    | Fan Pulley Kit               |
| 23  | 107-2488 | 1    | Screw                 | 53  | 114-1633 | 1    | Brake Arm Kit                |
| 24  | 105-1872 | 1    | Nut                   | 54  | 112-9861 | 1    | RH Center Section Filter Kit |
| 25  | 94-1936  | 1    | Spring-Block          | 55  | 104-2147 | 1    | Sealant                      |
| 26  | 94-1937  | 1    | Washer-Thrust, Block  | 56  | 107-2489 | 1    | Bypass Arm Kit               |
| 27  | 104-5306 | 1    | Shaft-Input           | 57  | 114-1634 | 1    | Filter Kit                   |
| 28  | 104-5311 | 1    | Bearing-Ball          | 59  | 106-8694 | 1    | Disc-Brake, Cog              |
| 30  | 104-5308 | 1    | Spacer                | 62  | 110-8566 | 1    | Fan-6 Inch, 10 Blade         |
| 33  | 94-6922  | 2    | Bearing-Thrust        | 63  | 104-1754 | 1    | Pulley                       |
| 34  | 104-5339 | 1    | Washer-Flat           | 64  | 105-1875 | 1    | Nut-Lock                     |
| 36  | 104-5316 | 1    | Gear-Pinnion, 13T     | 65  | 107-9122 | 1    | Washer-Slotted               |
| 37  | 114-1632 | 1    | Shaft-Motor           | 67  | 112-9866 | 1    | Breather Kit                 |
| 38  | 104-5360 | 1    | Washer-Shaft, Motor   | 68  | 114-1635 | 1    | Breather ASM                 |






## RH Hydro Assembly No. 110-6771 (continued)

| Ref | Part No. | Qty. | Description     |
|-----|----------|------|-----------------|
| 69  | 115-5057 | 1    | Cover-Nut, Axle |


|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |



## LH Hydro Assembly No. 110-6770

| Ref | Part No. | Qty. | Description           |
|-----|----------|------|-----------------------|
| 1   | 114-1636 | 1    | LH Main Housing ASM   |
| 2   | 114-1637 | 1    | LH Side ASM           |
| 4   | 110-8561 | 1    | Pump Block ASM        |
| 6   | 104-2189 | 1    | Plug-Thread, Straight |
| 7   | 103-2666 | 1    | Cylinder Block Kit    |
| 8   | 104-5305 | 16   | Screw-HHF             |
| 13  | 106-8678 | 1    | Rod-Bypass            |
| 17  | 104-5304 | 1    | Swashplate-Trunnion   |
| 19  | 104-2116 | 1    | Stud                  |
| 20  | 112-9853 | 1    | Puck-Friction         |
| 21  | 106-8747 | 1    | Arm-Control           |
| 22  | 5-4460   | 1    | Washer-Pivot          |
| 23  | 107-2488 | 1    | Screw                 |
| 24  | 105-1872 | 1    | Nut                   |
| 25  | 94-1936  | 1    | Spring-Block          |
| 26  | 94-1937  | 1    | Washer-Thrust, Block  |
| 27  | 104-5306 | 1    | Shaft-Input           |
| 28  | 104-5311 | 1    | Bearing-Ball          |
| 30  | 104-5308 | 1    | Spacer                |
| 33  | 94-6922  | 2    | Bearing-Thrust        |
| 34  | 104-5339 | 1    | Washer-Flat           |
| 36  | 104-5316 | 1    | Gear-Pinnion, 13T     |
| 37  | 114-1632 | 1    | Shaft-Motor           |
| 38  | 104-5360 | 1    | Washer-Shaft, Motor   |


| Ref | Part No. | Qty. | Description                  |
|-----|----------|------|------------------------------|
| 39  | 94-1933  | 2    | Washer                       |
| 40  | 104-5317 | 1    | Gear                         |
| 41  | 104-5318 | 1    | Gear-Jackshaft, 10T          |
| 42  | 104-5329 | 1    | Pin-Jackshaft                |
| 44  | 112-9855 | 1    | Gear-52T, Bull               |
| 45  | 112-9856 | 1    | Washer                       |
| 46  | 112-9857 | 1    | Bearing-Sleeve               |
| 47  | 112-9858 | 1    | Shaft-Axle                   |
| 48  | 112-9859 | 1    | Bushing-Axle                 |
| 50  | 106-8686 | 1    | Seal Kit                     |
| 51  | 106-8687 | 1    | LH Expansion Plate Kit       |
| 52  | 106-8698 | 1    | Fan Pulley Kit               |
| 53  | 114-1633 | 1    | Brake Arm Kit                |
| 54  | 112-9862 | 1    | LH Center Section Filter Kit |
| 55  | 104-2147 | 1    | Sealant                      |
| 56  | 107-2489 | 1    | Bypass Arm Kit               |
| 57  | 114-1634 | 1    | Filter Kit                   |
| 59  | 106-8694 | 1    | Disc-Brake, Cog              |
| 62  | 110-8566 | 1    | Fan-6 Inch, 10 Blade         |
| 63  | 104-1754 | 1    | Pulley                       |
| 64  | 105-1875 | 1    | Nut-Lock                     |
| 65  | 107-9122 | 1    | Washer-Slotted               |
| 67  | 112-9866 | 1    | Breather Kit                 |
| 68  | 114-1635 | 1    | Breather ASM                 |



## LH Hydro Assembly No. 110-6770 (continued)


| Ref | Part No. | Qty. | Description     |
|-----|----------|------|-----------------|
| 69  | 115-5057 | 1    | Cover-Nut, Axle |

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |




Engine, Muffler and Clutch Assembly

| Ref | Part No.  | Qty. | Description               | Ref | Part No. | Qty. | Description |
|-----|-----------|------|---------------------------|-----|----------|------|-------------|
| 1   |           | 1    | Engine-Kohler, Sv590-0212 | 29  | 46-8560  | 2    | Screw-HHF   |
| 2   | 32128-33  | 1    | Nut-HF                    |     |          |      |             |
| 3   | 3274-10   | 2    | Screw-HSH                 |     |          |      |             |
| 4   | 112-4024  | 1    | Muffler-Kohler            |     |          |      |             |
| 5   | 112-3976  | 1    | Isolator                  |     |          |      |             |
| 6   | 114-1622  | 1    | Pulley-Engine             |     |          |      |             |
| 7   | 112-4033  | 1    | Bumper                    |     |          |      |             |
| 8   | 110-6896  | 1    | Stop-Clutch               |     |          |      |             |
| 9   | 322-4     | 2    | Screw-HH                  |     |          |      |             |
| 10  | 3296-29   | 2    | Nut-Lock, NI              |     |          |      |             |
| 11  | 104-3334  | 1    | Clutch-Electric           |     |          |      |             |
| 12  | 3253-4    | 2    | Washer-Lock               |     |          |      |             |
| 13  | 3212-10   | 1    | Screw-HH                  |     |          |      |             |
| 14  | 32144-109 | 3    | Screw                     |     |          |      |             |
| 15  | 322-11    | 1    | Screw-HH                  |     |          |      |             |
| 16  | 104-8300  | 1    | Nut-Flange, NI            |     |          |      |             |
| 18  | 2412-98   | 2    | Clamp                     |     |          |      |             |
| 19  | 109-0306  | 1    | Hose-Fuel                 |     |          |      |             |
| 20  | 110-6798  | 1    | Support-Hydro, RH         |     |          |      |             |
| 21  | 110-6799  | 1    | Support-Hydro, LH         |     |          |      |             |
| 22  | 3296-42   | 1    | Nut-Lock, NI              |     |          |      |             |
| 23  | 3256-22   | 1    | Washer-Flat               |     |          |      |             |
| 27  | 106-7022  | 1    | Tube-Drain, Oil           |     |          |      |             |
| 28  | 114-8544  | 1    | Shield-Heat               |     |          |      |             |




**Styling and Fuel System Assembly**

| Ref | Part No.    | Qty. | Description          |  |  |  |  |
|-----|-------------|------|----------------------|--|--|--|--|
| 1   | 117-1219    | 1    | Pod-RH               |  |  |  |  |
| 2   | 117-1220    | 1    | Pod-LH               |  |  |  |  |
| 3   | 115-2500    | 1    | Decal-Panel, Control |  |  |  |  |
| 4   | 104-3626    | 1    | Cable-Throttle       |  |  |  |  |
| 5   | 3258-166    | 4    | Screw-PRH            |  |  |  |  |
| 6   | 107069      | 4    | Clip                 |  |  |  |  |
| 7   | 93-7198     | 1    | Gas Cap ASM          |  |  |  |  |
| 8   | 110-1927-03 | 1    | Panel-Control        |  |  |  |  |
| 9   | 110-6890    | 1    | Fuel Tank ASM        |  |  |  |  |
| 9:2 | 46-6560     | 1    | Bushing              |  |  |  |  |
| 9:3 | 95-3970     | 1    | Fitting-90 Degree    |  |  |  |  |
| 10  | 112-4004    | 6    | Screw-Shoulder       |  |  |  |  |
| 11  | 110-6786    | 2    | Cover-Control        |  |  |  |  |
| 12  | 112-9760    | 1    | Washer-Rubber        |  |  |  |  |
| 13  | 55-9310     | 1    | Seal-Foam            |  |  |  |  |
| 17  | 100-9064    | 1    | Tie-Cable            |  |  |  |  |
| 19  | 105-1853    | 1    | Clamp-Hose           |  |  |  |  |




# 42 Inch Deck Assembly

| Ref | Part No. | Qty. | Description                | Ref | Part No. | Qty. | Description |
|-----|----------|------|----------------------------|-----|----------|------|-------------|
| 1   | 117-1290 | 1    | 42 Inch Deck ASM           | 26  | 108-7889 | 2    | Cover-Belt  |
| 2   | 108-7836 | 1    | Bracket-Hanger, Right Rear |     |          |      |             |
| 3   | 108-7838 | 1    | Bracket-Hanger, Left Rear  |     |          |      |             |
| 4   | 3231-2   | 3    | Screw-CARR                 |     |          |      |             |
| 5   | 112-3980 | 1    | Eccentric                  |     |          |      |             |
| 6   | 3231-28  | 1    | Screw-CARR                 |     |          |      |             |
| 7   | 95-2747  | 1    | Fitting-Washout            |     |          |      |             |
| 8   | 46-6290  | 1    | O-Ring, Seal               |     |          |      |             |
| 9   | 46-8560  | 2    | Screw-HHF                  |     |          |      |             |
| 10  | 117-1222 | 1    | Decal-42 Inch              |     |          |      |             |
| 12  | 95-3270  | 1    | Connector-Hose             |     |          |      |             |
| 13  | 1-808284 | 1    | Pin-Clevis                 |     |          |      |             |
| 14  | 108-7847 | 1    | Rod-Lift                   |     |          |      |             |
| 15  | 87-7270  | 1    | Washer-Thrust              |     |          |      |             |
| 16  | 80-6990  | 3    | Washer-Hardened            |     |          |      |             |
| 17  | 3296-23  | 1    | Nut-Lock, NI               |     |          |      |             |
| 18  | 9335054  | 1    | Pin-Hair                   |     |          |      |             |
| 19  | 112-3951 | 1    | Deflector-42 Inch          |     |          |      |             |
| 20  | 110-6694 | 1    | Spring-Torsion             |     |          |      |             |
| 21  | 112-4026 | 1    | Rod-Pivot                  |     |          |      |             |
| 22  | 3296-39  | 7    | Nut-Lock, NI               |     |          |      |             |
| 23  | 1-603299 | 2    | Roller-Scalp, Anti         |     |          |      |             |
| 24  | 112-3977 | 2    | Bolt-Shoulder              |     |          |      |             |
| 25  | 32104-76 | 6    | Screw                      |     |          |      |             |



## 42 Inch Deck Assembly No. 117-1290


| Ref | Part No. | Qty. | Description             |  |  |  |  |
|-----|----------|------|-------------------------|--|--|--|--|
| 2   | 114-1606 | 2    | Decal-Danger, Pulley    |  |  |  |  |
| 3   | 93-7009  | 1    | Decal-Danger, Deflector |  |  |  |  |
| 4   | 110-6691 | 2    | Decal-Danger            |  |  |  |  |
| 5   | 105-7015 | 1    | Decal-Routing, Belt     |  |  |  |  |
| 6   | 3290-282 | 2    | Rivet-Blind             |  |  |  |  |
| 7   | 321-2    | 3    | Screw-HH                |  |  |  |  |
| 8   | 3296-42  | 3    | Nut-Lock, NI            |  |  |  |  |



42 Inch Deck Spindle and Belt Drive Assembly

| Ref  | Part No.    | Qty. | Description                | Ref | Part No. | Qty. | Description         |
|------|-------------|------|----------------------------|-----|----------|------|---------------------|
| 1    | 110-6871    | 1    | V-Belt                     | 23  | 88-5970  | 1    | Hook-Return, Spring |
| 2    | 323-9       | 1    | Screw-HH                   | 24  | 106-2177 | 1    | Spring-Extension    |
| 3    | 3256-24     | 2    | Washer-Flat                | 26  | 323-10   | 1    | Screw-HH            |
| 4    | 106-2175    | 2    | Pulley-Idler, Flat         |     |          |      |                     |
| 5    | 3296-39     | 1    | Nut-Lock, NI               |     |          |      |                     |
| 6    | 114-8540    | 1    | Arm-Idler                  |     |          |      |                     |
| 7    | 110-9981    | 2    | Washer-Plain               |     |          |      |                     |
| 8    | 114-0463    | 2    | Washer-Friction, Composite |     |          |      |                     |
| 9    | 115-4986    | 1    | Spacer                     |     |          |      |                     |
| 10   | 323-8       | 1    | Screw-HH                   |     |          |      |                     |
| 11   | 3219-6      | 2    | Nut-Hex                    |     |          |      |                     |
| 12   | 110-6864    | 2    | Pulley                     |     |          |      |                     |
| 13   | 32144-41    | 8    | Screw-Taptite              |     |          |      |                     |
| 14   | 26-0671     | 2    | Screw-HH                   |     |          |      |                     |
| 15   | 3290-465    | 2    | Washer-Belleville          |     |          |      |                     |
| 16   | 106-2248-03 | 2    | Stiffener-Blade            |     |          |      |                     |
| 17   | 110-6568-03 | 2    | Blade-21.6 Inch            |     |          |      |                     |
| 19   | 80-4360     | 2    | Shield-Bearing             |     |          |      |                     |
| 20   | 80-4380     | 2    | Spacer                     |     |          |      |                     |
| 21   | 110-6866    | 2    | Shaft-Spindle              |     |          |      |                     |
| 22   |             | 2    | Spindle ASM                |     |          |      |                     |
| 22:1 | 88-4510     | 1    | Housing-Spindle            |     |          |      |                     |
| 22:2 | 100-1048    | 2    | Bearing-Ball               |     |          |      |                     |
| 22:3 | 62-3661     | 1    | Spacer                     |     |          |      |                     |





Electrical Assembly

| Ref  | Part No. | Qty. | Description           |  |  |  |  |
|------|----------|------|-----------------------|--|--|--|--|
| 1    | 104-2493 | 1    | Battery               |  |  |  |  |
| 2    | 110-6764 | 1    | Switch-Ignition       |  |  |  |  |
| 3    | 63-8360  | 1    | Key-Ignition          |  |  |  |  |
| 4    | 93-9998  | 1    | Switch-PTO            |  |  |  |  |
| 5    | 32103-22 | 1    | Nut-Wing              |  |  |  |  |
| 6    | 110-6765 | 2    | Switch-Single Pole No |  |  |  |  |
| 7    | 82-2190  | 1    | Switch-Bail           |  |  |  |  |
| 8    | 117-1197 | 1    | Solenoid              |  |  |  |  |
| 9    | 110-6794 | 1    | Cable-Battery, Red    |  |  |  |  |
| 10   | 3229-1   | 1    | Screw-CARR            |  |  |  |  |
| 11   | 110-6793 | 1    | Cable-Battery, Black  |  |  |  |  |
| 12   | 104-2466 | 1    | Holddown-Battery      |  |  |  |  |
| 13   | 321-3    | 1    | Screw-HH              |  |  |  |  |
| 14   | 117-1276 | 1    | Harness-Wiring        |  |  |  |  |
| 14:1 | 109103   | 1    | Fuse-30 Amp           |  |  |  |  |
| 14:2 | 109102   | 1    | Fuse-25 Amp           |  |  |  |  |
| 14:3 | 100-4918 | 1    | Diode                 |  |  |  |  |
| 15   | 3256-22  | 2    | Washer-Flat           |  |  |  |  |
| 16   | 32144-1  | 3    | Screw-Taptite         |  |  |  |  |
| 17   | 110-6792 | 1    | Cable-Battery, Red    |  |  |  |  |
| 18   | 32128-33 | 2    | Nut-HF                |  |  |  |  |
| 19   | 98-7249  | 1    | Relay                 |  |  |  |  |
| 20   | 46-8560  | 2    | Screw-HHF             |  |  |  |  |
| 21   | 3220-2   | 2    | Nut-Jam               |  |  |  |  |

# Attachments and Accessories

## For 74360 - TimeCutter Z4200 Riding Mower

| Product Name                      | Model/Part |
|-----------------------------------|------------|
| Armrest Kit                       | 108-6163   |
| Smooth Tread Front Tire Kit       | 110-6739   |
| Hour Meter Kit                    | 112-9763   |
| 42 Inch Blowout Ring Kit          | 114-1620   |
| Striping Kit                      | 114-8545   |
| Armrest Kit                       | 79212      |
| 42 Inch Replacement Blade Kit     | 79220      |
| 42 Inch Recycler Kit              | 79311      |
| Foot Assist Cutting Unit Lift Kit | 79313      |
| Engine Cover Kit                  | 79314      |
| Floor Mat Kit                     | 79315      |
| Rear Engine Guard                 | 79316      |
| Storage Cover                     | 79317      |
| Rear Hitch Kit                    | 79318      |
| Sunshade                          | 79319      |
| 42 Inch and 50 Inch Twin Bagger   | 79324      |
| 10 cu. ft. Poly Dump Cart         | 79991      |
| 125 lb. Tow Spreader              | 79993      |
| 42 Inch Sweeper                   | 79994      |
| 48 Inch Dethatcher                | 79995      |
| 40 Inch Spike Aerator             | 79996      |
| Stake Side Kit                    | 79997      |

## NOTES

