


TORO®

MODEL NO. 30180-490731 & UP

PARTS CATALOG

PROLINE 180 MIDSIZE Traction Unit




C-0508

FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	55-3570	Cap - Fuel Tank	1
2	2412-98	Clamp - Fuel line	1
3	47-2982	Hose - Fuel	1
4	32103-25	Nut - Wing	2
5	3256-23	Washer - Flat	9
6	52-2890	Bushing	2
7	68-9690	Fitting - Rod	2
8	3290-307	Pin - Cotter	4
9	74-0220	Idler - Bracket L.H.	1
*	74-0230	Idler - Bracket R.H.	1
10	283-6	Pin - Clevis	2
11	74-0521	Fitting - Rod	2
12	67-6380	Bracket - Support L.H.	1
*	67-6370	Bracket - Support R.H.	1
13	323-16	Screw - Hex. Hd. Cap	2
14	323-6	Screw - Hex. Hd. Cap	5
15	323-7	Screw - Hex Head	1
16	3296-23	Nut - Lock	2
17	51-4480	Idler - Wheel	2

Ref. No.	Part No.	Description	No. Used
18	51-4490	Spacer - Idler Wheel	2
19	51-4380	Spring - Torsion L.H.	1
*	51-4370	Spring - Torsion R.H.	1
20	3296-39	Nut - Lock	8
21	51-4450	Screw - Leveler	2
22	74-0040	Spacer - Pivot Idler	4
23	82-4790	Anchor - Spring	1
24	237-124	Grommet	1
25	68-2190	Spring - Extension	1
26	27-6230	Bolt - Wheel	1
27	256-155	Bushing	2
28	16-7509	Level - Idler	1
29	62-4540	Pulley - Idler	1
30	323-9	Screw - Hex. Hd. Cap	1
31	74-0280	Frame	1
32	322-4	Screw - Hex. Hd. Cap	4
33	32149-2	Nut - Lock	2
34	47-1910	Solenoid - Starter	1

*Not Illustrated




C-050808

FRAME ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
35	12-3270	Screw - Hex. Hd. Cap	2
36	3296-6	Nut - Lock	1
37	3253-4	Washer - Lock	4
38	66-7400	Plate - Control	1
39	82-7750	Decal - Ground Speed	1
40	74-0490	Decal - Fuel Shut Off	1

Ref. No.	Part No.	Description	No. Used
41	74-0360	Frame - Rear	1
42	74-0510	Valve - Fuel	1
43	237-7	"O" Ring	1
44	82-8440	Tank - Fuel	1
45	28-3891	Wire Assembly	1
*	71-3040	Replacement Axle Kit	1

*Not Illustrated




C-0509

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	2412-98	Clamp - Fuel Line	2
2		Fuel-Filter	1
3	47-2982	Hose-Gas	1
4	32149-2	Nut - Lock	1
5	32149-1	Nut - Lock	1
6	32152-1	Nut - Lock	4
7	3255-8	Washer - External Tooth	1
8	68-3240	Gasket - Muffler	2
9	2811-10	Elbow - 90° Street	1
10	289-48	Pipe Nipple	1
11	288-4	Pipe Cap	1
12	3256-23	Washer - Plain	6
13	3253-4	Washer - Lock	5
14	322-9	Screw - Hex. Hd. Cap	4
15	3212-24	Screw - Hex. Hd. Cap	1
16	3253-22	Washer - Lock	1

Ref. No.	Part No.	Description	No. Used
17	44-8160	Washer - Clutch	1
18	54-3200	Clutch Brake Assembly	1
19	54-2750	V-Belt - Deck Drive (36" & 44" Cutting Units)	1
*	55-7660	V-Belt - Deck Drive (52" Cutting Unit)	1
20	74-0050	Sheave - Lower Half	1
21	608006	Key	1
22	74-0060	Sheave - Upper Half	1
23	51-4540	Retainer - Clutch	1
24	3274-10	Screw - Socket Hd. Cap	4
25	68-2050	Muffler	1
26	2412-73	R-Clamp	1
27		Engine (Incl. Ref. #2 & 3)	1
28	63-8440	Decal - Hot	1


*Not Illustrated



T-0080

CLUTCH ASSEMBLY NO. 54-3200

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	54-0230	Field Ass'y (Incl. Ref. #2 & 3)	1	6	44-8330	Spacer	1
2	251-292	Bearing - Field	1	7	44-8340	Collar - Bearing	1
3	44-8310	Ring - Retaining	2	8	251-291	Bearing - Pulley	1
4	44-8360	Field Coil, Rotor & Bearing Assembly (Incl. Ref. #1)	1	9	3296-5	Nut - Lock	3
5	55-7410	Armature & Pulley Assemble (Incl. Ref. #3,6,7, & 8)	1	10	44-8320	Spring	3




C-0502

AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	322-2	Screw - Hex. Hd. Cap	4
2	3253-4	Washer - Lock	12
3	74-0610	Transmission	1
4	72-2190	Mount - Shift Lever	1
5	7-5461	Spacer	1
7	329-10	Screw - Hex. Hd. Cap	1
8	47-1970	Grip - Engagement	1
9	74-0320	Lever - Shift	1
10	3296-42	Nut - Lock	4
11	32120-64	Ring - Retaining	3
12	51-4270	Bearing - Shaft Extension	2
13	321-4	Screw - Hex. Hd. Cap	4
14	51-4240	Shaft - Extension R.H.	1
*	51-4250	Shaft - Extension L.H.	1
15	3257-5	Key - Woodruff	3
16	3245-3	Screw - Socket Hd. Set	2
17	74-0480	Pulley - Drive	2
18	51-4290	Belt - Drive	2
19	51-4580	Rod - Brake	2
20	51-4610	Brake Arm L.H.	1
*	51-4600	Brake Arm R.H.	1
21	32151-40	Ring - Retaining	2
22	51-4650	Link - Brake	2

Ref. No.	Part No.	Description	No. Used
23	231-111	Tire	2
24	242-80	Rim	2
25	232-27	Valve Stem	2
26	32151-91	Ring - Retaining	2
27	92-1746	Bearing	4
28	302-11	Fitting - Grease	2
29	10-8110	Washer - Flat	A/R
30	51-4160	Pulley - Wheel	4
31	51-4170	Spacer - Pulley	8
32	51-4180	Drum - Brake	2
33	51-4700	Brake Band Assembly	2
34	322-7	Screw - Hex. Hd. Cap	8
35	51-4660	Plate - Link Brake	2
36	32151-72	Ring - Retaining	4
37	51-4230	Washer - Wheel	2
38	3241-5	Screw - Socket Hd. Cap	1
39	26-9671	Belt - Traction	1
40	51-4190	Pulley - Driven	1
41	32151-56	Ring - Retaining	2
42	3290-307	Pin - Cotter	2
43	51-4220	Guard - Coupler	2
44	302-5	Fitting - Grease	2
45	51-4260	Coupler	1

*Not Illustrated




T-0875

BATTERY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	323-9	Screw - Hex. Hd.	2
3	51-4210	Pad - Battery Mount	2
4	92-2350	Holder - Battery	2
5	82-4640	Battery	1
6	68-3810	Tube - Vent	1
7	54-3090	Cable - Battery	1
8	32149-1	Nut	2
9	77-0980	Boot - Terminal	1

Ref. No.	Part No.	Description	No. Used
10	77-0981	Boot - Terminal	1
11	3296-42	Nut - Lock	2
12	82-4620	Strap - Battery	1
13	28-3893	Cable - Battery	1
14	322-3	Screw - Cap Hex. Hd.	2
15	3296-39	Nut - Lock	2
16	12-5950	Rod - Battery Support	2
17	84-1830	Cap - Battery	1




C-0510

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	67-6440	Handle - Upper	1
2	74-0720	Tube - Manual	1
3	82-2180	Panel - Control	1
4	82-7740	Decal - Proline	1
5	82-7631	Rod - Control	2
6	51-4850	Lever - Parking Brake	1
7	52-2010	Decal - Parking Brake	1
8	237-141	Grommet - Rubber	2
10	3296-2	Nut - Lock	5
11	82-7680	Bail Assembly	1
12	82-2290	Decal - Control Bar	1
13	3290-307	Pin - Cotter	2
14	32105-1	Screw - Hex. Hd. Machine	1
15	82-7690	Bar - Control	1
16	63-8360	Key	2
17	82-3820	Boot	1
18	218-461	Nut	1
19	74-0640	Control - Throttle	1
20	82-2300	Switch - Clutch (Incl. Ref. #17)	1
21	74-0470	Rod - Pivot	1
22	32151-80	Ring - Push On	2
23	32105-14	Screw - Hex. Hd. Machine	4

Ref. No.	Part No.	Description	No. Used
24	74-0380	Control - Pivot	1
25	3254-5	Washer - Lock	1
26	82-2280	Decal - Reverse Handle	1
27	23-0660	Switch - Ignition (Incl. Ref. #16, 18, & 25)	1
28	57-5811	Panel - Bottom	1
29	3290-378	Cable Tie	3
30	3234-11	Screw - Hex. Hd. Cap	4
31	32128-21	Nut - Lock	4
32	82-4840	Wire Harness (Ref.)	1
33	2412-120	"R" Clamp	2
34	32144-19	Screw - Self Tapping	4
35	74-0730	Control - Choke	1
36	54-2970	Spacer	1
37	82-2190	Switch - Bail	1
38	71-1280	Decal - Danger	1
39	65-3090	Decal - Instruction	1
40	218-595	Connector - Body	1
41	86-7910	Module - Interlock	1
42	321-2	Screw - Hex Hd. Cap	2
43	3296-42	Nut - Hex	2
44	63-7590	Relay	1
45	3255-7	Washer - External Tooth	1




C-0749

ELECTRIC SCHEMATIC

Ref. No.	Part No.	Description	No. Used
1	82-4840	Wire Harness	1
2	63-7590	Relay	1

Ref. No.	Part No.	Description	No. Used
3	86-7910	Module - Interlock	1

*Not Illustrated




C-1776

PEERLESS TRANSMISSION MODEL NO. 700-039

Ref. No.	Part No.	Description	No. Used
1	792035	Ring - Retaining	1
2	780072	Washer - Thrust	5
3	776135	Shaft - Input	1
4	792001	"O"Ring	2
5	780142	Bearing - Needle	1
6	780086	Bearing - Needle	1
7	770090A	Case - Transmission	1
8	778153	Bevel Pinion - Input	1
9	788040	Ring - Retaining	1
10	772099A	Cover - Transmission	1
11	792073	Screw - Self Tapping	6
12	788069	Seal - Square Cut	1
13	792074	Plug - Threaded	1
14	792078	Screw - Set	1
15	792079	Spring	1
16	792077	Ball - Steel	1
17	780092	Bearing - Ball	2
18	780065	Washer - Thrust	2
19	780139	Washer - Thrust	1
20	786072	Spacer	1
21	778123A	Gear - Spur (25 Teeth)	1

Ref. No.	Part No.	Description	No. Used
22	780108	Washer - Thrust	4
23	778250	Gear - Spur (27 Teeth)	1
24	778124A	Gear - Spur (30 Teeth)	1
25	778125	Gear - Spur (35 Teeth)	1
26	792089A	Key	4
27	776289A	Shaft - Output & Brake	1
28	784266	Collar - Shift	1
29	786083	Sprocket (18 Teeth)	1
30	786081	Chain - Roller (No. 41 Chain 24 Links)	1
31	780105A	Bushing - Flanged	2
32	786082	Sprocket (9 Teeth)	1
33	784267	Rod & Fork Ass'y - Shift	1
34	776134	Shaft - Counter	1
35	778154	Gear - Bevel (42Teeth)	1
36	778136	Gear - Spur (15 Teeth)	1
37	778126A	Gear - Spur (20 Teeth)	1
38	778249	Gear - Spur (23 Teeth)	1
39	778127A	Gear - Spur (25 Teeth)	1
40	786071	Spacer	1




ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
AIR INTAKE -GROUP 1			
1	X-276-7	Nut - Wing	1
2	45 082 01	Cover - Air Cleaner	1
3	231032	Seal - Element Cover	1
4	52 082 04	Cover - Air Cleaner Element	1
5	45 083 01	Precleaner	1
6	45 083 02	Element	1
7	X-67-98	Screw - Hex. Washer Hd.	4
8	52 094 06	Base - Air Cleaner	1
9	277093	Gasket - Air Cleaner	1
10	52 754 02	Elbow - Kit (Incl. Ref. #11 & 12)	1
11	52 086 11	Screw - Self Tapping	1
12	25 041 06	Gasket - Elbow	1
13	X-22-79	Washer - Flat	1
14	X-50-37	Screw - Pan Hd.	1
15	X-50-57	Screw - Pan Hd.	2
16	X-22-9	Washer	2
*	25 113 07	Decal - Air Cleaner	1


Ref. No.	Part No.	Description	No. Used
BAFFLE & SHROUD GROUP 2			
1	52 063 21	Baffle - Cylinder Head	1
2	47 154 01	Clamp	2
3	52 063 01	Baffle - Cylinder Head	1
4	X-67-83	Screw Hex. Washer Hd.	20
5	82 755 01	Kit - Blower Housing (Incl. Ref. #6-8)	1
6	52 217 01	Support - Upper Housing	1
7	52 468 16	Washer	2
8	52 086 11	Screw - Hex. Washer Hd.	2
9	52 124 23	Baffle - Cylinder Head	1
10	52 112 12	Spacer	5
11	47 314 01	Guard - Grass Screen	1
12	25 468 03	Washer	5
13	X-101-12	Nut - Lock	5
*	45 113 07	Decal - Horsepower	3

*Not Illustrated

Group 3 BREATHER & VENT




Group 4 CAMSHAFT & VALVES



ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
BREATHER & VENT GROUP 3			
1	X-81-1	Nut - Hex	2
2	X-25-12	Washer - Plain	2
3	52 096 18	Cover - Cylinder Valve	1
4	52 055 01	Gasket - Cover	3
5	X-325-39	Stud - Valve Cover	1
6	52 326 12	Hose - Breather	1
7	52 096 08	Cover - Upper Cylinder Valve	1
8	52 032 04	Seal - Breather	1
9	52 462 01	Valve - Umbrella	1
10	52 096 22	Cover - Lower Cylinder Valve	1
11	275220	Stud - Cylinder Valve Cover	1

Ref. No.	Part No.	Description	No. Used
CAMSHAFT & VALVES GROUP 4			
1	52 012 09	Camshaft	1
2	52 019 03	Tappet	4
3	41 755 10	Kit - Retainer	4
4	52 413 01	Rotator - Exhaust Valve	2
5	25 089 01	Spring - Valve	4
6	52 016 05	Valve - Exhaust	2
7	52 017 08	Valve - Intake	2
8	52 032 13	Seal - Intake Valve Stem	2
9	230011	Retainer - Intake Valve	2


**Group 5
CARBURETOR**

ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
		CARBURETOR GROUP 5	
1	52 041 09	Gasket - Intake Manifold	2
2	52 164 14	Manifold, Intake	1
3	X-21-1	Washer	4
4	X-6-29	Screw	4
5	235778	Clamp - Cable	2
6	255 155 02	Connector - Hose	1
7	X-77-2	Nut - Hex Jam	2
8	52 853 09	Carburetor Kit w/Linkage	1
9	25 041 06	Gasket - Air Cleaner	1
10	52 053 34	Carburetor Assembly For Information Only	1
11	271030	Gasket - Carburetor	1
12	232867	Strap - Lifting	1
13	X-67-62	Screw - Hex Washer Hd.	1
14	25 086 27	Screw - Throttle & Choke Plate	4
15	25 146 02	Plate - Throttle	1
16	52 144 16	Shaft - Throttle w/Lever & Seal	1

Ref. No.	Part No.	Description	No. Used
17	25 368 01	Needle - Idle Fuel Adj.	1
18	25 089 02	Spring - Idle Fuel	1
19	25 086 26	Screw - Idle Speed Adj.	1
20	25 089 04	Spring - Idle Speed	1
21	52 090 13	Lever - Choke	1
22	25 089 03	Spring - Choke Friction	1
23	25 194 01	Ball - Choke Friction	1
24	25 146 03	Plate - Choke	1
25	52 337 06	Jet - Main	1
26	25 041 04	Gasket - Bowl	1
27	25 757 09	Kit - Float	1
28	25 104 01	Bowl - Fuel	1
29	25 041 03	Gasket - Retainer Screw	1
30	25 100 05	Screw - Bowl Retainer	1
31	52 853 25	Carburetor Kit w/Linkage	1
32	52 053 54	Carburetor Assembly For Information Only	1
33	25 089 02	Screw - Bowl	1
34	25 368 03	Needle - Main Fuel	1
*	25 757 11	Kit - Carburetor Repair	1
*	52 755 98	Kit - High Altitude	1

*Not Illustrated





**Group 7
CRANKCASE**



ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
		CRANKCASE GROUP 7					
1	X-82-2	Nut	12	12	52 030 10	Bearing - Sleeve (Std.)	2
2	52 468 12	Washer - Flat	12	*	52 030 11	Bearing - Sleeve (.010)	2
3	82 755 17	Kit - #2 Cylinder Barrel (Incl. Ref. #4-6)	1	*	52 030 12	Bearing - Sleeve (.020)	2
4	52 016 05	Valve - Exhaust	1	13	25 086 10	Screw - Hex. Flange	3
5	52 031 01	Inset - Valve Seat	2	14	25 086 13	Screw - Hex. Flange	2
6	52 316 06	Guide - Valve	2	15	52 141 02	O-Ring	1
7	52 755 50	Kit - Oil Relief	1	16	52 139 08	Plug	1
8	52 072 12	Stud - Step	12	17	25 086 11	Screw - Hex Flange	8
9	25 086 12	Screw - Hex. Flange	2	18	52 032 10	Seal - Oil Front	1
10	X-269-43	Ring - Retaining	1	19	82 755 16	Kit - #2 Cylinder Barrel (Incl. Ref. #4-6) Crankcase Service with Short Block 82 522 30	1
11	52 078 05	Shaft - Governor	1				

*Not Illustrated

**Group 11
ELECTRIC START**
**Group 8
CRANKSHAFT**

**Group 9
CYLINDER HEAD**

**Group 10
DIPSTICK**

**Group 12
EXHAUST**


ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
CRANKCASE GROUP 8			
1	52 014 93	Crankshaft	1
2	52 468 03	Washer - .119 / .122	A/R
*	52 468 04	Washer - .128 / .131	1
*	52 468 05	Washer - .137 / .140	A/R
CYLINDER HEAD GROUP 9			
1	52 041 02	Gasket - Head	2
2	52 015 10	Head - Cylinder	2
3	220534	Washer - Flat	18
4	41 086 02	Screw - Hex. Hd.	18
DIPSTICK GROUP 10			
1	52 038 14	Dipstick (Incl. Ref. #2-3)	1
2	X-25-44	Washer - Flat	1
3	52 032 14	Seal - Rubber	1
4	41 153 01	"O"Ring	1
5	52 126 11	Bracket - Oil Tube Support	1


Ref. No.	Part No.	Description	No. Used
6	52 123 20	Tube - Oil Fill	1
7	47 139 01	Plug - Countersunk Hex.	1
ELECTRIC START GROUP 11			
1	52 098 09	Starter Assembly (Incl. Ref. #4-10)	1
2	X-20-1	Washer - Lock	2
3	X-81-1	Nut - Hex.	2
4	52 755 05	Kit - Drive (Incl. Ref. #5)	1
5	52 755 08	Kit - Drive Parts	1
6	52 227 01	Cap - Drive End	1
7	52 170 02	Armature	1
8	52 227 09	Cap - Commutator End (Incl. Ref. #9)	1
9	48 755 15	Kit - Brush	1
10	52 211 01	Bolt	2
*	52 357 01	Lubricant - Starter	1
EXHAUST GROUP 12			
1	52 041 14	Gasket - Exhaust	2

*Not Illustrated

Group 13 FLYWHEEL



Group 14 FUEL PUMP




ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
FLYWHEEL GROUP 13			
1	25 162 01	Screen – Grass	1
2	25 086 21	Screw – Hex. Washer Hd.	4
3	25 112 04	Spacer	4
4	25 157 01	Fan	1
5	25 086 24	Screw – Hex. Hd. Machine	1
6	52 468 15	Washer – Flat	1
7	X-286-17	Key – Square	1
8	52 025 36	Flywheel	1

Ref. No.	Part No.	Description	No. Used
FUEL PUMP GROUP 14			
1	47 086 08	Screw – Posidriv T.H.	2
2	52 559 01	Pump – Fuel (Incl. Ref. #3-6)	1
3	X-380-1	Connector – Hose	1
4	X-25-63	Washer – Flat	2
5	25 041 09	Gasket – Fuel Pump	1
6	25 155 02	Connector – Hose	1
7	X-426-9	Clamp – Hose	4
8	52 353 18	Line – Fuel	1
9	25 050 03	Filter – Fuel	1
10	25 353 03	Line – Fuel	1





Group 17 GOVERNOR



ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
		GOVERNOR GROUP 17	
1	231355	Pin - Governor Stop	1
2	X-25-12	Washer - Flat	1
	237022	Washer - Governor Gear Thrust	1
4	A-235743-S	Kit - Governor Gear	1
5	52 078 04	Shaft - Governor Cross	1
6	X-25-102	Washer - Flat	2
7	X-269-28	Retainer - Governor	1
8	X-25-63	Washer - Flat	1
9	52 090 25	Lever - Speed Control	1
10	277341	Washer - Tension	1
11	52 158 07	Bushing - Throttle Control	1
12	25 086 15	Screw - Hex. Washer Hd.	1
13	52 089 07	Spring - Governor	1

Ref. No.	Part No.	Description	No. Used
14	x-81-1	Nut	1
15	X-25-72	Washer - Flat	2
16	52 186 09	Arm - Governor	1
17	52 211 04	Screw - R.H. Sq. Neck	1
18	25 141 03	Ring	4
19	25 158 08	Bushing - Linkage	4
20	52 079 07	Linkage - Governor	1
21	52 079 06	Linkage - Throttle	1
22	52 090 14	Lever - Throttle	1
23	52 089 08	Spring - Torsion	1
24	25 086 21	Screw - Hex. Washer Hd.	1
25	X-67-38	Screw - Hex. Washer Hd.	3
26	12 237 01	Clamp	3
27	25 431 01	Spacer	1
28	X-70-3	Nut	1
29	52 086 05	Screw - Hex. Hd.	1



**Group 18
IGNITION**

**Group 22
PISTON & ROD**

**Group 21
OIL PAN**


ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
		IGNITION GROUP 18	
1	25 755 03	Kit - Rectifier / Regulator (Incl. Ref.#2)	1
2	X-132-5	Screw - H.C.	2
3	236602	Connector	1
4	237878	Kit - Stator (Incl. Ref. #5)	1
5	X-67-51	Screw - H.C.	4
6	235173	Clip	1
7	236473	Connector	1
8	X-67-83	Screw - Hex. Washer Hd.	1
9	48 154 02	Clip	1
10	52 313 02	Grommet	1
11	52 132 02	Spark Plug	2
12	52 126 08	Bracket - Module	1
13	25 086 15	Screw - Hex. Washer Hd.	2
14	52 584 02	Module - Ignition	1
15	25 086 16	Screw - Hex. Washer Hd.	2
*	47 518 33	Lead - Violet	1
*	52 518 19	Lead - White	1

Ref. No.	Part No.	Description	No. Used
		OIL PAN GROUP 21	
1	X-67-64	Screw - Hex. Washer Hd.	2
2	52 050 03	Filter - Oil Pickup	1
3	52 199 03	Pan - Oil	1
4	X-75-10	Plug - Sq. Hd.	2
5	52 086 12	Screw - Hex. Washer Hd.	9
6	52 032 10	Seal - Rear Oil	1
7	X-75-38	Plug - Countersunk Hex.	1
8	X-75.23	Plug - Countersunk Hex	1
		PISTON & ROD GROUP 22	
1	52 067 67	Rod - Connecting (Std.)	2
*	52 067 68	Rod - Connecting (.010)	2
2	52 874 11	Piston - w/Ring Set (Std.)	2
*	52 874 12	Piston - w/Ring Set (.003)	2
*	52 874 13	Piston - w/Ring Set (.010)	2
*	52 874 14	Piston - w/Ring Set (.020)	2
*	52 874 15	Piston - w/Ring Set (.030)	2
3	230004	Retainer - Piston Pin	4
4	52 108 09	Ring - Set (Std. & .003)	2
*	52 108 10	Ring - Set (.010)	2
*	52 108 11	Ring - Set (.020)	2
*	52 108 12	Ring - Set (.030)	2

*Not Illustrated

**Group 25
OIL PUMP**

**Group 29
OIL FILTER**

**Group 32
LOW OIL PRESSURE CUTOUT**

ENGINE KOHLER MODEL NO. MV16S-TYPE PS56519

Ref. No.	Part No.	Description	No. Used
		OIL PUMP GROUP 25	
1	X-280-25	Pin - Roll	1
2	52 144 05	Shaft - Oil Pump	1
3	52 422 01	Spacer - Shim	2
4	52 043 05	Gear - Oil Pump	1
5	52 393 09	Rotor Set	1
6	52 096 03	Cover - Oil Pump	1
7	X-67-64	Screw - Hex. Washer Hd.	4

Ref. No.	Part No.	Description	No. Used
		OIL FILTER GROUP 29	
1	52 041 16	Gasket - Oil Filter	1
2	52 181 03	Adapter - Oil Filter	1
3	X-55-15	Screw - Hex. Socket Hd.	2
4	52 050 02	Oil Filter	1
		OIL PRESSURE SWITCH GROUP 32	
1	X-75-23	Plug - Pipe	1
*	52 522 30	Short Block	1
*	52 755 94	Gasket Set	1

*Not Illustrated

TORO PART NUMBER INDEX

3316-872

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
608006	Key	3 21 1	66-7400	Plate - Control	2 38 1
7-5461	Spacer	5 5 1	67-6370	Bracket - Support R.H.	1 * 1
10-8110	Washer - Flat	5 29A/R	67-6380	Bracket - Support L.H.	1 12 1
12-3270	Screw - Hex. Hd. Cap	2 35 2	67-6440	Handle - Upper	7 1 1
12-5950	Rod - Battery Support	6 16 2	68-2050	Muffler	3 25 1
16-7509	Level - Idler	1 28 1	68-2190	Spring - Extension	1 25 1
23-0660	Switch - Ignition	7 27 1	68-3240	Gasket - Muffler	3 8 2
26-9671	Belt - Traction	5 39 1	68-3810	Tube - Vent	6 6 1
27-6230	Bolt - Wheel	1 26 1	68-9690	Fitting - Rod	1 7 2
28-3891	Wire Assembly	2 45 1	71-1280	Decal - Danger	7 38 1
28-3893	Cable - Battery	6 13 1	71-3040	Replacement Axle Kit	2 * 1
44-8160	Washer - Clutch	3 17 1	72-2190	Mount - Shift Lever	5 4 1
44-8310	Ring - Retaining	4 3 2	74-0040	Spacer - Pivot Idler	1 22 4
44-8320	Spring	4 10 3	74-0050	Sheave - Lower Half	3 20 1
44-8330	Spacer	4 6 1	74-0060	Sheave - Upper Half	3 22 1
44-8340	Collar - Bearing	4 7 1	74-0220	Idler - Bracket L.H.	1 9 1
44-8360	Field Coil, Rotor & Bearing	4 4 1	74-0230	Idler - Bracket R.H.	1 * 1
47-1910	Solenoid - Starter	1 34 1	74-0280	Frame	1 31 1
47-1970	Grip - Engagement	5 8 1	74-0320	Lever - Shift	5 9 1
47-2982	Hose - Fuel	1 3 1	74-0360	Frame - Rear	2 41 1
47-2982	Hose - Gas	3 3 1	74-0380	Control - Pivot	7 24 1
51-4160	Pulley - Wheel	5 30 4	74-0470	Rod - Pivot	7 21 1
51-4170	Spacer - Pulley	5 31 8	74-0480	Pulley - Drive	5 17 2
51-4180	Drum - Brake	5 32 2	74-0490	Decal - Fuel Shut Off	2 40 1
51-4190	Pulley - Driven	5 40 1	74-0510	Valve - Fuel	2 42 1
51-4210	Pad - Battery Mount	6 3 2	74-0521	Fitting - Rod	1 11 2
51-4220	Guard - Coupler	5 43 2	74-0610	Transmission	5 3 1
51-4230	Washer - Wheel	5 37 2	74-0640	Control - Throttle	7 19 1
51-4240	Shaft - Extension R.H.	5 14 1	74-0720	Tube - Manual	7 2 1
51-4250	Shaft - Extension L.H.	5 * 1	74-0730	Control - Choke	7 35 1
51-4260	Coupler	5 45 1	77-0980	Boot - Terminal	6 9 1
51-4270	Bearing - Shaft Extension	5 12 2	77-0981	Boot - Terminal	6 10 1
51-4290	Belt - Drive	5 18 2	82-2180	Panel - Control	7 3 1
51-4370	Spring - Torsion R.H.	1 * 1	82-2190	Switch - Bail	7 37 1
51-4380	Spring - Torsion L.H.	1 19 1	82-2280	Decal - Reverse Handle	7 26 1
51-4450	Screw - Leveler	1 21 2	82-2290	Decal - Control Bar	7 12 1
51-4480	Idler - Wheel	1 17 2	82-2300	Switch - Clutch	7 20 1
51-4490	Spacer - Idler Wheel	1 18 2	82-3820	Boot	7 17 1
51-4540	Retainer - Clutch	3 23 1	82-4620	Strap - Battery	6 12 1
51-4580	Rod - Brake	5 19 2	82-4640	Battery	6 5 1
51-4600	Brake Arm R.H.	5 * 1	82-4790	Anchor - Spring	1 23 1
51-4610	Brake Arm L.H.	5 20 1	82-4840	Wire Harness (Ref.)	7 32 1
51-4650	Link - Brake	5 22 2	82-4840	Wire Harness	8 1 1
51-4660	Plate - Link Brake	5 35 2	82-7631	Rod - Control	7 5 2
51-4700	Brake Band Assembly	5 33 2	82-7680	Bail Assembly	7 11 1
51-4850	Lever - Parking Brake	7 6 1	82-7690	Bar - Control	7 15 1
52-2010	Decal - Parking Brake	7 7 1	82-7740	Decal - Proline	7 4 1
52-2890	Bushing	1 6 2	82-7750	Decal - Ground Speed	2 39 1
54-0230	Field Ass'y	4 1 1	82-8440	Tank - Fuel	2 44 1
54-2750	V-Belt - Deck Drive	3 19 1	84-1830	Cap - Battery	6 17 1
54-2970	Spacer	7 36 1	86-7910	Module - Interlock	8 3 1
54-3090	Cable - Battery	6 7 1	86-7910	Module - Interlock	7 41 1
54-3200	Clutch Brake Assembly	3 18 1	92-1746	Bearing	5 27 4
55-3570	Cap - Fuel Tank	1 1 1	92-2350	Holder - Battery	6 4 2
55-7410	Armature & Pulley Assemble	4 5 1	218-461	Nut	7 18 1
55-7660	V-Belt - Deck Drive	3 * 1	218-595	Connector - Body	7 40 1
57-5811	Panel - Bottom	7 28 1	231-111	Tire	5 23 2
62-4540	Pulley - Idler	1 29 1	232-27	Valve Stem	5 25 2
63-7590	Relay	8 2 1	237-7	"O"Ring	2 43 1
63-7590	Relay	7 44 1	237-124	Grommet	1 24 1
63-8360	Key	7 16 2	237-141	Grommet - Rubber	7 8 2
63-8440	Decal - Hot	3 28 1	242-80	Rim	5 24 2
65-3090	Decal - Instruction	7 39 1	2412-73	R-Clamp	3 26 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
2412-98	Clamp - Fuel Line	3 1 2	3296-2	Nut - Lock	7 10 5
2412-98	Clamp - Fuel line	1 2 1	3296-5	Nut - Lock	4 9 3
2412-120	R-Clamp	7 33 2	3296-6	Nut - Lock	2 36 1
251-291	Bearing - Pulley	4 8 1	3296-23	Nut - Lock	1 16 2
251-292	Bearing - Field	4 2 1	3296-39	Nut - Lock	6 15 2
256-155	Bushing	1 27 2	3296-39	Nut - Lock	1 20 8
283-6	Pin - Clevis	1 10 2	3296-42	Nut - Hex	7 43 2
288-4	Pipe Cap	3 11 1	3296-42	Nut - Lock	5 10 4
289-48	Pipe Nipple	3 10 1	3296-42	Nut - Lock	6 11 2
2811-10	Elbow - 90° Street	3 9 1	32103-25	Nut - Wing	1 4 2
302-5	Fitting - Grease	5 44 2	32105-1	Screw - Hex. Hd. Machine	7 14 1
302-11	Fitting - Grease	5 28 2	32105-14	Screw - Hex. Hd. Machine	7 23 4
321-2	Screw - Hex Hd. Cap	7 42 2	32120-64	Ring - Retaining	5 11 3
321-4	Screw - Hex. Hd. Cap	5 13 4	32128-21	Nut - Lock	7 31 4
322-2	Screw - Hex. Hd. Cap	5 1 4	32144-19	Screw - Self Tapping	7 34 4
322-3	Screw - Cap Hex. Hd.	6 14 2	32149-1	Nut	6 8 2
322-4	Screw - Hex. Hd. Cap	1 32 4	32149-1	Nut - Lock	3 5 1
322-7	Screw - Hex. Hd. Cap	5 34 8	32149-2	Nut - Lock	3 4 1
322-9	Screw - Hex. Hd. Cap	3 14 4	32149-2	Nut - Lock	1 33 2
323-6	Screw - Hex. Hd. Cap	1 14 5	32151-40	Ring - Retaining	5 21 2
323-7	Screw - Hex Head	1 15 1	32151-56	Ring - Retaining	5 41 2
323-9	Screw - Hex. Hd.	6 2 2	32151-72	Ring - Retaining	5 36 4
323-9	Screw - Hex. Hd. Cap	1 30 1	32151-80	Ring - Push On	7 22 2
323-16	Screw - Hex. Hd. Cap	1 13 2	32151-91	Ring - Retaining	5 26 2
329-10	Screw - Hex. Hd. Cap	5 7 1	32152-1	Nut - Lock	3 6 4
3212-24	Screw - Hex. Hd. Cap	3 15 1			
3234-11	Screw - Hex. Hd. Cap	7 30 4			
3241-5	Screw - Socket Hd. Cap	5 38 1			
3245-3	Screw - Socket Hd. Set	5 16 2			
3253-4	Washer - Lock	5 2 12			
3253-4	Washer - Lock	3 13 5			
3253-4	Washer - Lock	2 37 4			
3253-22	Washer - Lock	3 16 1			
3254-5	Washer - Lock	7 25 1			
3255-7	Washer - External Tooth	7 45 1			
3255-8	Washer - External Tooth	3 7 1			
3256-23	Washer - Flat	1 5 9			
3256-23	Washer - Plain	3 12 6			
3257-5	Key - Woodruff	5 15 3			
3274-10	Screw - Socket Hd. Cap	3 24 4			
3290-307	Pin - Cotter	1 8 4			
3290-307	Pin - Cotter	7 13 2			
3290-307	Pin - Cotter	5 42 2			
3290-378	Cable Tie	7 29 3			

OPTIONAL EQUIPMENT

36" Cutting Unit	Model No. 30136
37" Recycler Deck	Model No. 30137
44" Cutting Unit	Model No. 30144
48" Recycler Deck	Model No. 30148
52" Cutting Unit	Model No. 30152
62" Cutting Unit	Model No. 30162
36" Deck Bag Kit	Model No. 30125
37" Deck (Cloth Bag) Bag Kit	Model No. 30129
37" Deck (Steel Hopper) Bag Kit	Model No. 30130
44"/52" Deck Bag Kit	Model No. 30128
2"-5" HOC Kit	Part No. 84-5010
Front Weight Kit-36"/37" Deck	Part No. 80-3350
Standard Sulky	Model No. 30122
Steerable Sulky	Model No. 30123