




MODEL NO. 79370-4900001 & UP

PARTS CATALOG

**WHEEL HORSE®**  
36 in. Garden Tractor Tiller




C-1518

**HITCH ASSEMBLY**

Ref. No.	Part No.	Description	No. Used
1	3296-29	Nut - Lock	4
2	93-1608-01	Plate - Lift	1
3	3230-1	Bolt - Carriage	4
4	79-2280	Assembly - Clevis	1
5	933504	Hairpin - Cotter (Incl. Ref. #8 & 27)	4
6	110046	Chain - Lift	1
7	110044	Lever	1
8	105821	Pin - Clevis	1
9	108519	Bushing	2
10	1278	Washer - Shim	2
11	5210	Washer - Shim	2
12	5618	E-Ring	2
13	104524	Trunnion	1
14	3256-24	Washer - Flat	3
15	108144	Cable - Lift	1

Ref. No.	Part No.	Description	No. Used
16	108145	Clevis - Short, 8-Speed & Sundstrand Hyd. Transmission	1
*	108143	Clevis - Long, Eaton Hyd. Transmission	1
17	3272-1	Pin - Cotter	1
18	932120	Pin - Clevis	3
19	32146-2	Nut - Lock	11
20	108485	Link - RH	1
21	3697	Link - LH	1
22	7713	Spacer - Axle	2
23	104657	Latch - Hitch	2
24	3231-2	Bolt - Carriage	2
25	3231-11	Bolt - Carriage	4
26	104659	Bracket - Mounting	1
27	3272-6	Pin - Cotter	1

\* Not Illustrated




C-1519

## PULLEY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-0345	Pulley	1
2	1005	Key - Square	1
3	3242-2	Screw - Sq. Hd. Set	2
4	93-1607-01	Hitch	1
5	92-7104	Pulley - Idler	1
6	911404	Screw - Cap Hex. Hd.	1
7	32146-2	Nut - Lock	10
8	93-1606-01	Bracket - Spring	1
9	4629	Spring - Heavy, Lift	1
10	100653	Bolt - Eye	1
11	3296-39	Nut - Lock	1
12	110265	Belt - Drive	1
13	323-13	Screw - Cap Hex. Hd.	1
14	3256-4	Washer - Flat	2
15	83-2950	Spacer	1

Ref. No.	Part No.	Description	No. Used
16	92-7103	Pulley - Idler, V	1
17	MW8821	Pulley - Idler, Flat	1
18	323-9	Screw - Cap Hex. Hd.	1
19	102025	Spacer	1
20	92-4082	Arm - Idler	1
21	6135	Spring - Light, Idler	1
22	323-7	Screw - Cap Hex. Hd.	1
23	110008	Support - Idler, Mid-Mount	1
24	108903	Clamp - Conduit	1
26	110039	Guard - Idler	1
27	108315	Conduit - Hyd. Trans.	1
28	105845	Tube Assembly	1
29	926671	S.T. Bolt	2



C-1520

## GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-1600-01	RH Case	1
2	93-1600-01	LH Case	1
3	1540	Needle Bearing	1
4	1532	Needle Bearing	2
5	6838	Needle Bearing	1
6	100441	Seal	1
7	103118	Seal	4
8	1529	Needle Bearing	1
9	32121-41	Pin - Spirol	2
10	106009	Shaft - Tine	1
11	32120-33	Snap Ring	2
12	106011	Washer - Special	2
13	6848	Chain (Endless)	1
14	83-3330	Gasket	1
15	281-3	Plug - Pipe	2
16	323-21	Screw - Cap Hex. Hd.	1
17	323-13	Screw - Cap Hex. Hd.	3
18	323-15	Screw - Cap Hex. Hd.	1
19	323-23	Screw - Cap Hex. Hd.	1
20	323-25	Screw - Cap Hex. Hd.	1
21	323-42	Screw - Cap Hex. Hd.	1
22	3296-39	Nut - Lock	8
23	106007	Gear - Reduction	1
24	83-3340	Spacer	1
25	1535	Washer - Thrust	1

Ref. No.	Part No.	Description	No. Used
26	3528	Gear - Pinion	1
27	104387	Shaft - Input	1
28	32120-72	Snap Ring	1
29	3257-5	Key - Woodruff	1
30	93-1602-03	Tine - Inside, RH	1
*	93-1603-03	Tine - Inside, LH	1
31	283-5	Pin - Clevis	4
32	3272-11	Pin - Cotter	7
33	92-1653-03	Tine - Outside, RH	1
*	93-1604-03	Tine - Outside, LH	1
34	93-1601-03	Plate - Mounting, Outside Tine	2
35	324-4	Screw - Cap Hex. Hd.	8
36	3296-48	Nut - Lock	8
37	92-6514-01	Shield - Tine (Incl. ref.#44)	1
38	93-1609-01	Shield - Rear	1
39	93-1605-01	Cover - End	2
40	900036	Bolt - Carriage	12
41	3296-29	Nut - Lock	12
42	3256-23	Washer - Flat	12
43	3272-4	Pin - Cotter	3
44	92-7112	Decal - Danger	2
45	92-8748	Decal - Attachment	1

\* Not Illustrated

# TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No.	Qty.	Part No.	Description	Pg. Ref. No. No.	Qty.
1005	Key - Square	2	2 1	92-6514-01	Shield - Tine	3	37 1
1278	Washer - Shim	1	10 2	92-7103	Pulley - Idler, V	2	16 1
1529	Needle Bearing	3	8 1	92-7104	Pulley - Idler	2	5 1
1532	Needle Bearing	3	4 2	92-7112	Decal - Danger	3	44 2
1535	Washer - Thrust	3	25 1	92-8748	Decal - Attachment	3	45 1
1540	Needle Bearing	3	3 1	93-0345	Pulley	2	1 1
3528	Gear - Pinion	3	26 1	93-1600-01	LH Case	3	2 1
3697	Link - LH	1	21 1	93-1600-01	RH Case	3	1 1
4629	Spring - Heavy, Lift	2	9 1	93-1601-03	Plate - Mounting,	3	34 2
5210	Washer - Shim	1	11 2	93-1602-03	Tine - Inside, RH	3	30 1
5618	E-Ring	1	12 2	93-1603-03	Tine - Inside, LH	3	* 1
6135	Spring - Light, Idler	2	21 1	93-1604-03	Tine - Outside, LH	3	* 1
6838	Needle Bearing	3	5 1	93-1605-01	Cover - End	3	39 2
6848	Chain (Endless)	3	13 1	93-1606-01	Bracket - Spring	2	8 1
7713	Spacer - Axle	1	22 2	93-1607-01	Hitch	2	4 1
100441	Seal	3	6 1	93-1608-01	Plate - Lift	1	2 1
100653	Bolt - Eye	2	10 1	93-1609-01	Shield - Rear	3	38 1
102025	Spacer	2	19 1	281-3	Plug - Pipe	3	15 2
103118	Seal	3	7 4	283-5	Pin - Clevis	3	31 4
104387	Shaft - Input	3	27 1	323-7	Screw - Cap Hex. Hd.	2	22 1
104524	Trunnion	1	13 1	323-9	Screw - Cap Hex. Hd.	2	18 1
104657	Latch - Hitch	1	23 2	323-13	Screw - Cap Hex. Hd.	2	13 1
104659	Bracket - Mounting	1	26 1	323-13	Screw - Cap Hex. Hd.	3	17 3
105821	Pin - Clevis	1	8 1	323-15	Screw - Cap Hex. Hd.	3	18 1
105845	Tube Assembly	2	28 1	323-21	Screw - Cap Hex. Hd.	3	16 1
106007	Gear - Reduction	3	23 1	323-23	Screw - Cap Hex. Hd.	3	19 1
106009	Shaft - Tine	3	10 1	323-25	Screw - Cap Hex. Hd.	3	20 1
106011	Washer - Special	3	12 2	323-42	Screw - Cap Hex. Hd.	3	21 1
108144	Cable - Lift	1	15 1	324-4	Screw - Cap Hex. Hd.	3	35 8
108145	Clevis - Short, 8-Speed &	1	16 1	3230-1	Bolt - Carriage	1	3 4
108315	Conduit - Hyd. Trans.	2	27 1	3231-2	Bolt - Carriage	1	24 2
108485	Link - RH	1	20 1	3231-11	Bolt - Carriage	1	25 4
108519	Bushing	1	9 2	3242-2	Screw - Sq. Hd. Set	2	3 2
108903	Clamp - Conduit	2	24 1	3256-4	Washer - Flat	2	14 2
110008	Support - Idler, Mid-Mount	2	23 1	3256-23	Washer - Flat	3	42 12
110039	Guard - Idler	2	26 1	3256-24	Washer - Flat	1	14 3
110044	Lever	1	7 1	3257-5	Key - Woodruff	3	29 1
110046	Chain - Lift	1	6 1	3272-1	Pin - Cotter	1	17 1
110265	Belt - Drive	2	12 1	3272-4	Pin - Cotter	3	43 3
900036	Bolt - Carriage	3	40 12	3272-6	Pin - Cotter	1	27 1
911404	Screw - Cap Hex. Hd.	2	6 1	3272-11	Pin - Cotter	3	32 7
926671	S.T. Bolt	2	29 2	3296-29	Nut - Lock	1	1 4
932120	Pin - Clevis	1	18 3	3296-29	Nut - Lock	3	41 12
933504	Hairpin - Cotter	1	5 4	3296-39	Nut - Lock	2	11 1
108143	Clevis - Long, Eaton Hyd.	1	* 1	3296-39	Nut - Lock	3	22 8
MW8821	Pulley - Idler, Flat	2	17 1	3296-48	Nut - Lock	3	36 8
79-2280	Assembly - Clevis	1	4 1	32120-33	Snap Ring	3	11 2
83-2950	Spacer	2	15 1	32120-72	Snap Ring	3	28 1
83-3330	Gasket	3	14 1	32121-41	Pin - Spirol	3	9 2
83-3340	Spacer	3	24 1	32146-2	Nut - Lock	2	7 10
92-1653-03	Tine - Outside, RH	3	33 1	32146-2	Nut - Lock	1	19 11
92-4082	Arm - Idler	2	20 1				