





MODEL NO. 73380-4900001 & UP

PARTS
CATALOG**WHEEL HORSE[®]**
312-8e Garden Tractor




C-1481

HOOD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	102881	Headlight	2
2	108130	Wire - Headlight Ground	1
3	109459	Clamp	2
4	926671	Bolt	2
6	92-9826	Decal - Hood, Front	1
7	92-9825	Decal - Hood RH	1
*	92-9824	Decal - Hood LH	1
8	88-2782	Hood (Incl. Ref. # 9)	1
9	92-9837	Decal - Danger	1
10	117432	Rivet - Pop	4
11	117344	Handle Assembly	2
12	3296-42	Nut	4

Ref. No.	Part No.	Description	No. Used
13	3254-2	Washer - Intl. T	1
14	3256-22	Washer	3
15	5979	Bushing - Hood Pivot	2
16	105797	Ring - Retaining	2
17	116747	Bracket - LH	1
*	116746	Bracket - RH	1
18	116745	Rod - Pivot	1
19	101850	Rod - Hood Stop	1
20	3229-25	Bolt - Carriage	4
21	3272-1	Pin - Cotter	2
22	109495	Retainer - Headlight LH	1
*	109494	Retainer - Headlight RH	1
23	92-9836	Decal - Logo	1


*Not Illustrated



CONTROL PANEL

Ref. No.	Part No.	Description	No. Used
1	926694	Screw – Hex. Washer Hd.	3
2	112415	Stop – PTO	1
3	111757	Edging – Console	1
4	910792	Screw	6
5	66-0120	Knob – Control	1
6	79-3640	Console	1
7	910762	Screw	2
8	920150	Washer – Lock	2
9	112214	Control – Choke	1
10	109530	Nut	1
11	920262	Washer – Special	1
12	920160	Washer – IntL. T	1
13	101884	Nut – Special	1
14	62-7770	Key – Ignition, Padded	1
15	78-0020	Meter – Hour (Incl. Ref.# 27-28)	1
16	79-0060	Meter – Volt (Incl. Ref.# 24-25)	1
17	920259	Washer – Special	1
18	102950	Ring – Retaining	1
19	113179	Nut	1

Ref. No.	Part No.	Description	No. Used
20	910837	Screw	7
21	111034	Plate – Hood Stand	1
22	8830	Clip	2
23	102138	Switch – Light (Incl. Ref. #17-19)	1
24	78-0080	Clamp – Volt Meter	1
25	5924	Nut	2
26	78-3320	Clamp – Steel	1
27	3255-25	Washer – Lock	1
28	3217-27	Nut – Hex	1
29	116338	Switch – Ignition (Incl. Ref.#11-13)	1
30	117431	Rivet – Pop	4
31	117343	Latch – Hood	2
32	112506	Bracket – Indicator Lights	1
33	915960	Nut	2
34	115854	Control – Throttle	1
35	120590	Stop – Throttle	1
36	915740	Nut – Lock	2
37	111392	"J"Clip	1




HOOD STAND AND SUPPORTS

Ref. No.	Part No.	Description	No. Used
1	78-3010	Bracket - Battery Support	1
2	926694	Screw - Hex. Hd.	13
3	88-2170	Bracket - Belt	1
4	9151126	Nut	4
6	117371	Bolt - Carriage	4
8	92-1525	Hoodstand	1
10	92-8946	Decal - Danger	1

Ref. No.	Part No.	Description	No. Used
11	92-6529	Plate - Shift Cover (Incl. Ref.#10)	1
12	910837	Screw	7
14	107069	Nut - Speed	7
15	106250	Cover - Dust	1
16	113935	Cover - Side, LH	1
17	78-3020	Plate - Front	


*Not Illustrated



BELT GUARD & FOOTRESTS

Ref. No.	Part No.	Description	No. Used
1	107975	Guard – Belt	1
2	3296-29	Nut – Lock	7
3	108457	Nut – Push	1
4	910837	Bolt – Carriage	9
5	3296-42	Nut	1
6	109554	Bracket – Belt Guard	1
7	910794	Screw – Machine	2
8	321-4	Bolt	2
9	116000	Bolt – Carriage	6
10	518211	Bumper	2
12	107069	Clip	3

Ref. No.	Part No.	Description	No. Used
15	110636	Pad – Footrest	2
16	3296-29	Nut	11
17	7456	Clamp	4
18	106223	Footrest – LH	1
21	106352	Guard – Lower Belt	1
22	106222	Footrest – RH	1
23	915740	Nut	4
24	117331	Holder – Fuse	1
25	3230-1	Bolt	1
26	926694	Bolt	6




FENDER AND SUPPORT

Ref. No.	Part No.	Description	No. Used
1	106234	Tank – Fuel	1
2	3256-4	Washer	2
3	926697	Bolt	2
4	110960	Fender	1
5	926694	Bolt	2
6	55-3570	Fuel Cap	1
7	915551	Nut	4
8	3023	Clip – Small	1
9	3256-21	Washer	4
10	3254-1	Washer – Lock	4
11	105202	Base – Taillight, w/Bulb	2
12	910808	Screw	4
13	112564	Lens – Taillight	2
14	8043	Bulb – Light, Metal Base	2
*	109045	Bulb – Light, All Glass	2
15	104047	Bushing	1

Ref. No.	Part No.	Description	No. Used
16	104048	Valve – Fuel Shut-Off	1
17	3253-4	Washer – Lock	1
18	322-2	Bolt	5
19	2412-98	Clamp	2
20	79-4990	Bracket – Fender Support	1
21	108464	Support – Fuel Tank, LH	1
22	3296-29	Nut	6
23	322-3	Bolt	6
24	107951	Bracket – Fender Front	1
25	3256-23	Washer	2
26	92-9511	Line – Fuel 62"	1
27	8830	"J"Clip	1
28	3235-22	Screw – Hex. Hd.	1
29	322-5	Screw – Hex. Hd.	2
30	106236	Support – Fuel Tank, RH	1

*Not Illustrated



C-1501


SEAT

Ref. No.	Part No.	Description	No. Used
1	110920	Spring – Seat	2
2	3253-4	Washer – Lock	4
3	3296-29	Nut – Lock	6
4	78-0760	Seat	1
5	92-6697	Screw	4
6	3256-23	Washer	4
8	322-5	Screw – Hex. Hd.	4
9	105524	Bracket – Pivot	2
10	78-2990	Plate – Seat Pivot	1
11	114344	Spacer	2
12	3256-22	Washer	2

Ref. No.	Part No.	Description	No. Used
13	321-8	Screw – Hex. Hd.	2
14	114345	Bracket	1
15	3296-42	Nut – Lock	2
16	114343	Spring – Gas	1
17	111071	Bumper	2
18	322-4	Screw – Hex. Hd.	6
19	105503	Bushing	2
20	109989	Spacer	4
21	38-1420	Switch – Seat	1
22	3023	Clip – Speed	1

*Not Illustrated


FRONT AXLE AND STEERING



FRONT AXLE AND STEERING

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	1278	Washer – Shim	3	19	323-9	Bolt	2
2	32120-93	Ring – Retaining	2	20	32136-5	Nut – Slotted	1
3	102592	Tie Rod Asm, RH	1	21	6397	Bearing	1
4	3296-39	Nut – Lock	4	22	1481	Fitting – Grease, 45°	2
5	6472	Bearing – Flanged	1	23	3272-19	Pin – Cotter	1
6	323-6	Bolt	2	24	3296-6	Nut	4
7	78-2880	Shaft – Lower	1	25	78-2920	Tie Rod End	1
8	88-2710	Support – Steering Shaft	1	26	3219-3	Nut	1
9	92-4987	Shaft – Upper	1	27	78-2900	Tie Rod Assembly, LH (Incl. Ref. # 25 & 26)	1
10	237-69	"O"Ring	1	28	322-1	Bolt	1
11	5210	Washer – Shim	A/R	29	3253-4	Washer – Lock	1
12	76-1420	Steering Wheel (Incl. Ref. #13)	1	30	6216	Pin & Plate	1
13	78-0370	Insert	1	31	5638	Axle	1
14	32121-111	Pin – Spirol	1	32	5618	Ring – Retaining	1
15	7896	Washer – Bowed	1	33	113380	Spindle – LH	1
16	109262	Washer – Special	2	*	113379	Spindle – RH	1
17	113443	Tube – Steering	1	34	302-5	Fitting – Grease, Straight	2
18	3272-21	Pin – Cotter	1	35	109189	Bearing	1


*Not Illustrated



FRAME & HITCHES

Ref. No.	Part No.	Description	No. Used
1	8616	Spring	2
2	3296-39	Nut	9
3	101711	Housing - Front Hitch	1
4	102644	Plate - Mid Hitch	2
5	3231-25	Bolt - Carriage	3
6	323-5	Bolt	4
7	3253-21	Washer - Lock	4
8	78-2680	Frame	1
9	5618	Ring - Retaining	2
10	105269	Shaft - Drawbar Hitch	1
11	1644	Hitch - Drawbar	1
12	979120	Spacer	2
13	106634	Pin - Hitch	1

Ref. No.	Part No.	Description	No. Used
14	933505	Pin - Cotter	1
15	3256-26	Washer - Flat	1
16	323-44	Screw - Hex. Hd.	6
17	101017	Rod - Mid Hitch Lock	1
18	83-6520	Rod - Lock	1
19	105316	Cap - Lock Rod	2
20	9038	Grip	1
21	117930	Latch - Mid Hitch	1
22	101750	Rod - Pivot Latch	1
23	105859	Latch - Front Hitch	1
24	101707	Lock - Attachment	1
25	101751	Rod - Lock	1
26	105797	Ring - Retaining	8




C-1481

KOHLER ENGINE & MUFFLER

Ref. No.	Part No.	Description	No. Used
1	322-7	Bolt	1
2	3253-4	Washer	1
3	3256-23	Washer	1
4	6876	Spacer	1
5	KH10535	Nut - Lock	1
6	KH10278	Elbow	1
7	106858	Clamp	1
8	112213	Muffler	1
9	117255	Engine - 12HP Kohler M12S -PS471527	1

Ref. No.	Part No.	Description	No. Used
10		Screw (Engine) Ref	
11	8830	"J"Clip	1
12	3296-39	Nut	2
13	323-6	Bolt	2
14	3253-21	Washer - Lock	1
15	3023	Clip - Wire	1
16	109910	Wire - Ground	1
17	323-8	Bolt	2




C-1482

AIR INTAKE

Ref. No.	Part No.	Description	No. Used
1	KH10576	Nut – Wing	1
2	KH10299	Cover	1
3	KH10189	Nut	1
4	KH10412	Cover – Air Cleaner Element	1
5	KH10235	Element – Precleaner	1
6	KH10236	Element	1

Ref. No.	Part No.	Description	No. Used
7	KH10034	Seal	1
8	KH10609	Screw	3
9	KH10297	Base – Air Cleaner	1
10	KH10697	Gasket	1
*	KH10191	Decal – Air Cleaner	1

*Not Illustrated




CARBURETOR

Ref. No.	Part No.	Description	No. Used
1	KH10116	Screw	1
2	KH10093	Gasket	1
3	KH10117	Bowl – Fuel	1
4	KH10663	Kit – Float (Incl. Ref.#5)	1
5		Pin – Float	1
6	KH10094	Gasket	1
7	KH10128	Ball	1
8	KH10113	Spring	1
9		Connector 90°	1
10	KH10672	Carburetor Assembly (Complete)	1
11		Seal	1
12	KH10707	Shaft w/Lever & Seal (Incl. Ref# 11)	1
13	KH10121	Plate – Throttle	1
14	KH10110	Screw	4
15	KH10132	Needle – Idle Fuel Adj.	1
16	KH10112	Spring – Idle Fuel	1
17	25-3603	Main – Needle	1
18	KH10114	Spring – Adj.	1
19	KH10109	Screw – Idle Speed Adj.	1
20	KH10702	Shaft – Choke	1
21	KH10708	Plate – Choke	1
*	KH10696	Kit – Carburetor Repair (Includes	
	KH10009	Gasket – Flange	

Ref. No.	Part No.	Description	No. Used
	KH10146	Gasket – Carburetor	
	KH10733	Gasket	
	KH10093	Gasket – Bowl Screen	
	KH10094	Gasket– Bowl	
	KH10677	Gasket – Air Cleaner	
	KH10697	Gasket	
	KH10274	Gasket – Carburetor	
*	KH10358	Kit – Choke & Throttle Repair	1
*	KH10710	Kit – High Altitude Jet (Includes	
	KH10682	Bushing	
	KH10709	Jet – Main	1
*	KH10674	Kit – Carburetor w/Linkage (Includes	
	KH10682	Bushing &	
	KH10709	Main Jet	1
*	KH10693	Kit – Adjustable Jet w/Linkage (Includes	
	KH10701	Carburetor Linkage	
	KH10682	Bushing – Linkage Natural	
	KH10686	Bushing Linkage Black	
	KH10697	Gasket – Air Cleaner	
	KH10693	Carburetor Assembly	
	KH10146	Gasket	
	KH10274	Gasket	1


*Not Illustrated



FUEL PUMP

Ref. No.	Part No.	Description	No. Used
1	KH10130	Line – Fuel	1
2	KH10586	Clamp	2
3	KH10123	Connector – 90°	2
4	KH10319	Pump Assy – Fuel (Incl. Ref.#5 &7)	1


Ref. No.	Part No.	Description	No. Used
5	KH10095	Gasket	1
6	KH10569	Washer	2
7	KH10552	Screw – Pozidrive	2



C-1492

GOVERNOR LINKAGE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	KH10660	Kit – Governor Gear (Includes 24)	1	35	KH10570	Washer	1
3	KH10035	Pin – Governor Stop	1	37	KH10600	Screw	1
8	KH10629	Nut – Pal	1	38	KH10556	Washer – Lock	1
22	KH10070	Bushing	1	39	KH10569	Washer	1
23	KH10585	Spacer	1	40	KH10624	Nut	1
24	KH10087	Washer	1	41	KH10152	Washer	2
25	KH10136	Washer	1	42	KH10293	Lever – Choke Control	1
26	KH10538	Kit – Governor Cross Shaft	1	43	KH10294	Lever – Throttle Control	1
27	KH10295	Lever – Governor	1	44	KH10302	Space	1
28	KH10626	Screw	1	45	KH10605	Screw	1
29	KH10668	Bushing	1	46	KH10695	Washer	1
30	KH10701	Linkage (Governor to Carb.)	1	47	KH10040	Screw	1
31	KH10296	Spring (Governor to Carb.)	1	48	KH10303	Bracket – Clutch Control	1
32	KH10287	Linkage – Choke (Carb. to Choke Shaft)	1	49	KH10308	Clamp	1
33	KH10686	Bushing	1	50	KH10619	Nut	1
34	KH10545	Screw	1	*	KH10291	Choke Lever Assembly (Incl. Ref. #37 thru 44)	1




C-1484

BAFFLES AND SHROUDS

Ref. No.	Part No.	Description	No. Used
1	KH10231	Baffle – Head	1
2	KH10567	Washer	1
3	KH10289	Screw – Pozidrive T.H.	3
4	KH10413	Screw – Hex .Hd.	6
5	KH10282	Baffle – Cylinder	1

Ref. No.	Part No.	Description	No. Used
6	KH10280	Baffle – Inner	1
7	KH10265	Housing – Blower	1
9	KH10279	Baffle – Side Air	1
*		Decal – HP	1

*Not Illustrated




C-1491

FLYWHEEL

Ref. No.	Part No.	Description	No. Used
1	KH10263	Flywheel	1
2	KH10588	Key - Woodruff	1
3	KH10112	Spacer	4
4	KH10124	Fan	1

Ref. No.	Part No.	Description	No. Used
5	KH10107	Screw - Hex. Hd.	4
6	KH10126	Screen	1
7	KH10108	Screw	1
8	KH10666	Washer	1




C-1493

IGNITION SYSTEM

Ref. No.	Part No.	Description	No. Used
1	KH10321	Module – Ignition	1
2	KH10572	Washer	2
3	KH10548	Screw	2
4	KH10606	Screw – Hex. Hd.	1
5	KH10618	Clip	1
6	KH10610	Screw	1
7	KH10570	Washer – Flat	1
8		Clip	1
9	KH10091	Kit – Stator 15 am (Incl. Ref.#8)	1
10	KH10605	Screw – Pozidrive	4
11	KH10345	Connector	1

Ref. No.	Part No.	Description	No. Used
12	8830	Clip	1
13	321-2	Screw	1
14	KH10215	Regulator – Rectifier	2
15	KH10543	Screw	2
16	KH10082	Connector	1
17	KH10056	Plug – Spark	1
18	KH10010	Clip – Hi-Tension	1
*	KH10313	Lead – Violet, Regulator– Rectifier to Connector (23")	1
*	KH10570	Washer 1/4	1
*	KH10344	Clip	1




C-1485

BREATHER AND VENT

Ref. No.	Part No.	Description	No. Used
1	KH10058	Gasket	1
2	KH10072	Plate	1
3	KH10057	Reed	1
4	KH10143	Baffle	1
5	KH10275	Filter	1
6	KH10034	Seal	1

Ref. No.	Part No.	Description	No. Used
7	KH10149	Gasket	1
8	KH10298	Cover	1
9	KH10150	Stud	1
10	KH10629	Palnut	1
11	KH10309	Hose	1




C-1487

CRANKCASE AND CYLINDER HEAD

Ref. No.	Part No.	Description	No. Used
1	KH10691	Block – Cylinder Service With Short Block (Includes Crankshaft)	1
	KH10721	Miniblock (Less Crankshaft)	1
2	KH10061	Shaft – Governor Gear	1
3	KH10067	Ball Bearing	2
4	KH10269	Seal	1
5	KH10562	Plug	1
6	KH10015	Guide – Valve	2
7	KH10028	Insert – Exhaust Valve	1
8	KH10049	Bearing	1
9	KH10272	Gasket	1
10	KH10311	Gasket	1

Ref. No.	Part No.	Description	No. Used
11	KH10687	Plate – Bearing	1
12	KH10268	Seal	1
13	KH10549	Screw	4
14	KH10545	Screw	4
15	KH10661	Cover	1
16	KH10055	Gasket	1
18	KH10081	Shaft – Balance Gear	1
19	KH10261	Head – Cylinder	1
20	KH10700	Gasket	1
21	KH10145	Washer	9
22	KH10144	Screw	8
23	KH10312	Strap – Lifting	1
24	KH10290	Screw	1




C-1486

CAMSHAFT, CRANKSHAFT AND VALVES

Ref. No.	Part No.	Description	No. Used
1	KH10259	Camshaft Assy (Incl. Ref. #2)	1
2	KH10292	Spring	1
3	KH10147	Spacer .005	1
*	KH10148	Spacer .010	1
4	KH10310	Pin - Camshaft	1
5	KH10074	Valve - Exhaust	1
6	KH10052	Valve - Intake	1
7	KH10054	Retainer - Upper Spring	2
8	KH10053	Spring - Intake Valve	1
9	KH10018	Retainer - Spring	1

Ref. No.	Part No.	Description	No. Used
10	KH10221	Kit - Retainer	2
11	KH10539	Tappet - Intake Valve	1
12	KH10539	Tappet - Exhaust Valve	1
13	KH10496	Rotator - Valve	2
14	KH10062	Spring	1
15	KH10617	Plug - Cup .	1
16	KH10305	Kit - Crankshaft (Includes Flywheel Hdwr.)	1
19	KH10322	Kit - Spacer (Incl. Ref. #20)	2
20	KH10574	Retainer	1




C-1489

PISTON AND RINGS

Ref. No.	Part No.	Description	No. Used
1	KH10703	Set - Ring, Std. & .003	1
*	KH10704	Set - Ring .010	1
*	KH10705	Set - Ring .020	1
*	KH10706	Set - Ring .030	1
2	KH10711	Piston w/Ring Set Std.	1
*	KH10712	Piston w/Ring Set .003	1

Ref. No.	Part No.	Description	No. Used
*	KH10713	Piston w/Ring Set .010	1
*	KH10714	Piston w/Ring Set .020	1
*	KH10715	Piston w/Ring Set .030	1
3	KH10262	Retainer - Piston Pin	2
4	KH10698	Rod - Connecting Std.	1
*	KH10699	Rod - Connecting .010	1




C-1488

OIL PAN AND DIPSTICK

Ref. No.	Part No.	Description	No. Used
1	KH10270	Dipstick	1
2	KH10201	O-Ring	1
4	KH10266	Adapter - Oil Fill	1
5	KH10541	Screw	3
6	KH10088	Gasket	1
7	KH10248	Pan - Oil	1
8	KH10059	Gasket	1
9	KH10550	Screw	4
10	KH10620	Plug	4

Ref. No.	Part No.	Description	No. Used
11	KH10826	Kit - Float Switch (Includes Items 12 & Decal)	1
12	KH10134	Sleeve	1
*	KH10119	Decal - Float Switch	1
*	KH10345	Connector - Female (5-Contact)	1
*		Gasket Set w/Seal	1
*	KH10258	Gasket Set w/o Seals	1




C-1490

STARTER

Ref. No.	Part No.	Description	No. Used
1	KH10187	Starter Assembly (Includes Items 9 thru 15)	1
2	KH10244	Brace - Starter Tail	1
3	KH10607	Screw - Hex. Hd.	1
4	KH10610	Screw - Hex. Hd.	1
5	KH10304	Bracket - Starter	1
6	KH10549	Screw	2
7	KH10181	Bolt	2
8	KH10210	End Cap Ass'Y (Incl. Ref.#9)	1

Ref. No.	Part No.	Description	No. Used
9	KH10515	Kit - Brush	1
10	KH10247	Armature	1
11	KH10209	Cap - Drive End	1
12	KH10323	Kit - Drive (Incl. Ref. #15)	1
13	KH10324	Kit - Drive Parts	1
*	KH10135	Tag - Caution	1
*	KH10304	Bracket - Solenoid	1
*	KH10549	Screw	1




C-1472

DRIVE BELT AND PULLEYS

Ref. No.	Part No.	Description	No. Used
1	7466	Pulley – Engine Drive	1
2	3246-2	Screw – Set	2
3	105453	Key	1
4	937221	Key – Hi-Pro	1
5	3242-2	Screw – Set	2
6	7473	Belt – Drive	1

Ref. No.	Part No.	Description	No. Used
7	106165	Pulley – Transmission Drive	1
11	324-5	Bolt	3
12	3253-6	Washer – Lock	3
13	3256-25	Washer	3
14	111242	Guide – Belt, Bottom	1
16	112841	Cap	1

TRANSMISSION 8-SPEED



C-1473


TRANSMISSION 8-SPEED

Ref. No.	Part No.	Description	No. Used
*	92-8708	Transmission Assembly	1
1	111200	Case-Transmission, RH	1
2	111198	Case-Transmission, LH	1
3	323-16	Screw - Hex. Hd.	1
4	323-11	Screw - Hex. Hd.	5
5	3296-39	Nut	6
6	281-10	Plug - Pipe, Allen Hd.	1
7	281-2	Plug - Pipe, Sq. Hd.	1
8	111199	Bearing - Ball	2
9	1532	Bearing - Needle	2
10	1542	Bearing - Needle	1
11	9416	Bearing - Needle	2
12	1529	Bearing - Needle	1
13	100442	Seal - Input Shaft	1
14	100443	Seal - Axle	4
15	3915	Pin - Locating	2
16	1523	Bearing - Needle	1
17	83-2890	Bearing - Needle	1
18	100441	Seal - Brake Shaft	1

Ref. No.	Part No.	Description	No. Used
19	7201	Shaft - Input	1
20	7418	Washer - Thrust	1
21	7204	Gear Assembly (Incl. Ref. #22)	1
22	1518	Bearing - Needle	2
23	5175	Gear Assembly (Incl. Ref. # 22)	1
24	7205	Gear - Sliding	1
25	7206	Gear - Reduction	1
26	7207	Bearing - Needle	2
27	7208	Shaft - Reduction Gear	1
28	1243	Cup - Plug	1
29	5173	Gear - Hi & Second	1
30	5174	Gear Low & Reverse	1
31	5615	Rail - Shift, Front	1
32	5616	Rail - Shift, Rear	1
33	3503	Fork - Shift	2
34	933156	Pin - Spirol	2
35	5614	Pin - Shift	1

*Not Illustrated

TRANSMISSION 8-SPEED




C-1473A

TRANSMISSION 8-SPEED

Ref. No.	Part No.	Description	No. Used
36	7269	Gear Assembly (Incl. Ref.#37)	1
37	1504	Bushing – Bronze	2
38	3527	Gear – Reduction	1
39	83-3530	Shaft – Cluster	1
40	937089	Key – Woodruff	1
41	4204	Gear Assembly, Reverse Idler (Incl. Ref. #43)	1
42	3909	Pin – Reverse Idler	1
43	1516	Bushing – Reverse Idler	1
44	101847	Dipstick	1
45	102703	Nipple – Transmission Fill	1
46	3912	Gasket – Transmission	1
47	1239	Screw – Set – Special	1
48	3217-5	Nut	1
49	3577	Cover – Dust	1
50	9547	Washer – Thrust	1
51	102974	Gear Assembly (Incl. Ref. # 52 & 53)	1
52	101625	Shaft – Pinion	1
53	101626	Gear 44 Tooth	1
54	108758	Knob – Gear Shift	1
55	3517	Ball – Detent	3
56	106030	Spring – Detent	2
57	7213	Bolt – Detent	1

Ref. No.	Part No.	Description	No. Used
58	7214	Lever – Shift Hi–Low Range	1
59	116636	Fork – Shift Hi–Low Range	1
62	110727	Rod – Shift Hi–Low Range	1
63	933184	Pin – Spirol	1
64	111196	Cap – Diff End	2
65	911423	Bolt	4
66	107374	Washer – Special	4
67	108881	Nut – Hex	4
68	105061	Gear – Differential Ring 43 Tooth	1
70	101623	Gear – Differential Pinion	8
71	101889	Gear – Differential Axle	2
72	105875	Axle – Rear	2
73	105876	Ring – Special, Snap	2
74	110725	Stick – Shift	1
75	83-2710	Knob – Hi–Lo Range Shift	1
76	92-8749	Decal – Unidrive	1
77	106719	Drum – Brake	1
78	2844	Washer – Special	1
79	110234	Screw – Hex. Hd.	1
80	9598	Plate – Stop	1
81	9593	Band – Brake	1
82	3253-3	Washer – Lock	2
83	321 – 3	Screw – Hex. Hd.	2

CLUTCH, BRAKE AND SPEED CONTROL LINKAGE




CLUTCH, BRAKE AND SPEED CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
8	114814	Pedal – Clutch	1
9	114813	Pedal – Brake	1
10	111383	Collar	3
11	3245-32	Screw – Set	3
12	7896	Washer – Bowed	1
13	1278	Washer – Shim	1
14	103347	Rod – Clutch	1
15	3272-6	Pin – Cotter	1
16	78-2970	Arm – Clutch Idler	1
17	933190	Pin – Spirol	1
18	105896	Arm – Clutch Rod	1
19	920248	Washer – Nylon	3
20	3272-10	Pin – Cotter	3
21	3765	Washer – Shim	1
22	101161	Trunnion – Clutch Rod	1
23	103543	Bell Crank – Brake Linkage	1
24	7879	Bushing	2
25	3256-26	Washer	1
26	106417	Rod – Bell Crank Pivot	1
27	926694	Screw – Hex. Hd.	1
28	105900	Rod – Brake, Rear	1
29	105886	Rod – Brake, Front	1
31	933505	Pin – Cotter	1


Ref. No.	Part No.	Description	No. Used
32	3296-39	Nut	1
34	106451	Lever – Parking Brake	1
35	6820	Grip	1
36	102025	Spacer	1
37	323-9	Screw Hex. Hd.	1
38	3256-24	Washer	2
39	102809	Nut – Special	1
40	107677	Spring – Brake Return	1
41	103628	Spring – Return	1
42	7451	Pulley – Idler	1
43	106193	Bolt – Special	1
44	32146-2	Nut	1
49	920225	Washer – Special	1
50	933267	Pin – Spirol	1
53	78-3240	Spring – Gas	1
54	321-31	Screw – Hex. Hd.	1
55	78-3260	Spacer	1
56	3256-22	Washer	2
58	3296-42	Nut	2
59	321-9	Screw – Hex. Hd.	1
60	78-3250	Spacer	1
61	302-5	Fitting – Grease	2

MANUAL LIFT LINKAGE



MANUAL LIFT LINKAGE


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	108563	Lever – Lift (Incl. Ref.# 46, 47 & 48)	1	27	113445	Bar – Lift	1
2	106257	Rod – Latch	1	28	6229	Bearing	1
3	8130	Retainer – Spring	1	29	32120-47	Ring – Retaining	1
4	3624	Spring	1	34	110653	Rod – Height Control	1
5	933148	Pin – Spirol	1	35	3272-10	Pin – Cotter	1
6	6542	Grip – Lift Lever	1	36	3256-5	Washer	1
14	933507	Pin – Cotter	2	37	106345	Casting – Lift Lever	1
15	3256-62	Washer	2	38	322-5	Screw – Hex. Hd.	3
16	106269	Bushing	2	39	106258	Sleeve	1
17	32151-91	Retainer	1	40	5280	Knob – Height Control	1
18	1121	Key	1	41	106411	Latch – Bracket	1
19	78-1550	Lever – Lift	1	42	926694	Screw – Hex. Hd.	1
20	6739	Trunnion	1	44	3296-29	Nut	4
21	933505	Pin – Cotter	2	45	926696	Screw – Hex. Hd.	2
22	106522	Chain – Lift	1	46	108565	Shaft	1
24	322-6	Screw – Hex. Hd.	1	47	32121-103	Pin – Spirol	1
25	3256-23	Washer	3	48	32121-25	Pin – Roll	1
26	105316	Cap – Plunger	2	55	3256-25	Washer	1
				56	3296-39	Nut	1



ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	116338	Switch – Ignition	1
	111216	Switch – Ignition	1
2	920160	Washer – Intl. T	1
3	101884	Nut – Special	1
4	62-7770	Key – Ignition, Padded	1
5	79-3590	Harness Assy – Wiring (Inc. Ref.#6,7,9,44 & 64-68)	1
6	104926	Switch – Connector Body Ignition	1
7	518105	Terminal	1
8	103480	Switch – Clutch Interlock, w/Item 16	1
9	120930	Body – Fuse, Part of 5	1
12	109355	Fuse 15 Amp ATO or ATC	1
	109102	Fuse 25 Amp ATO or ATC	1
	NN10277	Fuse 30 Amp ATO or ATC	1
13	111642	Barrier – Switch Insulator	2
14	38-1420	Switch – Seat	1
16	110502	Shield – Dirt	1
17	112185	Body – Connector	1
18	115411	Support – Switch	1
19	926671	Bolt	1
20	111332	Switch – PTO Interlock	3
21	79-0060	Voltmeter	1
22	78-0080	Clamp – Voltmeter, Back	1
23	5924	Nut	2

Ref. No.	Part No.	Description	No. Used
24	92-9845	Solenoid	1
25	960152	Bolt – Whizlock	2
26	111069	Cable – Solenoid To Starter	1
27	111074	Cable – Battery, Positive	1
40	109910	Cable – Ground	1
41	100571	Tie – Cable	1
42	3254-2	Washer – Intl. T	1
44	102651	Terminal – Female	8
48	920262	Washer – Special	1
49	3253-3	Washer – Lock	2
50	3218-1	Nut	2
51	78-0020	Meter – Hour (Incl. Ref.# 52-54)	1
52	114017	Clamp – Steel	1
53	920120	Washer – Lock	1
54	915962	Nut – Hex	1
55	8830	Clip	1
59	910478	Screw	2
60	915732	Nut	2
62	116397	Relay	1
63	519337	Clip – Cable	1
64	518105	Terminal	1
65	6921	Terminal	1
69	915740	Nut	1
68	518077	Terminal	2




C-1497

ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	116796	Test Switch	1
2	117217	Switch – Button (Incl. Ref. #2-4)	1
3	111767	Washer	1
4	111359	Nut – Hex	2
5	915732	Nut – Lock	2


Ref. No.	Part No.	Description	No. Used
6	112506	Bracket	1
7	116723	Harness – Wiring	1
8	9107562	Screw	2
9	111343	Bushing Assembly & Indicator Lens	5
10	114825	PC Board w/Lights	1



BATTERY

Ref. No.	Part No.	Description	No. Used
1	111069	Cable – Battery	1
2	113010	Rod – Battery Hold Down	1
3	321-4	Screw – Hex. Hd.	2
4	32103-22	Nut – Wing	2
5	3256-22	Washer	4
6	111069	Cable – Battery	1
7	106948	Tray – Battery	1
9	113969	Hook – Battery	2

Ref. No.	Part No.	Description	No. Used
10	114720	Tube – Battery	1
11	8830	Retainer	1
12	322-2	Screw – Hex. Hd.	1
13	104962	Battery	1
14	3296-43	Nut	2
15	3253-3	Washer – Lock	2
16	109553	Boot – Battery Cable	1




C-1499

WHEELS AND TIRES

Ref. No.	Part No.	Description	No. Used
1	114428	Logo - Hub Cap 12" (Opt.)	2
2	1645	Tube - Rear (Opt.)	2
*	100291	Tube - Cleat Tire (Opt.)	2
3	116742	Tire - Turf Trac, Rear	2
4	7607	Tire - Cleat, (Opt.)	2
5	83-2720	Bolt - Lug	10
6	111516	Wheel - Rear	2
*	110677	Wheel - Cleat (Opt.)	2
7	5108	Stem - Valve	4
8	937108	Key - Woodruff	2
9	3243-5	Screw - Set	4
10	3218-3	Nut	4
11	105763	Hub - Rear	2

Ref. No.	Part No.	Description	No. Used
12	109500	Fitting - Grease	2
14	5210	Washer - Shim .015	2
15	1278	Washer - Shim .050	4
16	110513	Bearing - Ball	4
17	117286	Rim - Front	2
18	109114	Washer - Special Hub Cap	2
19	3272-17	Pin - Cotter	2
20	109154	Hubcap	2
21	116884	Tire - Turf Trac, Front	2
22	100079	Tube - Front" (Opt.)	2
23	114426	Logo - Hub Cap 6" (Opt.)	2
*	117285	Wheel Assembly - Front (Incl. Ref.# 7,12, 16 & 21)	2

*Not Illustrated




C-1500

PTO CLUTCH AND CONTROL

Ref. No.	Part No.	Description	No. Used
1	111234	Lever - PTO Clutch	1
2	9038	Grip	1
3	32151-11	Ring - Grip	1
4	3765	Washer - Shim	2
5	5666	Bushing - Nyliner	1
6	5983	Bushing	1
7	3272-10	Pin - Cotter	3
11	111052	Rod - PTO Clutch	1
13	103125	Spring	1
14	110656	Trunnion	1
16	323-7	Screw - Hex. Hd.	1
17	110669	Plate - PTO	1
18	104859	Spacer	1
19	3296-39	Nut	1
20	933505	Pin - Cotter	1
21	3218-1	Nut	2
22	3256-22	Washer	2
23	110665	Brake Assembly - PTO	1
24	3229-25	Bolt - Carriage	2
25	111240	Bracket - Engine	1

Ref. No.	Part No.	Description	No. Used
28	111314	Pin - Locking	1
29	113107	Clevis	1
30	933274	Pin - Spirol	1
31	113108	Rod - PTO Housing	1
32	933506	Pin - Cotter	1
33	102872	Shaft - Stub	1
34	32120-72	Ring - Retaining	2
35	32120-62	Ring - Retaining	1
36	109842	Bearing - Ball	1
37	103478	Housing - Pulley	1
38	6662	Bearing - Needle	1
39	6663	Seal	1
40	6658	Race - Bearing	1
41	321-8	Bolt - Nylok	4
42	6659	Retainer	2
43	114881	Facing - Clutch Plate	1
45	106695	Push-On Ring	1
47	3253-3	Washer - Lock	1
48	3256-27	Washer	1
49	102870	Bracket Support	1



DECALS

Ref. No.	Part No.	Description	No. Used
1	92-9825	Decal - Hood RH	1
	92-9824	Decal - Hood LH	1
2	111510	Decal - Parking Brake	1
3	111960	Decal - PTO Clutch	1
4	92-9827	Decal - Rear Fender	1
5	92-9826	Decal - Front Hood	1
8	92-9837	Decal - Rear Hood Danger	1
9	119190	Decal - Lower Dash	1
10	74-2470	Decal - Switch Plate	1
11	92-9828	Decal - 312-8 Speed	2

Ref. No.	Part No.	Description	No. Used
12	111926	Decal - Electrical System	1
13	92-8749	Decal - Unidrive	1
14	92-8747	Decal - Attach-A-Matic	2
15	112168	Decal - Lift	1
16	111534	Decal - Hi-Low Shift	1
	KH10191	Decal - Air Cleaner/Lub	1
20	92-8946	Decal - Danger	1
21	88-3200	Decal - Maintenance	1
22	114621	Decal - Noise Rating	1
*	92-1536	Loose Parts Package	1

TORO PART NUMBER INDEX

3316-897

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
1121	Key	33 18 1	7208	Shaft - Reduction Gear	27 27 1
1239	Screw - Set - Special	29 47 1	7213	Bolt - Detent	29 57 1
1243	Cup - Plug	27 28 1	7214	Lever - Shift Hi-Low Range	29 58 1
1278	Washer - Shim	31 13 1	7269	Gear Assembly	29 36 1
1278	Washer - Shim .050	38 15 4	7418	Washer - Thrust	27 20 1
1481	Fitting - Grease, 45°	9 22 2	7451	Pulley - Idler	31 42 1
1504	Bushing - Bronze	29 37 2	7456	Clamp	5 17 4
1516	Bushing - Reverse Idler	29 43 1	7473	Belt - Drive	25 6 1
1518	Bearing - Needle	27 22 2	7607	Tire - Cleat, (Opt.)	38 4 2
1523	Bearing - Needle	27 16 1	7879	Bushing	31 24 2
1529	Bearing - Needle	27 12 1	7896	Washer - Bowed	31 12 1
1532	Bearing - Needle	27 9 2	7896	Washer - Bowed	9 15 1
1542	Bearing - Needle	27 10 1	8043	Bulb - Light, Metal Base	6 14 2
1644	Hitch - Drawbar	10 11 1	8130	Retainer - Spring	33 3 1
1645	Tube - Rear (Opt.)	38 2 2	8616	Spring	10 1 2
2844	Washer - Special	29 78 1	8830	"J"Clip	11 11 1
3023	Clip - Small	6 8 1	8830	"J"Clip	6 27 1
3023	Clip - Speed	7 22 1	8830	Clip	18 12 1
3023	Clip - Wire	11 15 1	8830	Clip	3 22 2
3503	Fork - Shift	27 33 2	8830	Clip	35 55 1
3517	Ball - Detent	29 55 3	8830	Retainer	37 11 1
3527	Gear - Reduction	29 38 1	9038	Grip	39 2 1
3577	Cover - Dust	29 49 1	9038	Grip	10 20 1
3624	Spring	33 4 1	9416	Bearing - Needle	27 11 2
3765	Washer - Shim	39 4 2	9547	Washer - Thrust	29 50 1
3765	Washer - Shim	31 21 1	9593	Band - Brake	29 81 1
3909	Pin - Reverse Idler	29 42 1	9598	Plate - Stop	29 80 1
3912	Gasket - Transmission	29 46 1	100079	Tube - Front (Opt.)	38 22 2
3915	Pin - Locating	27 15 2	100291	Tube - Cleat Tire (Opt.)	38 * 2
4204	Gear Assembly, Reverse	29 41 1	100441	Seal - Brake Shaft	27 18 1
5108	Stem - Valve	38 7 4	100442	Seal - Input Shaft	27 13 1
5173	Gear - Hi & Second	27 29 1	100443	Seal - Axle	27 14 4
5174	Gear Low & Reverse	27 30 1	100571	Tie - Cable	35 41 1
5175	Gear Assembly	27 23 1	101017	Rod - Mid Hitch Lock	10 17 1
5210	Washer - Shim	9 11A/R	101161	Trunnion - Clutch Rod	31 22 1
5210	Washer - Shim .015	38 14 2	101623	Gear - Differential Pinion	29 70 8
5280	Knob - Height Control	33 40 1	101625	Shaft - Pinion	29 52 1
5614	Pin - Shift	27 35 1	101626	Gear 44 Tooth	29 53 1
5615	Rail - Shift, Front	27 31 1	101707	Lock - Attachment	10 24 1
5616	Rail - Shift, Rear	27 32 1	101711	Housing - Front Hitch	10 3 1
5618	Ring - Retaining	10 9 2	101750	Rod - Pivot Latch	10 22 1
5618	Ring - Retaining	9 32 1	101751	Rod - Lock	10 25 1
5638	Axle	9 31 1	101847	Dipstick	29 44 1
5666	Bushing - Nyliner	39 5 1	101850	Rod - Hood Stop	2 19 1
5924	Nut	35 23 2	101884	Nut - Special	35 3 1
5924	Nut	3 25 2	101884	Nut - Special	3 13 1
5979	Bushing - Hood Pivot	2 15 2	101889	Gear - Differential Axle	29 71 2
5983	Bushing	39 6 1	102025	Spacer	31 36 1
6216	Pin & Plate	9 30 1	102138	Switch - Light	3 23 1
6229	Bearing	33 28 1	102592	Tie Rod Asm, RH	9 3 1
6397	Bearing	9 21 1	102644	Plate - Mid Hitch	10 4 2
6472	Bearing - Flanged	9 5 1	102651	Terminal - Female	35 44 8
6542	Grip - Lift Lever	33 6 1	102703	Nipple - Transmission Fill	29 45 1
6658	Race - Bearing	39 40 1	102809	Nut - Special	31 39 1
6659	Retainer	39 42 2	102870	Bracket Support	39 49 1
6662	Bearing - Needle	39 38 1	102872	Shaft - Stub	39 33 1
6663	Seal	39 39 1	102950	Ring - Retaining	3 18 1
6739	Trunnion	33 20 1	102974	Gear Assembly	29 51 1
6820	Grip	31 35 1	103125	Spring	39 13 1
6876	Spacer	11 4 1	103347	Rod - Clutch	31 14 1
6921	Terminal	35 65 1	103478	Housing - Pulley	39 37 1
7201	Shaft - Input	27 19 1	103480	Switch - Clutch Interlock,	35 8 1
7204	Gear Assembly	27 21 1	103543	Bell Crank - Brake Linkage	31 23 1
7205	Gear - Sliding	27 24 1	103628	Spring - Return	31 41 1
7206	Gear - Reduction	27 25 1	104047	Bushing	6 15 1
7207	Bearing - Needle	27 26 2	104048	Valve - Fuel Shut-Off	6 16 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No.	Qty.	Part No.	Description	Pg. Ref. No. No.	Qty.
104859	Spacer	39 18	1	109530	Nut	3 10	1
104926	Switch - Connector Body	35 6	1	109553	Boot - Battery Cable	37 16	1
104962	Battery	37 13	1	109554	Bracket - Belt Guard	5 6	1
105061	Gear - Differential Ring	29 68	1	109842	Bearing - Ball	39 36	1
105202	Base - Taillight, w/Bulb	6 10	2	109910	Cable - Ground	35 40	1
105269	Shaft - Drawbar Hitch	10 10	1	109910	Wire - Ground	11 16	1
105316	Cap - Plunger	33 26	2	109989	Spacer	7 20	4
105316	Cap - Lock Rod	10 19	2	110234	Screw - Hex. Hd.	29 79	1
105453	Key	25 3	1	110502	Shield - Dirt	35 16	1
105503	Bushing	7 19	2	110513	Bearing - Ball	38 16	4
105524	Bracket - Pivot	7 9	2	110636	Pad - Footrest	5 15	2
105763	Hub - Rear	38 11	2	110653	Rod - Height Control	33 34	1
105797	Ring - Retaining	2 16	2	110656	Trunnion	39 14	1
105797	Ring - Retaining	10 26	8	110665	Brake Assembly - PTO	39 23	1
105859	Latch - Front Hitch	10 23	1	110669	Plate - PTO	39 17	1
105875	Axle - Rear	29 72	2	110677	Wheel - Cleat (Opt.)	38 *	2
105876	Ring - Special, Snap	29 73	2	110725	Stick - Shift	29 74	1
105886	Rod - Brake, Front	31 29	1	110727	Rod - Shift Hi-Low Range	29 62	1
105896	Arm - Clutch Rod	31 18	1	110920	Spring - Seat	7 1	2
105900	Rod - Brake, Rear	31 28	1	110960	Fender	6 4	1
106030	Spring - Detent	29 56	2	111034	Plate - Hood Stand	3 21	1
106165	Pulley - Transmission Drive	25 7	1	111052	Rod - PTO Clutch	39 11	1
106193	Bolt - Special	31 43	1	111069	Cable - Battery	37 1	1
106222	Footrest - RH	5 22	1	111069	Cable - Battery	37 6	1
106223	Footrest - LH	5 18	1	111069	Cable - Solenoid To Starter	35 26	1
106234	Tank - Fuel	6 1	1	111071	Bumper	7 17	2
106236	Support - Fuel Tank, RH	6 30	1	111074	Cable - Battery, Positive	35 27	1
106250	Cover - Dust	4 15	1	111196	Cap - Diff End	29 64	2
106257	Rod - Latch	33 2	1	111198	Case-Transmission, LH	27 2	1
106258	Sleeve	33 39	1	111199	Bearing - Ball	27 8	2
106269	Bushing	33 16	2	111200	Case-Transmission, RH	27 1	1
106345	Casting - Lift Lever	33 37	1	111216	Switch - Ignition	35	1
106352	Guard - Lower Belt	5 21	1	111234	Lever - PTO Clutch	39 1	1
106411	Latch - Bracket	33 41	1	111240	Bracket - Engine	39 25	1
106417	Rod - Bell Crank Pivot	31 26	1	111242	Guide - Belt, Bottom	25 14	1
106451	Lever - Parking Brake	31 34	1	111314	Pin - Locking	39 28	1
106522	Chain - Lift	33 22	1	111332	Switch - PTO Interlock	35 20	3
106634	Pin - Hitch	10 13	1	111343	Bushing Assembly	36 9	5
106695	Push-On Ring	39 45	1	111359	Nut - Hex	36 4	2
106719	Drum - Brake	29 77	1	111383	Collar	31 10	3
106858	Clamp	11 7	1	111392	"J"Clip	3 37	1
106948	Tray - Battery	37 7	1	111510	Decal - Parking Brake	40 2	1
107069	Clip	5 12	3	111516	Wheel - Rear	38 6	2
107069	Nut - Speed	4 14	7	111534	Decal - Hi-Low Shift	40 16	1
107374	Washer - Special	29 66	4	111642	Barrier - Switch Insulator	35 13	2
107677	Spring - Brake Return	31 40	1	111757	Edging - Console	3 3	1
107951	Bracket - Fender Front	6 24	1	111767	Washer	36 3	1
107975	Guard - Belt	5 1	1	111926	Decal - Electrical System	40 12	1
108130	Wire - Headlight Ground	2 2	1	111960	Decal - PTO Clutch	40 3	1
108457	Nut - Push	5 3	1	112168	Decal - Lift	40 15	1
108464	Support - Fuel Tank, LH	6 21	1	112185	Body - Connector	35 17	1
108563	Lever - Lift	33 1	1	112213	Muffler	11 8	1
108565	Shaft	33 46	1	112214	Control - Choke	3 9	1
108758	Knob - Gear Shift	29 54	1	112415	Stop - PTO	3 2	1
108881	Nut - Hex	29 67	4	112506	Bracket	36 6	1
109045	Bulb - Light, All Glass	6 *	2	112506	Bracket - Indicator Lights	3 32	1
109102	Fuse 25 Amp ATO or ATC	35	1	112564	Lens - Taillight	6 13	2
109114	Washer - Special Hub Cap	38 18	2	112841	Cap	25 16	1
109154	Hubcap	38 20	2	113010	Rod - Battery Hold Down	37 2	1
109189	Bearing	9 35	1	113107	Clevis	39 29	1
109262	Washer - Special	9 16	2	113108	Rod - PTO Housing	39 31	1
109355	Fuse 15 Amp ATO or ATC	35 12	1	113179	Nut	3 19	1
109459	Clamp	2 3	2	113379	Spindle - RH	9 *	1
109494	Retainer - Headlight RH	2 *	1	113380	Spindle - LH	9 33	1
109495	Retainer - Headlight LH	2 22	1	113443	Tube - Steering	9 17	1
109500	Fitting - Grease	38 12	2	113445	Bar - Lift	33 27	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
113935	Cover - Side, LH	4 16 1	920160	Washer - IntL. T	35 2 1
113969	Hook - Battery	37 9 2	920160	Washer - IntL. T	3 12 1
114017	Clamp - Steel	35 52 1	920225	Washer - Special	31 49 1
114343	Spring - Gas	7 16 1	920248	Washer - Nylon	31 19 3
114344	Spacer	7 11 2	920259	Washer - Special	3 17 1
114345	Bracket	7 14 1	920262	Washer - Special	3 11 1
114426	Logo - Hub Cap 6 (Opt.)	38 23 2	920262	Washer - Special	35 48 1
114428	Logo - Hub Cap 12 (Opt.)	38 1 2	926671	Bolt	2 4 2
114621	Decal - Noise Rating	40 22 1	926671	Bolt	35 19 1
114720	Tube - Battery	37 10 1	926694	Bolt	6 5 2
114813	Pedal - Brake	31 9 1	926694	Bolt	5 26 6
114814	Pedal - Clutch	31 8 1	926694	Screw - Hex. Hd.	4 2 13
114825	PC Board w/Lights	36 10 1	926694	Screw - Hex. Hd.	31 27 1
114881	Facing - Clutch Plate	39 43 1	926694	Screw - Hex. Hd.	33 42 1
115411	Support - Switch	35 18 1	926694	Screw - Hex. Washer Hd.	3 1 3
115854	Control - Throttle	3 34 1	926696	Screw - Hex. Hd.	33 45 2
116000	Bolt - Carriage	5 9 6	926697	Bolt	6 3 2
116338	Switch - Ignition	3 29 1	933148	Pin - Spirol	33 5 1
116338	Switch - Ignition	35 1 1	933156	Pin - Spirol	27 34 2
116397	Relay	35 62 1	933184	Pin - Spirol	29 63 1
116636	Fork - Shift Hi-Low Range	29 59 1	933190	Pin - Spirol	31 17 1
116723	Harness - Wiring	36 7 1	933267	Pin - Spirol	31 50 1
116742	Tire - Turf Trac, Rear	38 3 2	933274	Pin - Spirol	39 30 1
116745	Rod - Pivot	2 18 1	933505	Pin - Cotter	10 14 1
116746	Bracket - RH	2 * 1	933505	Pin - Cotter	39 20 1
116747	Bracket - LH	2 17 1	933505	Pin - Cotter	33 21 2
116796	Test Switch	36 1 1	933505	Pin - Cotter	31 31 1
116884	Tire - Turf Trac, Front	38 21 2	933506	Pin - Cotter	39 32 1
117217	Switch - Button	36 2 1	933507	Pin - Cotter	33 14 2
117255	Engine - 12HP Kohler	11 9 1	937089	Key - Woodruff	29 40 1
117285	Wheel Assembly - Front	38 * 2	937108	Key - Woodruff	38 8 2
117286	Rim - Front	38 17 2	937221	Key - Hi-Pro	25 4 1
117331	Holder - Fuse	5 24 1	960152	Bolt - Whizlock	35 25 2
117343	Latch - Hood	3 31 2	979120	Spacer	10 12 2
117344	Handle Assembly	2 11 2	9107562	Screw	36 8 2
117371	Bolt - Carriage	4 6 4	9151126	Nut	4 4 4
117431	Rivet - Pop	3 30 4	KH10009	Gasket - Flange	13
117432	Rivet - Pop	2 10 4	KH10010	Clip - Hi-Tension	18 18 1
117930	Latch - Mid Hitch	10 21 1	KH10015	Guide - Valve	20 6 2
119190	Decal - Lower Dash	40 9 1	KH10018	Retainer - Spring	21 9 1
120590	Stop - Throttle	3 35 1	KH10028	Insert - Exhaust Valve	20 7 1
120930	Body - Fuse, Part of 5	35 9 1	KH10034	Seal	19 6 1
518077	Terminal	35 68 2	KH10034	Seal	12 7 1
518105	Terminal	35 7 1	KH10035	Pin - Governor Stop	15 3 1
518105	Terminal	35 64 1	KH10040	Screw	15 47 1
518211	Bumper	5 10 2	KH10049	Bearing	20 8 1
519337	Clip - Cable	35 63 1	KH10052	Valve - Intake	21 6 1
910478	Screw	35 59 2	KH10053	Spring - Intake Valve	21 8 1
910762	Screw	3 7 2	KH10054	Retainer - Upper Spring	21 7 2
910792	Screw	3 4 6	KH10055	Gasket	20 16 1
910794	Screw - Machine	5 7 2	KH10056	Plug - Spark	18 17 1
910808	Screw	6 12 4	KH10057	Reed	19 3 1
910837	Bolt - Carriage	5 4 9	KH10058	Gasket	19 1 1
910837	Screw	4 12 7	KH10059	Gasket	23 8 1
910837	Screw	3 20 7	KH10061	Shaft - Governor Gear	20 2 1
911423	Bolt	29 65 4	KH10062	Spring	21 14 1
915551	Nut	6 7 4	KH10067	Ball Bearing	20 3 2
915732	Nut	35 60 2	KH10070	Bushing	15 22 1
915732	Nut - Lock	36 5 2	KH10072	Plate	19 2 1
915740	Nut	5 23 4	KH10074	Valve - Exhaust	21 5 1
915740	Nut	35 69 1	KH10081	Shaft - Balance Gear	20 18 1
915740	Nut - Lock	3 36 2	KH10082	Connector	18 16 1
915960	Nut	3 33 2	KH10087	Washer	15 24 1
915962	Nut - Hex	35 54 1	KH10088	Gasket	23 6 1
920120	Washer - Lock	35 53 1	KH10091	Kit - Stator 15 am	18 9 1
920150	Washer - Lock	3 8 2	KH10093	Gasket	13 2 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
KH10093	Gasket – Bowl Screen	13	KH10279	Baffle – Side Air	16 9 1
KH10094	Gasket	13 6 1	KH10280	Baffle – Inner	16 6 1
KH10094	Gasket – Bowl	13	KH10282	Baffle – Cylinder	16 5 1
KH10095	Gasket	14 5 1	KH10287	Linkage – Choke (Carb. to	15 32 1
KH10107	Screw – Hex. Hd.	17 5 4	KH10289	Screw – Pozidrive T.H.	16 3 3
KH10108	Screw	17 7 1	KH10290	Screw	20 24 1
KH10109	Screw – Idle Speed Adj.	13 19 1	KH10291	Choke Lever Assembly	15 * 1
KH10110	Screw	13 14 4	KH10292	Spring	21 2 1
KH10112	Spacer	17 3 4	KH10293	Lever – Choke Control	15 42 1
KH10112	Spring – Idle Fuel	13 16 1	KH10294	Lever – Throttle Control	15 43 1
KH10113	Spring	13 8 1	KH10295	Lever – Governor	15 27 1
KH10114	Spring – Adj.	13 18 1	KH10296	Spring (Governor to Carb.)	15 31 1
KH10116	Screw	13 1 1	KH10297	Base – Air Cleaner	12 9 1
KH10117	Bowl – Fuel	13 3 1	KH10298	Cover	19 8 1
KH10119	Decal – Float Switch	23 * 1	KH10299	Cover	12 2 1
KH10121	Plate – Throttle	13 13 1	KH10302	Space	15 44 1
KH10123	Connector – 90°	14 3 2	KH10303	Bracket – Clutch Control	15 48 1
KH10124	Fan	17 4 1	KH10304	Bracket – Solenoid	24 * 1
KH10126	Screen	17 6 1	KH10304	Bracket – Starter	24 5 1
KH10128	Ball	13 7 1	KH10305	Kit – Crankshaft	21 16
KH10130	Line – Fuel	14 1 1	KH10308	Clamp	15 49 1
KH10132	Needle – Idle Fuel Adj.	13 15 1	KH10309	Hose	19 11 1
KH10134	Sleeve	23 12 1	KH10310	Pin – Camshaft	21 4 1
KH10135	Tag – Caution	24 * 1	KH10311	Gasket	20 10 1
KH10136	Washer	15 25 1	KH10312	Strap – Lifting	20 23 1
KH10143	Baffle	19 4 1	KH10313	Lead – Violet, Regulator –	18 * 1
KH10144	Screw	20 22 8	KH10319	Pump Assy – Fuel	14 4 1
KH10145	Washer	20 21 9	KH10321	Module – Ignition	18 1 1
KH10146	Gasket	13	KH10322	Kit – Spacer	21 19 2
KH10146	Gasket – Carburetor	13	KH10323	Kit – Drive	24 12 1
KH10147	Spacer .005	21 3 1	KH10324	Kit – Drive Parts	24 13 1
KH10148	Spacer .010	21 * 1	KH10344	Clip	18 * 1
KH10149	Gasket	19 7 1	KH10345	Connector	18 11 1
KH10150	Stud	19 9 1	KH10345	Connector – Female	23 * 1
KH10152	Washer	15 41 2	KH10358	Kit – Choke & Throttle	13 * 1
KH10181	Bolt	24 7 2	KH10412	Cover – Air Cleaner Element	12 4 1
KH10187	Starter Assembly	24 1 1	KH10413	Screw – Hex .Hd.	16 4 6
KH10189	Nut	12 3 1	KH10496	Rotator – Valve	21 13 2
KH10191	Decal – Air Cleaner	12 * 1	KH10515	Kit – Brush	24 9 1
KH10191	Decal – Air Cleaner/Lub	40 19 1	KH10535	Nut – Lock	11 5 1
KH10201	"O" Ring	23 2 1	KH10538	Kit – Governor Cross Shaft	15 26 1
KH10209	Cap – Drive End	24 11 1	KH10539	Tappet – Exhaust Valve	21 12 1
KH10210	End Cap Ass'y	24 8 1	KH10539	Tappet – Intake Valve	21 11 1
KH10215	Regulator – Rectifier	18 14 2	KH10541	Screw	23 5 3
KH10221	Kit – Retainer	21 10 2	KH10543	Screw	18 15 2
KH10231	Baffle – Head	16 1 1	KH10545	Screw	20 14 4
KH10235	Element – Precleaner	12 5 1	KH10545	Screw	15 34 1
KH10236	Element	12 6 1	KH10548	Screw	18 3 2
KH10244	Brace – Starter Tail	24 2 1	KH10549	Screw	24 * 1
KH10247	Armature	24 10 1	KH10549	Screw	24 6 2
KH10248	Pan – Oil	23 7 1	KH10549	Screw	20 13 4
KH10258	Gasket Set w/o Seals	23 * 1	KH10550	Screw	23 9 4
KH10259	Camshaft Assy	21 1 1	KH10552	Screw – Pozidrive	14 7 2
KH10261	Head – Cylinder	20 19 1	KH10556	Washer – Lock	15 38 1
KH10262	Retainer – Piston Pin	22 3 2	KH10562	Plug	20 5 1
KH10263	Flywheel	17 1 1	KH10567	Washer	16 2 1
KH10265	Housing – Blower	16 7 1	KH10569	Washer	14 6 2
KH10266	Adapter – Oil Fill	23 4 1	KH10569	Washer	15 39 1
KH10268	Seal	20 12 1	KH10570	Washer	15 35 1
KH10269	Seal	20 4 1	KH10570	Washer – Flat	18 7 1
KH10270	Dipstick	23 1 1	KH10570	Washer 1/4	18 * 1
KH10272	Gasket	20 9 1	KH10572	Washer	18 2 2
KH10274	Gasket	13 1	KH10574	Retainer	21 20 1
KH10274	Gasket – Carburetor	13	KH10576	Nut – Wing	12 1 1
KH10275	Filter	19 5 1	KH10585	Spacer	15 23 1
KH10278	Elbow	11 6 1	KH10586	Clamp	14 2 2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
KH10588	Key - Woodruff	17 2 1	55-3570	Fuel Cap	6 6 1
KH10600	Screw	15 37 1	62-7770	Key - Ignition, Padded	35 4 1
KH10605	Screw	15 45 1	62-7770	Key - Ignition, Padded	3 14 1
KH10605	Screw - Pozidrive	18 10 4	66-0120	Knob - Control	3 5 1
KH10606	Screw - Hex. Hd.	18 4 1	74-2470	Decal - Switch Plate	40 10 1
KH10607	Screw - Hex. Hd.	24 3 1	76-1420	Steering Wheel	9 12 1
KH10609	Screw	12 8 3	78-0020	Meter - Hour	3 15 1
KH10610	Screw	18 6 1	78-0020	Meter - Hour	35 51 1
KH10610	Screw - Hex. Hd.	24 4 1	78-0080	Clamp - Volt Meter	3 24 1
KH10617	Plug - Cup	21 15 1	78-0080	Clamp - Voltmeter, Back	35 22 1
KH10618	Clip	18 5 1	78-0370	Insert	9 13 1
KH10619	Nut	15 50 1	78-0760	Seat	7 4 1
KH10620	Plug	23 10 4	78-1550	Lever - Lift	33 19 1
KH10624	Nut	15 40 1	78-2680	Frame	10 8 1
KH10626	Screw	15 28 1	78-2880	Shaft - Lower	9 7 1
KH10629	Nut - Pal	15 8 1	78-2900	Tie Rod Assembly, LH	9 27 1
KH10629	Palnut	19 10 1	78-2920	Tie Rod End	9 25 1
KH10660	Kit - Governor Gear	15 1 1	78-2970	Arm - Clutch Idler	31 16 1
KH10661	Cover	20 15 1	78-2990	Plate - Seat Pivot	7 10 1
KH10663	Kit - Float	13 4 1	78-3010	Bracket - Battery Support	4 1 1
KH10666	Washer	17 8 1	78-3020	Plate - Front	4 17
KH10668	Bushing	15 29 1	78-3240	Spring - Gas	31 53 1
KH10672	Carburetor Assembly	13 10 1	78-3250	Spacer	31 60 1
KH10674	Kit - Carburetor w/Linkage	13 *	78-3260	Spacer	31 55 1
KH10677	Gasket - Air Cleaner	13	78-3320	Clamp - Steel	3 26 1
KH10682	Bushing &	13	79-0060	Meter - Volt	3 16 1
KH10682	Bushing	13	79-0060	Voltmeter	35 21 1
KH10682	Bushing - Linkage Natural	13	79-3590	Harness Assy - Wiring	35 5 1
KH10686	Bushing	15 33 1	79-3640	Console	3 6 1
KH10686	Bushing Linkage Black	13	79-4990	Bracket - Fender Support	6 20 1
KH10687	Plate - Bearing	20 11 1	83-2710	Knob - Hi-Lo Range Shift	29 75 1
KH10691	Block - Cylinder	20 1 1	83-2720	Bolt - Lug	38 5 10
KH10693	Carburetor Assembly	13	83-2890	Bearing - Needle	27 17 1
KH10693	Kit - Adjustable Jet	13 *	83-3530	Shaft - Cluster	29 39 1
KH10695	Washer	15 46 1	83-6520	Rod - Lock	10 18 1
KH10696	Kit - Carburetor Repair	13 *	88-2170	Bracket - Belt	4 3 1
KH10697	Gasket	12 10 1	88-2710	Support - Steering Shaft	9 8 1
KH10697	Gasket	13	88-2782	Hood	2 8 1
KH10697	Gasket - Air Cleaner	13	88-3200	Decal - Maintenance	40 21 1
KH10698	Rod - Connecting Std.	22 4 1	92-1525	Hoodstand	4 8 1
KH10699	Rod - Connecting .010	22 * 1	92-1536	Loose Parts Package	40 * 1
KH10700	Gasket	20 20 1	92-4987	Shaft - Upper	9 9 1
KH10701	Carburetor Linkage	13	92-6529	Plate - Shift Cover	4 11 1
KH10701	Linkage (Governor to Carb.)	15 30 1	92-6697	Screw	7 5 4
KH10702	Shaft - Choke	13 20 1	92-8708	Transmission Assembly	27 * 1
KH10703	Set - Ring, Std. & .003	22 1 1	92-8747	Decal - Attach-A-Matic	40 14 2
KH10704	Set - Ring .010	22 * 1	92-8749	Decal - Unidrive	40 13 1
KH10705	Set - Ring .020	22 * 1	92-8749	Decal - Unidrive	29 76 1
KH10706	Set - Ring .030	22 * 1	92-8946	Decal - Danger	4 10 1
KH10707	Shaft w/Lever & Seal	13 12 1	92-8946	Decal - Danger	40 20 1
KH10708	Plate - Choke	13 21 1	92-9511	Line - Fuel 62	6 26 1
KH10709	Jet - Main	13 1	92-9824	Decal - Hood LH	2 * 1
KH10709	Main Jet	13 1	92-9824	Decal - Hood LH	40 1
KH10710	Kit - High Altitude Jet	13 *	92-9825	Decal - Hood RH	40 1 1
KH10711	Piston w/Ring Set Std.	22 2 1	92-9825	Decal - Hood RH	2 7 1
KH10712	Piston w/Ring Set .003	22 * 1	92-9826	Decal - Front Hood	40 5 1
KH10713	Piston w/Ring Set .010	22 * 1	92-9826	Decal - Hood, Front	2 6 1
KH10714	Piston w/Ring Set .020	22 * 1	92-9827	Decal - Rear Fender	40 4 1
KH10715	Piston w/Ring Set .030	22 * 1	92-9828	Decal - 312-8 Speed	40 11 2
KH10721	Miniblock (Less Crankshaft)	20 1	92-9836	Decal - Logo	2 23 1
KH10733	Gasket	13	92-9837	Decal - Danger	2 9 1
KH10826	Kit - Float Switch	23 11 1	92-9837	Decal - Rear Hood Danger	40 8 1
25-3603	Main - Needle	13 17 1	92-9845	Solenoid	35 24 1
NN10277	Fuse 30 Amp ATO or ATC	35 1	237-69	"O"Ring	9 10 1
38-1420	Switch - Seat	7 21 1	2412-98	Clamp	6 19 2
38-1420	Switch - Seat	35 14 1	281-2	Plug - Pipe, Sq. Hd.	27 7 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
281-10	Plug - Pipe, Allen Hd.	27 6 1	3255-25	Washer - Lock	3 27 1
302-5	Fitting - Grease	31 61 2	3256-4	Washer	6 2 2
302-5	Fitting - Grease, Straight	9 34 2	3256-5	Washer	33 36 1
321-2	Screw	18 13 1	3256-21	Washer	6 9 4
321-3	Screw - Hex. Hd.	29 83 2	3256-22	Washer	37 5 4
321-4	Bolt	5 8 2	3256-22	Washer	7 12 2
321-4	Screw - Hex. Hd.	37 3 2	3256-22	Washer	2 14 3
321-8	Bolt - Nylok	39 41 4	3256-22	Washer	39 22 2
321-8	Screw - Hex. Hd.	7 13 2	3256-22	Washer	31 56 2
321-9	Screw - Hex. Hd.	31 59 1	3256-23	Washer	11 3 1
321-31	Screw - Hex. Hd.	31 54 1	3256-23	Washer	7 6 4
322-1	Bolt	9 28 1	3256-23	Washer	33 25 3
322-2	Bolt	6 18 5	3256-23	Washer	6 25 2
322-2	Screw - Hex. Hd.	37 12 1	3256-24	Washer	31 38 2
322-3	Bolt	6 23 6	3256-25	Washer	25 13 3
322-4	Screw - Hex. Hd.	7 18 6	3256-25	Washer	33 55 1
322-5	Screw - Hex. Hd.	7 8 4	3256-26	Washer	31 25 1
322-5	Screw - Hex. Hd.	6 29 2	3256-26	Washer - Flat	10 15 1
322-5	Screw - Hex. Hd.	33 38 3	3256-27	Washer	39 48 1
322-6	Screw - Hex. Hd.	33 24 1	3256-62	Washer	33 15 2
323-5	Bolt	10 6 4	3269-3	Rivet - Pop	6 11 4
323-6	Bolt	9 6 2	3272-1	Pin - Cotter	2 21 2
323-6	Bolt	11 13 2	3272-6	Pin - Cotter	31 15 1
323-7	Screw - Hex. Hd.	39 16 1	3272-10	Pin - Cotter	39 7 3
323-8	Bolt	11 17 2	3272-10	Pin - Cotter	31 20 3
323-9	Bolt	9 19 2	3272-10	Pin - Cotter	33 35 1
323-9	Screw Hex. Hd.	31 37 1	3272-17	Pin - Cotter	38 19 2
323-11	Screw - Hex. Hd.	27 4 5	3272-19	Pin - Cotter	9 23 1
323-16	Screw - Hex. Hd.	27 3 1	3272-21	Pin - Cotter	9 18 1
323-44	Screw - Hex. Hd.	10 16 6	3296-6	Nut	9 24 4
324-5	Bolt	25 11 3	3296-29	Nut	5 16 11
3217-5	Nut	29 48 1	3296-29	Nut	6 22 6
3217-27	Nut - Hex	3 28 1	3296-29	Nut	33 44 4
3218-1	Nut	39 21 2	3296-29	Nut - Lock	5 2 7
3218-1	Nut	35 50 2	3296-29	Nut - Lock	7 3 6
3218-3	Nut	38 10 4	3296-39	Nut	10 2 9
3219-3	Nut	9 26 1	3296-39	Nut	27 5 6
3229-25	Bolt - Carriage	2 20 4	3296-39	Nut	39 19 1
3229-25	Bolt - Carriage	39 24 2	3296-39	Nut	31 32 1
3231-25	Bolt - Carriage	10 5 3	3296-39	Nut	33 56 1
3235-22	Screw - Hex. Hd.	6 28 1	3296-39	Nut	11 12 2
3242-2	Screw - Set	25 5 2	3296-39	Nut - Lock	9 4 4
3243-5	Screw - Set	38 9 4	3296-42	Nut	5 5 1
3245-32	Screw - Set	31 11 3	3296-42	Nut	2 12 4
3246-2	Screw - Set	25 2 2	3296-42	Nut	31 58 2
3253-3	Washer - Lock	37 15 2	3296-42	Nut - Lock	7 15 2
3253-3	Washer - Lock	39 47 1	3296-43	Nut	37 14 2
3253-3	Washer - Lock	29 82 2	32103-22	Nut - Wing	37 4 2
3253-3	Washer - Lock	35 49 2	32120-47	Ring - Retaining	33 29 1
3253-4	Washer	11 2 1	32120-62	Ring - Retaining	39 35 1
3253-4	Washer - Lock	7 2 4	32120-72	Ring - Retaining	39 34 2
3253-4	Washer - Lock	6 17 1	32120-93	Ring - Retaining	9 2 2
3253-4	Washer - Lock	9 29 1	32121-25	Pin - Roll	33 48 1
3253-6	Washer - Lock	25 12 3	32121-103	Pin - Spirol	33 47 1
3253-21	Washer - Lock	10 7 4	32121-111	Pin - Spirol	9 14 1
3253-21	Washer - Lock	11 14 1	32136-5	Nut - Slotted	9 20 1
3254-1	Washer - Lock	6 31 4	32146-2	Nut	31 44 1
3254-2	Washer - Intl. T	2 13 1	32151-11	Ring - Grip	39 3 1
3254-2	Washer - Intl. T	35 42 1	32151-91	Retainer	33 17 1

*Not Illustrated

[illegible]

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number .
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Hood Assembly	2	Breather And Vent	19
Control Panel	3	Crankcase And Cylinder Head	20
Hood Stand And Supports	4	Camshaft, Crankshaft And Valves	21
Belt Guard & Footrest	5	Piston And Rings	22
Fender And Supports	6	Oil Pan And Dipstick	23
Seat	7	Starter	24
Front Axle and Steering	8	Drive Belt And Pulleys	25
Frame & Hitches	10	Mechanical Transmission 8-Speed	26-29
Kohler Engine & Muffler	11	Clutch, Brake and Speed Control Linkage	30
Air Intake	12	Manual Lift Linkage	32
Carburetors	13	Electrical System	34-36
Fuel Pump	14	Battery	37
Governor Linkage	15	Wheel And Tires	38
Baffles And Shrouds	16	P.T.O. Clutch And Control	39
Flywheel	17	Decals	40
Ignition System	18	Numerical Parts List	41

Optional Equipment

Description	Model / Part No.	Description	Model / Part No.
36" Rear Discharge Deck	78305	Wheel Weight, Rear Flush	81117
42" Side Discharge Deck	78345	Tire Chains	82522
42" Rear Discharge Deck	78350	Clevis Hitch	85518
42" Recycler	78355	Chrome Front LoGo Hub Cap	111427
36" Tiller	79370	Chrome Rear LoGo Hub Cap	114428
48" Dozer Blade	79350	Auxiliary Fuel Tank	*83300
50" Grader Blade	79351	Kits	
42" Single Stage Snowthrower	79360	H.D. Spindles, Wheels & Tires	80494
11 cu. ft. Twin Bagger (42" Mower)	79301	Recycler (42' R.D. Mower)	86001
Wheel Weight, Rear	81115	Leaf Baffle (42' S.D. Mower)	85501

* CAN NOT BE USED WITH CLEVIS HITCH OR REAR BAGGER