FORM NO. 3316–916

TORO®


PART NO. 92–9229

PARTS CATALOG

REAR AXLE KIT

For Reelmaster® 450D

Model No. 03700–60001 thru 09999 & 03701–00001 thru 09999



REAR AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3234–12	Screw – Hex. Flange Hd.	2
2	69–8890	Cap – Spindle	2
3	32151–10	Ring – Retaining	2
4	256–304	Washer – Thrust	4
5	69–6470	Bushing – Flange	4
6	58–6520	Decal – Grease	2
7	82–9850	Axle – Rear	1
8	93–0311	Spindle – Wheel L.H.	1
9	69–2990	Screw – Drive	10
10	69–2960	Wheel Rear Hub Assembly (Incl. Ref. #9, 11 & 18)	2
11	254–72	Cup – Bearing Outer	2
12	254–92	Cone – Bearing Outer	2
13	93–0309	Washer	2
14	3220–7	Nut – Jam	2
15	93–0307	Retainer – Nut	2
16	3272–13	Pin – Cotter	2


Ref. No.	Part No.	Description	No. Used
17	69–2970	Cap – Hub	2
18	254–107	Cup – Bearing Inner	2
19	254–106	Cone – Bearing Inner	2
20	69–2980	Seal – Inner	2
21	2116–4	Joint – Ball, R.H.	1
*	2116–3	Joint – Ball, L.H.	1
22	302–33	Fitting – Grease	2
23	2412–7	Clamp Assembly (Incl. Ref. #24 & 26)	2
†24		Nut – Lock	2
25	82–9260	Tie Rod Assembly (Incl. Ref. #21–24, 26 & 28)	1
†26		Screw – Cap Hex. Hd.	2
27	3272–12	Pin – Cotter	4
28	32136–2	Nut – Castle	2
29	32136–13	Nut – Castle	2
30	48–6640	Bushing – Flange	2

*Not Illustrated

†Not Serviceable Separately

TPS

Copyright 1994 The TORO Company




REAR AXLE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
31	48–6660	Washer – Thrust	2
32	82–9840	Hose – Hydraulic	1
33	82–9210	Shaft – Pivot	1
34	60–3670	Pin – Roll	1
35	340–97	Fitting – Hydraulic 90° (Incl. Ref. #38–39)	1
36	77–4800	Cylinder – Steering	1
37	82–9841	Hose – Hydraulic	1
38	237–22	Seal – O–Ring	2

Ref. No.	Part No.	Description	No. Used
39	237–78	Seal – O–Ring	2
†40		Nut – Hex.	1
41	302–5	Fitting – Grease	4
42	69–9810	Ball Joint Assembly (Incl. Ref. #29, 40–41 & 43)	1
†43		Screw – Cap Hex. Hd.	1
44	93–0310	Spindle – Wheel R.H.	1
45	3296–49	Nut – Lock	1
46	3334–945	Tie – Cable	2

†Not Serviceable Separately



T–1209

HYDRAULIC CYLINDER 77–4800

Ref. No.	Part No.	Description	No. Used
1	82–5780	Cap – Threaded	1
2	82–5770	Rod	1
†3		Wiper – Rod	1
†4		U–Cup	1
5	82–5790	Head – Cap	1
†6		Backup Washer	1
†7		O–Ring	1
†8		O–Ring	1
†9		Servon	1
†10		O–Ring	1
11	82–5760	Piston	1
12	82–5750	Nut – Lock	1
†13		Assembly – Barrel	1
14	82–5740	Nut – Jam	1
15	82–5730	Rod Tie, End	1
16	32121–44	Pin – Roll	1
*	82–5800	Kit – Repair, Seal (Incl. Ref. #3, 4, & 6–10)	1

*Not Illustrated
†Not Serviceable Separately

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.