



## Super Bagger Lawn Mower

Model No. 20192 - 290000001 and up.

### Parts Catalog

#### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

#### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                                           | Page     | Description                                         | Page     |
|-------------------------------------------------------|----------|-----------------------------------------------------|----------|
| Deck Housing, Front Wheel and Rear Door Assembly      | ..... 3  | Camshaft Pulley Assembly Honda GCV160L AS3A         | ..... 13 |
| Side Discharge, Transmission and Rear Wheel Assembly  | ..... 4  | Recoil Starter Assembly Honda GCV160L AS3A          | ..... 14 |
| Upper Handle Assembly                                 | ..... 5  | Carburetor Assembly Honda GCV160L AS3A              | ..... 15 |
| Lower Handle Assembly                                 | ..... 6  | Fan Cover and Fuel Tank Assembly Honda GCV160L AS3A | ..... 16 |
| Engine and Blade Assembly                             | ..... 7  | Air Cleaner Assembly Honda GCV160L AS3A             | ..... 18 |
| Rear Bag Assembly                                     | ..... 8  | Muffler Assembly Honda GCV160L AS3A                 | ..... 19 |
| Cylinder Barrel Assembly Honda GCV160L AS3A           | ..... 9  | Flywheel Assembly Honda GCV160L AS3A                | ..... 20 |
| Oil Pan Assembly Honda GCV160L AS3A                   | ..... 10 | Control Assembly Honda GCV160L AS3A                 | ..... 21 |
| Crankshaft Assembly Honda GCV160L AS3A                | ..... 11 | Choke Base Assembly Honda GCV160L AS3A              | ..... 22 |
| Piston and Connecting Rod Assembly Honda GCV160L AS3A | ..... 12 | Label Assembly Honda GCV160L AS3A                   | ..... 23 |
|                                                       |          | Attachments and Accessories List                    | ..... 24 |


## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HWHTF. .... hex washer head thread forming   |
| ASM. .... assembly                         | HYD. .... hydraulic                          |
| BBC. .... blade brake clutch               | LH. .... left hand                           |
| CARR. .... carriage                        | NI. .... nylon insert                        |
| CCW. .... counter clock wise               | NPTF. .... national pipe thread fine         |
| CW. .... clockwise                         | PFH. .... phillips flat head                 |
| DEG. .... degrees                          | PPH. .... phillips pan head                  |
| ECM. .... electronic control module        | PPHTF. .... phillips pan head thread forming |
| EXT. .... external                         | PRH. .... phillips round head                |
| FH. .... flat head                         | PTH. .... phillips truss head                |
| GA. .... gauge                             | PTO. .... power-take-off                     |
| HD. .... heavy-duty                        | RH. .... right hand                          |
| HF. .... hex flange                        | ROPS. .... roll-over protection system       |
| HH. .... hex head                          | SFH. .... slotted fillister head             |
| HHF. .... hex head flange                  | SHH. .... slotted hex head                   |
| HHFTF. .... hex head flange thread forming | SHWH. .... slotted hex washer head           |
| HJ. .... hex jam                           | SPH. .... slotted pan head                   |
| HLH. .... hex lag head                     | SQH. .... square head                        |
| HOC. .... height-of-cut                    | SRH. .... slotted round head                 |
| HSBH. .... hex socket button head          | STD. .... standard                           |
| HSFH. .... hex socket flat head            | TAP. .... self tapping                       |
| HS. .... hex socket head                   | TTH. .... torx truss head                    |
| HWH. .... hex washer head                  |                                              |

## Footnotes


- ① Obtain parts from [www.honda-engines.com](http://www.honda-engines.com)



## Deck Housing, Front Wheel and Rear Door Assembly

| Ref  | Part No.    | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 117-4167    | 1    | Housing ASM       |
| 1:2  | 107-3889    | 1    | Decal-Safety      |
| 1:3  | 94-8072     | 1    | Decal-Danger      |
| 2    | 110-9415-03 | 1    | Mount-Handle, LH  |
| 3    | 614650      | 2    | Bolt-Shoulder     |
| 4    | 117-4103    | 2    | 8 Inch Wheel ASM  |
| 5    | 614672      | 2    | Bolt-Shoulder     |
| 6    | 40-1940     | 2    | Washer            |
| 7    | 110-9421    | 1    | Arm-Pivot, RH     |
| 8    | 117-5902    | 1    | Decal-Quick Stow  |
| 9    | 110-9434    | 2    | Arm-Spring, Front |
| 10   | 110-0549    | 2    | Knob-HOC          |
| 12   | 108-7476    | 6    | Screw-Plastite    |
| 13   | 3296-39     | 2    | Nut-Lock, NI      |
| 14   | 115-3177    | 1    | Cover-Rear        |
| 14:2 | 114-2820    | 1    | Decal-Warning     |
| 15   | 110-9455    | 1    | Tunnel            |
| 16   | 110-9446    | 1    | Plug-Mulch, LH    |
| 17   | 110-9448    | 1    | Latch-Plug, Mulch |
| 18   | 110-9447    | 1    | Plug-Mulch, RH    |
| 19   | 110-9416-03 | 1    | Mount-Handle, RH  |
| 20   | 110-1786    | 1    | Module-Switch     |
| 21   | 94-1610     | 2    | Nut-Clip          |
| 23   | 108-0965    | 2    | Screw-PTH         |


| Ref | Part No. | Qty. | Description        |
|-----|----------|------|--------------------|
| 24  | 110-9420 | 1    | Arm-Pivot, LH      |
| 26  | 117-4164 | 1    | Decal-Super Bagger |
| 28  | 110-9458 | 1    | Spring-Extension   |
| 30  | 49-2040  | 11   | Screw-HWHTF        |
| 31  | 110-9468 | 1    | Mulch Plug ASM     |
| 32  | 110-9413 | 1    | Baffle-Rear        |
| 33  | 3256-14  | 1    | Washer-Flat        |
| 34  | 110-9457 | 1    | Decal-Plug, Mulch  |
| 35  | 3256-22  | 2    | Washer-Flat        |



## Side Discharge, Transmission and Rear Wheel Assembly


| Ref | Part No.    | Qty. | Description           |
|-----|-------------|------|-----------------------|
| 1   | 614650      | 2    | Bolt-Shoulder         |
| 2   | 117-4104    | 2    | Rear Wheel ASM        |
| 3   | 32151-61    | 2    | Ring-Retaining        |
| 4   | 110-9417    | 2    | Pinion                |
| 5   | 36-4780     | 2    | Washer-Plain          |
| 6   | 108-7476    | 3    | Screw-Plastite        |
| 7   | 117-4197    | 2    | Wheel Cover ASM       |
| 7:2 | 614426      | 1    | Washer-Stepped        |
| 8   | 32151-36    | 2    | Ring-Retaining        |
| 9   | 108-9344    | 1    | Arm-Rear Pivot, LH    |
| 10  | 110-9445    | 2    | Arm-Spring, Rear      |
| 11  | 110-0549    | 2    | Knob-HOC              |
| 12  | 110-9422    | 2    | Retainer-Bearing      |
| 13  | 104-8699    | 2    | Bearing-Ball          |
| 14  | 110-9429    | 1    | V-Belt                |
| 15  | 112-8768    | 1    | Shield-Trailing       |
| 16  | 114-2812    | 1    | Transmission ASM      |
| 17  | 105-3028    | 1    | Chute-Discharge, Side |
| 18  | 108-9343    | 1    | Arm-Rear Pivot, RH    |
| 19  | 114-7977-03 | 1    | Bracket-Transmission  |
| 20  | 99-8445     | 2    | Screw-HWH             |
| 21  | 99-5293     | 1    | Spring-Torsion        |
| 22  | 112-6416    | 1    | Bracket-Cover         |
| 23  | 99-5291     | 1    | Rod-Cover             |

| Ref  | Part No. | Qty. | Description        |
|------|----------|------|--------------------|
| 24   | 106-8376 | 1    | Discharge Door ASM |
| 24:2 | 107-0795 | 1    | Latch-Door         |
| 24:3 | 107-7456 | 1    | Cap-Door           |
| 24:4 | 107-7461 | 1    | Screw-Plastite     |
| 25   | 65-2720  | 1    | Ring-Clip, Locking |
| 26   | 24-7922  | 1    | Cover-Shaft, Drive |
| 27   | 114-2755 | 2    | Cap-Bearing        |
| 28   | 117-1092 | 2    | Screw-PTH          |




Upper Handle Assembly

| Ref | Part No.    | Qty. | Description         |  |  |  |  |
|-----|-------------|------|---------------------|--|--|--|--|
| 1   | 108-0974    | 1    | Upper Handle ASM    |  |  |  |  |
| 2   | 112-8754    | 2    | Sleeve-Inner        |  |  |  |  |
| 3   | 112-1544    | 1    | Sleeve-Outer, LH    |  |  |  |  |
| 4   | 107-3869    | 2    | Spring-Compression  |  |  |  |  |
| 5   | 104-0858    | 1    | Bolt-Shoulder       |  |  |  |  |
| 6   | 112-8764    | 1    | Stop-Pivot          |  |  |  |  |
| 7   | 110-1819-03 | 1    | Bail-Brake          |  |  |  |  |
| 8   | 112-1545    | 1    | Sleeve-Outer, RH    |  |  |  |  |
| 9   | 106-4161    | 1    | Knob-Handle         |  |  |  |  |
| 10  | 107-3867-03 | 1    | Tube-Cross          |  |  |  |  |
| 11  | 107-3871    | 1    | Rod-Threaded        |  |  |  |  |
| 12  | 107-3865    | 2    | Mount-Handle, Lower |  |  |  |  |
| 13  | 110-9465    | 1    | Cable-Traction      |  |  |  |  |
| 14  | 107-3903    | 1    | Cable-Brake         |  |  |  |  |
| 15  | 112-8801    | 1    | Clamp-Cable         |  |  |  |  |
| 17  | 3296-73     | 2    | Nut-Lock, NI        |  |  |  |  |
| 18  | 3256-1      | 1    | Washer-Flat         |  |  |  |  |
| 19  | 107-3893    | 1    | Lever-Traction      |  |  |  |  |
| 21  | 321-5       | 1    | Screw-HH            |  |  |  |  |
| 22  | 108-0959    | 1    | Pin-Handle          |  |  |  |  |
| 23  | 108-1008    | 1    | Pin-Bail, LH        |  |  |  |  |
| 25  | 117-5901    | 1    | Decal-Personal Pace |  |  |  |  |
| 26  | 108-9378    | 1    | Retainer-Push On    |  |  |  |  |




Lower Handle Assembly

| Ref | Part No.    | Qty. | Description         |  |  |  |  |
|-----|-------------|------|---------------------|--|--|--|--|
| 1   | 108-0988    | 3    | Screw-CARR          |  |  |  |  |
| 2   | 3296-73     | 8    | Nut-Lock, NI        |  |  |  |  |
| 3   | 107-3887-03 | 2    | Tube-Lower          |  |  |  |  |
| 4   | 114-2791    | 2    | Mount-Handle, Lower |  |  |  |  |
| 6   | 95-4453     | 4    | Screw               |  |  |  |  |
| 7   | 112-8755    | 1    | Rod-Release, Handle |  |  |  |  |
| 8   | 117-4141    | 1    | Guide-Rope, Lower   |  |  |  |  |
| 9   | 107-3908    | 1    | Guide-Rope, Upper   |  |  |  |  |
| 10  | 106-6805    | 1    | Guide-Cable         |  |  |  |  |
| 11  | 107-3944-03 | 2    | Plate               |  |  |  |  |
| 12  | 49-2040     | 1    | Screw-HWHTF         |  |  |  |  |
| 13  | 112-1542    | 1    | Spring-Extension    |  |  |  |  |
| 14  | 112-1539    | 1    | Plate-Rod, Release  |  |  |  |  |
| 15  | 110-1823-03 | 1    | Lever-Release       |  |  |  |  |



**Engine and Blade Assembly**

| Ref | Part No.    | Qty. | Description                |  |  |  |  |
|-----|-------------|------|----------------------------|--|--|--|--|
| 1   | 112-8789    | 1    | Bolt-Shoulder              |  |  |  |  |
| 2   | 108-3766-03 | 1    | Support-Blade              |  |  |  |  |
| 3   | 108-0954-03 | 1    | Blade-21 Inch              |  |  |  |  |
| 4   | 114-2774    | 1    | Driver-Blade               |  |  |  |  |
| 5   | 106-3999    | 1    | Spacer-Driver              |  |  |  |  |
| 6   | 108-8110-03 | 1    | Guide-Belt                 |  |  |  |  |
| 7   | 32144-102   | 3    | Screw-HWH                  |  |  |  |  |
| 8   | 117-5955    | 1    | Decal-Engine               |  |  |  |  |
| 10  | 92-1701     | 1    | Stop-Rope                  |  |  |  |  |
| 11  | 117-5903    | 1    | Engine-Honda, Gcv160L As3A |  |  |  |  |
| 12  | 98-1394     | 1    | Screw-HWH                  |  |  |  |  |
| 15  | 117-2718    | 1    | Decal-Arrester, Spark      |  |  |  |  |




## Rear Bag Assembly

| Ref | Part No.    | Qty. | Description   |
|-----|-------------|------|---------------|
| 1   | 117-4191    | 1    | Grass Bag ASM |
| 2   | 112-8750-03 | 1    | Frame-Bag     |

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |






E-3

# Cylinder Barrel Assembly

## Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                                                  |
|-----|---------------|------|--------------------------------------------------------------|
| ❶1  | 12000-Z0L-840 | 1    | Cylinder ASM                                                 |
| ❶3  | 12209-ZM0-003 | 1    | Seal-Stem, Valve                                             |
| ❶4  | 12310-Z0J-000 | 1    | Cover-Head, Cylinder                                         |
| ❶4  | 12311-ZL8-D00 | 1    | Cover-Head                                                   |
| ❶4  | 12311-ZL8-000 | 1    | Cover-Head                                                   |
| ❶5  | 12355-ZL8-000 | 1    | Cover-Breather (Breather Valve ASM)                          |
| ❶6  | 14711-Z0J-000 | 1    | Valve-Intake (Rocknel) (Engine Serial Numbers Up To 6330748) |
| ❶6  | 14711-Z0J-800 | 1    | Valve-Intake (Engine Serial Numbers Starting At 6330749)     |
| ❶7  | 14721-ZL8-000 | 1    | Valve-Exhaust                                                |
| ❶8  | 14751-ZL8-000 | 2    | Spring-Valve                                                 |
| ❶9  | 14771-Z0J-000 | 2    | Retainer-Spring, Valve                                       |
| ❶10 | 90013-883-000 | 4    | Bolt-Flange (6X12) (C T200)                                  |
| ❶11 | 90014-952-000 | 1    | Bolt-Flange (6X14) (C T200)                                  |

| Ref  | Part No.      | Qty. | Description                     |
|------|---------------|------|---------------------------------|
| ❶ 12 | 91201-ZL8-003 | 1    | Seal (25.4X62X6)                |
| ❶ 13 | 98079-56846   | 1    | Spark Plug (B P R 6E S) (N G K) |




E-6

## Oil Pan Assembly Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                 |
|-----|---------------|------|-----------------------------|
| ❶1  | 11300-ZM0-811 | 1    | Oil Pan ASM                 |
| ❶2  | 15625-ZE6-000 | 1    | Gasket-Cap, Oil Filler      |
| ❶4  | 15631-ZM0-000 | 1    | Extension-Filler, Oil       |
| ❶5  | 15639-ZM0-000 | 1    | Washer-Lock, Extension      |
| ❶6  | 15650-ZM0-801 | 1    | Oil Level Gauge ASM         |
| ❶8  | 16508-ZM0-010 | 1    | Shaft-Holder, Governor      |
| ❶9  | 16510-ZM0-010 | 1    | Governor ASM                |
| ❶10 | 16511-ZL8-000 | 2    | Weight-Governor             |
| ❶11 | 16512-ZM0-000 | 1    | Holder-Weight, Governor     |
| ❶12 | 16513-ZE1-000 | 2    | Pin-Weight, Governor        |
| ❶13 | 16531-ZE1-000 | 1    | Slider-Governor             |
| ❶14 | 16541-ZM0-000 | 1    | Shaft-Arm, Governor         |
| ❶15 | 90014-952-000 | 1    | Bolt-Flange (6X14) (C T200) |

| Ref | Part No.      | Qty. | Description                  |
|-----|---------------|------|------------------------------|
| ❶16 | 90121-952-000 | 8    | Bolt-Flange (6X25) (C T 200) |
| ❶18 | 90451-ZE1-000 | 1    | Washer-Thrust (6Mm)          |
| ❶19 | 90602-ZE1-000 | 1    | Clip-Holder, Governor        |
| ❶20 | 91202-ZL8-003 | 1    | Seal-Oil (28X41.25X6)        |
| ❶22 | 91356-MA6-005 | 1    | O-Ring (14.8X24) (N O K)     |
| ❶23 | 94101-06800   | 1    | Washer-Plain (6Mm)           |
| ❶25 | 94251-08000   | 1    | Pin-Lock (8Mm)               |
| ❶26 | 94301-08200   | 2    | Pin-Dowel (8X20)             |




E-7

# Crankshaft Assembly

## Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description   |
|-----|---------------|------|---------------|
| ❶3  | 13310-ZM0-610 | 1    | Crankshaft    |
| ❶7  | 90402-ZL8-000 | 1    | Washer-Thrust |




E-8

## Piston and Connecting Rod Assembly Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                     |
|-----|---------------|------|---------------------------------|
| ❶1  | 13010-Z0L-014 | 1    | Piston Ring Set (STD) (Teikoku) |
| ❶2  | 13101-Z2A-010 | 1    | Piston                          |
| ❶3  | 13111-ZE0-000 | 1    | Pin-Piston                      |
| ❶4  | 13200-Z0J-000 | 1    | Connecting Rod ASM              |
| ❶5  | 90001-ZE1-000 | 2    | Bolt-Rod, Connecting            |
| ❶6  | 90551-ZE0-000 | 2    | Clip-Pin, Piston (13Mm)         |


|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |



E-10

Camshaft Pulley Assembly  
Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                |  |  |  |  |
|-----|---------------|------|----------------------------|--|--|--|--|
| ❶1  | 14320-ZL8-010 | 1    | Pulley-Camshaft            |  |  |  |  |
| ❷2  | 14324-ZL8-000 | 1    | Shaft-Pulley, Cam          |  |  |  |  |
| ❸3  | 14400-Z0J-014 | 1    | Belt-Timing (84H U7 G-200) |  |  |  |  |
| ❹4  | 14431-Z0J-000 | 1    | Arm-Rocker, Intake Valve   |  |  |  |  |
| ❺5  | 14441-Z0J-000 | 1    | Arm-Rocker, Exhaust Valve  |  |  |  |  |
| ❻6  | 14461-ZL8-000 | 2    | Shaft-Arm, Rocker          |  |  |  |  |
| ❼7  | 90012-333-000 | 2    | Screw-Adjusting, Tappet    |  |  |  |  |
| ❽8  | 90206-001-000 | 2    | Nut-Adjusting, Tappet      |  |  |  |  |
| ❾9  | 91301-ZM0-V31 | 1    | O-Ring (6.8X19) (Arai)     |  |  |  |  |




E-11

# Recoil Starter Assembly

## Honda GCV160L AS3A

| Ref | Part No.        | Qty. | Description                                    |  |  |  |  |
|-----|-----------------|------|------------------------------------------------|--|--|--|--|
| ❶2  | 28400-Z0L-V20ZA | 1    | Recoil Starter ASM (N H1) (Long Rope) (Black)  |  |  |  |  |
| ❶2  | 28400-Z0L-V20ZC | 1    | Recoil Starter ASM (T98) (Long Rope) (Mtd Red) |  |  |  |  |
| ❶3  | 28461-ZL8-003   | 1    | Grip-Starter                                   |  |  |  |  |
| ❶4  | 28462-Z0L-V20   | 1    | Rope-Starter, Recoil (Black) (Long Type)       |  |  |  |  |
| ❶5  | 90201-ZM0-000   | 3    | Nut-Flange (6Mm)                               |  |  |  |  |





E-14

## Carburetor Assembly Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                                                            |
|-----|---------------|------|------------------------------------------------------------------------|
| ❶1  | 16010-883-015 | 1    | Gasket Set                                                             |
| ❶2  | 16013-ZL1-003 | 1    | Float Set                                                              |
| ❶3  | 16015-887-782 | 1    | Float Chamber Set (Engine Serial Numbers Up To B B62Z A)               |
| ❶5  | 16024-ZE1-811 | 1    | Drain Screw Set (Engine Serial Numbers Up To B B62Z A)                 |
| ❶6  | 16028-ZE0-005 | 1    | Screw Set                                                              |
| ❶6  | 16028-ZK7-S91 | 1    | Screw Set                                                              |
| ❶8  | 16100-Z0L-851 | 1    | Carburetor Assy (B B62Z A) (Engine Serial Numbers Up To 7161134)       |
| ❶8  | 16100-Z0L-852 | 1    | Carburetor Assy (B B62Z B) (Engine Serial Numbers Starting At 7161135) |
| ❶9  | 16155-ZM0-013 | 1    | Valve-Float                                                            |
| ❶10 | 16166-ZM0-003 | 1    | Nozzle-Main                                                            |
| ❶13 | 16211-ZL8-000 | 1    | Insulator-Carburetor                                                   |
| ❶14 | 16212-ZL8-000 | 1    | Gasket-Insulator                                                       |
| ❶15 | 16221-883-800 | 2    | Gasket-Carburetor (Engine Serial Numbers Up To 6349022)                |

| Ref | Part No.       | Qty. | Description                                                    |
|-----|----------------|------|----------------------------------------------------------------|
| ❶16 | 16228-ZL8-000  | 1    | Gasket-Carburetor                                              |
| ❶19 | 19650-ZM0-000  | 1    | Guide-Air (Engine Serial Numbers Up To 6349022)                |
| ❶20 | 93500-05006-0H | 1    | Screw-Pan (5X6)                                                |
| ❶22 | 99101-124-0600 | 1    | Jet-Main (No.60) (Optional Equipment)                          |
| ❶22 | 99101-124-0620 | 1    | Jet-Main (No.62) (Optional Equipment)                          |
| ❶22 | 99101-124-0650 | 1    | Jet-Main (No.65)                                               |
| ❶23 | 19651-Z0L-000  | 1    | Guide-Air (Engine Serial Numbers Starting At 6349023)          |
| ❶24 | 16015-Z0L-881  | 1    | Float Chamber Set (Engine Serial Numbers Starting At B B62Z B) |

## Fan Cover and Fuel Tank Assembly Honda GCV160L AS3A






## Fan Cover and Fuel Tank Assembly

### Honda GCV160L AS3A

| Ref | Part No.        | Qty. | Description                                                                  | Ref | Part No.        | Qty. | Description                                                                         |
|-----|-----------------|------|------------------------------------------------------------------------------|-----|-----------------|------|-------------------------------------------------------------------------------------|
| ❶3  | 16854-ZH8-000   | 1    | Supporter-Rubber (107Mm)<br>(Engine Serial Numbers Up To 6901760)            | ❶29 | 95002-02080     | 2    | Clip-Tube (B8)                                                                      |
| ❶5  | 16950-ZM0-003   | 1    | Petcock ASM (Engine Serial Numbers Up To 6901760)                            | ❶30 | 95002-02100     | 1    | Clip-Tube (B10) (Engine Serial Numbers Up To 6901760)                               |
| ❶6  | 16952-ZA8-800   | 1    | Filter-Fuel                                                                  | ❶33 | 95002-70000     | 1    | Clip-Tube (C11) (Engine Serial Numbers Up To 6901760)                               |
| ❶7  | 17511-Z0L-000   | 1    | Tank-Fuel (Engine Serial Numbers Up To 6183839)                              | ❶36 | 90043-ZL8-000   | 1    | Bolt-Stud (H=42.5Mm)                                                                |
| ❶7  | 17511-Z0L-010   | 1    | Tank-Fuel (Engine Serial Numbers Starting At 6183840)                        | ❶37 | 16950-Z0Y-003   | 1    | Petcock ASM (Engine Serial Numbers Starting At 6901761)                             |
| ❶8  | 17514-Z0L-000   | 1    | Seal-Neck, Fuel Filler                                                       | ❶38 | 16961-Z0L-900   | 1    | Stay-Petcock (Engine Serial Numbers Starting At 6901761)                            |
| ❶9  | 17516-Z0L-000   | 1    | Clip-Mounting, Tank                                                          | ❶39 | 90013-883-000   | 1    | Bolt-Flange (6X12) (C T200)<br>(Engine Serial Numbers Starting At 6901761)          |
| ❶10 | 17532-Z0L-000   | 1    | Rubber A-Mounting, Tank                                                      | ❶40 | 90015-883-000   | 1    | Bolt-Flange (6X28) (C T200)<br>(Engine Serial Numbers Starting At 6901761)          |
| ❶11 | 17533-Z0L-000   | 1    | Rubber B-Mounting, Tank                                                      | ❶41 | 93913-25220     | 1    | Screw-Tapping (5X12) (P O)<br>(Engine Serial Numbers Starting At 6901761)           |
| ❶12 | 17534-Z0L-000   | 1    | Nut-Mounting, Tank                                                           | ❶42 | 95001-45003-50M | 1    | Fuel-Hose, Bulk (4.5X3000)<br>(4.5X110) (Engine Serial Numbers Starting At 6901761) |
| ❶13 | 17620-Z0J-800   | 1    | Fuel Tank Cap ASM                                                            | ❶43 | 95001-75008-60M | 1    | Fuel-Hose, Bulk (7.5X8000)<br>(7.3X160) (Engine Serial Numbers Starting At 6901761) |
| ❶14 | 17636-Z0L-000   | 1    | Gauge-Level, Fuel                                                            | ❶44 | 95002-02120     | 2    | Clip-Tube (B12) (Engine Serial Numbers Starting At 6901761)                         |
| ❶16 | 17701-Z0L-810   | 1    | Tube-Tank, Fuel (Engine Serial Numbers Up To 6901760)                        |     |                 |      |                                                                                     |
| ❶17 | 17702-ZM0-800   | 1    | Tube-Fuel (Engine Serial Numbers Starting At 6901760)                        |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-860ZA | 1    | Cover-Fan (Nh1) (Black) (Engine Serial Numbers Up To 6702082)                |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-860ZC | 1    | Cover-Fan (T89) (Craftsman Red) (Engine Serial Numbers Up To 6702082)        |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-860ZD | 1    | Cover-Fan (T93) (Husqvarna Gray) (Engine Serial Numbers Up To 6702082)       |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-860ZE | 1    | Cover-Fan (T98) (M T D Red) (Engine Serial Numbers Up To 6702082)            |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-861ZA | 1    | Cover-Fan (Nh1) (Black) (Engine Serial Numbers Starting At 6702083)          |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-861ZC | 1    | Cover-Fan (T89) (Craftsman Red) (Engine Serial Numbers Starting At 6702083)  |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-861ZD | 1    | Cover-Fan (T93) (Husqvarna Gray) (Engine Serial Numbers Starting At 6702083) |     |                 |      |                                                                                     |
| ❶19 | 19610-Z0L-861ZE | 1    | Cover-Fan (T98) (M T D Red) (Engine Serial Numbers Starting At 6702083)      |     |                 |      |                                                                                     |
| ❶20 | 19619-ZL8-300   | 3    | Collar-Cover, Fan                                                            |     |                 |      |                                                                                     |
| ❶21 | 91501-Z0L-800   | 1    | Collar-Petcock, Fuel (Engine Serial Numbers Up To 6901760)                   |     |                 |      |                                                                                     |
| ❶23 | 90043-ZL8-000   | 2    | Bolt-Stud (H=42.5Mm)                                                         |     |                 |      |                                                                                     |
| ❶26 | 93891-05010-08  | 1    | Screw-Washer (5X10) (Engine Serial Numbers Up To 6901760)                    |     |                 |      |                                                                                     |




E-15

# Air Cleaner Assembly

## Honda GCV160L AS3A

| Ref | Part No.       | Qty. | Description                                                       |  |  |  |  |
|-----|----------------|------|-------------------------------------------------------------------|--|--|--|--|
| ❶1  | 15721-ZM0-000  | 1    | Tube-Breather                                                     |  |  |  |  |
| ❶2  | 17211-ZL8-023  | 1    | Element-Cleaner, Air                                              |  |  |  |  |
| ❶3  | 17220-ZM0-000  | 1    | Air Cleaner Case ASM (Engine Serial Numbers Up To 6624355)        |  |  |  |  |
| ❶3  | 17220-ZM0-010  | 1    | Air Cleaner Case ASM                                              |  |  |  |  |
| ❶4  | 17228-ZM0-000  | 1    | Gasket-Cleaner, Air                                               |  |  |  |  |
| ❶5  | 17231-Z0L-030  | 1    | Cover-Cleaner, Air                                                |  |  |  |  |
| ❶6  | 90003-ZM0-000  | 2    | Bolt-Flange (6X86) (C T200) (Engine Serial Numbers Up To 6349022) |  |  |  |  |
| ❶6  | 90003-ZM0-010  | 2    | Bolt, Flange (6X85) (C T200)                                      |  |  |  |  |
| ❶7  | 95701-06014-08 | 1    | Bolt-Flange (6X14) (Engine Serial Numbers Up To 6624355)          |  |  |  |  |




E-16

# Muffler Assembly

## Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                                 |  |  |  |  |
|-----|---------------|------|---------------------------------------------|--|--|--|--|
| ❶   | 06180-Z0J-000 | 1    | Spark Arrester Kit (Optional Equipment)     |  |  |  |  |
| ❷   | 18310-ZM0-000 | 1    | Muffler                                     |  |  |  |  |
| ❸   | 18321-Z0L-J00 | 1    | Protector-Muffler                           |  |  |  |  |
| ❺   | 18350-ZL8-000 | 1    | Arrester-Spark (Optional Equipment)         |  |  |  |  |
| ❻   | 18356-ZL8-000 | 1    | Plate-Number, Arrester (Optional Equipment) |  |  |  |  |
| ❼   | 18381-ZL8-305 | 1    | Gasket-Muffler (Optional Equipment)         |  |  |  |  |
| ❽   | 90004-ZL8-000 | 2    | Bolt-Flange (6X79) (C T200)                 |  |  |  |  |
| ❾   | 90013-883-000 | 3    | Bolt-Flange (6X12) (C T200)                 |  |  |  |  |
| ❾❶  | 90055-ZE1-000 | 1    | Screw-Tapping (4X6) (Optional Equipment)    |  |  |  |  |




E-19

**Flywheel Assembly**  
**Honda GCV160L AS3A**


| Ref | Part No.      | Qty. | Description                                                            |
|-----|---------------|------|------------------------------------------------------------------------|
| ❶1  | 11344-MB0-000 | 1    | Grommet A-Cover, Rear (8X16X6.6) (Engine Serial Numbers Up To 7132770) |
| ❶1  | 11344-Z0L-800 | 1    | Grommet A-Cover, Rear (8X16X8) (Engine Serial Numbers Up To 7132770)   |
| ❷2  | 13331-357-000 | 1    | Key-Woodruff, Special (25X18)                                          |
| ❹4  | 30500-ZL8-004 | 1    | Ignition Coil ASM (Use For Flywheel Of Tec)                            |
| ❺5  | 31105-ZM0-000 | 1    | Flywheel ASM (Use For Ignition Coil Of Tec)                            |
| ❹9  | 32195-ZM0-800 | 1    | Wire-Switch, Stop                                                      |
| ❶10 | 35120-ZM0-003 | 1    | Engine Stop Switch ASM (N C)                                           |
| ❶11 | 51125-Z0L-003 | 1    | Holder-Wire (Fastex)                                                   |
| ❶11 | 90681-959-003 | 1    | Clip A-Cable (3.8Mm Black) (Nifco)                                     |
| ❶13 | 75110-Z0L-800 | 1    | Brake ASM (Engine Serial Numbers Up To 7132770)                        |
| ❶13 | 75110-Z0Y-000 | 1    | Brake ASM (Engine Serial Numbers Starting At 7132771)                  |
| ❶15 | 75113-ZM0-000 | 1    | Spring-Lever, Brake                                                    |
| ❶16 | 90018-ZE1-000 | 1    | Bolt-Flange (6X23) (C T200)                                            |

| Ref | Part No.       | Qty. | Description                                                             |
|-----|----------------|------|-------------------------------------------------------------------------|
| ❶18 | 90014-952-000  | 1    | Bolt-Flange (6X14) (C T200)                                             |
| ❶19 | 90018-ZE1-000  | 1    | Bolt-Flange (6X23) (C T200) (Engine Serial Numbers Starting At 6702083) |
| ❶19 | 90022-888-010  | 1    | Bolt-Flange (6X20) (C T200) (Engine Serial Numbers Up To 6702082)       |
| ❶20 | 90201-878-003  | 1    | Nut-Special (14 Mm)                                                     |
| ❶21 | 93892-04012-00 | 1    | Screw-Washer (4X12)                                                     |
| ❶22 | 94103-04000    | 1    | Washer-Plain (4Mm)                                                      |
| ❶23 | 91601-Z0L-300  | 1    | Grommet-Plate, Brake (Engine Serial Numbers Starting At 7132771)        |



# Control Assembly Honda GCV160L AS3A


| Ref | Part No.      | Qty. | Description                                                       |  |  |  |  |
|-----|---------------|------|-------------------------------------------------------------------|--|--|--|--|
| ❶1  | 16551-ZM0-010 | 1    | Arm-Governor                                                      |  |  |  |  |
| ❶2  | 16555-Z0L-800 | 1    | Rod-Governor (Engine Serial Numbers Up To 6349022)                |  |  |  |  |
| ❶2  | 16555-Z0L-801 | 1    | Rod-Governor (Engine Serial Numbers Starting At 6349023)          |  |  |  |  |
| ❶3  | 16561-Z0L-000 | 1    | Spring-Governor                                                   |  |  |  |  |
| ❶4  | 16562-ZM0-000 | 1    | Spring-Return, Throttle                                           |  |  |  |  |
| ❶6  | 16580-Z0L-810 | 1    | Base-Control (Engine Serial Numbers Up To 6901760)                |  |  |  |  |
| ❶13 | 90015-ZE5-010 | 1    | Bolt-Arm, Governor                                                |  |  |  |  |
| ❶14 | 90016-ZE8-000 | 1    | Bolt-Flange (6X45) (C T200) (Engine Serial Numbers Up To 6901760) |  |  |  |  |
| ❶15 | 94050-06000   | 1    | Nut-Flange (6 Mm)                                                 |  |  |  |  |
| ❶17 | 16221-Z0L-900 | 1    | Spacer-Carburetor (Engine Serial Numbers Starting At 6901761)     |  |  |  |  |



E-22-3

# Choke Base Assembly Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                 |  |  |  |  |
|-----|---------------|------|-----------------------------|--|--|--|--|
| ❶1  | 16592-Z2D-800 | 1    | Spring-Return               |  |  |  |  |
| ❶2  | 16610-Z2D-801 | 1    | Choke Lever ASM             |  |  |  |  |
| ❶3  | 16614-Z2D-800 | 1    | Spring-Lever, Choke         |  |  |  |  |
| ❶4  | 16632-Z0L-800 | 1    | Rod-Stop                    |  |  |  |  |
| ❶5  | 90022-888-010 | 1    | Bolt-Flange (6X20) (C T200) |  |  |  |  |



E-29

# Label Assembly

## Honda GCV160L AS3A

| Ref | Part No.      | Qty. | Description                            |  |  |  |  |
|-----|---------------|------|----------------------------------------|--|--|--|--|
| ❶3  | 87114-ZH7-821 | 1    | Label-Warning (Not Certified For Sale) |  |  |  |  |
| ❶5  | 87528-Z0L-V20 | 1    | Mark-Indication, Choke                 |  |  |  |  |

**Attachments and Accessories**

**For 20192 - Super Bagger Lawn Mower**

| Product Name             | Model/Part |
|--------------------------|------------|
| Cruise Control Kit ..... | 89919      |



## NOTES

## NOTES

## NOTES

