



## TimeCutter™ Z380 Riding Mower

Model No. 74402 - 250000001 and up.

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

## Contents

| Description                                               | Page     | Description                                                           | Page     |
|-----------------------------------------------------------|----------|-----------------------------------------------------------------------|----------|
| Frame Assembly                                            | ..... 3  | Crankshaft Assembly Briggs and Stratton 280h07-0166-e1                | ..... 20 |
| Seat Assembly                                             | ..... 4  | Crankcase Assembly Briggs and Stratton 280h07-0166-e1                 | ..... 21 |
| Control Assembly                                          | ..... 5  | Oil Filter, Tube and Pump Assembly Briggs and Stratton 280h07-0166-e1 | ..... 22 |
| Hydro and Belt Drive Assembly                             | ..... 6  | Carburetor Assembly Briggs and Stratton 280h07-0166-e1                | ..... 23 |
| LH Hydrostat Assembly Part No. 108-2394                   | ..... 7  | Governor Assembly Briggs and Stratton 280h07-0166-e1                  | ..... 24 |
| RH Hydrostat Assembly Part No. 108-2393                   | ..... 9  | Blower Housing Assembly Briggs and Stratton 280h07-0166-e1            | ..... 25 |
| Engine Assembly                                           | ..... 11 | Starter Assembly Briggs and Stratton 280h07-0166-e1                   | ..... 26 |
| Styling Assembly                                          | ..... 12 | Gasket Assembly Briggs and Stratton 280h07-0166-e1                    | ..... 27 |
| 38 Inch Deck Assembly                                     | ..... 13 | Carburetor Overhaul Kit Assembly Briggs and Stratton 280h07-0166-e1   | ..... 28 |
| 38 Inch Deck Decal Assembly No. 107-9139                  | ..... 14 | Attachments and Accessories List                                      | ..... 29 |
| 38 Inch Deck Recycler Assembly                            | ..... 15 |                                                                       |          |
| 38 Inch Deck Spindle and Belt Drive Assembly              | ..... 16 |                                                                       |          |
| Electrical System Assembly                                | ..... 17 |                                                                       |          |
| Cylinder Assembly Briggs and Stratton 280h07-0166-e1      | ..... 18 |                                                                       |          |
| Cylinder Head Assembly Briggs and Stratton 280h07-0166-e1 | ..... 19 |                                                                       |          |


## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

|                                            |                                              |
|--------------------------------------------|----------------------------------------------|
| AR. .... as required                       | HWHTF. .... hex washer head thread forming   |
| ASM. .... assembly                         | HYD. .... hydraulic                          |
| BBC. .... blade brake clutch               | LH. .... left hand                           |
| CARR. .... carriage                        | NI. .... nylon insert                        |
| CCW. .... counter clock wise               | NPTF. .... national pipe thread fine         |
| CW. .... clockwise                         | PFH. .... phillips flat head                 |
| DEG. .... degrees                          | PPH. .... phillips pan head                  |
| ECM. .... electronic control module        | PPHTF. .... phillips pan head thread forming |
| EXT. .... external                         | PRH. .... phillips round head                |
| FH. .... flat head                         | PTH. .... phillips truss head                |
| GA. .... gauge                             | PTO. .... power-take-off                     |
| HD. .... heavy-duty                        | RH. .... right hand                          |
| HF. .... hex flange                        | ROPS. .... roll-over protection system       |
| HH. .... hex head                          | SFH. .... slotted fillister head             |
| HHF. .... hex head flange                  | SHH. .... slotted hex head                   |
| HHFTF. .... hex head flange thread forming | SHWH. .... slotted hex washer head           |
| HJ. .... hex jam                           | SPH. .... slotted pan head                   |
| HLH. .... hex lag head                     | SQH. .... square head                        |
| HOC. .... height-of-cut                    | SRH. .... slotted round head                 |
| HSBH. .... hex socket button head          | STD. .... standard                           |
| HSFH. .... hex socket flat head            | TAP. .... self tapping                       |
| HSH. .... hex socket head                  | TTH. .... torx truss head                    |
| HWH. .... hex washer head                  |                                              |

## Footnotes


- |                                                 |                                                                                              |
|-------------------------------------------------|----------------------------------------------------------------------------------------------|
| ❶ Not illustrated                               | ❷ Not serviced separately                                                                    |
| ❸ Included in Engine Gasket Set-Ref. 358.       | ❹ Included in Valve Gasket Set-Ref. 1095.                                                    |
| ❺ Included in Carburetor Overhaul Kit-Ref. 121. | ❻ Included in Carburetor Gasket Set-Ref. 977.                                                |
| ❽ Optional Equipment                            | ❼ Obtain parts from <a href="http://www.briggsandstratton.com">www.briggsandstratton.com</a> |



## Frame Assembly


| Ref   | Part No.    | Qty. | Description              |
|-------|-------------|------|--------------------------|
| 1     | 108-2325-01 | 1    | Frame                    |
| 4     | 323-4       | 4    | Screw-HH                 |
| 5     | 3229-1      | 4    | Screw-CARR               |
| 6     | 105-3439    | 2    | Bracket-Lift             |
| 7     | 3296-42     | 4    | Nut-Lock, NI             |
| 8     | 1-633102    | 2    | Bearing-Flange, Side     |
| 9     | 3290-357    | 4    | Nut-HHF, Whiz            |
| 10    | 105-3499-03 | 1    | Lift Arm ASM             |
| 11    | 106-2222    | 1    | Spacer                   |
| 12    | 105-3460    | 1    | Pad-Antiskid             |
| 13    | 105-3471    | 2    | Front Wheel And Tire ASM |
| 13:1  | 105-1943    | 1    | Tire                     |
| 13:2  | 302-11      | 1    | Fitting-Lube, 45 DEG     |
| 13:3  | 232-27      | 1    | Stem-Valve               |
| 13:5  | 114-1640    | 2    | Bushing-Flange           |
| 13:99 | 93-4244     | 1    | Tube-Inner (W/Valve)     |
| 14    | 104-3667    | 2    | Spanner-Wheel            |
| 15    | 325-22      | 2    | Screw-HH                 |
| 16    | 32128-23    | 2    | Nut-HF                   |
| 17    | 107-9119-01 | 2    | Castor Fork ASM          |
| 18    | 3296-39     | 9    | Nut-Lock, NI             |
| 19    | 3-6498      | 2    | Washer-Thrust            |
| 20    | 105-6986-01 | 1    | Caster-LH                |
| 21    | 105-6985-01 | 1    | Castor-RH                |

| Ref | Part No.    | Qty. | Description         |
|-----|-------------|------|---------------------|
| 22  | 302-5       | 2    | Fitting-Grease      |
| 23  | 28-2480     | 2    | Washer-Plain        |
| 24  | 32151-103   | 2    | Ring-Retaining, EXT |
| 25  | 61-9780     | 2    | Cap-Hub             |
| 26  | 323-18      | 10   | Screw-HH            |
| 27  | 3256-24     | 8    | Washer-Flat         |
| 28  | 105-3450    | 1    | Grip-Lever, Lift    |
| 29  | 108-2317-03 | 1    | Lever-Lift          |
| 30  | 106-8743    | 1    | Decal               |
| 31  | 98-5975     | 2    | Washer-Belleville   |
| 33  | 106-2211    | 1    | Block-Lift          |
| 34  | 108-6109    | 1    | Decal-Transport, Ce |



Seat Assembly


| Ref | Part No.    | Qty. | Description        |  |  |  |  |
|-----|-------------|------|--------------------|--|--|--|--|
| 1   | 3296-42     | 4    | Nut-Lock, NI       |  |  |  |  |
| 2   | 3256-23     | 6    | Washer-Flat        |  |  |  |  |
| 3   | 3296-29     | 12   | Nut-Lock, NI       |  |  |  |  |
| 4   | 322-4       | 14   | Screw-HH           |  |  |  |  |
| 5   | 106-2158-03 | 1    | RH Plate ASM       |  |  |  |  |
| 6   | 106-2159-03 | 1    | LH Plate ASM       |  |  |  |  |
| 7   | 106-2223    | 1    | Decal-HOC          |  |  |  |  |
| 8   | 321-4       | 4    | Screw-HH           |  |  |  |  |
| 9   | 106-2180    | 2    | Bracket-Bellcrank  |  |  |  |  |
| 10  | 105-6954-03 | 1    | Brace-Seat, Front  |  |  |  |  |
| 11  | 106-2240    | 2    | Knob               |  |  |  |  |
| 12  | 5-4460      | 2    | Washer-Pivot       |  |  |  |  |
| 13  | 105-7004    | 1    | E-Ring             |  |  |  |  |
| 14  | 105-6953-03 | 1    | Bracket-Seat       |  |  |  |  |
| 15  | 108-2329    | 1    | Seat               |  |  |  |  |
| 16  | 106-8717    | 1    | Decal-Service      |  |  |  |  |
| 17  | 105-6955    | 1    | Pin-Pivot          |  |  |  |  |
| 18  | 613529      | 2    | Screw-Shoulder     |  |  |  |  |
| 19  | 701178      | 2    | Cap-Protector      |  |  |  |  |
| 20  | 32128-25    | 2    | Nut-HF             |  |  |  |  |
| 21  | 92-7054     | 2    | Spring-Compression |  |  |  |  |
| 22  | 108-2358-03 | 1    | Brace-Seat, Rear   |  |  |  |  |
| 23  | 614249      | 1    | Strap-Tie          |  |  |  |  |
| 24  | 107-4902    | 4    | Spacer-Nylon       |  |  |  |  |



## Control Assembly

| Ref  | Part No. | Qty. | Description            |
|------|----------|------|------------------------|
| 1    | 105-7045 | 1    | Rod-Brake, LH          |
| 2    | 105-7044 | 1    | Rod-Brake, RH          |
| 3    | 105-3481 | 6    | Washer-Thrust          |
| ①5   | 107-4909 | 1    | LH Activator Arm ASM   |
| ①5:2 | 105-3455 | 4    | Bushing                |
| 6    | 107-4910 | 1    | RH Activator Arm ASM   |
| 6:2  | 105-3455 | 4    | Bushing                |
| ①7   | 105-3488 | 1    | LH Pivot Shaft ASM     |
| 8    | 105-3487 | 1    | RH Pivot Shaft ASM     |
| 9    | 3296-53  | 2    | Nut-Lock, NI           |
| 10   | 3256-24  | 2    | Washer-Flat            |
| 11   | 3296-59  | 2    | Nut-Lock, NI           |
| 12   | 107-4874 | 2    | Eccentric              |
| 13   | 321-9    | 2    | Screw-HH               |
| 14   | 103-2913 | 2    | Damper-Control, Motion |
| 15   | 106-2181 | 2    | Bellcrank              |
| 17   | 1-806003 | 2    | Pin-Cotter, Hair       |
| 18   | 105-3486 | 2    | Stop-Adjustment        |
| 19   | 3217-6   | 4    | Nut-Hex                |
| 21   | 3256-22  | 12   | Washer-Flat            |
| 22   | 321-4    | 4    | Screw-HH               |
| 23   | 3296-42  | 8    | Nut-Lock, NI           |
| 24   | 106-2179 | 2    | Link-Brake             |
| 25   | 1-543017 | 2    | Balljoint-RH           |


| Ref  | Part No. | Qty. | Description          |
|------|----------|------|----------------------|
| 26   | 105-7048 | 2    | Rod-Hydro            |
| 27   | 3219-2   | 2    | Nut-Hex              |
| 28   | 322-6    | 2    | Screw-HH             |
| 29   | 32128-20 | 4    | Nut-HF               |
| 30   | 106-2242 | 2    | Handle ASM           |
| 30:2 | 1-633257 | 1    | Grip-Control, Motion |
| 31   | 105-3469 | 2    | Spring-Compression   |
| 32   | 106-2214 | 4    | Bolt-Shoulder        |
| 33   | 105-3465 | 2    | Spring-Compression   |
| 34   | 37-8771  | 4    | Bolt-Shoulder        |
| 35   | 3296-2   | 2    | Nut-Lock, NI         |
| 36   | 3274-52  | 2    | Screw-HSH            |
| 37   | 106-8742 | 2    | Decal                |
| 38   | 32128-25 | 2    | Nut-HF               |



## Hydro and Belt Drive Assembly


| Ref   | Part No.    | Qty. | Description         |
|-------|-------------|------|---------------------|
| 1     | 108-2394    | 1    | Transaxle-Hydro, LH |
| 2     | 108-2393    | 1    | Transaxle-Hydro, RH |
| 3     | 106-2174    | 2    | V-Belt              |
| 4     | 95-3805     | 2    | Spring              |
| 5     | 105-3438    | 2    | Tab-Locking         |
| 6     | 3234-13     | 2    | Screw-HHF           |
| 7     | 105-7047    | 2    | Arm-Idler           |
| 8     | 106-2176    | 2    | Pulley-Idler        |
| 9     | 32128-25    | 1    | Nut-HF              |
| 10    | 37-8770     | 2    | Bolt-Shoulder       |
| 11    | 3256-3      | 2    | Washer-Flat         |
| 12    | 107-4878-03 | 1    | Hydro Mount ASM     |
| 13    | 106-7003    | 2    | Rear Wheel ASM      |
| 13:1  | 242-76      | 1    | Rim                 |
| 13:2  | 105-3496    | 1    | Tire                |
| 13:3  | 232-27      | 1    | Stem-Valve          |
| 13:99 | 107-2491    | 1    | Tube-Tire           |
| 14    | 3256-1      | 2    | Washer-Flat         |
| 15    | 3210-5      | 2    | Screw-HH            |
| 16    | 322-20      | 4    | Screw-HH            |
| 17    | 322-13      | 4    | Screw-HH            |
| 18    | 3256-23     | 18   | Washer-Flat         |
| 19    | 3296-29     | 18   | Nut-Lock, NI        |
| 20    | 322-7       | 2    | Screw-HH            |

| Ref    | Part No.    | Qty. | Description      |
|--------|-------------|------|------------------|
| 21     | 5-4460      | 5    | Washer-Pivot     |
| 22     | 106-7001    | 2    | Washer-Wheel     |
| 23     | 242-50      | 8    | Nut-Lug          |
| 24     | 106-7002    | 2    | Vent Hose ASM    |
| 24:2   | 93-3818     | 1    | Fitting ASM      |
| 24:2:1 | 93-3816     | 1    | O-Ring           |
| 24:7   | 107-1701    | 1    | Cap Vent ASM     |
| 25     | 322-5       | 6    | Screw-HH         |
| 26     | 322-13      | 2    | Screw-HH         |
| 28     | 105-7039-03 | 2    | Support-Hydro    |
| 30     | 107-4875    | 2    | Rod-Bypass       |
| 31     | 1-806003    | 2    | Pin-Cotter, Hair |
| 32     | 108-9533    | 2    | Hub ASM          |
| 33     | 3217-6      | 2    | Nut-Hex          |




## LH Hydrostat Assembly Part No. 108-2394

| Ref | Part No.     | Qty. | Description           | Ref | Part No. | Qty. | Description              |
|-----|--------------|------|-----------------------|-----|----------|------|--------------------------|
| 1   | 106-8695     | 1    | RH Main Housing ASM   | 24  | 94-1937  | 1    | Washer-Thrust, Block     |
| 2   | 106-8696     | 1    | RH Side ASM           | 25  | 104-5306 | 1    | Shaft-Input              |
| 3   | 104-2106     | 1    | Cylinder Block ASM    | 26  | 104-5311 | 1    | Bearing-Ball             |
| 4   | 104-2189     | 1    | Plug-Thread, Straight | 27  | 104-5307 | 1    | Ring-Retaining           |
| 5   | 9004800-2506 | 2    | Pin-Hydrogear         | 28  | 104-5308 | 1    | Spacer                   |
| 6   | 104-5305     | 16   | Screw-HHF             | 29  | 104-5310 | 1    | Seal-Lip                 |
| 7   | 104-5347     | 1    | Seal-Oil              | 30  | 104-5309 | 2    | Ring-Retaining           |
| 8   | 94-6926      | 3    | Bolt                  | 31  | 94-6922  | 2    | Bearing-Thrust           |
| 9   | 106-8676     | 1    | Seal-Lip              | 32  | 104-5339 | 1    | Washer-Flat              |
| 10  | 106-8677     | 2    | Ring-Retaining, EXT   | 33  | 104-5340 | 1    | Ring-Retaining           |
| 11  | 106-8678     | 1    | Rod-Bypass            | 34  | 104-5316 | 1    | Gear-Pinnion, 13T        |
| 12  | 106-8679     | 1    | Ring-Retaining, Int   | 35  | 106-8683 | 1    | Shaft-Motor              |
| 13  | 107-2490     | 1    | Arm-Bypass            | 36  | 104-5360 | 1    | Washer-Shaft, Motor      |
| 14  | 106-8681     | 1    | Ring-Retaining, EXT   | 37  | 94-1933  | 2    | Washer                   |
| 15  | 104-5304     | 1    | Swashplate-Trunnion   | 38  | 104-5317 | 1    | Gear                     |
| 16  | 104-5313     | 1    | Seal-Lip              | 39  | 104-5318 | 1    | Gear-Jackshaft, 10T      |
| 17  | 104-2116     | 1    | Stud                  | 40  | 104-5329 | 1    | Pin-Jackshaft            |
| 18  | 105-1873     | 2    | Puck-Friction         | 41  | 104-5328 | 1    | Ring-Retaining, Spiral   |
| 19  | 106-8747     | 1    | Arm-Control           | 42  | 106-8684 | 1    | Gear-Bull, 52T           |
| 20  | 5-4460       | 1    | Washer-Pivot          | 43  | 94-1943  | 1    | Washer                   |
| 21  | 107-2488     | 1    | Screw                 | 44  | 104-5320 | 1    | Bearing-Sleeve           |
| 22  | 105-1872     | 1    | Nut                   | 45  | 106-8685 | 1    | Axle                     |
| 23  | 94-1936      | 1    | Spring-Block          | 46  | 104-5321 | 1    | Bearing-Sleeve, Outboard |
|     |              |      |                       | 47  | 104-5322 | 1    | Seal-Lip                 |



LH Hydrostat Assembly Part No. 108-2394 (continued)


| Ref | Part No. | Qty. | Description                    |  |  |  |  |
|-----|----------|------|--------------------------------|--|--|--|--|
| ❶48 | 106-8686 | 1    | Seal Kit                       |  |  |  |  |
| 49  | 106-8697 | 1    | RH Expansion Plate Kit         |  |  |  |  |
| 50  | 106-8698 | 1    | Fan Pulley Kit                 |  |  |  |  |
| 51  | 106-8688 | 1    | Brake Arm Kit                  |  |  |  |  |
| 53  | 108-6190 | 1    | RH 7-Piston Center Section Kit |  |  |  |  |
| ❶54 | 104-2147 | 1    | Sealant                        |  |  |  |  |
| 55  | 107-2489 | 1    | Bypass Arm Kit                 |  |  |  |  |
| 57  | 106-8693 | 1    | Filter Kit                     |  |  |  |  |
| 58  | 106-8694 | 1    | Disc-Brake, Cog                |  |  |  |  |
| 59  | 110-8566 | 1    | Fan-6 Inch, 10 Blade           |  |  |  |  |
| 60  | 104-1754 | 1    | Pulley                         |  |  |  |  |
| 61  | 105-1875 | 1    | Nut-Lock                       |  |  |  |  |
| 62  | 107-9122 | 3    | Washer-Slotted                 |  |  |  |  |



## RH Hydrostat Assembly Part No. 108-2393


| Ref | Part No.     | Qty. | Description           |
|-----|--------------|------|-----------------------|
| 1   | 106-8674     | 1    | LH Main Housing ASM   |
| 2   | 106-8675     | 1    | LH Side ASM           |
| 3   | 104-2106     | 1    | Cylinder Block ASM    |
| 4   | 104-2189     | 1    | Plug-Thread, Straight |
| 5   | 9004800-2506 | 2    | Pin-Hydrogear         |
| 6   | 104-5305     | 16   | Screw-HHF             |
| 7   | 104-5347     | 1    | Seal-Oil              |
| 8   | 94-6926      | 3    | Bolt                  |
| 9   | 106-8676     | 1    | Seal-Lip              |
| 10  | 106-8677     | 2    | Ring-Retaining, EXT   |
| 11  | 106-8678     | 1    | Rod-Bypass            |
| 12  | 106-8679     | 1    | Ring-Retaining, Int   |
| 13  | 107-2490     | 1    | Arm-Bypass            |
| 14  | 106-8681     | 1    | Ring-Retaining, EXT   |
| 15  | 104-5304     | 1    | Swashplate-Trunnion   |
| 16  | 104-5313     | 1    | Seal-Lip              |
| 17  | 104-2116     | 1    | Stud                  |
| 18  | 105-1873     | 2    | Puck-Friction         |
| 19  | 106-8747     | 1    | Arm-Control           |
| 20  | 5-4460       | 1    | Washer-Pivot          |
| 21  | 107-2488     | 1    | Screw                 |
| 22  | 105-1872     | 1    | Nut                   |
| 23  | 94-1936      | 1    | Spring-Block          |

| Ref | Part No. | Qty. | Description              |
|-----|----------|------|--------------------------|
| 24  | 94-1937  | 1    | Washer-Thrust, Block     |
| 25  | 104-5306 | 1    | Shaft-Input              |
| 26  | 104-5311 | 1    | Bearing-Ball             |
| 27  | 104-5307 | 1    | Ring-Retaining           |
| 28  | 104-5308 | 1    | Spacer                   |
| 29  | 104-5310 | 1    | Seal-Lip                 |
| 30  | 104-5309 | 2    | Ring-Retaining           |
| 31  | 94-6922  | 2    | Bearing-Thrust           |
| 32  | 104-5339 | 1    | Washer-Flat              |
| 33  | 104-5340 | 1    | Ring-Retaining           |
| 34  | 104-5316 | 1    | Gear-Pinnion, 13T        |
| 35  | 106-8683 | 1    | Shaft-Motor              |
| 36  | 104-5360 | 1    | Washer-Shaft, Motor      |
| 37  | 94-1933  | 2    | Washer                   |
| 38  | 104-5317 | 1    | Gear                     |
| 39  | 104-5318 | 1    | Gear-Jackshaft, 10T      |
| 40  | 104-5329 | 1    | Pin-Jackshaft            |
| 41  | 104-5328 | 1    | Ring-Retaining, Spiral   |
| 42  | 106-8684 | 1    | Gear-Bull, 52T           |
| 43  | 94-1943  | 1    | Washer                   |
| 44  | 104-5320 | 1    | Bearing-Sleeve           |
| 45  | 106-8685 | 1    | Axle                     |
| 46  | 104-5321 | 1    | Bearing-Sleeve, Outboard |
| 47  | 104-5322 | 1    | Seal-Lip                 |



**RH Hydrostat Assembly Part No. 108-2393 (continued)**


| Ref | Part No. | Qty. | Description                    |  |  |  |  |
|-----|----------|------|--------------------------------|--|--|--|--|
| ❶48 | 106-8686 | 1    | Seal Kit                       |  |  |  |  |
| 49  | 106-8687 | 1    | LH Expansion Plate Kit         |  |  |  |  |
| 50  | 105-1928 | 1    | Fan Pulley Kit                 |  |  |  |  |
| 51  | 106-8688 | 1    | Brake Arm Kit                  |  |  |  |  |
| 53  | 108-6189 | 1    | LH 7-Piston Center Section Kit |  |  |  |  |
| ❶54 | 104-2147 | 1    | Sealant                        |  |  |  |  |
| 55  | 107-2489 | 1    | Bypass Arm Kit                 |  |  |  |  |
| 57  | 106-8693 | 1    | Filter Kit                     |  |  |  |  |
| 58  | 106-8694 | 1    | Disc-Brake, Cog                |  |  |  |  |
| 59  | 105-1927 | 1    | Fan                            |  |  |  |  |
| 60  | 105-1896 | 1    | Pulley                         |  |  |  |  |
| 61  | 105-1875 | 1    | Nut-Lock                       |  |  |  |  |
| 62  | 104-2120 | 3    | Screw                          |  |  |  |  |



## Engine Assembly

| Ref | Part No. | Qty. | Description                                |
|-----|----------|------|--------------------------------------------|
| 1   |          | 1    | Engine-Briggs And Stratton, 280H07-0166-E1 |
| 2   | 88-4410  | 1    | Gasket-Exhaust                             |
| 3   | 3253-4   | 2    | Washer-Lock                                |
| 4   | 3274-10  | 2    | Screw-HSH                                  |
| 5   | 104-2488 | 2    | Foam-Switch, Seat                          |
| 6   | 107-4873 | 1    | Bracket-Pivot                              |
| 7   | 106-7007 | 1    | Muffler                                    |
| 8   | 321-4    | 1    | Screw-HH                                   |
| 9   | 32144-44 | 2    | Screw-HWH                                  |
| 10  | 322-7    | 4    | Screw-HH                                   |
| 11  | 106-7022 | 1    | Tube-Drain, Oil                            |
| 12  | 3296-42  | 1    | Nut-Lock, NI                               |
| 13  | 92-6877  | 1    | Valve-Drain, Oil                           |
| 14  | 105-3472 | 1    | Pulley-Engine                              |
| 15  | 98-5023  | 1    | Bumpon                                     |
| 16  | 105-3462 | 1    | Clutch-Electric                            |
| 17  | 112843   | 1    | Washer                                     |
| 18  | 3212-16  | 1    | Screw-HH                                   |
| 19  | 106-2156 | 1    | Plate-Mount, Idler                         |
| 20  | 32128-25 | 4    | Nut-HF                                     |
| 21  | 3296-29  | 2    | Nut-Lock, NI                               |
| 23  | 322-4    | 2    | Screw-HH                                   |
| 24  | 46-8560  | 4    | Screw-HHF                                  |


| Ref  | Part No.    | Qty. | Description   |
|------|-------------|------|---------------|
| 25   | 237-124     | 1    | Grommet       |
| 26   | 609830      | 2    | Spring        |
| 27   | 108-2315-03 | 1    | Plate-Support |
| 28   | 106-8720    | 1    | Hose-Fuel     |
| 29   | 2412-98     | 2    | Clamp         |
| 30   | 105-3464    | 1    | Gas Tank ASM  |
| 30:2 | 46-6560     | 1    | Bushing       |
| 30:3 | 104048      | 1    | Valve-Fuel    |
| 31   | 108-2314-03 | 1    | Plate-Tank    |
| 32   | 107-4924    | 1    | Decal         |
| 34   | 106-7028-03 | 1    | Guard-Muffler |



# Styling Assembly


| Ref  | Part No.    | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 3296-42     | 6    | Nut-Lock, NI           |
| 2    | 3229-7      | 2    | Screw-CARR             |
| 3    | 106-2164-03 | 1    | Bracket-Support, Front |
| 4    | 107-2514    | 1    | Decal-Danger           |
| 5    | 108-7127    | 1    | Decal                  |
| 6    | 105-6971    | 2    | Decal                  |
| 7    | 105-6965    | 1    | Footrest ASM           |
| 8    | 105-1853    | 2    | Clamp-Hose             |
| 9    | 321-4       | 2    | Screw-HH               |
| 10   | 106-6994-03 | 1    | Brace ASM              |
| 11   | 108-2313-03 | 1    | Channel-Cross          |
| 12   | 46-8560     | 2    | Screw-HHF              |
| 13   | 46-8090     | 4    | Screw-Plastite         |
| 14   | 3256-22     | 4    | Washer-Flat            |
| 15   | 107069      | 4    | Clip                   |
| 16   | 3258-166    | 4    | Screw-PRH              |
| 17   | 106-2224    | 1    | Decal-Control          |
| 18   | 106-2167-03 | 1    | Panel-Control          |
| 19   | 88-3980     | 1    | Gas Cap ASM            |
| 19:3 | 88-4010     | 1    | Gasket-Cap, Gas        |
| 20   | 106-7042    | 1    | Seal-Rubber            |
| 21   | 106-2161    | 1    | Cover-Side, RH         |
| 22   | 106-2162    | 1    | Cover-Side, LH         |
| 23   | 104-3626    | 1    | Cable-Throttle         |

| Ref | Part No. | Qty. | Description    |
|-----|----------|------|----------------|
| 24  | 11-9030  | 2    | Screw-Shoulder |
| 25  | 106-8737 | 2    | Nut-Retainer   |
| 26  | 106-7017 | 2    | Knob           |
| 27  | 106-2163 | 1    | Cover-Hood     |




## 38 Inch Deck Assembly

| Ref | Part No.   | Qty. | Description         | Ref | Part No.    | Qty. | Description                     |
|-----|------------|------|---------------------|-----|-------------|------|---------------------------------|
| 1   | 107-9139   | 1    | 38 Inch Deck ASM    | 23  | 322-2       | 6    | Screw-HH                        |
| 2   | 57-6950    | 1    | Spring              | 26  | 56-6591     | 2    | Screw-Shoulder, HWH             |
| 3   | 93-7695    | 1    | Deflector ASM       | 27  | 701756      | 2    | Wheel-Gage                      |
| 3:1 | 93-7010    | 1    | Decal-Danger        | 28  | 107-1717-01 | 1    | Bracket-Wheel, Gage (Front, LH) |
| 3:3 | 93-7696    | 2    | Kicker              | 29  | 3256-4      | 8    | Washer-Flat                     |
| 3:4 | 93-0231    | 4    | Screw-PPH           | 30  | 3296-38     | 2    | Nut-Lock, NI                    |
| 4   | 95-1661    | 1    | Rod-Pivot           | 31  | 106-8704-01 | 1    | Bracket-Wheel, Gage (Front, RH) |
| 5   | 3296-39    | 3    | Nut-Lock, NI        | 32  | 3219-4      | 2    | Nut-Hex                         |
| 6   | 32128-25   | 8    | Nut-HF              | 33  | 3256-25     | 2    | Washer-Flat                     |
| 7   | 32104-76   | 5    | Screw               | 34  | 106-8745    | 1    | O-Ring                          |
| 8   | 5-4460     | 2    | Washer-Pivot        |     |             |      |                                 |
| 9   | 88-4230    | 2    | Trunnion-HOC        |     |             |      |                                 |
| 10  | 105-3437   | 4    | Rod-Hanger          |     |             |      |                                 |
| 11  | 7-0030     | 2    | Screw-Shoulder, HH  |     |             |      |                                 |
| 12  | 88-5570-03 | 2    | Link-Adjusting, HOC |     |             |      |                                 |
| 13  | 80-6990    | 10   | Washer-Hardened     |     |             |      |                                 |
| 14  | 9335054    | 8    | Pin-Hair            |     |             |      |                                 |
| 15  | 3296-16    | 2    | Nut-Lock, NI        |     |             |      |                                 |
| 16  | 3256-1     | 2    | Washer-Flat         |     |             |      |                                 |
| 17  | 95-2747    | 1    | Fitting-Washout     |     |             |      |                                 |
| 19  | 46-6290    | 1    | O-Ring, Seal        |     |             |      |                                 |
| 20  | 88-4030    | 1    | Guide-Belt, LH      |     |             |      |                                 |
| 21  | 88-4020    | 1    | Guide-Belt, RH      |     |             |      |                                 |
| 22  | 3229-1     | 2    | Screw-CARR          |     |             |      |                                 |




## 38 Inch Deck Decal Assembly No. 107-9139

| Ref | Part No. | Qty. | Description             |  |  |  |  |
|-----|----------|------|-------------------------|--|--|--|--|
| 2   | 93-7010  | 2    | Decal-Danger            |  |  |  |  |
| 3   | 93-6677  | 1    | Decal-Danger, Shield    |  |  |  |  |
| 4   | 93-7009  | 1    | Decal-Danger, Deflector |  |  |  |  |
| 5   | 105-7015 | 1    | Decal-Routing, Belt     |  |  |  |  |
| 6   | 106-6407 | 1    | Decal                   |  |  |  |  |



38 Inch Deck Recycler Assembly


| Ref | Part No.    | Qty. | Description    |  |  |  |  |
|-----|-------------|------|----------------|--|--|--|--|
| 1   | 3296-42     | 2    | Nut-Lock, NI   |  |  |  |  |
| 2   | 107-2484-03 | 1    | Baffle-Rear    |  |  |  |  |
| 3   | 32128-25    | 4    | Nut-HF         |  |  |  |  |
| 4   | 3230-1      | 1    | Bolt-CARR      |  |  |  |  |
| 5   | 321-4       | 2    | Screw-HH       |  |  |  |  |
| 6   | 323-5       | 2    | Screw-HH       |  |  |  |  |
| 7   | 79-1600-03  | 1    | Baffle ASM     |  |  |  |  |
| 8   | 3296-39     | 2    | Nut-Lock, NI   |  |  |  |  |
| 9   | 79-1640-03  | 1    | Baffle ASM     |  |  |  |  |
| 10  | 321-55      | 2    | Screw-HH       |  |  |  |  |
| 11  | 32111-7     | 2    | Nut-Cap        |  |  |  |  |
| 12  | 88-4430     | 1    | Cover-Recycler |  |  |  |  |
| 13  | 32144-111   | 8    | Screw-PPH      |  |  |  |  |
| 14  | 76-2160     | 4    | Plate-Kicker   |  |  |  |  |
| 15  | 322-2       | 3    | Screw-HH       |  |  |  |  |



38 Inch Deck Spindle and Belt Drive Assembly


| Ref  | Part No.    | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 106-2173    | 1    | Belt-V             |
| 2    | 323-9       | 2    | Screw-HH           |
| 3    | 3256-24     | 3    | Washer-Flat        |
| 4    | 106-2175    | 2    | Pulley-Idler, Flat |
| 5    | 32128-25    | 1    | Nut-HF             |
| 6    | 107-2467-03 | 1    | Arm-Idler          |
| 7    | 32128-21    | 2    | Nut-HF             |
| 8    | 323-7       | 1    | Screw-HH           |
| 9    | 107-7307    | 1    | Guide-Idler, Belt  |
| 10   | 88-4980     | 1    | Bushing-Arm, Idler |
| 11   | 322-4       | 2    | Screw-HH           |
| 12   | 5-4460      | 1    | Washer-Pivot       |
| 13   | 3219-6      | 2    | Nut-Hex            |
| 14   | 88-5330     | 2    | Pully ASM          |
| 15   | 32144-41    | 8    | Screw-Taptite      |
| 16   | 26-0671     | 2    | Screw-HH           |
| 17   | 3290-465    | 2    | Washer-Belleville  |
| 18   | 80-0510-03  | 2    | Stiffener-Blade    |
| 19   | 79-3061-03  | 2    | Blade-Recycling    |
| 20   | 80-4360     | 2    | Shield-Bearing     |
| 21   | 80-4380     | 2    | Spacer             |
| 22   | 80-4341     | 2    | Shaft-Spindle      |
| 23   |             | 2    | Spindle ASM        |
| 23:1 | 88-4510     | 1    | Housing-Spindle    |

| Ref  | Part No. | Qty. | Description         |
|------|----------|------|---------------------|
| 23:2 | 100-1048 | 2    | Bearing-Ball        |
| 23:3 | 62-3661  | 1    | Spacer              |
| 24   | 88-5970  | 1    | Hook-Return, Spring |
| 25   | 106-2177 | 1    | Spring-Extension    |
| 26   | 7-0030   | 1    | Screw-Shoulder, HH  |
| 27   | 3296-29  | 2    | Nut-Lock, NI        |



Electrical System Assembly

| Ref | Part No. | Qty. | Description              |  |  |  |  |
|-----|----------|------|--------------------------|--|--|--|--|
| 1   | 104-2491 | 1    | Battery                  |  |  |  |  |
| 2   | 88-9830  | 1    | Key Switch ASM           |  |  |  |  |
| 2:1 | 3254-5   | 1    | Washer-Tooth             |  |  |  |  |
| 2:2 | 218-461  | 1    | Nut-HH                   |  |  |  |  |
| 3   | 63-8360  | 1    | Key-Ignition             |  |  |  |  |
| 4   | 95-7489  | 1    | Switch-PTO               |  |  |  |  |
| 5   | 28-8080  | 1    | Boot-Terminal            |  |  |  |  |
| 6   | 106-2216 | 2    | Switch                   |  |  |  |  |
| 7   | 82-2190  | 1    | Switch-Bail              |  |  |  |  |
| 8   | 106-8245 | 1    | Solenoid-Starter         |  |  |  |  |
| 9   | 56-7670  | 2    | Wire ASM                 |  |  |  |  |
| 10  | 93-3190  | 1    | Boot-Insulator, Terminal |  |  |  |  |
| 11  | 95-7654  | 1    | Cable-Negative, Black    |  |  |  |  |
| 12  | 104-2466 | 1    | Holddown-Battery         |  |  |  |  |
| 13  | 99-7420  | 1    | Plug-Hole                |  |  |  |  |
| 14  | 32149-2  | 2    | Nut-Keps                 |  |  |  |  |
| 15  | 3256-22  | 2    | Washer-Flat              |  |  |  |  |
| 16  | 32144-1  | 3    | Screw-Taptite            |  |  |  |  |
| 17  | 321-4    | 2    | Screw-HH                 |  |  |  |  |
| 18  | 32128-33 | 3    | Nut-HF                   |  |  |  |  |
| 19  | 98-7249  | 1    | Relay                    |  |  |  |  |
| 20  | 46-8560  | 2    | Screw-HHF                |  |  |  |  |
| 22  | 107-2500 | 1    | Harness-Wire, 9 Amp      |  |  |  |  |




Assemblies include all parts shown in frames.

# Cylinder Assembly

## Briggs and Stratton 280h07-0166-e1


| Ref  | Part No. | Qty. | Description             |  |  |  |  |
|------|----------|------|-------------------------|--|--|--|--|
| 1    | 697132   | 1    | Cylinder ASM            |  |  |  |  |
| 2    | 399265   | 1    | Bushing And Seal Kit    |  |  |  |  |
| 3    | 391086   | 1    | Seal-Oil                |  |  |  |  |
| 9    | 697109   | 1    | Gasket-Breather         |  |  |  |  |
| 11   | 697113   | 1    | Tube-Breather           |  |  |  |  |
| 548  | 697761   | 1    | Short Block             |  |  |  |  |
| 306  | 697107   | 1    | Shield-Cylinder         |  |  |  |  |
| 307  | 691003   | 1    | Screw                   |  |  |  |  |
| 337  | 691043   | 1    | Spark Plug              |  |  |  |  |
| 383  | 89838    | 1    | Wrench-Plug, Spark      |  |  |  |  |
| 404  | 691691   | 1    | Washer                  |  |  |  |  |
| 552  | 697144   | 1    | Bushing-Crank, Governor |  |  |  |  |
| 584  | 697112   | 1    | Cover-Passage, Breather |  |  |  |  |
| 614  | 691620   | 1    | Pin-Cotter              |  |  |  |  |
| 616  | 692012   | 1    | Crank-Governor          |  |  |  |  |
| 635  | 691909   | 1    | Boot-Spark Plug         |  |  |  |  |
| 684  | 697157   | 1    | Screw                   |  |  |  |  |
| 691  | 692407   | 1    | Seal-Shaft, Governor    |  |  |  |  |
| 718  | 690959   | 1    | Pin-Locating            |  |  |  |  |
| 1019 | 697143   | 1    | Label Kit               |  |  |  |  |
| 1263 | 697124   | 1    | Reed-Breather           |  |  |  |  |
| 1264 | 697104   | 1    | Screw                   |  |  |  |  |



## Cylinder Head Assembly Briggs and Stratton 280h07-0166-e1

| Ref  | Part No. | Qty. | Description           |
|------|----------|------|-----------------------|
| 5    | 698148   | 1    | Head-Cylinder         |
| 7    | 273280   | 1    | Gasket-Head, Cylinder |
| 13   | 690360   | 1    | Screw                 |
| 33   | 695760   | 1    | Valve-Exhaust         |
| 34   | 695761   | 1    | Valve-Intake          |
| 35   | 691279   | 1    | Spring-Valve          |
| 36   | 691279   | 1    | Spring-Valve          |
| 40   | 691752   | 1    | Retainer-Valve        |
| 45   | 690564   | 1    | Tappet-Valve          |
| 50   | 690193   | 1    | Manifold-Intake       |
| 51   | 692137   | 1    | Gasket-Intake         |
| 54   | 691148   | 1    | Screw                 |
| 192  | 691986   | 1    | Adjustor-Arm, Rocker  |
| 238  | 691843   | 1    | Cap-Valve             |
| 617  | 692138   | 1    | Seal-O Ring           |
| 830  | 691095   | 1    | Stud-Arm, Rocker      |
| 868  | 690968   | 1    | Seal-Valve            |
| 883  | 692236   | 1    | Gasket-Exhaust        |
| 914  | 690960   | 1    | Screw                 |
| 1022 | 272475   | 1    | Gasket-Cover, Rocker  |
| 1023 | 692492   | 1    | Cover-Rocker          |

| Ref  | Part No. | Qty. | Description     |
|------|----------|------|-----------------|
| 1026 | 692003   | 1    | Rod-Push        |
| 1026 | 692011   | 1    | Rod-Push        |
| 1029 | 691751   | 1    | Arm-Rocker      |
| 1034 | 690822   | 1    | Guide-Rod, Push |




Assemblies include all parts shown in frames.

# Crankshaft Assembly

## Briggs and Stratton 280h07-0166-e1

| Ref  | Part No. | Qty. | Description                       |  |  |  |  |
|------|----------|------|-----------------------------------|--|--|--|--|
| 16   | 697127   | 1    | Crankshaft                        |  |  |  |  |
| 24   | 222698   | 1    | Key                               |  |  |  |  |
| 25   | 698371   | 1    | Piston ASM (Standard)             |  |  |  |  |
| 25   | 698393   | 1    | Piston ASM (.010 Oversize)        |  |  |  |  |
| 25   | 698394   | 1    | Piston ASM (.020 Oversize)        |  |  |  |  |
| 25   | 698395   | 1    | Piston ASM (.030 Oversize)        |  |  |  |  |
| 26   | 697375   | 1    | Ring Set (Standard)               |  |  |  |  |
| 26   | 698396   | 1    | Ring Set (.010 Oversize)          |  |  |  |  |
| 26   | 698397   | 1    | Ring Set (.020 Oversize)          |  |  |  |  |
| 26   | 698398   | 1    | Ring Set (.030 Oversize)          |  |  |  |  |
| 27   | 698469   | 1    | Lock-Pin, Piston                  |  |  |  |  |
| 28   | 697099   | 1    | Pin-Piston (STD)                  |  |  |  |  |
| 29   | 697126   | 1    | Rod-Connecting (Standard)         |  |  |  |  |
| 29   | 697263   | 1    | Rod-Connecting (.020In Undersize) |  |  |  |  |
| 32   | 692852   | 1    | Screw                             |  |  |  |  |
| 146  | 691639   | 1    | Key-Timing                        |  |  |  |  |
| 741  | 697128   | 1    | Gear-Timing                       |  |  |  |  |
| 757  | 697607   | 1    | Link-Counterweight                |  |  |  |  |
| 758  | 697134   | 1    | Counterweight                     |  |  |  |  |
| 759  | 697392   | 1    | Pin-Counterweight                 |  |  |  |  |
| 1270 | 697156   | 1    | Plug-Counterweight, Avs           |  |  |  |  |




Assemblies include all parts shown in frames.

# Crankcase Assembly

## Briggs and Stratton 280h07-0166-e1


| Ref    | Part No. | Qty. | Description           |  |  |  |  |
|--------|----------|------|-----------------------|--|--|--|--|
| ④      | 697106   | 1    | Sump-Engine           |  |  |  |  |
| ④④12   | 697110   | 1    | Gasket-Crankcase      |  |  |  |  |
| ④15    | 690946   | 1    | Plug-Drain, Oil       |  |  |  |  |
| ④④20   | 690947   | 1    | Seal-Oil              |  |  |  |  |
| ④22    | 692125   | 1    | Screw                 |  |  |  |  |
| ④43    | 691968   | 1    | Slinger-Governor, Oil |  |  |  |  |
| ④46    | 698577   | 1    | Camshaft              |  |  |  |  |
| ④1051A | 698802   | 1    | Ring-Retaining        |  |  |  |  |



Assemblies include all parts shown in frames.

# Oil Filter, Tube and Pump Assembly Briggs and Stratton 280h07-0166-e1

| Ref   | Part No. | Qty. | Description           |
|-------|----------|------|-----------------------|
| ③523  | 697086   | 1    | Dipstick              |
| ③③524 | 691032   | 1    | Seal-O Ring           |
| ③525  | 697184   | 1    | Tube-Dipstick         |
| ③③842 | 691031   | 1    | Seal-O Ring           |
| ③847  | 697611   | 1    | Dipstick And Tube ASM |




Assemblies include all parts shown in frames.

## Carburetor Assembly

### Briggs and Stratton 280h07-0166-e1

| Ref           | Part No. | Qty. | Description                 |
|---------------|----------|------|-----------------------------|
| ⑤ ④ 51<br>⑤ ⑥ | 692137   | 1    | Gasket-Intake               |
| ⑤ 53          | 690227   | 1    | Stud                        |
| ⑤ ⑤ 93        | 690602   | 1    | Bushing-Shaft, Throttle     |
| ⑤ 94          | 498030   | 1    | Idle Mixture Kit            |
| ⑤ ⑤ 95        | 691636   | 1    | Screw                       |
| ⑤ 98          | 495800   | 1    | Idle Speed Kit              |
| ⑤ ⑤ 104       | 690525   | 1    | Pin-Hinge, Carburetor Float |
| ⑤ ⑤ 105       | 231855   | 1    | Valve-Needle, Float         |
| ⑤ ⑤ 106       | 690577   | 1    | Seat-Inlet                  |
| ⑤ 108         | 690464   | 1    | Valve-Choke                 |
| ⑤ 108A        | 692344   | 1    | Valve-Choke                 |
| ⑤ ⑤ 117       | 694352   | 1    | Jet-Main (STD)              |
| ⑤ 118         | 697228   | 1    | Jet-Main (High Altitude)    |
| ⑤ 125         | 697190   | 1    | Carburetor                  |
| ⑤ 130         | 691750   | 1    | Valve-Throttle              |
| ⑤ 131         | 494379   | 1    | Throttle Shaft Kit          |
| ⑤ 133         | 494381   | 1    | Float-Carburetor            |
| ⑤ ⑥ 137<br>⑤  | 281165   | 1    | Gasket-Bowl, Float          |
| ⑤ 141         | 495097   | 1    | Choke Shaft Kit             |
| ⑤ 141A        | 495931   | 1    | Choke Shaft Kit             |
| ⑤ ⑤ 142       | 697140   | 1    | Nozzle-Carburetor           |
| ⑤ 186         | 692317   | 1    | Connector-Hose              |

| Ref          | Part No. | Qty. | Description          |
|--------------|----------|------|----------------------|
| ⑤ 187        | 697098   | 1    | Line-Fuel            |
| ⑤ 240        | 394358   | 1    | Filter-Fuel          |
| ⑤ ⑥ 276<br>⑤ | 692255   | 1    | Washer-Sealing       |
| ⑤ 601        | 95162    | 1    | Clamp-Hose           |
| ⑤ ⑤ 634      | 690801   | 1    | Spring / Seal ASM    |
| ⑤ ⑤ 634A     | 690802   | 1    | Spring And Seal ASM  |
| ⑤ 654        | 690958   | 1    | Nut                  |
| ⑤ 947        | 694393   | 1    | Solenoid-Fuel        |
| ⑤ 950        | 691657   | 1    | Screw                |
| ⑤ 975        | 495933   | 1    | Bowl-Float           |
| ⑤ ⑤ 987      | 691326   | 1    | Seal-Shaft, Throttle |
| ⑤ 1091       | 691333   | 1    | Cap-Limiter          |




Assemblies include all parts shown in frames.

# Governor Assembly

## Briggs and Stratton 280h07-0166-e1

| Ref  | Part No. | Qty. | Description               | Ref  | Part No. | Qty. | Description |
|------|----------|------|---------------------------|------|----------|------|-------------|
| 188  | 691693   | 1    | Screw                     | 1119 | 691183   | 1    | Screw       |
| 202  | 691841   | 1    | Link-Governor, Mechanical |      |          |      |             |
| 209  | 692208   | 1    | Spring-Governor           |      |          |      |             |
| 216  | 691840   | 1    | Link-Choke                |      |          |      |             |
| 222  | 694042   | 1    | Bracket-Control           |      |          |      |             |
| 227  | 691374   | 1    | Lever-Control, Governor   |      |          |      |             |
| 232  | 691842   | 1    | Spring-Link, Governor     |      |          |      |             |
| 265  | 691024   | 1    | Clamp-Casing              |      |          |      |             |
| 267  | 695134   | 1    | Screw                     |      |          |      |             |
| 333  | 492341   | 1    | Armature-Magneto          |      |          |      |             |
| 334  | 691061   | 1    | Screw                     |      |          |      |             |
| 356  | 697089   | 1    | Stop-Wire                 |      |          |      |             |
| 474  | 696457   | 1    | Alternator                |      |          |      |             |
|      | 696458   | 1    | Alternator                |      |          |      |             |
| 501  | 691188   | 1    | Regulator                 |      |          |      |             |
| 501  | 691185   | 1    | Regulator                 |      |          |      |             |
| 505  | 691251   | 1    | Nut                       |      |          |      |             |
| 526  | 697088   | 1    | Screw                     |      |          |      |             |
|      | 697348   | 1    | Screw                     |      |          |      |             |
| 562  | 691119   | 1    | Screw                     |      |          |      |             |
| 729  | 691335   | 1    | Clip-Wire                 |      |          |      |             |
| 789  | 692037   | 1    | Wiring-Harness            |      |          |      |             |
| 851  | 692424   | 1    | Terminal-Spark Plug       |      |          |      |             |
| 1059 | 698516   | 1    | Screw And Washer Kit      |      |          |      |             |




Assemblies include all parts shown in frames.

# Blower Housing Assembly

## Briggs and Stratton 280h07-0166-e1



| Ref   | Part No. | Qty. | Description                   | Ref  | Part No. | Qty. | Description           |
|-------|----------|------|-------------------------------|------|----------|------|-----------------------|
| 323   | 693556   | 1    | Flywheel                      | 1267 | 697419   | 1    | Latch-Housing, Blower |
| 37    | 697352   | 1    | Guard-Flywheel                |      |          |      |                       |
| 73    | 697384   | 1    | Screen-Rotating               |      |          |      |                       |
| 74    | 697897   | 1    | Screw                         |      |          |      |                       |
| 75    | 690582   | 1    | Washer-Flywheel               |      |          |      |                       |
| 78    | 691003   | 1    | Screw                         |      |          |      |                       |
| 304   | 698599   | 1    | Housing-Blower                |      |          |      |                       |
| 305   | 697102   | 1    | Screw                         |      |          |      |                       |
| 305A  | 697103   | 1    | Screw                         |      |          |      |                       |
| 363   | 19203    | 1    | Puller-Flywheel               |      |          |      |                       |
| 431   | 697122   | 1    | Elbow-Intake                  |      |          |      |                       |
| 445   | 698083   | 1    | Filter-Cartridge, Air Cleaner |      |          |      |                       |
| 643   | 698401   | 1    | Retainer-Filter, Air          |      |          |      |                       |
| 783   | 693713   | 1    | Gear-Pinion                   |      |          |      |                       |
| 967   | 697015   | 1    | Filter-Cleaner, Pre           |      |          |      |                       |
| 968   | 698403   | 1    | Cover-Cleaner, Air            |      |          |      |                       |
| 1005  | 697853   | 1    | Fan-Flywheel                  |      |          |      |                       |
| 1036  | 695700   | 1    | Label-Emission                |      |          |      |                       |
| 1040  | 698368   | 1    | Plate-Trim                    |      |          |      |                       |
| 1044  | 691658   | 1    | Screw-Crankshaft Extension    |      |          |      |                       |
| 1051  | 691265   | 1    | Ring-Retaining                |      |          |      |                       |
| 1070  | 690372   | 1    | Screw                         |      |          |      |                       |
| 1266  | 691917   | 1    | Seal-O Ring                   |      |          |      |                       |
| 1266A | 697123   | 1    | Seal-O Ring                   |      |          |      |                       |



# Starter Assembly

## Briggs and Stratton 280h07-0166-e1



| Ref  | Part No. | Qty. | Description      |  |  |  |  |
|------|----------|------|------------------|--|--|--|--|
| 309  | 693551   | 1    | Motor-Starter    |  |  |  |  |
| 310  | 690323   | 1    | Bolt             |  |  |  |  |
| 311  | 497608   | 1    | Brush Set        |  |  |  |  |
| 462  | 691261   | 1    | Washer           |  |  |  |  |
| 503  | 691532   | 1    | Strap-Starter    |  |  |  |  |
| 510  | 693699   | 1    | Drive-Starter    |  |  |  |  |
| 513  | 692024   | 1    | Clutch-Drive     |  |  |  |  |
| 544  | 692034   | 1    | Armature-Starter |  |  |  |  |
| 579  | 691029   | 1    | Nut              |  |  |  |  |
| 697  | 690372   | 1    | Screw            |  |  |  |  |
| 729A | 691224   | 1    | Clip-Wire        |  |  |  |  |
| 729B | 694123   | 1    | Clip-Wire        |  |  |  |  |
| 783  | 693713   | 1    | Gear-Pinion      |  |  |  |  |
| 797  | 693167   | 1    | Nut              |  |  |  |  |
| 801  | 691283   | 1    | Cap-Drive        |  |  |  |  |
| 802  | 691286   | 1    | Cap-End          |  |  |  |  |
| 803  | 693757   | 1    | Housing-Starter  |  |  |  |  |
| 1051 | 691265   | 1    | Ring-Retaining   |  |  |  |  |
| 1090 | 691293   | 1    | Retainer-Brush   |  |  |  |  |



Assemblies include all parts shown in frames.

**Gasket Assembly**  
**Briggs and Stratton 280h07-0166-e1**

| Ref       | Part No. | Qty. | Description           |  |  |  |  |
|-----------|----------|------|-----------------------|--|--|--|--|
| 3 3       | 391086   | 1    | Seal-Oil              |  |  |  |  |
| 3 7       | 273280   | 1    | Gasket-Head, Cylinder |  |  |  |  |
| 3 9       | 697109   | 1    | Gasket-Breather       |  |  |  |  |
| 3 12      | 697110   | 1    | Gasket-Crankcase      |  |  |  |  |
| 3 20      | 690947   | 1    | Seal-Oil              |  |  |  |  |
| 3 4 51    | 692137   | 1    | Gasket-Intake         |  |  |  |  |
| 3 6       |          |      |                       |  |  |  |  |
| 3 358     | 697151   | 1    | Engine Gasket Set     |  |  |  |  |
| 3 4 617   | 692138   | 1    | Seal-O Ring           |  |  |  |  |
| 3 8       |          |      |                       |  |  |  |  |
| 3 524     | 691032   | 1    | Seal-O Ring           |  |  |  |  |
| 3 691     | 692407   | 1    | Seal-Shaft, Governor  |  |  |  |  |
| 3 842     | 691031   | 1    | Seal-O Ring           |  |  |  |  |
| 3 4 868   | 690968   | 1    | Seal-Valve            |  |  |  |  |
| 3         |          |      |                       |  |  |  |  |
| 3 8 1022  | 272475   | 1    | Gasket-Cover, Rocker  |  |  |  |  |
| 3 1095    | 691581   | 1    | Valve Gasket Set      |  |  |  |  |
| 3 5 1266  | 691917   | 1    | Seal-O Ring           |  |  |  |  |
| 3         |          |      |                       |  |  |  |  |
| 3 5 1266A | 697123   | 0    | Seal-O Ring           |  |  |  |  |
| 3         |          |      |                       |  |  |  |  |



Assemblies include all parts shown in frames.

**Carburetor Overhaul Kit Assembly**  
**Briggs and Stratton 280h07-0166-e1**

| Ref          | Part No. | Qty. | Description                 |  |  |  |  |
|--------------|----------|------|-----------------------------|--|--|--|--|
| 3451<br>56   | 692137   | 1    | Gasket-Intake               |  |  |  |  |
| 5893         | 690602   | 1    | Bushing-Shaft, Throttle     |  |  |  |  |
| 5895         | 691636   | 1    | Screw                       |  |  |  |  |
| 58104        | 690525   | 1    | Pin-Hinge, Carburetor Float |  |  |  |  |
| 58105        | 231855   | 1    | Valve-Needle, Float         |  |  |  |  |
| 58106        | 690577   | 1    | Seat-Inlet                  |  |  |  |  |
| 58117        | 694352   | 1    | Jet-Main (STD)              |  |  |  |  |
| 8121         | 697154   | 1    | Carburetor Overhaul Kit     |  |  |  |  |
| 56137<br>8   | 281165   | 1    | Gasket-Bowl, Float          |  |  |  |  |
| 58142        | 697140   | 1    | Nozzle-Carburetor           |  |  |  |  |
| 58231        | 691636   | 1    | Screw                       |  |  |  |  |
| 56276<br>8   | 692255   | 1    | Washer-Sealing              |  |  |  |  |
| 55617<br>8   | 692138   | 1    | Seal-O Ring                 |  |  |  |  |
| 58634        | 690801   | 1    | Spring / Seal ASM           |  |  |  |  |
| 58634A       | 690802   | 1    | Spring And Seal ASM         |  |  |  |  |
| 8977         | 690192   | 1    | Carburetor Gasket Set       |  |  |  |  |
| 58987        | 691326   | 0    | Seal-Shaft, Throttle        |  |  |  |  |
| 551266<br>8  | 691917   | 0    | Seal-O Ring                 |  |  |  |  |
| 551266A<br>8 | 697123   | 1    | Seal-O Ring                 |  |  |  |  |

# Attachments and Accessories

For 74402 - TimeCutter Z380 Riding Mower

| Product Name                      | Model/Part |
|-----------------------------------|------------|
| Smooth Caster Wheel Kit . . . . . | 105-1856   |
| Tire Chain Kit . . . . .          | 107-1737   |
| Armrest Kit . . . . .             | 108-6163   |
| 38 Inch Twin Bagger . . . . .     | 79215      |
| 48 Inch Snow Blade . . . . .      | 79216      |

## NOTES

## NOTES

