




PART NO. 92-6020

PARTS  
CATALOG**STARTER MOTOR REPLACEMENT KIT**

C-2095

**MOUNTING BRACKET ASSEMBLY**

| Ref. No. | Part No. | Description        | No. Used |
|----------|----------|--------------------|----------|
| †1       | 3296-42  | Nut – Lock         | 2        |
| 2        | 92-6018  | Bracket – Mounting | 1        |
| 3        | 84-5290  | Motor – Starter    | 1        |


| Ref. No. | Part No. | Description            | No. Used |
|----------|----------|------------------------|----------|
| 4        | 56-6380  | Screw – Mounting       | 2        |
| *5       | 11-9760  | Screw – Thread Forming | 3        |

† For Use with Units w/Studs

\*For Use with Units w/out Studs

Copyright 1994 The Toro Company  
All Rights Reserved

TPS



C-1738

## STARTER MOTOR & SWITCH HOUSING ASSEMBLY

| Ref. No. | Part No. | Description          | No. Used |
|----------|----------|----------------------|----------|
| 1        | 61-4680  | Ring - Lock          | 1        |
| 2        | 61-4670  | Stop - Pinion        | 1        |
| 3        | 61-4690  | Spring - Anti Drift  | 3        |
| 4        | 61-4700  | Pinion Assembly      | 1        |
| 5        | 80-0710  | Housing - Mtg.       | 1        |
| 6        | 2412-91  | R-Clamp              | 1        |
| 7        | 61-4820  | Switch - Starter     | 1        |
| 8        | 61-4810  | Boot - Switch        | 1        |
| 9        | 80-3740  | Cap - Switch Housing | 1        |
| 10       | 32144-27 | Screw - Self Tap     | 3        |
| 11       | 36-8370  | Plug - Power         | 1        |

| Ref. No. | Part No.  | Description              | No. Used |
|----------|-----------|--------------------------|----------|
| 12       | 80-3730   | Base - Switch Housing    | 1        |
| 13       | 3296-2    | Nut - Lock               | 2        |
| 14       | 83-7350   | Housing - Motor          | 1        |
| 15       | 70-7801   | Starter Motor Assembly   | 1        |
| 16       | 70-7900   | Bushing - upper          | 1        |
| 17       | 70-7850   | Cover - Gear             | 1        |
| 18       | 92-6003   | Shaft & Gear Assembly    | 1        |
| 19       | 56-6380   | Screw - Mounting         | 2        |
| 20       | 32144-101 | Screw - Phillips Pan Hd. | 2        |