Form Number 3361-957 Rev B

# Commercial Walk-Behind Mower

## Floating Deck, T-Bar, Hydro Drive with 36in TURBO FORCE® Cutting Unit

**Model No. 38494 - 290000001 and up.**

# Parts Catalog

**Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2009
All Rights Reserved

Register your product at www.Toro.com

# Contents


| Description | Page |
|---|---|
| Engine and Clutch Assembly | 3 |
| Fuel System, Hydraulic Pump and Filter Assembly | 4 |
| Hydraulic Pump Assembly No. 115-4480 | 5 |
| Hydraulic Pump Assembly No. 115-4481 | 6 |
| Pump Drive and Wheel Assembly | 7 |
| Hydraulic Motor Assembly 104-1171 | 8 |
| Lower Control Assembly | 9 |
| Hydraulic Hose Assembly | 10 |
| Upper Control Assembly | 11 |
| Control Panel Assembly | 12 |
| Battery Assembly | 13 |
| Parking Brake Assembly | 14 |
| Power-Take-Off Idler Assembly | 15 |
| Carrier Frame Assembly | 16 |
| Deck Drive and Baffle Assembly | 17 |
| Deck Assembly No. 112-7080 | 18 |
| Lever Assembly No. 107-1664 | 19 |
| Spindle Assembly No. 110-0730 | 20 |
| Spindle Assembly No. 110-0728 | 21 |
| Outer Deck Assembly | 22 |
| Deflector Assembly No. 110-0790 | 23 |
| Cylinder and Crankcase Assembly Kawasaki FH541V-ES24 | 24 |
| Piston and Crankshaft Assembly Kawasaki FH541V-ES24 | 25 |
| Valve and Camshaft Assembly Kawasaki FH541V-ES23 | 26 |
| Lubrication Equipment Assembly Kawasaki FH541V-ES24 | 27 |
| Cooling Equipment Assembly Kawasaki FH541V-ES24 | 28 |
| Electric Equipment Assembly Kawasaki FH541V-ES24 | 29 |
| Control Equipment Assembly Kawasaki FH541V-ES24 | 30 |
| Carburetor Assembly Kawasaki FH541V-ES24 | 31 |
| Air Filter and Muffler Assembly Kawasaki FH541V-ES24 | 32 |
| Fuel Tank and Valve Assembly Kawasaki FH541V-ES24 | 33 |
| Starter Assembly Kawasaki FH541V-ES24 | 34 |
| Label Set Kawasaki FH541V-ES24 | 35 |
| Attachments and Accessories List | 36 |


# Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

| | |
|---|---|
| AR | as required |
| ASM | assembly |
| BBC | blade brake clutch |
| CARR | carriage |
| CCW | counter clock wise |
| CW | clockwise |
| DEG | degrees |
| ECM | electronic control module |
| EXT | external |
| FH | flat head |
| GA | gauge |
| HD | heavy-duty |
| HF | hex flange |
| HH | hex head |
| HHF | hex head flange |
| HHFTF | hex head flange thread forming |
| HJ | hex jam |
| HLH | hex lag head |
| HOC | height-of-cut |
| HSBH | hex socket button head |
| HSFH | hex socket flat head |
| HSH | hex socket head |
| HWH | hex washer head |
| HWHTF | hex washer head thread forming |
| HYD | hydraulic |
| LH | left hand |
| NI | nylon insert |
| NPTF | national pipe thread fine |
| PFH | phillips flat head |
| PPH | phillips pan head |
| PPHTF | phillips pan head thread forming |
| PRH | phillips round head |
| PTH | phillips truss head |
| PTO | power-take-off |
| RH | right hand |
| ROPS | roll-over protection system |
| SFH | slotted fillister head |
| SHH | slotted hex head |
| SHWH | slotted hex washer head |
| SPH | slotted pan head |
| SQH | square head |
| SRH | slotted round head |
| STD | standard |
| TAP | self tapping |
| TTH | torx truss head |

# Footnotes

❶ Not serviced separately


❷ Obtain parts from www.kawpowerepc.com




# Engine and Clutch Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 32144-4 | 2 | Screw-HWH |
| 2 | 3220-2 | 2 | Nut-Jam |
| 3 | 115-4191 | 1 | Harness-Wire |
| 4 | 1-513075 | 1 | Switch-Solenoid |
| 5 | 112-7069 | 1 | Grommet |
| 6 | 32128-20 | 6 | Nut-HF |
| 7 | 1-613235 | 4 | Washer |
| 8 | 104-6373 | 1 | Tube-Retainer |
| 9 | 1-633630 | 2 | Grommet-Brake |
| 10 | 1-633543-03 | 1 | Strap-Clutch, Brake |
| 11 | 1-633545 | 2 | Spacer |
| 12 | 322-11 | 1 | Screw-HH |
| 13 | 1-603610 | 2 | Washer-Spring |
| 14 | 322-7 | 4 | Screw-HH |
| 15 | 3212-9 | 1 | Screw-HH |
| 16 | 107-4136 | 1 | Washer |
| 17 | 105-2635 | 1 | Clutch / Brake |
| 18 | 44-5940 | 1 | Pulley |
| 19 | 608006 | 1 | Key-Square |
| 20 | 3256-23 | 5 | Washer-Flat |
| 21 | 94-5847-01 | 1 | Cover-Pulley |
| 24 | 92-6877 | 1 | Valve-Drain, Oil |
| 25 | 103-1966 | 1 | Adapter |
| 26 | 106-0699 | 1 | Decal-Warning |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❶❷27 | | 1 | Engine-Kawasaki, FH541V-Es24 |
| 28 | 322-9 | 1 | Screw-HH |
| 29 | 2412-87 | 1 | Clamp-Cable |
| 30 | 3255-8 | 1 | Washer-Lock |
| 31 | 112-9707 | 1 | Cable-Battery, Pos |
| 32 | 32149-2 | 1 | Nut-Keps |
| 33 | 56-6360 | 1 | Filter-Fuel |
| 34 | 2412-72 | 1 | Clip-Closed, Insulated |
| 35 | 12-3270 | 2 | Screw |
| 37 | 3253-4 | 2 | Washer-Lock |
| 38 | 115-4150-03 | 1 | Muffler Shield ASM |
| 39 | 115-4154-03 | 1 | Bracket-Muffler |
| 40 | 322-3 | 4 | Screw-HH |
| 41 | 94-2413 | 4 | U-Nut |
| 42 | 2412-134 | 1 | Clamp-R |
| 43 | 3290-378 | 3 | Tie-Cable |
| 44 | 109102 | 1 | Fuse-25 Amp |
| 45 | 109103 | 1 | Fuse-30 Amp |
| 46 | 218-578 | 1 | Fuse-10 Amp |
| 99 | 103-1964 | 1 | Hose-Drain, Oil |




# Fuel System, Hydraulic Pump and Filter Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 88-3980 | 1 | Gas Cap ASM |
| 1:3 | 88-4010 | 1 | Gasket-Cap, Gas |
| 2 | 106-0730 | 1 | Fuel Tank ASM |
| 2:2 | 103-2605 | 1 | Fitting-Fuel, Bulkhead |
| 3 | 321-4 | 2 | Screw-HH |
| 4 | 107-8433 | 1 | HYD Reservoir ASM |
| ❶4:1 | | 1 | Reservoir-HYD |
| 4:1:1 | 103-1948 | 1 | Cap-Reservoir, HYD |
| 4:1:2 | 103-1949 | 1 | Gasket-Cap |
| 4:2 | 115-4212 | 1 | Decal-Warning |
| 5 | 353-374 | 4 | Elbow-90 DEG |
| 5:1 | 237-42 | 1 | O-Ring |
| 6 | 32128-33 | 2 | Nut-HF |
| 7 | 3256-23 | 4 | Washer-Flat |
| 8 | 104-8121 | 2 | Stud-Threaded |
| 9 | 1-633349 | 2 | Spring-Tank, Fuel |
| 10 | 3296-47 | 2 | Nut-Lock, NI |
| 11 | 32128-42 | 4 | Nut-HF |
| 12 | 353-384 | 3 | Fitting-Straight |
| 12:1 | 237-42 | 1 | O-Ring |
| 13 | 115-4480 | 1 | Pump-Hydraulic |
| 14 | 340-101 | 4 | Fitting-HYD, 45 DEG |
| 14:1 | 237-30 | 1 | O-Ring |
| 14:2 | 237-79 | 1 | O-Ring |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 15 | 324-5 | 4 | Screw-HH |
| 16 | 353-212 | 1 | Fitting-HYD, 45 DEG |
| 16:1 | 237-42 | 1 | O-Ring |
| 17 | 1-633750 | 1 | Filter-Oil, HYD |
| 17 | 1-633752 | 1 | Filter-HYD, Winter |
| 18 | 104-7836 | 1 | Head-Filter |
| 19 | 2412-98 | 4 | Clamp |
| 20 | 110-4894 | 1 | Hose-Fuel |
| 21 | 1-603770 | 1 | Valve-Fuel |
| 22 | 322-4 | 2 | Screw-HH |
| 23 | 3253-4 | 2 | Washer-Lock |
| 24 | 107-0588 | 1 | Hose-Fuel |
| 25 | 112-7069 | 1 | Grommet |
| 26 | 3253-3 | 2 | Washer-Lock |
| 27 | 321-3 | 2 | Screw-HH |
| 28 | 115-4481 | 1 | Pump-Hydraulic |




# Hydraulic Pump Assembly No. 115-4480

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 115-4464 | 1 | Housing Kit |
| 2 | 106-8752 | 1 | End Cap Kit (W/Poppets) |
| 3 | 106-8753 | 2 | Pin-Headless, Straight |
| 4 | 106-8754 | 4 | Bolt-HF |
| 5 | 106-8755 | 1 | O-Ring |
| 6 | 106-8756 | 1 | Charge Pump Kit |
| 7 | 104-2122 | 1 | Gerotor ASM |
| 8 | 106-8757 | 1 | O-Ring |
| 10 | 104-2111 | 2 | Capscrew |
| 15 | 106-8759 | 1 | Bypass Valve Kit |
| 18 | 103-2664 | 1 | Input Shaft Kit |
| 19 | 104-5311 | 1 | Bearing-Ball |
| 20 | 104-5310 | 1 | Seal-Lip |
| 21 | 104-5308 | 1 | Spacer |
| 22 | 104-5309 | 1 | Ring-Retaining |
| 25 | 103-2666 | 1 | Cylinder Block Kit |
| 29 | 94-1936 | 1 | Spring-Block |
| 30 | 94-1937 | 1 | Washer-Thrust, Block |
| 31 | 105-6185 | 1 | Plate-Valve |
| 32 | 94-1907 | 1 | Swashplate-Variable |
| 34 | 94-6922 | 1 | Bearing-Thrust |
| 37 | 115-4458 | 1 | Arm-Trunnion, Tapered Square |
| 38 | 94-1910 | 1 | Guide-Slot |
| 42 | 98-3252 | 2 | Valve-Check (W/Poppet) |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 44 | 106-8760 | 1 | Charge Relief Valve Kit |
| 49 | 114-8155 | 1 | Trunnion Seal Kit |
| 56 | 106-8762 | 1 | Plug-HSH |
| 66 | 106-8763 | 1 | Plug-HSH |
| 98 | 115-4459 | 1 | Kit-Return |
| 99 | 105-6184 | 1 | Seal Overhaul Kit |




# Hydraulic Pump Assembly No. 115-4481

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 115-4464 | 1 | Housing Kit |
| 2 | 106-8752 | 1 | End Cap Kit (W/Poppets) |
| 3 | 106-8753 | 2 | Pin-Headless, Straight |
| 4 | 106-8754 | 4 | Bolt-HF |
| 5 | 106-8755 | 1 | O-Ring |
| 6 | 106-8756 | 1 | Charge Pump Kit |
| 7 | 104-2122 | 1 | Gerotor ASM |
| 8 | 106-8757 | 1 | O-Ring |
| 10 | 104-2111 | 2 | Capscrew |
| 15 | 106-8759 | 1 | Bypass Valve Kit |
| 18 | 103-2664 | 1 | Input Shaft Kit |
| 19 | 104-5311 | 1 | Bearing-Ball |
| 20 | 104-5310 | 1 | Seal-Lip |
| 21 | 104-5308 | 1 | Spacer |
| 22 | 104-5309 | 1 | Ring-Retaining |
| 25 | 103-2666 | 1 | Cylinder Block Kit |
| 29 | 94-1936 | 1 | Spring-Block |
| 30 | 94-1937 | 1 | Washer-Thrust, Block |
| 31 | 105-6185 | 1 | Plate-Valve |
| 32 | 94-1907 | 1 | Swashplate-Variable |
| 34 | 94-6922 | 1 | Bearing-Thrust |
| 37 | 115-4458 | 1 | Arm-Trunnion, Tapered Square |
| 38 | 94-1910 | 1 | Guide-Slot |
| 42 | 98-3252 | 2 | Valve-Check (W/Poppet) |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 44 | 106-8760 | 1 | Charge Relief Valve Kit |
| 49 | 114-8155 | 1 | Trunnion Seal Kit |
| 56 | 106-8762 | 1 | Plug-HSH |
| 66 | 106-8763 | 1 | Plug-HSH |
| 98 | 115-4459 | 1 | Kit-Return |
| 99 | 105-6184 | 1 | Seal Overhaul Kit |




# Pump Drive and Wheel Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3296-6 | 1 | Nut-Lock |
| 2 | 98-0776 | 1 | Decal-Caution |
| 4 | 114-0243-01 | 1 | Frame ASM |
| 5 | 95-1526 | 1 | Shield-Trailing |
| 6 | 104-1171 | 2 | Motor-Wheel |
| 7 | 340-6 | 4 | Fitting-HYD, Straight |
| 7:1 | 237-30 | 1 | O-Ring |
| 7:2 | 237-80 | 1 | O-Ring |
| 8 | 3257-8 | 2 | Key-Woodruff |
| 9 | 95-1529 | 1 | Rod-Shield |
| 10 | 105-0800 | 2 | Wheel Hub / Stud ASM |
| 10:2 | 10-6830 | 4 | Stud-Type, Drive |
| 11 | 106-0892 | 2 | Wheel And Tire ASM |
| 11:1 | 104-6322 | 1 | Tire |
| 11:2 | 106-0893 | 1 | Wheel |
| 11:3 | 232-27 | 1 | Stem-Valve |
| 12 | 85-7310 | 2 | Nut-Motor, Wheel |
| 13 | 242-50 | 8 | Nut-Lug |
| 14 | 325-12 | 8 | Screw-HH |
| 15 | 3234-32 | 4 | Screw-HHF |
| 16 | 105-5648 | 2 | Pulley-Pump |
| 17 | 3234-22 | 2 | Screw-HHF |
| 18 | 68-9950 | 1 | Spring-Traction |
| 19 | 110-5049 | 1 | Belt-V |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 20 | 27-6230 | 1 | Bolt-Wheel |
| 21 | 3296-39 | 1 | Nut-Lock, NI |
| 22 | 86-4770 | 1 | Idler Lever ASM |
| 23 | 93-1622 | 1 | Pulley-Idler |
| 24 | 323-9 | 1 | Screw-HH |
| 25 | 3241-5 | 4 | Screw-Set |
| 26 | 1-807272 | 2 | Key |
| 27 | 9202204 | 1 | Washer |
| 28 | 32128-49 | 8 | Nut-HHF |
| 29 | 108-6657-01 | 2 | Plate-Frame |
| 30 | 32128-23 | 6 | Nut-HF |
| 32 | 3256-24 | 1 | Washer-Flat |





# Hydraulic Motor Assembly 104-1171

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 1-000119 | 1 | Seal Kit |
| ❶1:1 | | 1 | Ring-Back Up |
| ❶1:2 | | 1 | Seal-Commutator |
| ❶1:3 | | 1 | Seal-Shaft (Viton) |
| ❶1:4 | | 1 | Washer-Back Up, Steel |
| ❶1:5 | | 5 | Ring-Seal (Viton) |
| ❶1:7 | | 1 | Seal-Dirt And Water |
| 2 | 3257-8 | 1 | Key-Woodruff |
| 3 | 85-7310 | 1 | Nut-Motor, Wheel |
| 4 | 106-5549 | 6 | Bolt-Special |
| 5 | 106-8764 | 1 | Shaft-Coupling |




# Lower Control Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 114-0227 | 2 | Bracket-Adapter, Pump |
| 2 | 322-4 | 4 | Screw-HH |
| 3 | 3296-29 | 4 | Nut-Lock, NI |
| 4 | 3296-2 | 4 | Nut-Lock, NI |
| 5 | 114-0282 | 2 | Screw-HH |
| 6 | 3217-5 | 2 | Nut-Hex |
| 9 | 105-0023 | 2 | Switch-Proximity |
| 10 | 32105-13 | 4 | Screw-HWH |




# Hydraulic Hose Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 112-9704 | 2 | HYD Hose ASM |
| 2 | 114-3430 | 2 | HYD Hose ASM |
| 3 | 114-3436 | 1 | HYD Hose ASM |
| 4 | 105-5699 | 1 | HYD Hose ASM |
| 5 | 114-3434 | 1 | HYD Hose ASM |


| | | | |
|---|---|---|---|




# Upper Control Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 115-4200 | 1 | T-Bar Handle ASM |
| 1:2 | 115-4179 | 1 | Decal-Warning, Control |
| 2 | 3234-42 | 6 | Screw-HHF |
| 3 | 32128-43 | 6 | Nut-Flange |
| 4 | 3229-1 | 2 | Screw-CARR |
| 5 | 3234-4 | 4 | Screw-HHF |
| 6 | 114-0235 | 1 | Bracket-Support |
| 7 | 114-0272-03 | 1 | Control Lever ASM |
| 8 | 114-0260 | 2 | Shaft-Pivot |
| 9 | 114-0234 | 1 | Motion Control ASM |
| 10 | 103-9928 | 6 | Bearing |
| 11 | 3296-42 | 3 | Nut-Lock, NI |
| 13 | 114-0268 | 1 | Cam-Lever, Handle Stop |
| 14 | 114-0239 | 1 | Screw-HSH |
| 15 | 114-0238-03 | 1 | Lever ASM |
| 16 | 3296-47 | 1 | Nut-Lock, NI |
| 17 | 114-0241 | 2 | Grip-Lever |
| 18 | 114-0249 | 1 | Spring-Extension |
| 19 | 1-513152 | 1 | Switch-Closed, Normally |
| 20 | 1-633181 | 1 | Plate-Tapped |
| 21 | 32105-13 | 2 | Screw-HWH |
| 22 | 3256-22 | 1 | Washer-Flat |
| 23 | 114-3424 | 1 | Decal-Control |
| 24 | 115-4189 | 1 | Decal-Panel, Control |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 26 | 117-2718 | 1 | Decal-Arrester, Spark |





# Control Panel Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 114-0275 | 2 | Rod-Control, Upper |
| 2 | 114-0276 | 2 | Rod-Control, Lower |
| 3 | 114-0279 | 1 | Switch-PTO |
| 4 | 110-4994 | 1 | Cable-Throttle |
| 5 | 104-7050 | 1 | Tube-Manual |
| 6 | 115-4180 | 1 | Module-Meter, Hour |
| 7 | 114-0270-03 | 1 | Cover-Panel, Control |
| 8 | 2412-120 | 2 | R-Clamp |
| 9 | 95-1504 | 2 | Turnbuckle |
| 10 | 32103-3 | 2 | Nut-Wing |
| 12 | 3290-360 | 4 | Screw-HH |
| 13 | 116-0050 | 1 | Switch-Ignition |
| 14 | 32104-76 | 6 | Screw |
| 15 | 3256-23 | 4 | Washer-Flat |
| 16 | 3290-307 | 4 | Pin-Hair |
| 18 | 3296-2 | 4 | Nut-Lock, NI |
| 19 | 63-8360 | 1 | Key-Ignition |
| 20 | 104-7048 | 1 | Cap-Housing |
| 21 | 110-4995 | 1 | Cable-Choke |
| 22 | 3290-378 | 4 | Tie-Cable |
| 23 | 114-0281 | 2 | Nut-Wing, LH |




# Battery Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3296-42 | 2 | Nut-Lock, NI |
| 2 | 104-8568-03 | 1 | Plate-Hold Down, Battery |
| 3 | 3256-2 | 2 | Washer-Flat |
| 4 | 32149-1 | 2 | Nut-Keps |
| 5 | 112-9709 | 1 | Cable-Battery, Black |
| 6 | 112-9708 | 1 | Cable-Battery, Red |
| 7 | 322-3 | 2 | Screw-HH |
| 8 | 104-8162 | 1 | Battery |
| 9 | 62-4300 | 1 | Pad-Skid, Anti |
| 10 | 105-3150-01 | 1 | Battery Tray ASM |
| 11 | 104-8567 | 2 | Holdown-Battery |




# Parking Brake Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3296-45 | 1 | Nut-Lock, NI |
| 2 | 112-8716-01 | 1 | Support-Handle |
| 3 | 112-8720 | 1 | Decal-Brake |
| 4 | 3296-29 | 2 | Nut-Lock, NI |
| 5 | 1-633181 | 1 | Plate-Tapped |
| 6 | 32105-13 | 2 | Screw-HWH |
| 7 | 1-513152 | 1 | Switch-Closed, Normally |
| 8 | 1-808285 | 2 | Pin-Clevis |
| 9 | 106-0671-01 | 1 | Handle-Brake |
| 10 | 257-7 | 1 | Bearing-Thrust |
| 11 | 325-17 | 1 | Screw-HH |
| 12 | 115-1465 | 1 | Brake Rod ASM |
| 12:1 | 108-2747 | 1 | Rod-Brake |
| 12:2 | 1-633131 | 2 | Yoke-Linkage, Brake |
| 12:3 | 3219-3 | 1 | Nut-Hex |
| 13 | 1-303020 | 1 | Grip-Lever |
| 14 | 3290-307 | 2 | Pin-Hair |
| 15 | 322-6 | 2 | Screw-HH |
| 18 | 323-6 | 3 | Screw-HH |
| 19 | 3296-39 | 3 | Nut-Lock, NI |
| 20 | 110-4976-01 | 1 | Parking Brake ASM |
| 21 | 3290-357 | 2 | Nut-HHF, Whiz |
| 22 | 27-5240 | 1 | Bolt-Shoulder |
| 23 | 613386 | 1 | Spring-Brake |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 24 | 56-6590 | 1 | Bolt-Wheel |
| 26 | 112-9972 | 1 | Washer-Conical, Spring |




# Power-Take-Off Idler Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 3296-39 | 1 | Nut-Lock, NI |
| 4 | 52-2860 | 3 | Washer |
| 5 | 104-6377 | 1 | Tube-Idler |
| 6 | 112-7055 | 1 | Idler Arm ASM |
| 6:1 | 1-513034 | 2 | Sleeve-Bearing |
| 6:2 | 302-5 | 1 | Fitting-Grease |
| 7 | 323-42 | 1 | Screw-HH |
| 8 | 323-6 | 1 | Screw-HH |
| 9 | 98-5975 | 1 | Washer-Belleville |
| 10 | 3256-24 | 1 | Washer-Flat |
| 11 | 1-413099 | 1 | Pulley-Idler |
| 12 | 105-8443 | 1 | Spring-Extension |
| 13 | 323-10 | 1 | Screw-HH |
| 14 | 3290-357 | 1 | Nut-HHF, Whiz |
| 15 | 32128-21 | 1 | Nut-HF |
| 16 | 112-7059-01 | 1 | Weight-Cast |
| 17 | 322-9 | 2 | Screw-HH |
| 18 | 3256-23 | 2 | Washer-Flat |
| 19 | 3296-26 | 2 | Nut-Lock, NI |




# Carrier Frame Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 110-6960 | 1 | Carrier Frame ASM |
| 1:2 | 32148-9 | 2 | Insert-Nut |
| 1:3 | 94-1291 | 4 | Bushing |
| 1:4 | 302-5 | 2 | Fitting-Grease |
| 2 | 110-6970 | 1 | Cover-Frame, Carrier |
| 3 | 112-9710 | 1 | Decal |
| 4 | 1-804254 | 3 | Nut |
| 5 | 106-6778 | 3 | Bushing-Latch, Swell |
| 6 | 99-3058 | 3 | Washer |
| 7 | 106-6777 | 3 | Handle-Latch, Swell |
| 8 | 110-6971-01 | 1 | Shield-Belt |
| 10 | 104-1105 | 4 | Spacer-Support, Deck |
| 11 | 1-513336 | 2 | Bushing-Deck |
| 12 | 323-6 | 2 | Screw-HH |
| 13 | 3256-24 | 2 | Washer-Flat |
| 14 | 32120-33 | 2 | Ring-Retaining |
| 15 | 1-323539 | 4 | Spacer |
| 16 | 106-0635 | 2 | Decal-HOC |
| 17 | 105-3159-01 | 2 | Castor Fork ASM |
| 18 | 32153-5 | 2 | Nut-Lock, Side |
| 19 | 110-5024 | 2 | Wheel And Tire ASM |
| 19:2 | 112-7066 | 1 | Bearing-Roller |
| 19:3 | 1-513810 | 2 | Bushing |
| 19:4 | 302-61 | 1 | Zerk |


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 20 | 100-6453 | 2 | Bushing-Spanner |
| 21 | 325-19 | 2 | Screw-HH |
| 22 | 283-71 | 2 | Pin-Lynch |
| 23 | 3-6781 | 8 | Washer-Thrust |




# Deck Drive and Baffle Assembly


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 112-7080 | 1 | Deck ASM |
| 2 | 3290-357 | 22 | Nut-HHF, Whiz |
| 3 | 107-1664 | 1 | Lever ASM |
| 4 | 323-8 | 1 | Screw-HH |
| 5 | 1-633166 | 1 | Pulley-Idler |
| 6 | 3256-24 | 4 | Washer-Flat |
| 7 | 98-5975 | 1 | Washer-Belleville |
| 8 | 323-6 | 1 | Screw-HH |
| 9 | 3296-39 | 1 | Nut-Lock, NI |
| 10 | 51-3660 | 1 | Pulley-Idler |
| 11 | 105-2673 | 1 | Spring-Extension |
| 12 | 32128-21 | 1 | Nut-HF |
| 13 | 105-0889 | 1 | Idler Arm ASM |
| 14 | 51-3641 | 1 | Sleeve-Pivot, Idler |
| 15 | 110-6953 | 1 | Belt-V |
| 16 | 110-6954 | 1 | Belt-V |
| 17 | 110-2037-01 | 1 | Plate-Skid |
| 18 | 3231-1 | 4 | Screw-CARR |
| 19 | 323-5 | 2 | Screw-HH |
| 20 | 110-6903-03 | 1 | Baffle-Front, LH |
| 21 | 110-0730 | 1 | Spindle ASM |
| 22 | 323-12 | 1 | Screw-HH |
| 23 | 92-1624 | 14 | Screw-HWH |
| 24 | 51-4060 | 2 | Screw-Blade |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 25 | 103-0865 | 2 | Washer-Blade Bolt, Heavy |
| 26 | 108-2727 | 2 | Stiffener-Blade |
| 27 | 105-7781-03 | 2 | Blade-18 Inch (Hi Flow) |
| 28 | 110-0728 | 1 | Spindle ASM |
| 29 | 110-6955-03 | 1 | Adjust Baffle ASM |
| 30 | 110-0754-01 | 1 | Baffle-Discharge |
| 31 | 323-4 | 2 | Screw-HH |





# Deck Assembly No. 112-7080

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 2 | 104-8569 | 1 | Decal-Warning |
| 3 | 43-8480 | 1 | Decal-Danger |
| 4 | 104-8185 | 1 | Decal |
| 5 | 98-5954 | 2 | Decal-Cover, Missing |
| 6 | 68-8340 | 1 | Decal-Torque |
| 7 | 66-1340 | 1 | Decal-Danger, Thrown Object |
| 8 | 105-7798 | 1 | Decal-Scalp, Anti |
| 9 | 110-2068 | 1 | Decal-Adjustment, Baffle |
| 10 | 110-2067 | 1 | Decal-Setting, Baffle |





# Lever Assembly No. 107-1664

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 106-3239 | 1 | Screw-Lock |
| 2 | 107-1644 | 1 | Cap-Lock |
| 3 | 106-3241 | 1 | Lever-Lock |
| 4 | 3296-29 | 1 | Nut-Lock, NI |





# Spindle Assembly No. 110-0730

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3219-7 | 1 | Nut-Hex |
| 2 | 7-4150 | 1 | Washer |
| 3 | 108-6627 | 1 | Pulley And Hub ASM |
| 4 | 106-0873 | 1 | Shield-Bearing |
| 5 | 104-6325 | 2 | Bearing-Ball |
| 6 | 108-6696 | 1 | Housing-Spindle |
| 7 | 110-0727 | 1 | Spacer-Bearing |
| 8 | 110-0725 | 1 | Shaft-Spindle |





# Spindle Assembly No. 110-0728

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3219-7 | 1 | Nut-Hex |
| 2 | 7-4150 | 1 | Washer |
| 3 | 104-1181 | 1 | Pulley ASM |
| 4 | 106-0873 | 1 | Shield-Bearing |
| 5 | 104-6325 | 2 | Bearing-Ball |
| 6 | 108-6696 | 1 | Housing-Spindle |
| 7 | 110-0727 | 1 | Spacer-Bearing |
| 8 | 110-0726 | 1 | Shaft-Spindle |





# Outer Deck Assembly

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 110-0790 | 1 | Deflector ASM |
| 2 | 105-4622 | 1 | Spacer |
| 3 | 104-8554 | 1 | Spring-Torsion |
| 4 | 3296-29 | 2 | Nut-Lock, NI |
| 5 | 110-6964-01 | 1 | Cover ASM |
| 7 | 106-6777 | 2 | Handle-Latch, Swell |
| 8 | 99-3058 | 2 | Washer |
| 9 | 108-2674 | 2 | Front Pin ASM |
| 10 | 3220-3 | 2 | Nut-HJ |
| 11 | 3296-39 | 4 | Nut-Lock, NI |
| 12 | 1-613204 | 2 | Balljoint |
| 13 | 104-1156 | 2 | Spacer |
| 14 | 323-8 | 2 | Screw-HH |
| 15 | 110-2086 | 2 | Rear Pin ASM |
| 16 | 3290-256 | 6 | Pin-Hair |
| 17 | 323-10 | 2 | Screw-HH |
| 18 | 1-603299 | 2 | Roller-Scalp, Anti |
| 19 | 98-5967 | 1 | Spacer-Wheel |
| 20 | 322-50 | 2 | Screw-HH |
| 21 | 1-804254 | 2 | Nut |
| 22 | 106-6778 | 2 | Bushing-Latch, Swell |




# Deflector Assembly No. 110-0790


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 3231-4 | 4 | Screw-CARR |
| 2 | 110-0792-01 | 1 | Deflector |
| 3 | 110-0793-03 | 1 | Strap-Discharge |
| 4 | 110-0791 | 1 | Deflector-Rubber |
| 5 | 107-4164-01 | 1 | Bracket-Mounting, Deflector |
| 6 | 3296-39 | 4 | Nut-Lock, NI |




# Cylinder and Crankcase Assembly
# Kawasaki FH541V-ES24


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0640 | 4 | Bolt-Flanged (6X40) |
| ❷130A | 130CA0875 | 2 | Bolt-Flanged (8X75) |
| ❷172 | 172BA0818 | 4 | Bolt-Stud (8X18) |
| ❷11004 | 11004-7016 | 2 | Gasket-Head |
| ❷11008 | 11008-6043 | 1 | Head-Cylinder, No. 1 |
| ❷11008A | 11008-7020 | 1 | Head-Cylinder, No. 2 |
| ❷11022A | 11022-7018 | 2 | Case-Rocker |
| ❷11060 | 11060-7001 | 2 | Gasket-Case, Rocker |
| ❷11060A | 11060-7008 | 1 | Gasket-Cover, Crankcase |
| ❷11061 | 11061-7001 | 1 | Gasket-Breather |
| ❷13271 | 13271-7016 | 1 | Plate |
| ❷14091 | 14091-7006 | 1 | Cover |
| ❷49015 | 49015-6253 | 1 | Cover-Crankcase |
| ❷49109 | 49109-7002 | 1 | Element-Breather |
| ❷49120A | 49120-7113 | 1 | Crankcase |
| ❷59071 | 59071-2079 | 1 | Joint |
| ❷92033 | 92033-7003 | 2 | Ring-Snap |
| ❷92043 | 92043-7001 | 6 | Pin |
| ❷92049 | 92049-7001 | 4 | Seal-Oil, R V C2 (6X11X10.2) |
| ❷92049A | 92049-7015 | 1 | Seal-Oil, S D (35X62X8 L HSH) |
| ❷92049B | 92049-7016 | 1 | Seal-Oil, S D (35X48X8 R HSH) |
| ❷92049C | 92049-7019 | 1 | Seal-Oil, S O (8X14X5 HSH) |
| ❷92066 | 92066-7026 | 1 | Plug |
| ❷92153 | 92153-7043 | 4 | Bolt (6X12) |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷92153A | 92153-7054 | 17 | Bolt (8X50) |





# Piston and Crankshaft Assembly
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷13001 | 13001-7010 | 2 | Piston-Engine |
| ❷13002 | 13002-7001 | 2 | Pin-Piston |
| ❷13008 | 13008-6060 | 2 | Piston Ring Set |
| ❷13031A | 13031-7073 | 1 | Crankshaft |
| ❷13251 | 13251-7010 | 2 | Connecting Rod ASM |
| ❷92033 | 92033-7002 | 4 | Ring-Snap |
| ❷92151 | 92151-7017 | 4 | Bolt (6X35) |





# Valve and Camshaft Assembly
# Kawasaki FH541V-ES23

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷12004 | 12004-7003 | 2 | Valve-Intake |
| ❷12005 | 12005-7003 | 2 | Valve-Exhaust |
| ❷12009 | 12009-7001 | 4 | Retainer-Spring, Valve |
| ❷12011 | 12011-2056 | 8 | Collet |
| ❷12016 | 12016-7008 | 4 | Arm-Rocker |
| ❷12032 | 12032-7001 | 4 | Tappet |
| ❷13070 | 13070-7001 | 2 | Guide |
| ❷13070A | 13070-7004 | 1 | Guide |
| ❷13116 | 13116-2057 | 4 | Rod-Push |
| ❷13271 | 13271-7007 | 1 | Plate |
| ❷13271A | 13271-7021 | 1 | Plate-Governor |
| ❷42036 | 42036-7010 | 1 | Sleeve |
| ❷49078 | 49078-7001 | 4 | Spring-Valve, Engine |
| ❷49118 | 49118-7004 | 1 | Camshaft |
| ❷92009 | 92009-2341 | 4 | Screw |
| ❷92015 | 92015-2253 | 4 | Nut |
| ❷92033 | 92033-7001 | 2 | Ring-Snap |
| ❷92140A | 92140-7005 | 6 | Ball |
| ❷92145 | 92145-7001 | 1 | Spring |
| ❷92153 | 92153-7019 | 4 | Bolt |
| ❷92200 | 92200-7001 | 1 | Washer |





# Lubrication Equipment Assembly
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷670 | 670D2016 | 3 | O-Ring (16Mm) |
| ❷13107 | 13107-7009 | 1 | Shaft |
| ❷13271 | 13271-7017 | 1 | Plate |
| ❷14075 | 14075-7009 | 1 | Cap ASM |
| ❷16154 | 16154-2053 | 1 | Rotor-Pump (In) |
| ❷16154A | 16154-2054 | 1 | Rotor-Pump (Out) |
| ❷49065A | 49065-2078 | 1 | Filter-Oil (Part May Be Used As Substitute And Is Supplied Until The Stock Is Exhausted) |
| ❷49065B | 49065-7004 | 1 | Filter-Oil |
| ❷49065C | 49065-7010 | 1 | Filter-Oil |
| ❷59051 | 59051-7011 | 1 | Gear-Spur |
| ❷59231 | 59231-7005 | 1 | Filler |
| ❷92043 | 92043-7003 | 2 | Pin |
| ❷92066 | 92066-7003 | 2 | Plug |
| ❷92140 | 92140-7003 | 1 | Ball |
| ❷92145 | 92145-7002 | 1 | Spring |
| ❷92153 | 92153-7043 | 3 | Bolt (6X12) |





# Cooling Equipment Assembly
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0616 | 2 | Bolt-Flanged (6X16) |
| ❷130A | 130AA0625 | 2 | Bolt-Flanged (6X25) |
| ❷130B | 130AA0816 | 1 | Bolt-Flanged (8X16) |
| ❷311 | 311AA0600 | 2 | Nut-Hex (6Mm) |
| ❷13270 | 13270-7007 | 1 | Plate |
| ❷14037 | 14037-7020-9H | 1 | Screen |
| ❷23062 | 23062-7010 | 1 | Bracket |
| ❷49089 | 49089-7032 | 1 | Shroud-Engine |
| ❷49089A | 49089-7042 | 1 | Shroud-Engine |
| ❷49089B | 49089-7043 | 1 | Shroud-Engine |
| ❷55020 | 55020-7004 | 1 | Guard |
| ❷59041 | 59041-7012 | 1 | Fan |
| ❷59066 | 59066-7037 | 1 | Housing-Fan |
| ❷92004 | 92004-7006 | 2 | Stud |
| ❷92026 | 92026-7007 | 1 | Spacer |
| ❷92151 | 92151-7012 | 3 | Bolt (6X12) |
| ❷92153 | 92153-7007 | 3 | Bolt |
| ❷92153A | 92153-7008 | 1 | Bolt |
| ❷92153B | 92153-7043 | 2 | Bolt (6X12) |
| ❷92210 | 92210-0003 | 4 | Nut |





# Electric Equipment Assembly
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0620 | 2 | Bolt-Flanged (6X20) |
| ❷311 | 311AA0600 | 2 | Nut-Hex (6Mm) |
| ❷510 | 510A5100 | 1 | Key-Woodruff |
| ❷21066 | 21066-7011 | 1 | Regulator-Voltage |
| ❷21171A | 21171-7034 | 2 | Ignition Coil ASM |
| ❷21193A | 21193-7032 | 1 | Flywheel ASM |
| ❷26030 | 26030-7001 | 1 | Harness |
| ❷26031 | 26031-7012 | 1 | Harness |
| ❷59031A | 59031-7014 | 1 | Coil-Charging |
| ❷92004 | 92004-7009 | 2 | Stud |
| ❷92009 | 92009-2308 | 1 | Screw |
| ❷92066 | 92066-7026 | 1 | Plug |
| ❷92070 | 92070-7003 | 2 | Spark Plug (R C J 8 Y, Solid) |
| ❷92072 | 92072-7003 | 3 | Band |
| ❷92151 | 92151-2097 | 1 | Bolt (12X30) |
| ❷92172 | 92172-7018 | 4 | Screw (5X20) |
| ❷92200 | 92200-7002 | 1 | Washer |




# Control Equipment Assembly
# Kawasaki FH541V-ES24


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷214 | 214AA0408 | 2 | Screw-Pan +-(4X8) |
| ❷311 | 311AA0600 | 1 | Nut-Hex (6Mm) |
| ❷411 | 411AA0600 | 1 | Washer-Plain (6Mm) |
| ❷13107 | 13107-7010 | 1 | Shaft |
| ❷13271 | 13271-7032 | 1 | Plate |
| ❷16169 | 16169-7010 | 1 | Link-Choke |
| ❷16171 | 16171-7001 | 1 | Link |
| ❷39129 | 39129-7003 | 1 | Spring-Governor |
| ❷49103 | 49103-7004 | 1 | Arm-Governor |
| ❷49113A | 49113-7054 | 1 | Control Panel ASM |
| ❷92009 | 92009-7007 | 1 | Screw (4X35) |
| ❷92145 | 92145-7003 | 1 | Spring |
| ❷92145A | 92145-7005 | 1 | Spring |
| ❷92150 | 92150-2182 | 2 | Bolt (5X18) |
| ❷92153 | 92153-7033 | 1 | Bolt (6X35) |
| ❷92153A | 92153-7043 | 2 | Bolt (6X12) |
| ❷92170 | 92170-7001 | 2 | Clamp |




# Carburetor Assembly
# Kawasaki FH541V-ES24


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0635 | 4 | Bolt-Flanged (6X35) |
| ❷172 | 172BA0690 | 2 | Bolt-Stud (6X90) |
| ❷214 | 214AA0510 | 1 | Screw-Pan +-(5X10) |
| ❷11061 | 11061-7004 | 2 | Gasket-Insulator |
| ❷11061A | 11061-7009 | 1 | Gasket-Chamber |
| ❷11061B | 11061-7010 | 1 | Gasket-Screw |
| ❷11061C | 11061-7018 | 1 | Gasket-Cleaner, Air |
| ❷11061D | 11061-7019 | 2 | Gasket |
| ❷13107 | 13107-7018 | 1 | Shaft |
| ❷15004 | 15004-7056 | 1 | Carburetor ASM |
| ❷16014 | 16014-7005 | 1 | Screw-Air, Pilot |
| ❷16020 | 16020-7003 | 1 | Chamber-Float |
| ❷16025 | 16025-7006 | 1 | Valve-Throttle |
| ❷16030 | 16030-7003 | 1 | Valve-Float |
| ❷16031 | 16031-7002 | 1 | Float |
| ❷16041 | 16041-7016 | 1 | Shaft-Choke, Carburetor |
| ❷16041A | 16041-7018 | 1 | Shaft-Throttle, Carburetor |
| ❷16073 | 16073-7007 | 1 | Insulator |
| ❷16186 | 16186-7001 | 1 | Choke Valve ASM |
| ❷21188 | 21188-7002 | 1 | Solenoid |
| ❷39076 | 39076-7001 | 1 | Limiter |
| ❷49121A | 49121-7017 | 1 | Nozzle-Main |
| ❷59076A | 59076-7017 | 1 | Manifold-Intake |
| ❷92009 | 92009-2083 | 2 | Screw |

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷92009A | 92009-2349 | 1 | Screw |
| ❷92063 | 92063-7029 | 1 | Jet-Main, No.82 (6560 Ft) |
| ❷92063D | 92063-7147 | 1 | Jet-Main, No.86 |
| ❷92063E | 92063-7148 | 1 | Jet-Main-No.84 (3280 Ft) |
| ❷92081 | 92081-2234 | 1 | Spring |
| ❷92093 | 92093-2100 | 1 | Seal |
| ❷92093A | 92093-7003 | 1 | Seal |
| ❷92145 | 92145-7015 | 1 | Spring |





# Air Filter and Muffler Assembly
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0816 | 3 | Bolt-Flanged (8X16) |
| ❷233 | 233AA0416 | 1 | Screw-Pan, Wp +-(4X16) |
| ❷311 | 311AA0400 | 1 | Nut-Hex (4Mm) |
| ❷461 | 461DA0800 | 4 | Washer-Spring (8Mm) |
| ❷11011 | 11011-7046 | 1 | Case-Filter, Air |
| ❷11013 | 11013-7025 | 1 | Element-Filter, Air |
| ❷11013A | 11013-7031 | 1 | Element-Filter, Air |
| ❷11054 | 11054-7002-9H | 1 | Bracket |
| ❷11060 | 11060-7021 | 2 | Gasket-Muffler |
| ❷13270 | 13270-7008 | 1 | Plate |
| ❷16060 | 16060-7016 | 1 | Pipe-Intake |
| ❷18049 | 18049-7001 | 1 | Pipe-Exhaust |
| ❷49070 | 49070-7021 | 1 | Muffler |
| ❷92015A | 92015-1367 | 2 | Nut |
| ❷92055 | 92055-7015 | 1 | O-Ring |
| ❷92072 | 92072-7012 | 1 | Band |
| ❷92170 | 92170-7002 | 1 | Clamp |
| ❷92192 | 92192-7010 | 1 | Tube |
| ❷92210 | 92210-7004 | 2 | Nut (M6) |
| ❷92210A | 92210-7019 | 1 | Nut |
| ❷92210B | 92210-7027 | 4 | Nut (M8) |




# Fuel Tank and Valve Assembly
# Kawasaki FH541V-ES24


| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0620 | 2 | Bolt-Flanged (6X20) |
| ❷23062A | 23062-7019-9H | 1 | Bracket |
| ❷42036 | 42036-7012 | 1 | Sleeve |
| ❷49019 | 49019-7001 | 1 | Filter-Fuel |
| ❷49040 | 49040-7001 | 1 | Pump-Fuel |
| ❷92170 | 92170-2009 | 4 | Clamp |
| ❷92191 | 92191-7002 | 1 | Tube |
| ❷92192D | 92192-7135 | 1 | Tube (6.35X12.7X160) |
| ❷92192F | 92192-7136 | 1 | Tube (6.35X12.7X180) |




# Starter Assembly
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷130 | 130AA0814 | 2 | Bolt-Flanged (8X14) |
| ❷13101 | 13101-7010 | 1 | Gear ASM |
| ❷16146 | 16146-7013 | 1 | Cover ASM |
| ❷21039 | 21039-7002 | 1 | Brush |
| ❷21080 | 21080-7007 | 1 | Armature |
| ❷21163 | 21163-7031 | 1 | Starter-Electric |
| ❷39184 | 39184-7009 | 1 | Bracket ASM |
| ❷92153 | 92153-7034 | 2 | Bolt |
| ❷92200 | 92200-7023 | 1 | Washer |
| ❷92200A | 92200-7024 | 1 | Washer |
| ❷92210 | 92210-7037 | 2 | Nut |

56033




56070




56080A




# Label Set
# Kawasaki FH541V-ES24

| Ref | Part No. | Qty. | Description |
|---|---|---|---|
| ❷56033 | 56033-7001 | 1 | Label-Manual |
| ❷56070 | 56070-7001 | 1 | Label-Warning |
| ❷56080A | 56080-7056 | 1 | Label-Brand |

# Attachments and Accessories

## For 38494 - Commercial Walk-Behind Mower, Floating Deck, T-Bar, Hydro Drive with 36in TURBO FORCE Cutting Unit

| Product Name | Model/Part |
|---|---|
| Blade-Recycler, 18 Inch | 105-7779-03 |
| Blade-Med Flow, 18 Inch | 105-7794-03 |
| Blade-Low Flow, 18 Inch | 105-7795-03 |
| Blade-Atomic, 18 Inch | 105-7796-03 |
| Blade-Hi-Flow, 18 Inch (6 Pack) | 108-1117 |
| Blade-Atomic, 18 Inch (6 Pack) | 108-1118 |
| Blade-Lo-Flow, 18 Inch (6 Pack) | 110-0406 |
| Blade-Recycler, 18 Inch (6 Pack) | 110-0408 |
| Blade-Med-Flow, 18 Inch (6 Pack) | 110-0409 |
| 36 Inch Bagger Enhancement Kit | 110-2026 |
| 36 Inch Recycler Kit | 110-2080 |
| Weight-Cast | 112-7059-01 |
| Weight Kit | 112-9971 |
| Operator-Controlled Discharge Chute Kit | 115-4190 |
| Soft Bag (3 Bushel) | 30104 |
| Tru Trak Sulky | 30110 |

# NOTES

# NOTES

# NOTES


TORO®