



Commercial Walk-Behind Mower Fixed Deck, Pistol Grip, Gear Drive with 36in TURBO FORCE® Cutting Unit

Model No. 38684 - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Engine and Fuel Tank Assembly	 3	Lubrication Equipment Assembly Kawasaki FH541V-FS23	 19
Transmission Drive Assembly	 4	Cooling Equipment Assembly Kawasaki FH541V-FS23	 20
Drive Wheel and Brake Assembly	 6	Electric Equipment Assembly Kawasaki FH541V-FS23	 21
Handle and Control Assembly	 7	Control Equipment Assembly Kawasaki FH541V-FS23	 22
Handle Assembly No. 110-6906	 9	Carburetor Assembly Kawasaki FH541V-FS23	 23
Deck Assembly	 10	Air Filter and Muffler Assembly Kawasaki FH541V-FS23	 24
Deck Assembly No. 110-4907	 11	Fuel Tank and Valve Assembly Kawasaki FH541V-FS23	 25
Deflector Assembly No. 110-0790	 12	Starter Assembly Kawasaki FH541V-FS23	 26
Sheave, Spindle and Blade Assembly	 13	Label Assembly Kawasaki FH541V-FS23	 27
Idler Assembly	 14	Attachments and Accessories List	 28
Caster Assembly	 15		
Cylinder and Crankcase Assembly Kawasaki FH541V-FS23	 16		
Piston and Crankshaft Assembly Kawasaki FH541V-FS23	 17		
Valve and Camshaft Assembly Kawasaki FH541V-FS23	 18		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HWHTF. hex washer head thread forming
ASM. assembly	HYD. hydraulic
BBC. blade brake clutch	LH. left hand
CARR. carriage	NI. nylon insert
CCW. counter clock wise	NPTF. national pipe thread fine
CW. clockwise	PFH. phillips flat head
DEG. degrees	PPH. phillips pan head
ECM. electronic control module	PPHTF. phillips pan head thread forming
EXT. external	PRH. phillips round head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power-take-off
HD. heavy-duty	RH. right hand
HF. hex flange	ROPS. roll-over protection system
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HSBH. hex socket button head	STD. standard
HSFH. hex socket flat head	TAP. self tapping
HSB. hex socket head	TTH. torx truss head
HWH. hex washer head	

Footnotes

❶ Not serviced separately


❷ Obtain parts from www.kawpowerepc.com



Engine and Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	1-633023	2	Stud
2	3256-23	4	Washer-Flat
3	1-633349	2	Spring-Tank, Fuel
4	3296-47	2	Nut-Lock, NI
5	1-303077	4	Clamp
26		1	Engine-Kawasaki, FH541V-Fs23
7	106-0699	1	Decal-Warning
8	3290-357	1	Nut-HHF, Whiz
9	323-14	1	Screw-HH
10	322-7	4	Screw-HH
11	1-303334	4	Washer-Spring
12	103-1966	1	Adapter
13	92-6877	1	Valve-Drain, Oil
14	32128-20	4	Nut-HF
15	109-0293	1	Hose-Fuel
16	1-603770	1	Valve-Fuel
17	109-0306	1	Hose-Fuel
18	322-3	2	Screw-HH
19	1-805005	2	Washer-Lock
20	106-0730	1	Fuel Tank ASM
20:2	103-2605	1	Fitting-Fuel, Bulkhead
21	88-3980	1	Gas Cap ASM
21:3	88-4010	1	Gasket-Cap, Gas
22	33113-016	1	Screw-HH


Ref	Part No.	Qty.	Description
23	1-805004	1	Washer-Lock
26	98-5975	2	Washer-Belleville
27	32128-21	1	Nut-HF
28	1-413510	1	Clip-Loom
29	33114-016	1	Screw-HH
30	323-8	8	Screw-HH
31	98-5975	8	Washer-Belleville
32	3290-357	8	Nut-HHF, Whiz
33	1-303335	1	Tie-Plastic
36	115-4150-03	1	Muffler Shield ASM
37	115-4154-03	1	Bracket-Muffler
38	94-2413	4	U-Nut
39	322-3	4	Screw-HH
99	103-1964	1	Hose-Drain, Oil



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	103-9897-01	1	Deck-Engine
2	1-323252	2	Bearing-Shaft
3	1-323254	2	Flange-Output
4	1-803310	2	Screw-Set
5	103-6511	2	Sheave-Transmission
6	321-3	6	Screw-HH
7	103-4177	1	Key
9	3296-39	1	Nut-Lock, NI
10	3256-24	1	Washer-Flat
11	1-323285	1	Idler-Drive, Transmission
12	3256-5	2	Washer-Flat
13	322-3	4	Screw-HH
14	1-805005	4	Washer-Lock
15	1-633181	1	Plate-Tapped
16	1-513051	1	Switch-Open, Normally
17	32151-62	2	Ring-Retaining
18	3257-5	3	Key-Woodruff
19	1-323502	2	Shaft-Transmission
20	51-4220	2	Guard-Coupler
21	1-323680	2	Coupler
22	1-323630	1	V-Belt
23	3245-41	2	Screw-HSH
24	1-323278	1	Sheave-Transmission
25	302-19	2	Fitting-Grease

Ref	Part No.	Qty.	Description
26	1-323500	1	Transmission
27	3230-1	2	Bolt-CARR
28	1-323387-03	1	Plate-Shift
29	105-4104	1	Decal-Speed, Ground
30	1-303020	1	Grip-Lever
31	98-3274-03	1	Lever-Shift
32	98-5975	1	Washer-Belleville
33	3296-6	1	Nut-Lock
35	1-323379	1	Washer
36	32128-20	2	Nut-HF
37	9264964	4	Screw-HWH, Thread Cut
38	1-603403	1	Bolt-Shoulder
39	1-323389-03	2	Bracket-Plate, Shift
40	1-806003	3	Pin-Cotter, Hair
41	1-303186	1	Bellcrank
42	32128-21	1	Nut-HF
44	3290-500	2	Screw-PPH
45	1-543296	1	Grommet
46	3231-6	1	Screw-CARR
47	3296-42	4	Nut-Lock, NI
48	98-0776	1	Decal-Caution
49	103-1666	1	Sheave-Transmission
50	110-4891	1	Pulley ASM
56	1-603610	2	Washer-Spring



Transmission Drive Assembly (continued)


Ref	Part No.	Qty.	Description				
57	3212-6	1	Screw-HH				
58	1-633453	1	Spacer-Clutch				
59	1-373034	2	Washer				
62	32128-33	2	Nut-HF				
64	103-1797-01	1	Bracket-Cable, Choke				
65	103-1796	1	Cable-Choke				
66	1-303282	1	Switch-Start, Neutral				
67	1-323303	1	Linkage-Arm				
68	110-4886	1	Belt-V				
69	1-808280	1	Pin-Clevis				
70	1-303105	1	Yoke-Adjustable				
71	3219-2	1	Nut-Hex				
73	321-4	1	Screw-HH				
74	1-323430	1	Module-Interlock				
75	1-323229	1	Clip-Loom				
76	3256-22	1	Washer-Flat				
77	3296-42	1	Nut-Lock, NI				
78	1-303335	3	Tie-Plastic				



Drive Wheel and Brake Assembly

Ref	Part No.	Qty.	Description
2	99-8664	2	Screw-HH
3	32151-47	6	Ring-Retaining
4	1-806003	2	Pin-Cotter, Hair
5	1-323245	2	Spring-Compression
6	103-1864	2	Swivel-Lever, Drive
7	322-6	2	Screw-HH
9	3256-23	4	Washer-Flat
10	1-323548	2	Linkage-Brake
11	110-5866	2	Swivel-Brake
12	1-513959	2	Wingnut-Nylock
13	3290-357	10	Nut-HHF, Whiz
14	323-39	4	Screw-HH
18	1-323277	2	Idler-Wheel, Drive
19	302-19	2	Fitting-Grease
21	1-323307	2	Pin-Clevis
22	103-1611-03	2	Arm-Brake
23	32120-47	2	Ring-Retaining, External
24	1-803051	2	Nut-Push
25	1-323262	2	Band-Brake
26	1-322117-03	1	Axle
27	1-523157	6	Washer-Spacer
27	1-543436	8	Washer-Spacer
30	109-4359	2	Drum And Sheave ASM
34	1-808519	2	Ring-Snap


Ref	Part No.	Qty.	Description
36	322-5	8	Screw-HH
38	1-323631	2	V-Belt
39	3296-29	4	Nut-Lock, NI
40	2412-104	2	R-Clamp
41	98-3259	1	Shield-Trailing
42	322-3	2	Screw-HH
43	98-5975	4	Washer-Belleville
44	323-6	4	Screw-HH
46	1-805005	8	Washer-Lock
47	1-323719	2	Wheel And Tire ASM
47:1	1-323720	1	Tire-Turfmaster
47:2	1-323328	1	Wheel And Hub ASM
47:2:1	1-323329	2	Bearing-Flanged
47:2:2		1	Rim ASM
47:2:3		1	Fitting-Grease
47:2:4		1	Stem-Valve
50	32128-20	4	Nut-HF
52	3296-39	4	Nut-Lock, NI
53	1-323287-01	2	Shield-Wheel, Drive
55	1-603402	2	Spring-Extension
56	1-323283	4	Spacer-Shield
57	103-1615-03	1	Arm-Idler, LH
58	103-1616-03	1	Arm-Idler, RH



Handle and Control Assembly


Ref	Part No.	Qty.	Description
1	1-808286	2	Pin-Clevis
2	1-323359	2	Linkage-Wheel, Drive
4	1-303365	2	Bushing-Nylon
5	106-2717-03	1	Rod-Control, Operator Presence
6	106-5486	1	RH Operator Presence Control Lever ASM
7	104-9838	2	Grip-Foam
8	321-18	2	Screw-HH
9	1-303435	6	Washer-Spring
10	1-323549	2	Spacer
11	3296-42	2	Nut-Lock, NI
12	3290-500	2	Screw-PPH
13	1-513051	1	Switch-Open, Normally
14	1-806003	3	Pin-Cotter, Hair
15	1-633181	1	Plate-Tapped
16	110-6906	1	Handle ASM
17	1-303363	1	Spring-Extension
18	1-633696	1	Throttle Cable ASM
19	2412-120	2	R-Clamp
20	1-303287	2	Tie-Plastic
22	1-303160	1	Spring-Compression
23	3256-4	2	Washer-Flat
24	3296-39	1	Nut-Lock, NI
26	1-323298	1	Linkage-Blade, Upper

Ref	Part No.	Qty.	Description
27	1-322157	1	Lever ASM
27:1	1-303020	1	Grip-Lever
28	3234-11	4	Screw-HHF
29	32104-76	2	Screw
30	32128-21	4	Nut-HF
31	104-7050	1	Tube-Manual
32	3296-2	2	Nut-Lock, NI
34	1-513592	1	Knob-Ball
36	1-803001	2	Nut
38	1-807513	2	Bolt-CARR
39	106-5485	1	LH Operator Presence Control Lever ASM
48	1-324280	1	RH Thumb Latch ASM
48:1	1-303019	1	Grip-Latch
49	1-324279	1	LH Thumb Latch ASM
49:1	1-303019	1	Grip-Latch
50	1-806340	2	Pin-Roll
51	1-808250	2	Pin-Lever, Drive
52	103-1610	1	Harness-Wiring
53	1-303088	1	Clip-Cable
54	1-302006	2	Drive Lever ASM
54:1	1-303021	1	Grip-Lever, Drive
55	29-5560	1	Switch-On / Off
55:1	218-461	1	Nut-HH




Handle and Control Assembly (continued)

Ref	Part No.	Qty.	Description				
55:2	3254-5	1	Washer-Tooth				
56	63-8360	1	Key-Ignition				
57	1-803322	2	Screw-Set				
58	323-10	1	Screw-HH				
61	104-7048	1	Cap-Housing				
64	117-2718	1	Decal-Arrester, Spark				




Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	110-4907	1	Deck ASM	21	323-4	2	Screw-HH
2	110-2031-03	1	Baffle-Adjustable	22	323-6	1	Screw-HH
3	110-0754-01	1	Baffle-Discharge	23	110-6903-03	1	Baffle-Front, LH
4	110-2037-01	1	Plate-Skid	24	3256-24	1	Washer-Flat
5	110-0790	1	Deflector ASM				
6	110-2036-01	1	Cover-Deck				
7	92-1624	3	Screw-HWH				
8	3290-357	10	Nut-HHF, Whiz				
9	322-50	1	Screw-HH				
10	105-4622	1	Spacer				
11	104-8554	1	Spring-Torsion				
12	107-1664	1	Lever ASM				
12:1	106-3239	1	Screw-Lock				
12:2	107-1644	1	Cap-Lock				
12:3	106-3241	1	Lever-Lock				
12:4	3296-29	1	Nut-Lock, NI				
13	3296-29	1	Nut-Lock, NI				
14	106-4161	4	Knob-Handle				
15	1-323417	4	Washer				
16	1-303536	2	Stud-Shield, Belt (Long)				
17	1-303537	2	Stud-Shield, Belt (Short)				
18	3231-1	4	Screw-CARR				
19	32128-20	4	Nut-HF				
20	112-9710	1	Decal				




Deck Assembly No. 110-4907

Ref	Part No.	Qty.	Description
1		1	36 Inch Deck ASM
2	98-3296	1	Decal-Routing, Belt
3	43-8480	1	Decal-Danger
4	98-5130	1	Decal-Torque, Bolt
5	104-8569	1	Decal-Warning
6	98-5954	2	Decal-Cover, Missing
7	110-2067	1	Decal-Setting, Baffle
8	66-1340	1	Decal-Danger, Thrown Object
9	110-2068	1	Decal-Adjustment, Baffle




Deflector Assembly No. 110-0790

Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	110-0792-01	1	Deflector				
3	110-0793-03	1	Strap-Discharge				
4	110-0791	1	Deflector-Rubber				
5	107-4164-01	1	Bracket-Mounting, Deflector				
6	3296-39	4	Nut-Lock, NI				




Sheave, Spindle and Blade Assembly

Ref	Part No.	Qty.	Description				
1	108-6697	2	Spindle Housing ASM				
1:1	110-2118	2	Bearing				
1:2	110-2116	1	Spacer-Bearing				
1:3	108-6694	1	Housing-Spindle				
1:4	32120-8	1	Ring-Snap				
2	92-1624	12	Screw-HWH				
3	3290-357	12	Nut-HHF, Whiz				
4	110-4888	2	Washer-Spacer				
5	103-2535	2	Spacer-Guard, Bottom				
6	1-807267	2	Key				
7	1-323529	2	Tube-Spindle, Short				
8	1-323539	8	Spacer				
9	105-7781-03	2	Blade-18 Inch (Hi Flow)				
10	1-513208	2	Washer-Spring				
11	1-800861	2	Screw-Cap, HH				
12	103-1330	2	Guard-Bearing, Top				
13	1-403183	2	Sheave				
14	1-323339	2	Washer-Retainer, Sheave				
15	3219-6	2	Nut-Hex				
16	1-803310	2	Screw-Set				




Idler Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	1-324372	1	Pad And Spring ASM	24	1-323715	1	Rod-Brake
2	321-4	2	Screw-HH	25	1-323748	1	Ring-Push On
3	3296-42	2	Nut-Lock, NI	26	1-323747	1	Spring-Compression
4	322-10	1	Screw-HH	27	1-323746	1	Spacer-Flanged
5	1-403179	1	Tube-Pivot	28	3296-56	1	Nut-Lock, NI
6	32120-35	1	Ring-Retaining, EXT	29	1-323071	1	Spring-Extension
7	3256-23	1	Washer-Flat	30	1-303334	1	Washer-Spring
8	1-322235	1	Arm-Assist	31	302-19	2	Fitting-Grease
9	3256-3	1	Washer-Flat				
10	3296-29	1	Nut-Lock, NI				
11	1-303238	1	Eyebolt-Thread, RH				
12	32128-20	3	Nut-HF				
13	1-303236	1	Body-Turnbuckle				
14	1-303348	1	Eyebolt-Thread, LH				
15	702809	1	Screw-Cap				
16	98-5975	1	Washer-Belleville				
17	1-603843	1	Pulley-Idler				
18	1-303434	1	Bushing-Engagement				
19	103-3600	1	Idler Arm ASM				
19:2	1-323729	2	Sleeve-Bearing				
20	32151-103	1	Ring-Retaining, EXT				
21	322-6	1	Screw-HH				
22	1-303352	1	Washer-Spindle				
23	1-806003	1	Pin-Cotter, Hair				



Caster Assembly

Ref	Part No.	Qty.	Description				
1	110-5023	2	Wheel And Tire ASM				
1:1		1	Tire				
1:2	1-513809	1	Bearing				
1:3	1-513810	2	Bushing				
1:4	302-61	1	Zerk				
1:5		1	Wheel				
2	1-513547	2	Spacer				
3	325-20	2	Screw-HH				
4	1-322145-01	2	Fork				
5	3217-9	2	Nut-HH				
6	3253-7	2	Washer-Lock				
7	1-303314	8	Spacer-Caster				
8	110-2130	2	Support ASM				
8:2	1-303514	2	Bearing-Flanged				
8:3	302-52	1	Fitting-Grease				
9	1-513338	2	Washer-Flat				
10	1-809020	2	Pin				
11	323-6	8	Screw-HH				
12	3290-357	8	Nut-HHF, Whiz				
13	3256-24	8	Washer-Flat				




Cylinder and Crankcase Assembly

Kawasaki FH541V-FS23


Ref	Part No.	Qty.	Description
● 130	130AA0640	4	Bolt-Flanged (6X40)
● 130B	130CA0875	2	Bolt-Flanged (8X75)
● 172	172BA0818	4	Bolt-Stud (8X18)
● 11004	11004-7016	2	Gasket-Head
● 11008	11008-6043	1	Head-Cylinder, No. 1
● 11008A	11008-7020	1	Head-Cylinder, No. 2
● 11022A	11022-7018	2	Case-Rocker
● 11060	11060-7001	2	Gasket-Case, Rocker
● 11060A	11060-7008	1	Gasket-Cover, Crankcase
● 11061	11061-7001	1	Gasket-Breather
● 13271	13271-7016	1	Plate
● 14091	14091-7006	1	Cover
● 49015	49015-6253	1	Cover-Crankcase
● 49109	49109-7002	1	Element-Breather
● 49120A	49120-7113	1	Crankcase
● 59071	59071-2079	1	Joint
● 92033	92033-7003	2	Ring-Snap
● 92043	92043-7001	6	Pin
● 92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)
● 92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)
● 92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)
● 92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)
● 92066	92066-7026	1	Plug
● 92153	92153-7043	4	Bolt (6X12)

Ref	Part No.	Qty.	Description
● 92153B	92153-7054	17	Bolt (8X50)




Piston and Crankshaft Assembly Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
②13001	13001-7010	2	Piston-Engine				
②13002	13002-7001	2	Pin-Piston				
②13008	13008-6060	2	Piston Ring Set				
②13031	13031-7073	1	Crankshaft				
②13251	13251-7010	2	Connecting Rod ASM				
②92033	92033-7002	4	Ring-Snap				
②92151	92151-7017	4	Bolt (6X35)				




Valve and Camshaft Assembly
Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
②12004	12004-7003	2	Valve-Intake				
②12005	12005-7003	2	Valve-Exhaust				
②12009	12009-7001	4	Retainer-Spring, Valve				
②12011	12011-2056	8	Collet				
②12016	12016-7008	4	Arm-Rocker				
②12032	12032-7001	4	Tappet				
②13070	13070-7001	2	Guide				
②13070A	13070-7004	1	Guide				
②13116	13116-2057	4	Rod-Push				
②13271	13271-7007	1	Plate				
②13271A	13271-7021	1	Plate-Governor				
②42036	42036-7010	1	Sleeve				
②49078	49078-7001	4	Spring-Valve, Engine				
②49118	49118-7004	1	Camshaft				
②92009	92009-2341	4	Screw				
②92015	92015-2253	4	Nut				
②92033	92033-7001	2	Ring-Snap				
②92140A	92140-7005	6	Ball				
②92145	92145-7001	1	Spring				
②92153	92153-7019	4	Bolt				
②92200	92200-7001	1	Washer				



Lubrication Equipment Assembly
Kawasaki FH541V-FS23


Ref	Part No.	Qty.	Description				
2670	670D2016	3	O-Ring (16Mm)				
213107	13107-7009	1	Shaft				
213271	13271-7017	1	Plate				
214075	14075-7009	1	Cap ASM				
216154	16154-2053	1	Rotor-Pump (In)				
216154A	16154-2054	1	Rotor-Pump (Out)				
249065A	49065-2078	1	Filter-Oil (Part May Be Used As Substitute And Is Supplied Until The Stock Is Exhausted)				
249065B	49065-7004	1	Filter-Oil				
249065C	49065-7010	1	Filter-Oil				
259051	59051-7011	1	Gear-Spur				
259231	59231-7005	1	Filler				
292043	92043-7003	2	Pin				
292066	92066-7003	2	Plug				
292140	92140-7003	1	Ball				
292145	92145-7002	1	Spring				
292153	92153-7043	3	Bolt (6X12)				



Cooling Equipment Assembly


Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
② 130	130AA0616	2	Bolt-Flanged (6X16)				
② 130A	130AA0625	2	Bolt-Flanged (6X25)				
② 130B	130AA0816	1	Bolt-Flanged (8X16)				
② 311	311AA0600	2	Nut-Hex (6Mm)				
② 13270	13270-7007	1	Plate				
② 13271	13271-7002	1	Plate				
② 14037	14037-7025-9H	1	Screen				
② 49089	49089-7032	1	Shroud-Engine				
② 49089A	49089-7042	1	Shroud-Engine				
② 49089B	49089-7043	1	Shroud-Engine				
② 59041	59041-7012	1	Fan				
② 59066	59066-7037	1	Housing-Fan				
② 92004	92004-7006	2	Stud				
② 92066	92066-7004	1	Plug				
② 92153	92153-7007	3	Bolt				
② 92153A	92153-7008	1	Bolt				
② 92153B	92153-7043	3	Bolt (6X12)				




Electric Equipment Assembly
Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
2130	130AA0620	2	Bolt-Flanged (6X20)				
2311	311AA0600	2	Nut-Hex (6Mm)				
2510	510A5100	1	Key-Woodruff				
221171A	21171-7034	2	Ignition Coil ASM				
221194	21194-7027	1	Flywheel				
226030	26030-7001	1	Harness				
292004	92004-7009	2	Stud				
292066	92066-7026	1	Plug				
292070	92070-7003	2	Spark Plug (R C J 8 Y, Solid)				
292072	92072-7003	3	Band				
292151	92151-2097	1	Bolt (12X30)				
292200	92200-7002	1	Washer				



Control Equipment Assembly
Kawasaki FH541V-FS23


Ref	Part No.	Qty.	Description				
214	214AA0408	2	Screw-Pan +-(4X8)				
311	311AA0600	1	Nut-Hex (6Mm)				
411	411AA0600	1	Washer-Plain (6Mm)				
13107	13107-7010	1	Shaft				
13271	13271-7032	1	Plate				
16169	16169-7010	1	Link-Choke				
16171	16171-7001	1	Link				
39129	39129-7003	1	Spring-Governor				
49103	49103-7004	1	Arm-Governor				
49113B	49113-7054	1	Control Panel ASM				
92009	92009-7007	1	Screw (4X35)				
92145	92145-7003	1	Spring				
92145A	92145-7005	1	Spring				
92150	92150-2182	2	Bolt (5X18)				
92153	92153-7033	1	Bolt (6X35)				
92153A	92153-7043	2	Bolt (6X12)				
92170	92170-7001	2	Clamp				



Carburetor Assembly
Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description
130	130AA0635	4	Bolt-Flanged (6X35)
172	172BA0690	2	Bolt-Stud (6X90)
11061	11061-7004	2	Gasket-Insulator
11061A	11061-7009	1	Gasket-Chamber
11061B	11061-7010	1	Gasket-Screw
11061C	11061-7018	1	Gasket-Cleaner, Air
11061D	11061-7019	2	Gasket
13107	13107-7018	1	Shaft
15004	15004-7057	1	Carburetor ASM
16014	16014-7005	1	Screw-Air, Pilot
16020	16020-7003	1	Chamber-Float
16025	16025-7006	1	Valve-Throttle
16030	16030-7003	1	Valve-Float
16031	16031-7002	1	Float
16041	16041-7016	1	Shaft-Choke, Carburetor
16041A	16041-7018	1	Shaft-Throttle, Carburetor
16073	16073-7007	1	Insulator
16186	16186-7001	1	Choke Valve ASM
39076	39076-7001	1	Limiter
49121A	49121-7017	1	Nozzle-Main
59076B	59076-7017	1	Manifold-Intake
92009	92009-2083	2	Screw
92009A	92009-2349	1	Screw
92063	92063-7029	1	Jet-Main, No.82 (6560 Ft)


Ref	Part No.	Qty.	Description
92063D	92063-7147	1	Jet-Main, No.86
92063E	92063-7148	1	Jet-Main-No.84 (3280 Ft)
92081	92081-2234	1	Spring
92093	92093-2100	1	Seal
92093A	92093-7003	1	Seal
92145	92145-7015	1	Spring
92172	92172-7002	1	Screw



Air Filter and Muffler Assembly


Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
②130	130AA0816	3	Bolt-Flanged (8X16)				
②233	233AA0416	1	Screw-Pan, Wp +-(4X16)				
②311	311AA0400	1	Nut-Hex (4Mm)				
②461	461DA0800	4	Washer-Spring (8Mm)				
②11011	11011-7046	1	Case-Filter, Air				
②11013	11013-7025	1	Element-Filter, Air				
②11013A	11013-7031	1	Element-Filter, Air				
②11054	11054-7002-9H	1	Bracket				
②11060	11060-7021	2	Gasket-Muffler				
②13270	13270-7008	1	Plate				
②16060	16060-7016	1	Pipe-Intake				
②18049	18049-7001	1	Pipe-Exhaust				
②49070	49070-7021	1	Muffler				
②92015B	92015-1367	2	Nut				
②92055	92055-7015	1	O-Ring				
②92072	92072-7012	1	Band				
②92170	92170-7002	1	Clamp				
②92192	92192-7010	1	Tube				
②92210	92210-7004	2	Nut (M6)				
②92210A	92210-7019	1	Nut				
②92210B	92210-7027	4	Nut (M8)				



Fuel Tank and Valve Assembly Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
②130	130AA0620	2	Bolt-Flanged (6X20)				
②23062A	23062-7019-9H	1	Bracket				
②42036	42036-7012	1	Sleeve				
②49019	49019-7001	1	Filter-Fuel				
②49040	49040-7001	1	Pump-Fuel				
②92170	92170-2009	4	Clamp				
②92191	92191-7002	1	Tube				
②92192D	92192-7135	1	Tube (6.35X12.7X160)				
②92192F	92192-7136	1	Tube (6.35X12.7X180)				



Starter Assembly
Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description				
② 130	130AA0608	3	Bolt-Flanged (6X8)				
② 13165	13165-7001	2	Pawl-Starter, Recoil				
② 13271	13271-7003-9H	1	Plate				
② 14020	14020-7001	1	Retainer				
② 32099	32099-7002	1	Case-Starter, Recoil				
② 46075	46075-7001	1	Grip-Starter, Recoil				
② 49080	49080-7001	1	Pulley-Starting				
② 49088	49088-7013	1	Starter-Recoil				
② 59101	59101-7001	1	Reel-Starter, Recoil				
② 59106	59106-7005	1	Rope				
② 92145	92145-7006	1	Spring				
② 92145A	92145-7007	2	Spring				
② 92145B	92145-7008	1	Spring				
② 92151	92151-7008	1	Bolt				
② 92200	92200-7004	1	Washer				
② 92200A	92200-7005	1	Washer				
② 92210	92210-0003	4	Nut				

56033



56070



56080



56080B



Label Assembly

Kawasaki FH541V-FS23

Ref	Part No.	Qty.	Description
②56033	56033-7001	1	Label-Manual
②56070	56070-7001	1	Label-Warning
②56080	56080-2077	1	Label-Brand
②56080B	56080-7056	1	Label-Brand

Attachments and Accessories

For 38684 - Commercial Walk-Behind Mower, Fixed Deck, Pistol Grip, Gear Drive with 36in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Recycler, 18 Inch	105-7779-03
Blade-Med Flow, 18 Inch	105-7794-03
Blade-Low Flow, 18 Inch	105-7795-03
Blade-Atomic, 18 Inch	105-7796-03
Blade-Hi-Flow, 18 Inch (6 Pack)	108-1117
Blade-Atomic, 18 Inch (6 Pack)	108-1118
Blade-Lo-Flow, 18 Inch (6 Pack)	110-0406
Blade-Recycler, 18 Inch (6 Pack)	110-0408
Blade-Med-Flow, 18 Inch (6 Pack)	110-0409
36 Inch Bagger Enhancement Kit	110-2026
36 Inch Recycler Kit	110-2080
Weight Kit	110-2085
Operator-Controlled Discharge Chute Kit	115-4190
Soft Bag (3 Bushel)	30104
Sulky	30109

NOTES

NOTES

NOTES

