Form Number 3362-543 Rev C

GrandStand® Mower
With 52in TURBO FORCE® Cutting Unit

Model No. 74559 - 290003001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2009
All Rights Reserved

Register your product at www.Toro.com

Contents

Description	Page
52 Inch Deck Assembly	3
Deck Assembly No. 117-5754	4
Spring Idler Assembly No. 117-0445	5
Idler Adjust Assembly No. 117-0446	6
Spindle Assembly No. 107-8504	7
Deflector Assembly No. 114-1910	8
Wheel Assembly	9
Frame and Muffler Guard Assembly	10
Deck Lift Assembly	11
Upper Control and Tower Assembly	12
Lower Control Assembly	13
Hydraulic Assembly	14
Hydraulic Motor Assembly No. 114-0549	16
Hydraulic Pump Assembly No. 117-3597	17
Hydraulic Belt Drive Assembly	18
Platform Assembly	19
Cushion Assembly No. 114-1917	20
Platform Assembly No. 117-9640	21
Parking Brake Assembly	22
Electrical Assembly	23
Fuel Tank Assembly	24
Engine Assembly	25
Cylinder and Crankcase Assembly Kawasaki FH580V-FS30	26
Piston and Crankshaft Assembly Kawasaki FH580V-FS30	27
Valve and Camshaft Assembly Kawasaki FH580V-FS30	28
Lubrication Equipment Assembly Kawasaki FH580V-FS30	29
Cooling Equipment Assembly Kawasaki FH580V-FS30	30
Electric Equipment Assembly Kawasaki FH580V-FS30	31
Control Equipment Assembly Kawasaki FH580V-FS30	32
Carburetor Assembly Kawasaki FH580V-FS30	33
Air Filter and Muffler Assembly Kawasaki FH580V-FS30	34
Fuel Tank and Valve Assembly Kawasaki FH580V-FS30	35
Starter Assembly Kawasaki FH580V-FS30	36
Label Assembly Kawasaki FH580V-FS30	37
Attachments and Accessories List	38

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
CCW. . . . . counter clock wise
CW. . . . . clockwise
DEG. . . . . degrees
ECM. . . . . electronic control module
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head

Footnotes

❶ Not serviced separately


❷ Obtain parts from www.kawpowerepc.com



52 Inch Deck Assembly


Ref	Part No.	Qty.	Description
1	117-5754	1	Deck ASM
2	105-7781-03	3	Blade-18 Inch (Hi Flow)
3	103-0865	3	Washer-Blade Bolt, Heavy
4	103-0862	3	Screw-Cap
5	114-1908-01	1	Skid
6	106-3216-01	1	Baffle-Discharge
7	105-7755-01	1	Baffle ASM
8	114-1979-01	1	52 Inch Baffle ASM
9	107-1664	1	Lever ASM
9:1	106-3239	1	Screw-Lock
9:2	107-1644	1	Cap-Lock
9:3	106-3241	1	Lever-Lock
9:4	3296-29	1	Nut-Lock, NI
10	117-5758-03	4	Bracket-Cover
11	105-7735	3	Pulley
12	117-0445	1	Spring Idler ASM
13	117-0446	1	Idler Adjust ASM
14	114-0454	1	Belt-V
15	107-8504	3	Spindle ASM
16	32144-70	4	Screw-HWHTF
17	92-1624	14	Screw-HWH
18	3290-357	9	Nut-HHF, Whiz
19	3231-1	4	Screw-CARR
22	114-1910	1	Deflector ASM

Ref	Part No.	Qty.	Description
23	33115-025	18	Screw-HH
24	33025-00	18	Nut-Lock
28	109-6935	1	Cover-Belt, RH
29	109-6936	1	Cover-Belt, LH
30	3296-39	4	Nut-Lock, NI
31	109-6982	2	Wireform-Cover




Deck Assembly No. 117-5754

Ref	Part No.	Qty.	Description
2	54-9220	1	Decal-Danger
3	98-5954	2	Decal-Cover, Missing
4	1-403005	1	Decal-Danger
5	68-8340	1	Decal-Torque
6	117-0486	1	Decal-Tension, Belt
7	107-1618	1	Decal
8	110-2067	1	Decal-Setting, Baffle
9	110-2068	1	Decal-Adjustment, Baffle
10	58-6520	3	Decal-Grease




Spring Idler Assembly No. 117-0445

Ref	Part No.	Qty.	Description
1	114-1992	1	Plate-Idler
2	114-0463	2	Washer-Friction, Composite
3	110-9981	2	Washer-Plain
4	3231-5	2	Screw-CARR
5	3256-24	3	Washer-Flat
6	93-1622	1	Pulley-Idler
7	117-0447-01	1	Bracket-Anchor, Spring
8	108-4056	1	Spring-Extension
9	3296-39	2	Nut-Lock, NI
10	1-413088	1	Bushing-Lever, Lift




Idler Adjust Assembly No. 117-0446

Ref	Part No.	Qty.	Description
1	114-1991	1	Plate-Idler
2	3256-24	3	Washer-Flat
3	93-1622	1	Pulley-Idler
4	105-7788	2	Spacer
5	3231-5	1	Screw-CARR
6	3231-4	2	Screw-CARR
7	98-5975	1	Washer-Belleville
8	3296-39	3	Nut-Lock, NI




Spindle Assembly No. 107-8504

Ref	Part No.	Qty.	Description
1	10-8040	1	Key-Square
2	106-3277	1	Hub-Pulley
3	103-0865	1	Washer-Blade Bolt, Heavy
4	106-3204	2	Shield-Bearing
❶5		1	Spindle Bearing ASM
5:1	106-3211	1	Housing-Spindle
5:2	113514	2	Bearing-Ball
5:3	107-8502	1	Spacer-Bearing
5:4	302-5	1	Fitting-Grease
6	3-8514	2	Washer-Thrust
7	107-8501	1	Spindle ASM
8	3219-6	1	Nut-Hex




Deflector Assembly No. 114-1910

Ref	Part No.	Qty.	Description
1	106-3248-03	1	Strap-Discharge
2	110-0759	1	Deflector-Rubber
3	108-7766-03	1	Bracket-Hinge, Front
4	108-7767-03	1	Bracket-Hinge, Rear
5	3231-25	4	Screw-CARR
6	3296-39	4	Nut-Lock, NI
7	105-4622	1	Spacer
8	322-50	1	Screw-HH
9	3296-29	1	Nut-Lock, NI
10	108-4052	1	Spring-Torsion




Wheel Assembly

Ref	Part No.	Qty.	Description
1	112-3810	2	Wheel And Bearing ASM
❶1:1		1	Wheel Bearing ASM
1:1:1	1-633585	2	Bearing-Cone, Taper
1:1:2	103-0063	2	Seal-Caster
1:1:3	103-3051	2	Spacer-Nut
1:1:4	103-3157	1	Axle-Caster
1:1:5	110-9965	1	Wheel And Tire ASM
1:2	103-2768	2	Guard-Seal
1:3	3296-45	1	Nut-Lock, NI
1:4	325-20	1	Screw-HH
2	117-0429	2	Wheel ASM
2:1	232-27	1	Stem-Valve
2:2	117-0428	1	Tire
2:3	106-8133	1	Rim-8 Inch
3	242-50	8	Nut-Lug



Frame and Muffler Guard Assembly


Ref	Part No.	Qty.	Description
1	117-9630	1	Front Frame ASM
1:2	302-5	2	Fitting-Grease
1:3	1-543508	4	Cup-Bearing
1:4	1-811010	2	Plug
2	103-8618-01	2	Fork-Caster
3	1-543511	2	Seal-Grease
4	1-543509	4	Bearing-Roller, Tapered
5	1-633508	6	Washer-Bellville
6	3296-51	2	Nut-Lock, NI
7	103-4882	2	Cap-Grease
8	92-1624	4	Screw-HWH
9	117-0434	1	Muffler Guard ASM
9:2	106-5517	1	Decal-Surface, Hot
10	117-0427-01	2	Bracket-Mounting, Guard
11	3231-31	4	Screw-CARR
12	104-8301	4	Nut-Flange, NI
13	2412-87	3	Clamp-Cable
14	3296-42	3	Nut-Lock, NI
15	321-4	3	Screw-HH
16	117-3591	2	Decal-Commercial
17	68-3640	1	Decal
18	3290-357	4	Nut-HHF, Whiz
24	117-2620-01	2	Support-Hose
25	32144-70	4	Screw-HWHTF



Deck Lift Assembly

Ref	Part No.	Qty.	Description
1	117-0505	1	Lift ASM
1:2	302-5	4	Fitting-Grease
2	117-0489-01	1	RH Lift ASM
3	117-0488-01	1	LH Lift ASM
4	114-5268	2	Lift Rod ASM
5	117-0498	2	Spacer
6	117-0513	2	Bracket-Rod, Lift
7	114-5274	1	Pin-HOC
8	117-3611	1	Bar-Lift
10	3256-29	8	Washer-Flat
11	32151-103	7	Ring-Retaining, EXT
12	324-10	2	Screw-HH
13	3217-9	3	Nut-HH
14	117-0519	2	Link-Lift
15	3256-25	2	Washer-Flat
16	3296-48	2	Nut-Lock, NI
17	117-0506	2	Gas Spring ASM
17:2	88-6770	2	Stud-Ball
17:3	3296-47	2	Nut-Lock, NI
18	109-9840	4	Screw-Shoulder, HHF
19	117-3575	2	Cover-Spring
20	114-3512	1	HOC Handle ASM
21	3256-22	1	Washer-Flat
22	302-5	1	Fitting-Grease


Ref	Part No.	Qty.	Description
23	114-5305-03	1	Lever-HOC
24	1-633268	1	Grip-Lever, Brake
25	3231-24	1	Screw-CARR
26	32128-21	4	Nut-HF
27	111044	2	Spacer
28	3256-26	1	Washer-Flat
29	66-0561	1	Screw-Shoulder
30	65-9940	1	Spring
31	3231-22	1	Screw-CARR
32	3296-59	3	Nut-Lock, NI
33	114-5307	1	Bracket-HOC
34	3296-23	3	Nut-Lock, NI
35	323-7	1	Screw-HH
36	117-3645	1	Hub-Pivot
37	32151-47	1	Ring-Retaining
38	40-1940	4	Washer



Upper Control and Tower Assembly

Ref	Part No.	Qty.	Description
1	114-1922	1	Control Tower ASM
1:2	117-0453	1	Decal-Panel, Control
1:3	117-0454	1	Decal-Opc
1:4	117-3626	1	Decal-Warning
1:5	117-0456	1	Decal-HOC
1:6	117-0485	1	Decal-Service Aid
2	114-3593	1	LH Lever ASM
2:2	114-0241	1	Grip-Lever
3	114-3594	1	RH Lever ASM
3:2	114-0241	1	Grip-Lever
4	114-0260	1	Shaft-Pivot
5	114-1904	1	Shaft-Pivot, Motion Control
6	114-5302	1	Motion Control ASM
7	103-9928	6	Bearing
8	3234-4	3	Screw-HHF
9	114-0239	1	Screw-HSH
10	3296-47	1	Nut-Lock, NI
11	114-0268	1	Cam-Lever, Handle Stop
12	3256-22	1	Washer-Flat
13	3296-42	1	Nut-Lock, NI
14	114-0249	1	Spring-Extension
15	1-633181	1	Plate-Tapped
16	32105-13	2	Screw-HWH
18	106-9962	1	Control-Choke, Push / Pull


Ref	Part No.	Qty.	Description
19	110-5547	2	Control Lever ASM
20	1-603175	1	Knob-Ball
21	99-7981	1	Knob-Grip, Soft
23	2411-38	2	Joint-Ball
24	3296-27	2	Nut-Lock, NI
25	93-2279	2	Clamp-Cable
26	32144-70	6	Screw-HWHTF
27	114-1966	1	Cable-Control
28	114-1950	1	Cable-Speed
29	1-807533	6	Bolt-CARR
30	3290-148	6	Nut-HF
31	114-1921-01	1	Bar-Cable
32	114-0409	1	HOC Pin ASM
33	2412-87	1	Clamp-Cable
34	2412-120	2	R-Clamp
35	32144-1	2	Screw-Taptite
36	104-7048	1	Cap-Housing
37	104-7050	1	Tube-Manual
38	92-1624	4	Screw-HWH
39	3290-357	3	Nut-HHF, Whiz
40	3256-23	2	Washer-Flat
41	2412-138	1	R-Clamp
42	3296-39	1	Nut-Lock, NI



Lower Control Assembly

Ref	Part No.	Qty.	Description
1	114-5304-01	1	Mount-Linkage, Drive
2	114-1993	1	Lever-Switch
3	114-1999	1	Lever-Switch
4	114-1956	2	Control Fork ASM
5	114-1955	2	Hub-Shoulder
6	114-3547	2	Arm-Control
7	321-15	2	Screw-HH
8	3256-22	8	Washer-Flat
9	65-8270	1	Washer
10	114-5155-03	1	Arm-Switch, Stop
11	32128-14	2	Nut-Hex, Flange
12	114-5295	2	Rod-Link, Shifter
13	3290-307	6	Pin-Hair
14	322-4	4	Screw-HH
15	3296-29	4	Nut-Lock, NI
16	114-3534	4	Roller
17	114-1912-03	1	Bracket-Shifter
18	106-7297	1	Clamp-Cable
19	49-2040	1	Screw-HWHTF
20	32144-70	5	Screw-HWHTF
21	3256-23	2	Washer-Flat
22	106-2584	1	Spring-Torsion
23	114-1978	1	Pin-Hinge
24	114-5347	1	Arm-Dual, Shifter


Ref	Part No.	Qty.	Description
25	2411-38	2	Joint-Ball
26	3296-27	2	Nut-Lock, NI
27	114-0433	1	Clip-Spring
28	117-0474	2	Cable-Control, Traction
29	1-633181	1	Plate-Tapped
30	32105-13	2	Screw-HWH
31	3290-378	1	Tie-Cable
32	114-3576	2	Bushing-Guide, Drill



Hydraulic Assembly


Ref	Part No.	Qty.	Description
1	105-0800	2	Wheel Hub / Stud ASM
1:2	10-6830	4	Stud-Type, Drive
2	114-0549	2	Motor-Wheel
3	3257-8	2	Key-Woodruff
4	85-7310	2	Nut-Motor, Wheel
5	325-8	8	Screw-HH
6	117-3572-01	1	LH Motor Mount ASM
7	117-3571-01	1	RH Motor Mount ASM
8	114-5168-01	1	Mount-Motor, Center
9	114-5166-01	1	Base-Engine
10	3232-3	4	Screw-CARR
11	3296-48	4	Nut-Lock, NI
12	3256-25	4	Washer-Flat
13	117-3597	2	Pump-Hydraulic
15	3231-22	4	Screw-CARR
16	3290-357	9	Nut-HHF, Whiz
17	114-5345-01	2	Plate-Lift
18	92-1624	5	Screw-HWH
20	107-8433	1	HYD Reservoir ASM
❶20:1		1	Reservoir-HYD
20:1:1	103-1948	1	Cap-Reservoir, HYD
20:1:2	103-1949	1	Gasket-Cap
20:2	115-4212	1	Decal-Warning
21	321-4	4	Screw-HH

Ref	Part No.	Qty.	Description
22	32128-33	2	Nut-HF
23	104-7836	1	Head-Filter
24	1-633750	1	Filter-Oil, HYD
26	3256-22	2	Washer-Flat
27	340-89	4	Fitting-HYD, 45 DEG
27:1	237-30	1	O-Ring
27:2	237-80	1	O-Ring
28	340-101	4	Fitting-HYD, 45 DEG
28:1	237-30	1	O-Ring
28:2	237-79	1	O-Ring
29	100-4887	5	Fitting-Barb
29:1	237-42	1	O-Ring
30	103-1807	3	Elbow-45 DEG
30:1	237-42	1	O-Ring
32	103-1988	2	Clamp-Hose
33	117-0442	2	HYD Hose ASM
34	117-0449	2	HYD Hose ASM
36	117-0459	1	Hose-Hydraulic
37	117-3569	1	Filter Hose ASM
37:1	117-0460	1	Hose-Hydraulic
37:2	117-0458	2	Hose-Hydraulic
37:3	1-603721	2	Fitting-Tee, Hose
37:4	103-1988	6	Clamp-Hose
38	117-3570	1	Tank Hose ASM




Hydraulic Assembly (continued)

Ref	Part No.	Qty.	Description
38:1	117-0461	1	Hose-Hydraulic
38:2	117-0459	2	Hose-Hydraulic
38:3	1-603721	2	Fitting-Tee, Hose
38:4	103-1988	6	Clamp-Hose
39	98-5975	8	Washer-Belleville
40	3296-39	8	Nut-Lock, NI
41	3231-25	8	Screw-CARR



Hydraulic Motor Assembly No. 114-0549


Ref	Part No.	Qty.	Description
1	1-000119	1	Seal Kit
❶1:1		1	Ring-Back Up
❶1:2		1	Seal-Commutator
❶1:3		1	Seal-Shaft (Viton)
❶1:4		1	Washer-Back Up, Steel
❶1:5		5	Ring-Seal (Viton)
❶1:7		1	Seal-Dirt And Water
2	3257-8	1	Key-Woodruff
3	85-7310	1	Nut-Motor, Wheel
4	106-5549	6	Bolt-Special
5	106-8764	1	Shaft-Coupling



Hydraulic Pump Assembly No. 117-3597


Ref	Part No.	Qty.	Description
1	115-4464	1	Housing Kit
2	106-8752	1	End Cap Kit (W/Poppets)
3	106-8753	2	Pin-Headless, Straight
4	106-8754	4	Bolt-HF
5	106-8755	1	O-Ring
6	106-8756	1	Charge Pump Kit
7	104-2122	1	Gerotor ASM
8	106-8757	1	O-Ring
10	104-2111	2	Capscrew
15	106-8759	1	Bypass Valve Kit
18	103-2664	1	Input Shaft Kit
19	104-5311	1	Bearing-Ball
20	104-5310	1	Seal-Lip
21	104-5308	1	Spacer
22	104-5309	1	Ring-Retaining
25	103-2666	1	Cylinder Block Kit
29	94-1936	1	Spring-Block
30	94-1937	1	Washer-Thrust, Block
31	105-6185	1	Plate-Valve
32	94-1907	1	Swashplate-Variable
34	94-6922	1	Bearing-Thrust
37	115-4458	1	Arm-Trunnion, Tapered Square
38	94-1910	1	Guide-Slot
42	98-3252	2	Valve-Check (W/Poppet)

Ref	Part No.	Qty.	Description
44	106-8760	1	Charge Relief Valve Kit
49	114-8155	1	Trunnion Seal Kit
56	106-8762	1	Plug-HSH
66	106-8763	1	Plug-HSH
98	117-3629	1	Kit-Return
99	105-6184	1	Seal Overhaul Kit




Hydraulic Belt Drive Assembly

Ref	Part No.	Qty.	Description
❶1		1	Pump Idler Assembly
1:1	117-3568	1	Hub-Idler
1:2	1-413088	1	Bushing-Lever, Lift
1:3	114-0463	2	Washer-Friction, Composite
1:4	117-3622	1	Plate-Idler
1:5	110-9981	1	Washer-Plain
1:6	323-13	1	Screw-HH
1:7	3296-39	2	Nut-Lock, NI
1:8	3256-24	1	Washer-Flat
1:9	93-1622	1	Pulley-Idler
1:10	323-9	1	Screw-HH
1:11	108-4056	1	Spring-Extension
2	1-807272	2	Key
3	3241-5	4	Screw-Set
4	114567	1	Belt-V Lower PTO
5	105-5648	2	Pulley-Pump




Platform Assembly

Ref	Part No.	Qty.	Description
1	114-1917	1	Cushion ASM
2	117-9640	1	Platform ASM
3	114-1924	1	Plate-Strike
4	1-807512	2	Bolt-CARR
5	3296-42	2	Nut-Lock, NI




Cushion Assembly No. 114-1917

Ref	Part No.	Qty.	Description
1	114-0463	4	Washer-Friction, Composite
2	114-1915-01	2	Link-Pad
3	114-1918-03	2	Hinge-Pad
4	114-1919	1	Shield-Rear
5	114-5314	1	Cushion-Pad
6	322-5	4	Screw-HH
7	3231-2	2	Screw-CARR
8	3256-23	4	Washer-Flat
9	3256-4	8	Washer-Flat
10	3296-59	4	Nut-Lock, NI
11	111044	4	Spacer
12	93-2891	2	Bushing-Plastic
13	3290-355	2	Pin-Hair
14	3231-27	2	Screw-CARR




Platform Assembly No. 117-9640

Ref	Part No.	Qty.	Description
1	117-9641-01	1	Platform ASM
2	114-1925	2	Bumper-Rubber
3	114-1926	2	Bumper-Rubber
4	3296-47	4	Nut-Lock, NI
5	111044	2	Spacer
6	3256-4	4	Washer-Flat
7	3231-25	2	Screw-CARR
8	3296-59	2	Nut-Lock, NI
9	1-603175	1	Knob-Ball
10	114-5288	1	Pin-Latch
11	114-5348	1	Spring
12	114-1920-03	1	Clamp-Shield
13	114-5349	1	Mat-Foot
14	32144-70	2	Screw-HWHTF
15	68-3640	1	Decal



Parking Brake Assembly


Ref	Part No.	Qty.	Description
1	114-5187-03	1	Brake ASM
2	114-5186-01	2	Support-Brake
3	1-633131	1	Yoke-Linkage, Brake
4	114-5196	1	Rod-Brake
5	3220-3	1	Nut-HJ
6	283-2	1	Pin-Clevis
7	3290-307	2	Pin-Hair
8	614672	2	Bolt-Shoulder
9	5-0652	2	Spacer
10	3296-39	3	Nut-Lock, NI
11	117-5759-03	1	Lever-Brake
12	117-0452-03	1	Plate-Switch, Brake
13	106-3214	1	Mount-Pulley
14	63-7400	2	Washer-Rebound
15	3231-44	1	Screw-CARR
16	1-633268	1	Grip-Lever, Brake
17	32105-13	2	Screw-HWH
18	1-633181	1	Plate-Tapped
19	114-0463	1	Washer-Friction, Composite
20	3256-7	1	Washer-Flat



Electrical Assembly


Ref	Part No.	Qty.	Description
1	114-3536	1	Harness-Wire
1:1	109103	1	Fuse-30 Amp
1:2	109102	1	Fuse-25 Amp
1:3	218-578	1	Fuse-10 Amp
1:4	116-0053	1	Cap-Plug
2	110-6764	1	Switch-Ignition
3	1-513152	3	Switch-Closed, Normally
4	114-0279	1	Switch-PTO
5	115-4180	1	Module-Meter, Hour
6	117-1197	1	Solenoid
7	3220-2	2	Nut-Jam
8	3253-4	2	Washer-Lock
9	104-2491	1	Battery
10	117-0543-01	1	Cover-Battery
11	1-633651	2	Bolt-Holddown
12	1-543792	2	Wingnut
13	114-9404	1	Cable-Battery, Positive
14	105-0836	1	Cable-Battery, Black
15	106-8268	1	Cable-Battery, Red
16	3256-23	2	Washer-Flat
17	109-5715	2	Nut-HHF, Smooth
18	322-3	2	Screw-HH
19	32144-4	2	Screw-HWH
20	68-3640	1	Decal

Ref	Part No.	Qty.	Description
21	3256-22	1	Washer-Flat
22	32128-33	1	Nut-HF
23	3290-378	1	Tie-Cable
24	63-8360	1	Key-Ignition



Fuel Tank Assembly


Ref	Part No.	Qty.	Description
1	117-9672	1	Tank ASM
1:1	1-643172	2	Elbow-90 DEG
1:2	95-8972	1	Grommet
1:3	46-6560	3	Bushing
1:4	109-9619	1	Cap-Fuel
1:5	114-1928	1	Fitting-Fuel, Screen Tube
1:7	99-7262	1	Gauge-Fuel
2	114-1952-01	1	Support-Tank
3	3231-2	1	Screw-CARR
4	3296-39	1	Nut-Lock, NI
5	109-0294	2	Hose-Fuel
6	71-9280	2	Filter-Fuel
7	2412-98	4	Clamp
8	1-603770	1	Valve-Fuel
9	109-3491	1	Hose-Fuel
10	109-0678	1	Hose-Fuel
11	112-7069	1	Grommet
12	3290-378	1	Tie-Cable



Engine Assembly

Ref	Part No.	Qty.	Description
1	114-3590	1	Engine-Kawasaki, FH580V-Fs30
2	117-0430	1	Muffler-Engine
3	112-7067	1	Pulley
4	608006	1	Key-Square
5	105-2635	1	Clutch / Brake
6	107-4136	1	Washer
7	1-603610	1	Washer-Spring
8	3212-9	1	Screw-HH
9	3256-23	6	Washer-Flat
10	322-7	5	Screw-HH
11	1-613235	1	Washer
12	1-633545	2	Spacer
13	1-633630	2	Grommet-Brake
14	1-633543-03	1	Strap-Clutch, Brake
15	32128-20	8	Nut-HF
16	109-3476-03	1	Bracket-Muffler, LH
17	109-3477-03	1	Bracket-Muffler, RH
18	322-3	2	Screw-HH
19	3256-3	2	Washer-Flat
20	33113-016	3	Screw-HH
21	33114-016	2	Screw-HH
22	3256-22	3	Washer-Flat
24	322-11	1	Screw-HH
25	104-6373	1	Tube-Retainer


Ref	Part No.	Qty.	Description
26	103-1966	1	Adapter
27	92-6877	1	Valve-Drain, Oil
28	112-7069	1	Grommet
29	33094-00	1	Washer-Plain
30	2412-87	1	Clamp-Cable
31	46-8090	1	Screw-Plastite
99	103-1964	1	Hose-Drain, Oil



Cylinder and Crankcase Assembly
Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description
❷130	130AA0640	4	Bolt-Flanged (6X40)
❷130A	130CA0875	2	Bolt-Flanged (8X75)
❷172	172BA0818	4	Bolt-Stud (8X18)
❷11004	11004-7016	2	Gasket-Head
❷11008	11008-6043	1	Head-Cylinder, No. 1
❷11008A	11008-7020	1	Head-Cylinder, No. 2
❷11022	11022-7018	2	Case-Rocker
❷11060	11060-7001	2	Gasket-Case, Rocker
❷11060A	11060-7008	1	Gasket-Cover, Crankcase
❷11061	11061-7001	1	Gasket-Breather
❷13271	13271-7016	1	Plate
❷14091	14091-7006	1	Cover
❷49015	49015-6253	1	Cover-Crankcase
❷49109	49109-7002	1	Element-Breather
❷49120	49120-7113	1	Crankcase
❷59071	59071-2079	1	Joint
❷92033	92033-7003	2	Ring-Snap
❷92043	92043-7001	6	Pin
❷92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)
❷92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)
❷92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)
❷92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)
❷92066	92066-7026	1	Plug
❷92153	92153-7043	4	Bolt (6X12)

Ref	Part No.	Qty.	Description
❷92153A	92153-7054	17	Bolt (8X50)




Piston and Crankshaft Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷13001	13001-7010	2	Piston-Engine
❷13002	13002-7001	2	Pin-Piston
❷13008	13008-6060	2	Piston Ring Set
❷13031	13031-7073	1	Crankshaft
❷13251	13251-7010	2	Connecting Rod ASM
❷92033	92033-7002	4	Ring-Snap
❷92151	92151-7017	4	Bolt (6X35)




Valve and Camshaft Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷12004	12004-7003	2	Valve-Intake
❷12005	12005-7003	2	Valve-Exhaust
❷12009	12009-7001	4	Retainer-Spring, Valve
❷12011	12011-2056	8	Collet
❷12016	12016-7008	4	Arm-Rocker
❷12032	12032-7001	4	Tappet
❷13070	13070-7001	2	Guide
❷13070A	13070-7004	1	Guide
❷13116	13116-2057	4	Rod-Push
❷13271	13271-7007	1	Plate
❷13271A	13271-7021	1	Plate-Governor
❷42036	42036-7010	1	Sleeve
❷49078	49078-7001	4	Spring-Valve, Engine
❷49118	49118-7004	1	Camshaft
❷92009	92009-2341	4	Screw
❷92015	92015-2253	4	Nut
❷92033	92033-7001	2	Ring-Snap
❷92140	92140-7005	6	Ball
❷92145	92145-7001	1	Spring
❷92153	92153-7019	4	Bolt
❷92200	92200-7001	1	Washer




Lubrication Equipment Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷670	670D2016	3	O-Ring (16Mm)
❷13107	13107-7009	1	Shaft
❷13271	13271-7017	1	Plate
❷14075	14075-7009	1	Cap ASM
❷16154	16154-2053	1	Rotor-Pump (In)
❷16154A	16154-2054	1	Rotor-Pump (Out)
❷49065	49065-2078	1	Filter-Oil (Part Can Be Used As Substitute On Product And Is Supplied Until Stock Exhausted)
❷49065A	49065-7004	1	Filter-Oil
❷49065B	49065-7010	1	Filter-Oil
❷59051	59051-7011	1	Gear-Spur
❷59231	59231-7005	1	Filler
❷92043	92043-7003	2	Pin
❷92066	92066-7003	2	Plug
❷92140	92140-7003	1	Ball
❷92145	92145-7002	1	Spring
❷92153	92153-7043	3	Bolt (6X12)




Cooling Equipment Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷130	130AA0616	2	Bolt-Flanged (6X16)
❷130A	130AA0625	2	Bolt-Flanged (6X25)
❷130B	130AA0816	1	Bolt-Flanged (8X16)
❷311	311AA0600	2	Nut-Hex (6Mm)
❷13270	13270-7007	1	Plate
❷14037	14037-7020-9H	1	Screen
❷23062	23062-7010	1	Bracket
❷49089	49089-7032	1	Shroud-Engine
❷49089A	49089-7042	1	Shroud-Engine
❷49089B	49089-7043	1	Shroud-Engine
❷55020	55020-7004	1	Guard
❷59041	59041-7012	1	Fan
❷59066	59066-7037	1	Housing-Fan
❷92004	92004-7006	2	Stud
❷92026	92026-7007	1	Spacer
❷92151	92151-7012	3	Bolt (6X12)
❷92153	92153-7007	3	Bolt
❷92153A	92153-7008	1	Bolt
❷92153B	92153-7043	2	Bolt (6X12)
❷92210	92210-0003	4	Nut




Electric Equipment Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷130	130AA0620	2	Bolt-Flanged (6X20)
❷311	311AA0600	2	Nut-Hex (6Mm)
❷510	510A5100	1	Key-Woodruff
❷21066	21066-7011	1	Regulator-Voltage
❷21171	21171-7034	2	Ignition Coil ASM
❷21193	21193-7032	1	Flywheel ASM
❷26030	26030-7001	1	Harness
❷26031	26031-7012	1	Harness
❷27010	27010-7001	1	Switch
❷59031A	59031-7014	1	Coil-Charging
❷92004	92004-7009	2	Stud
❷92009	92009-2308	1	Screw
❷92070	92070-7003	2	Spark Plug (R C J 8 Y, Solid)
❷92072	92072-7003	3	Band
❷92151	92151-2097	1	Bolt (12X30)
❷92172	92172-7018	4	Screw (5X20)
❷92200	92200-7002	1	Washer



Control Equipment Assembly
Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description
❷214	214AA0408	2	Screw-Pan +-(4X8)
❷311	311AA0600	1	Nut-Hex (6Mm)
❷411	411AA0600	1	Washer-Plain (6Mm)
❷13107	13107-7010	1	Shaft
❷13271	13271-7032	1	Plate
❷16169	16169-7010	1	Link-Choke
❷16171	16171-7001	1	Link
❷39129	39129-7003	1	Spring-Governor
❷49103	49103-7004	1	Arm-Governor
❷49113A	49113-7052	1	Panel-Comp-Control
❷92009	92009-7007	1	Screw (4X35)
❷92145	92145-7003	1	Spring
❷92145A	92145-7004	1	Spring
❷92145B	92145-7005	1	Spring
❷92150	92150-2182	2	Bolt (5X18)
❷92153	92153-7033	1	Bolt (6X35)
❷92153A	92153-7043	2	Bolt (6X12)
❷92170	92170-7001	2	Clamp



Carburetor Assembly
Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description
❷130	130AA0635	4	Bolt-Flanged (6X35)
❷172	172BA0690	2	Bolt-Stud (6X90)
❷214	214AA0510	1	Screw-Pan +-(5X10)
❷11061	11061-7004	2	Gasket-Insulator
❷11061A	11061-7009	1	Gasket-Chamber
❷11061B	11061-7010	1	Gasket-Screw
❷11061C	11061-7018	1	Gasket-Cleaner, Air
❷11061D	11061-7019	2	Gasket
❷13107	13107-7018	1	Shaft
❷15004	15004-7060	1	Carburetor ASM
❷16014	16014-7005	1	Screw-Air, Pilot
❷16020	16020-7003	1	Chamber-Float
❷16025	16025-7006	1	Valve-Throttle
❷16030	16030-7003	1	Valve-Float
❷16031	16031-7002	1	Float
❷16041	16041-7016	1	Shaft-Choke, Carburetor
❷16041A	16041-7018	1	Shaft-Throttle, Carburetor
❷16073	16073-7007	1	Insulator
❷16186	16186-7001	1	Choke Valve ASM
❷21188	21188-7002	1	Solenoid
❷39076	39076-7001	1	Limiter
❷49121A	49121-7016	1	Nozzle-Main
❷59076A	59076-7017	1	Manifold-Intake
❷92009	92009-2083	2	Screw

Ref	Part No.	Qty.	Description
❷92009A	92009-2349	1	Screw
❷92063C	92063-7066	1	Jet-Main, No. 108
❷92063D	92063-7090	1	Jet-Main, No.106 (2380Ft)
❷92063E	92063-7091	1	Jet-Main, No.104 (6560Ft)
❷92081	92081-2234	1	Spring
❷92093	92093-2100	1	Seal
❷92093A	92093-7003	1	Seal
❷92145	92145-7015	1	Spring




Air Filter and Muffler Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷461	461DA0800	4	Washer-Spring (8Mm)
❷11011	11011-7046	1	Case-Filter, Air
❷11013	11013-7025	1	Element-Filter, Air
❷11013A	11013-7031	1	Element-Filter, Air
❷11060	11060-7021	2	Gasket-Muffler
❷16060	16060-7016	1	Pipe-Intake
❷92015A	92015-1367	2	Nut
❷92055	92055-7015	1	O-Ring
❷92192	92192-7010	1	Tube
❷92210	92210-7004	2	Nut (M6)
❷92210A	92210-7019	1	Nut
❷92210B	92210-7027	4	Nut (M8)



Fuel Tank and Valve Assembly
Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description
❷130	130AA0620	2	Bolt-Flanged (6X20)
❷23062	23062-7019-9H	1	Bracket
❷42036	42036-7012	1	Sleeve
❷49019	49019-7001	1	Filter-Fuel
❷49040	49040-7001	1	Pump-Fuel
❷92170	92170-2009	4	Clamp
❷92191	92191-7002	1	Tube
❷92192	92192-7135	1	Tube (6.35X12.7X160)
❷92192A	92192-7136	1	Tube (6.35X12.7X180)



Starter Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷130	130AA0814	2	Bolt-Flanged (8X14)
❷13101	13101-7010	1	Gear ASM
❷16146	16146-7013	1	Cover ASM
❷21039	21039-7002	1	Brush
❷21080	21080-7007	1	Armature
❷21163	21163-7031	1	Starter-Electric
❷39184	39184-7009	1	Bracket ASM
❷92153	92153-7034	2	Bolt
❷92200	92200-7023	1	Washer
❷92200A	92200-7024	1	Washer
❷92210	92210-7037	2	Nut

56033



56070



56080



Label Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
❷56033	56033-7001	1	Label-Manual
❷56070	56070-7001	1	Label-Warning
❷56080	56080-7055	1	Label-Brand

Attachments and Accessories

For 74559 - GrandStand Mower, With 52in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Hi-Flow, 18 Inch (6 Pack)	108-1117
Blade-Atomic, 18 Inch (6 Pack)	108-1118
Blade-Lo-Flow, 18 Inch (6 Pack)	110-0406
Blade-Recycler, 18 Inch (6 Pack)	110-0408
Blade-Med-Flow, 18 Inch (6 Pack)	110-0409
Light Kit	114-3505
Trash Bag Kit	117-0448
Recycler Kit	117-0541
Operator-Controlled Discharge Chute Kit	117-3600
Weight Kit	117-3620
Soft Bag (3 Bushel)	30104

NOTES


TORO®