



GrandStand[®] Mower

With 48in TURBO FORCE[®] Cutting Unit

Model No. 79558 - 290003001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
48 Inch Deck Assembly	 3	Cylinder and Crankcase Assembly Kawasaki FH580V-FS30	 26
Deck Assembly No. 117-5764	 4	Piston and Crankshaft Assembly Kawasaki FH580V-FS30	 27
Spring Idler Assembly No. 117-0445	 5	Valve and Camshaft Assembly Kawasaki FH580V-FS30	 28
Idler Adjust Assembly No. 117-0446	 6	Lubrication Equipment Assembly Kawasaki FH580V-FS30	 29
Spindle Assembly No. 107-8504	 7	Cooling Equipment Assembly Kawasaki FH580V-FS30	 30
Deflector Assembly No. 114-1910	 8	Electric Equipment Assembly Kawasaki FH580V-FS30	 31
Wheel Assembly	 9	Control Equipment Assembly Kawasaki FH580V-FS30	 32
Frame and Muffler Guard Assembly	 10	Carburetor Assembly Kawasaki FH580V-FS30	 33
Deck Lift Assembly	 11	Air Filter and Muffler Assembly Kawasaki FH580V-FS30	 34
Upper Control and Tower Assembly	 12	Fuel Tank and Valve Assembly Kawasaki FH580V-FS30	 35
Lower Control Assembly	 13	Starter Assembly Kawasaki FH580V-FS30	 36
Hydraulic Assembly	 14	Label Assembly Kawasaki FH580V-FS30	 37
Hydraulic Wheel Motor Assembly No. 114-0549	 16	Attachments and Accessories List	 38
Hydraulic Pump Assembly No. 117-3597	 17		
Hydraulic Belt Drive Assembly	 18		
Platform Assembly	 19		
Cushion Assembly No. 114-1917	 20		
Platform Assembly No. 117-9640	 21		
Parking Brake Assembly	 22		
Electrical Assembly	 23		
Fuel Tank Assembly	 24		
Engine Assembly	 25		

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HWHTF. hex washer head thread forming
ASM. assembly	HYD. hydraulic
BBC. blade brake clutch	LH. left hand
CARR. carriage	NI. nylon insert
CCW. counter clock wise	NPTF. national pipe thread fine
CW. clockwise	PFH. phillips flat head
DEG. degrees	PPH. phillips pan head
ECM. electronic control module	PPHTF. phillips pan head thread forming
EXT. external	PRH. phillips round head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power-take-off
HD. heavy-duty	RH. right hand
HF. hex flange	ROPS. roll-over protection system
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HSBH. hex socket button head	STD. standard
HSFH. hex socket flat head	TAP. self tapping
HSH. hex socket head	TTH. torx truss head
HWH. hex washer head	

Footnotes


❶ Not serviced separately

❷ Obtain parts from www.kawpowerepc.com




48 Inch Deck Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	117-5764	1	Deck ASM	23	33115-025	18	Screw-HH
2	107-3192-03	3	Blade-16.5 Inch (High Flow)	24	33025-00	18	Nut-Lock
3	103-0865	3	Washer-Blade Bolt, Heavy	28	109-6935	1	Cover-Belt, RH
4	103-0862	3	Screw-Cap	29	109-6936	1	Cover-Belt, LH
5	114-1908-01	1	Skid	30	3296-39	4	Nut-Lock, NI
6	107-8541-01	1	Baffle-Discharge	31	109-6982	2	Wireform-Cover
7	105-7755-01	1	Baffle ASM				
8	117-0410-01	1	48 Inch Baffle ASM				
9	107-1664	1	Lever ASM				
9:1	106-3239	1	Screw-Lock				
9:2	107-1644	1	Cap-Lock				
9:3	106-3241	1	Lever-Lock				
9:4	3296-29	1	Nut-Lock, NI				
10	117-5758-03	4	Bracket-Cover				
11	115-7440	3	Pulley				
12	117-0445	1	Spring Idler ASM				
13	117-0446	1	Idler Adjust ASM				
14	114-0453	1	Belt-V				
15	107-8504	3	Spindle ASM				
16	32144-70	4	Screw-HWHTF				
17	92-1624	14	Screw-HWH				
18	3290-357	9	Nut-HHF, Whiz				
19	3231-1	4	Screw-CARR				
22	114-1910	1	Deflector ASM				




Deck Assembly No. 117-5764

Ref	Part No.	Qty.	Description				
2	54-9220	1	Decal-Danger				
3	98-5954	2	Decal-Cover, Missing				
4	1-403005	1	Decal-Danger				
5	68-8340	1	Decal-Torque				
6	117-0486	1	Decal-Tension, Belt				
7	107-1690	1	Decal				
8	110-2067	1	Decal-Setting, Baffle				
9	110-2068	1	Decal-Adjustment, Baffle				
10	58-6520	3	Decal-Grease				




Spring Idler Assembly No. 117-0445

Ref	Part No.	Qty.	Description				
1	114-1992	1	Plate-Idler				
2	114-0463	2	Washer-Friction, Composite				
3	110-9981	2	Washer-Plain				
4	3231-5	2	Screw-CARR				
5	3256-24	3	Washer-Flat				
6	93-1622	1	Pulley-Idler				
7	117-0447-01	1	Bracket-Anchor, Spring				
8	108-4056	1	Spring-Extension				
9	3296-39	2	Nut-Lock, NI				
10	1-413088	1	Bushing-Lever, Lift				




Idler Adjust Assembly No. 117-0446

Ref	Part No.	Qty.	Description				
1	114-1991	1	Plate-Idler				
2	3256-24	3	Washer-Flat				
3	93-1622	1	Pulley-Idler				
4	105-7788	2	Spacer				
5	3231-5	1	Screw-CARR				
6	3231-4	2	Screw-CARR				
7	98-5975	1	Washer-Belleville				
8	3296-39	3	Nut-Lock, NI				




Spindle Assembly No. 107-8504

Ref	Part No.	Qty.	Description				
1	10-8040	1	Key-Square				
2	106-3277	1	Hub-Pulley				
3	103-0865	1	Washer-Blade Bolt, Heavy				
4	106-3204	2	Shield-Bearing				
5		1	Spindle Bearing ASM				
5:1	106-3211	1	Housing-Spindle				
5:2	113514	2	Bearing-Ball				
5:3	107-8502	1	Spacer-Bearing				
5:4	302-5	1	Fitting-Grease				
6	3-8514	2	Washer-Thrust				
7	107-8501	1	Spindle ASM				
8	3219-6	1	Nut-Hex				




Deflector Assembly No. 114-1910

Ref	Part No.	Qty.	Description				
1	106-3248-03	1	Strap-Discharge				
2	110-0759	1	Deflector-Rubber				
3	108-7766-03	1	Bracket-Hinge, Front				
4	108-7767-03	1	Bracket-Hinge, Rear				
5	3231-25	4	Screw-CARR				
6	3296-39	4	Nut-Lock, NI				
7	105-4622	1	Spacer				
8	322-50	1	Screw-HH				
9	3296-29	1	Nut-Lock, NI				
10	108-4052	1	Spring-Torsion				




Wheel Assembly

Ref	Part No.	Qty.	Description				
1	112-3810	2	Wheel And Bearing ASM				
1:1		1	Wheel Bearing ASM				
1:1:1	1-633585	2	Bearing-Cone, Taper				
1:1:2	103-0063	2	Seal-Caster				
1:1:3	103-3051	2	Spacer-Nut				
1:1:4	103-3157	1	Axle-Caster				
1:1:5	110-9965	1	Wheel And Tire ASM				
1:2	103-2768	2	Guard-Seal				
1:3	3296-45	1	Nut-Lock, NI				
1:4	325-20	1	Screw-HH				
2	117-0429	2	Wheel ASM				
2:1	232-27	1	Stem-Valve				
2:2	117-0428	1	Tire				
2:3	106-8133	1	Rim-8 Inch				
3	242-50	8	Nut-Lug				




Frame and Muffler Guard Assembly

Ref	Part No.	Qty.	Description				
1	117-9630	1	Front Frame ASM				
1:2	302-5	2	Fitting-Grease				
1:3	1-543508	4	Cup-Bearing				
1:4	1-811010	2	Plug				
2	103-8618-01	2	Fork-Caster				
3	1-543511	2	Seal-Grease				
4	1-543509	4	Bearing-Roller, Tapered				
5	1-633508	6	Washer-Bellville				
6	3296-51	2	Nut-Lock, NI				
7	103-4882	2	Cap-Grease				
8	92-1624	4	Screw-HWH				
9	117-0434	1	Muffler Guard ASM				
9:2	106-5517	1	Decal-Surface, Hot				
10	117-0427-01	2	Bracket-Mounting, Guard				
11	3231-31	4	Screw-CARR				
12	104-8301	4	Nut-Flange, NI				
13	2412-87	3	Clamp-Cable				
14	3296-42	3	Nut-Lock, NI				
15	321-4	3	Screw-HH				
16	117-3591	2	Decal-Commercial				
17	68-3640	1	Decal				
18	3290-357	4	Nut-HHF, Whiz				
24	117-2620-01	2	Support-Hose				
25	32144-70	4	Screw-HWHTF				



Deck Lift Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	117-0505	1	Lift ASM	23	114-5305-03	1	Lever-HOC
1:2	302-5	4	Fitting-Grease	24	1-633268	1	Grip-Lever, Brake
2	117-0489-01	1	RH Lift ASM	25	3231-24	1	Screw-CARR
3	117-0488-01	1	LH Lift ASM	26	32128-21	4	Nut-HF
4	114-5268	2	Lift Rod ASM	27	111044	2	Spacer
5	117-0498	2	Spacer	28	3256-26	1	Washer-Flat
6	117-0513	2	Bracket-Rod, Lift	29	66-0561	1	Screw-Shoulder
7	114-5274	1	Pin-HOC	30	65-9940	1	Spring
8	117-3611	1	Bar-Lift	31	3231-22	1	Screw-CARR
10	3256-29	8	Washer-Flat	32	3296-59	3	Nut-Lock, NI
11	32151-103	7	Ring-Retaining, EXT	33	114-5307	1	Bracket-HOC
12	324-10	2	Screw-HH	34	3296-23	3	Nut-Lock, NI
13	3217-9	3	Nut-HH	35	323-7	1	Screw-HH
14	117-0519	2	Link-Lift	36	117-3645	1	Hub-Pivot
15	3256-25	2	Washer-Flat	37	32151-47	1	Ring-Retaining
16	3296-48	2	Nut-Lock, NI	38	40-1940	4	Washer
17	117-0506	2	Gas Spring ASM				
17:2	88-6770	2	Stud-Ball				
17:3	3296-47	2	Nut-Lock, NI				
18	109-9840	4	Screw-Shoulder, HHF				
19	117-3575	2	Cover-Spring				
20	114-3512	1	HOC Handle ASM				
21	3256-22	1	Washer-Flat				
22	302-5	1	Fitting-Grease				



Upper Control and Tower Assembly


Ref	Part No.	Qty.	Description
1	114-1922	1	Control Tower ASM
1:2	117-0453	1	Decal-Panel, Control
1:3	117-0454	1	Decal-OpC
1:4	117-3626	1	Decal-Warning
1:5	117-0456	1	Decal-HOC
1:6	117-0485	1	Decal-Service Aid
2	114-3593	1	LH Lever ASM
2:2	114-0241	1	Grip-Lever
3	114-3594	1	RH Lever ASM
3:2	114-0241	1	Grip-Lever
4	114-0260	1	Shaft-Pivot
5	114-1904	1	Shaft-Pivot, Motion Control
6	114-5302	1	Motion Control ASM
7	103-9928	6	Bearing
8	3234-4	3	Screw-HHF
9	114-0239	1	Screw-HSH
10	3296-47	1	Nut-Lock, NI
11	114-0268	1	Cam-Lever, Handle Stop
12	3256-22	1	Washer-Flat
13	3296-42	1	Nut-Lock, NI
14	114-0249	1	Spring-Extension
15	1-633181	1	Plate-Tapped
16	32105-13	2	Screw-HWH
18	106-9962	1	Control-Choke, Push / Pull

Ref	Part No.	Qty.	Description
19	110-5547	2	Control Lever ASM
20	1-603175	1	Knob-Ball
21	99-7981	1	Knob-Grip, Soft
23	2411-38	2	Joint-Ball
24	3296-27	2	Nut-Lock, NI
25	93-2279	2	Clamp-Cable
26	32144-70	6	Screw-HWHTF
27	114-1966	1	Cable-Control
28	114-1950	1	Cable-Speed
29	1-807533	6	Bolt-CARR
30	3290-148	6	Nut-HF
31	114-1921-01	1	Bar-Cable
32	114-0409	1	HOC Pin ASM
33	2412-87	1	Clamp-Cable
34	2412-120	2	R-Clamp
35	32144-1	2	Screw-Taptite
36	104-7048	1	Cap-Housing
37	104-7050	1	Tube-Manual
38	92-1624	4	Screw-HWH
39	3290-357	3	Nut-HHF, Whiz
40	3256-23	2	Washer-Flat
41	2412-138	1	R-Clamp
42	3296-39	1	Nut-Lock, NI



Lower Control Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	114-5304-01	1	Mount-Linkage, Drive	25	2411-38	2	Joint-Ball
2	114-1993	1	Lever-Switch	26	3296-27	2	Nut-Lock, NI
3	114-1999	1	Lever-Switch	27	114-0433	1	Clip-Spring
4	114-1956	2	Control Fork ASM	28	117-0474	2	Cable-Control, Traction
5	114-1955	2	Hub-Shoulder	29	1-633181	1	Plate-Tapped
6	114-3547	2	Arm-Control	30	32105-13	2	Screw-HWH
7	321-15	2	Screw-HH	31	3290-378	1	Tie-Cable
8	3256-22	8	Washer-Flat	32	114-3576	2	Bushing-Guide, Drill
9	65-8270	1	Washer				
10	114-5155-03	1	Arm-Switch, Stop				
11	32128-14	2	Nut-Hex, Flange				
12	114-5295	2	Rod-Link, Shifter				
13	3290-307	6	Pin-Hair				
14	322-4	4	Screw-HH				
15	3296-29	4	Nut-Lock, NI				
16	114-3534	4	Roller				
17	114-1912-03	1	Bracket-Shifter				
18	106-7297	1	Clamp-Cable				
19	49-2040	1	Screw-HWHTF				
20	32144-70	5	Screw-HWHTF				
21	3256-23	2	Washer-Flat				
22	106-2584	1	Spring-Torsion				
23	114-1978	1	Pin-Hinge				
24	114-5347	1	Arm-Dual, Shifter				



Hydraulic Assembly


Ref	Part No.	Qty.	Description
1	105-0800	2	Wheel Hub / Stud ASM
1:2	10-6830	4	Stud-Type, Drive
2	114-0549	2	Motor-Wheel
3	3257-8	2	Key-Woodruff
4	85-7310	2	Nut-Motor, Wheel
5	325-8	8	Screw-HH
6	117-3572-01	1	LH Motor Mount ASM
7	117-3571-01	1	RH Motor Mount ASM
8	114-5168-01	1	Mount-Motor, Center
9	114-5166-01	1	Base-Engine
10	3232-3	4	Screw-CARR
11	3296-48	4	Nut-Lock, NI
12	3256-25	4	Washer-Flat
13	117-3597	2	Pump-Hydraulic
15	3231-22	4	Screw-CARR
16	3290-357	9	Nut-HHF, Whiz
17	114-5345-01	2	Plate-Lift
18	92-1624	5	Screw-HWH
20	107-8433	1	HYD Reservoir ASM
20:1		1	Reservoir-HYD
20:1:1	103-1948	1	Cap-Reservoir, HYD
20:1:2	103-1949	1	Gasket-Cap
20:2	115-4212	1	Decal-Warning
21	321-4	4	Screw-HH

Ref	Part No.	Qty.	Description
22	32128-33	2	Nut-HF
23	104-7836	1	Head-Filter
24	1-633750	1	Filter-Oil, HYD
26	3256-22	2	Washer-Flat
27	340-89	4	Fitting-HYD, 45 DEG
27:1	237-30	1	O-Ring
27:2	237-80	1	O-Ring
28	340-101	4	Fitting-HYD, 45 DEG
28:1	237-30	1	O-Ring
28:2	237-79	1	O-Ring
29	100-4887	5	Fitting-Barb
29:1	237-42	1	O-Ring
30	103-1807	3	Elbow-45 DEG
30:1	237-42	1	O-Ring
32	103-1988	2	Clamp-Hose
33	117-0442	2	HYD Hose ASM
34	117-0449	2	HYD Hose ASM
36	117-0459	1	Hose-Hydraulic
37	117-3569	1	Filter Hose ASM
37:1	117-0460	1	Hose-Hydraulic
37:2	117-0458	2	Hose-Hydraulic
37:3	1-603721	2	Fitting-Tee, Hose
37:4	103-1988	6	Clamp-Hose
38	117-3570	1	Tank Hose ASM



Hydraulic Wheel Motor Assembly No. 114-0549


Ref	Part No.	Qty.	Description				
1	1-000119	1	Seal Kit				
1:1		1	Ring-Back Up				
1:2		1	Seal-Commutator				
1:3		1	Seal-Shaft (Viton)				
1:4		1	Washer-Back Up, Steel				
1:5		5	Ring-Seal (Viton)				
1:7		1	Seal-Dirt And Water				
2	3257-8	1	Key-Woodruff				
3	85-7310	1	Nut-Motor, Wheel				
4	106-5549	6	Bolt-Special				
5	106-8764	1	Shaft-Coupling				



Hydraulic Pump Assembly No. 117-3597


Ref	Part No.	Qty.	Description
1	115-4464	1	Housing Kit
2	106-8752	1	End Cap Kit (W/Poppets)
3	106-8753	2	Pin-Headless, Straight
4	106-8754	4	Bolt-HF
5	106-8755	1	O-Ring
6	106-8756	1	Charge Pump Kit
7	104-2122	1	Gerotor ASM
8	106-8757	1	O-Ring
10	104-2111	2	Capscrew
15	106-8759	1	Bypass Valve Kit
18	103-2664	1	Input Shaft Kit
19	104-5311	1	Bearing-Ball
20	104-5310	1	Seal-Lip
21	104-5308	1	Spacer
22	104-5309	1	Ring-Retaining
25	103-2666	1	Cylinder Block Kit
29	94-1936	1	Spring-Block
30	94-1937	1	Washer-Thrust, Block
31	105-6185	1	Plate-Valve
32	94-1907	1	Swashplate-Variable
34	94-6922	1	Bearing-Thrust
37	115-4458	1	Arm-Trunnion, Tapered Square
38	94-1910	1	Guide-Slot
42	98-3252	2	Valve-Check (W/Poppet)

Ref	Part No.	Qty.	Description
44	106-8760	1	Charge Relief Valve Kit
49	114-8155	1	Trunnion Seal Kit
56	106-8762	1	Plug-HSH
66	106-8763	1	Plug-HSH
98	117-3629	1	Kit-Return
99	105-6184	1	Seal Overhaul Kit




Hydraulic Belt Drive Assembly

Ref	Part No.	Qty.	Description				
❶ 1		1	Pump Idler Assembly				
1:1	117-3568	1	Hub-Idler				
1:2	1-413088	1	Bushing-Lever, Lift				
1:3	114-0463	2	Washer-Friction, Composite				
1:4	117-3622	1	Plate-Idler				
1:5	110-9981	1	Washer-Plain				
1:6	323-13	1	Screw-HH				
1:7	3296-39	2	Nut-Lock, NI				
1:8	3256-24	1	Washer-Flat				
1:9	93-1622	1	Pulley-Idler				
1:10	323-9	1	Screw-HH				
1:11	108-4056	1	Spring-Extension				
2	1-807272	2	Key				
3	3241-5	4	Screw-Set				
4	114567	1	Belt-V Lower PTO				
5	105-5648	2	Pulley-Pump				




Cushion Assembly No. 114-1917

Ref	Part No.	Qty.	Description				
1	114-0463	4	Washer-Friction, Composite				
2	114-1915-01	2	Link-Pad				
3	114-1918-03	2	Hinge-Pad				
4	114-1919	1	Shield-Rear				
5	114-5314	1	Cushion-Pad				
6	322-5	4	Screw-HH				
7	3231-2	2	Screw-CARR				
8	3256-23	4	Washer-Flat				
9	3256-4	8	Washer-Flat				
10	3296-59	4	Nut-Lock, NI				
11	111044	4	Spacer				
12	93-2891	2	Bushing-Plastic				
13	3290-355	2	Pin-Hair				
14	3231-27	2	Screw-CARR				




Platform Assembly No. 117-9640

Ref	Part No.	Qty.	Description				
1	117-9641-01	1	Platform ASM				
2	114-1925	2	Bumper-Rubber				
3	114-1926	2	Bumper-Rubber				
4	3296-47	4	Nut-Lock, NI				
5	111044	2	Spacer				
6	3256-4	4	Washer-Flat				
7	3231-25	2	Screw-CARR				
8	3296-59	2	Nut-Lock, NI				
9	1-603175	1	Knob-Ball				
10	114-5288	1	Pin-Latch				
11	114-5348	1	Spring				
12	114-1920-03	1	Clamp-Shield				
13	114-5349	1	Mat-Foot				
14	32144-70	2	Screw-HWHTF				
15	68-3640	1	Decal				



Parking Brake Assembly


Ref	Part No.	Qty.	Description				
1	114-5187-03	1	Brake ASM				
2	114-5186-01	2	Support-Brake				
3	1-633131	1	Yoke-Linkage, Brake				
4	114-5196	1	Rod-Brake				
5	3220-3	1	Nut-HJ				
6	283-2	1	Pin-Clevis				
7	3290-307	2	Pin-Hair				
8	614672	2	Bolt-Shoulder				
9	5-0652	2	Spacer				
10	3296-39	3	Nut-Lock, NI				
11	117-5759-03	1	Lever-Brake				
12	117-0452-03	1	Plate-Switch, Brake				
13	106-3214	1	Mount-Pulley				
14	63-7400	2	Washer-Rebound				
15	3231-44	1	Screw-CARR				
16	1-633268	1	Grip-Lever, Brake				
17	32105-13	2	Screw-HWH				
18	1-633181	1	Plate-Tapped				
19	114-0463	1	Washer-Friction, Composite				
20	3256-7	1	Washer-Flat				



Electrical Assembly


Ref	Part No.	Qty.	Description
1	114-3536	1	Harness-Wire
1:1	109103	1	Fuse-30 Amp
1:2	109102	1	Fuse-25 Amp
1:3	218-578	1	Fuse-10 Amp
1:4	116-0053	1	Cap-Plug
2	110-6764	1	Switch-Ignition
3	1-513152	3	Switch-Closed, Normally
4	114-0279	1	Switch-PTO
5	115-4180	1	Module-Meter, Hour
6	117-1197	1	Solenoid
7	3220-2	2	Nut-Jam
8	3253-4	2	Washer-Lock
9	104-2491	1	Battery
10	117-0543-01	1	Cover-Battery
11	1-633651	2	Bolt-Holddown
12	1-543792	2	Wingnut
13	114-9404	1	Cable-Battery, Positive
14	105-0836	1	Cable-Battery, Black
15	106-8268	1	Cable-Battery, Red
16	3256-23	2	Washer-Flat
17	109-5715	2	Nut-HHF, Smooth
18	322-3	2	Screw-HH
19	32144-4	2	Screw-HWH
20	68-3640	1	Decal

Ref	Part No.	Qty.	Description
21	3256-22	1	Washer-Flat
22	32128-33	1	Nut-HF
23	3290-378	1	Tie-Cable
24	63-8360	1	Key-Ignition



Fuel Tank Assembly


Ref	Part No.	Qty.	Description				
1	117-9672	1	Tank ASM				
1:1	1-643172	2	Elbow-90 DEG				
1:2	95-8972	1	Grommet				
1:3	46-6560	3	Bushing				
1:4	109-9619	1	Cap-Fuel				
1:5	114-1928	1	Fitting-Fuel, Screen Tube				
1:7	99-7262	1	Gauge-Fuel				
2	114-1952-01	1	Support-Tank				
3	3231-2	1	Screw-CARR				
4	3296-39	1	Nut-Lock, NI				
5	109-0294	2	Hose-Fuel				
6	71-9280	2	Filter-Fuel				
7	2412-98	4	Clamp				
8	1-603770	1	Valve-Fuel				
9	109-3491	1	Hose-Fuel				
10	109-0678	1	Hose-Fuel				
11	112-7069	1	Grommet				
12	3290-378	1	Tie-Cable				



Engine Assembly

Ref	Part No.	Qty.	Description
1	114-3590	1	Engine-Kawasaki, FH580V-Fs30
2	117-0430	1	Muffler-Engine
3	112-7067	1	Pulley
4	608006	1	Key-Square
5	105-2635	1	Clutch / Brake
6	107-4136	1	Washer
7	1-603610	1	Washer-Spring
8	3212-9	1	Screw-HH
9	3256-23	6	Washer-Flat
10	322-7	5	Screw-HH
11	1-613235	1	Washer
12	1-633545	2	Spacer
13	1-633630	2	Grommet-Brake
14	1-633543-03	1	Strap-Clutch, Brake
15	32128-20	8	Nut-HF
16	109-3476-03	1	Bracket-Muffler, LH
17	109-3477-03	1	Bracket-Muffler, RH
18	322-3	2	Screw-HH
19	3256-3	2	Washer-Flat
20	33113-016	3	Screw-HH
21	33114-016	2	Screw-HH
22	3256-22	3	Washer-Flat
24	322-11	1	Screw-HH
25	104-6373	1	Tube-Retainer


Ref	Part No.	Qty.	Description
26	103-1966	1	Adapter
27	92-6877	1	Valve-Drain, Oil
28	112-7069	1	Grommet
29	33094-00	1	Washer-Plain
30	2412-87	1	Clamp-Cable
31	46-8090	1	Screw-Plastite
99	103-1964	1	Hose-Drain, Oil



Cylinder and Crankcase Assembly


Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
● 130	130AA0640	4	Bolt-Flanged (6X40)	● 92153A	92153-7054	17	Bolt (8X50)
● 130A	130CA0875	2	Bolt-Flanged (8X75)				
● 172	172BA0818	4	Bolt-Stud (8X18)				
● 11004	11004-7016	2	Gasket-Head				
● 11008	11008-6043	1	Head-Cylinder, No. 1				
● 11008A	11008-7020	1	Head-Cylinder, No. 2				
● 11022	11022-7018	2	Case-Rocker				
● 11060	11060-7001	2	Gasket-Case, Rocker				
● 11060A	11060-7008	1	Gasket-Cover, Crankcase				
● 11061	11061-7001	1	Gasket-Breather				
● 13271	13271-7016	1	Plate				
● 14091	14091-7006	1	Cover				
● 49015	49015-6253	1	Cover-Crankcase				
● 49109	49109-7002	1	Element-Breather				
● 49120	49120-7113	1	Crankcase				
● 59071	59071-2079	1	Joint				
● 92033	92033-7003	2	Ring-Snap				
● 92043	92043-7001	6	Pin				
● 92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)				
● 92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)				
● 92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)				
● 92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)				
● 92066	92066-7026	1	Plug				
● 92153	92153-7043	4	Bolt (6X12)				




Piston and Crankshaft Assembly Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
②13001	13001-7010	2	Piston-Engine				
②13002	13002-7001	2	Pin-Piston				
②13008	13008-6060	2	Piston Ring Set				
②13031	13031-7073	1	Crankshaft				
②13251	13251-7010	2	Connecting Rod ASM				
②92033	92033-7002	4	Ring-Snap				
②92151	92151-7017	4	Bolt (6X35)				




Valve and Camshaft Assembly **Kawasaki FH580V-FS30**

Ref	Part No.	Qty.	Description				
②12004	12004-7003	2	Valve-Intake				
②12005	12005-7003	2	Valve-Exhaust				
②12009	12009-7001	4	Retainer-Spring, Valve				
②12011	12011-2056	8	Collet				
②12016	12016-7008	4	Arm-Rocker				
②12032	12032-7001	4	Tappet				
②13070	13070-7001	2	Guide				
②13070A	13070-7004	1	Guide				
②13116	13116-2057	4	Rod-Push				
②13271	13271-7007	1	Plate				
②13271A	13271-7021	1	Plate-Governor				
②42036	42036-7010	1	Sleeve				
②49078	49078-7001	4	Spring-Valve, Engine				
②49118	49118-7004	1	Camshaft				
②92009	92009-2341	4	Screw				
②92015	92015-2253	4	Nut				
②92033	92033-7001	2	Ring-Snap				
②92140	92140-7005	6	Ball				
②92145	92145-7001	1	Spring				
②92153	92153-7019	4	Bolt				
②92200	92200-7001	1	Washer				



Lubrication Equipment Assembly
Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
②670	670D2016	3	O-Ring (16Mm)				
②13107	13107-7009	1	Shaft				
②13271	13271-7017	1	Plate				
②14075	14075-7009	1	Cap ASM				
②16154	16154-2053	1	Rotor-Pump (In)				
②16154A	16154-2054	1	Rotor-Pump (Out)				
②49065	49065-2078	1	Filter-Oil (Part Can Be Used As Substitute On Product And Is Supplied Until Stock Exhausted)				
②49065A	49065-7004	1	Filter-Oil				
②49065B	49065-7010	1	Filter-Oil				
②59051	59051-7011	1	Gear-Spur				
②59231	59231-7005	1	Filler				
②92043	92043-7003	2	Pin				
②92066	92066-7003	2	Plug				
②92140	92140-7003	1	Ball				
②92145	92145-7002	1	Spring				
②92153	92153-7043	3	Bolt (6X12)				



Cooling Equipment Assembly


Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
②130	130AA0616	2	Bolt-Flanged (6X16)				
②130A	130AA0625	2	Bolt-Flanged (6X25)				
②130B	130AA0816	1	Bolt-Flanged (8X16)				
②311	311AA0600	2	Nut-Hex (6Mm)				
②13270	13270-7007	1	Plate				
②14037	14037-7020-9H	1	Screen				
②23062	23062-7010	1	Bracket				
②49089	49089-7032	1	Shroud-Engine				
②49089A	49089-7042	1	Shroud-Engine				
②49089B	49089-7043	1	Shroud-Engine				
②55020	55020-7004	1	Guard				
②59041	59041-7012	1	Fan				
②59066	59066-7037	1	Housing-Fan				
②92004	92004-7006	2	Stud				
②92026	92026-7007	1	Spacer				
②92151	92151-7012	3	Bolt (6X12)				
②92153	92153-7007	3	Bolt				
②92153A	92153-7008	1	Bolt				
②92153B	92153-7043	2	Bolt (6X12)				
②92210	92210-0003	4	Nut				




Electric Equipment Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
②130	130AA0620	2	Bolt-Flanged (6X20)				
②311	311AA0600	2	Nut-Hex (6Mm)				
②510	510A5100	1	Key-Woodruff				
②21066	21066-7011	1	Regulator-Voltage				
②21171	21171-7034	2	Ignition Coil ASM				
②21193	21193-7032	1	Flywheel ASM				
②26030	26030-7001	1	Harness				
②26031	26031-7012	1	Harness				
②27010	27010-7001	1	Switch				
②59031A	59031-7014	1	Coil-Charging				
②92004	92004-7009	2	Stud				
②92009	92009-2308	1	Screw				
②92070	92070-7003	2	Spark Plug (R C J 8 Y, Solid)				
②92072	92072-7003	3	Band				
②92151	92151-2097	1	Bolt (12X30)				
②92172	92172-7018	4	Screw (5X20)				
②92200	92200-7002	1	Washer				



Control Equipment Assembly Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
214	214AA0408	2	Screw-Pan +- (4X8)				
311	311AA0600	1	Nut-Hex (6Mm)				
411	411AA0600	1	Washer-Plain (6Mm)				
13107	13107-7010	1	Shaft				
13271	13271-7032	1	Plate				
16169	16169-7010	1	Link-Choke				
16171	16171-7001	1	Link				
39129	39129-7003	1	Spring-Governor				
49103	49103-7004	1	Arm-Governor				
49113A	49113-7052	1	Panel-Comp-Control				
92009	92009-7007	1	Screw (4X35)				
92145	92145-7003	1	Spring				
92145A	92145-7004	1	Spring				
92145B	92145-7005	1	Spring				
92150	92150-2182	2	Bolt (5X18)				
92153	92153-7033	1	Bolt (6X35)				
92153A	92153-7043	2	Bolt (6X12)				
92170	92170-7001	2	Clamp				



Carburetor Assembly Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description
②130	130AA0635	4	Bolt-Flanged (6X35)
②172	172BA0690	2	Bolt-Stud (6X90)
②214	214AA0510	1	Screw-Pan +- (5X10)
②11061	11061-7004	2	Gasket-Insulator
②11061A	11061-7009	1	Gasket-Chamber
②11061B	11061-7010	1	Gasket-Screw
②11061C	11061-7018	1	Gasket-Cleaner, Air
②11061D	11061-7019	2	Gasket
②13107	13107-7018	1	Shaft
②15004	15004-7060	1	Carburetor ASM
②16014	16014-7005	1	Screw-Air, Pilot
②16020	16020-7003	1	Chamber-Float
②16025	16025-7006	1	Valve-Throttle
②16030	16030-7003	1	Valve-Float
②16031	16031-7002	1	Float
②16041	16041-7016	1	Shaft-Choke, Carburetor
②16041A	16041-7018	1	Shaft-Throttle, Carburetor
②16073	16073-7007	1	Insulator
②16186	16186-7001	1	Choke Valve ASM
②21188	21188-7002	1	Solenoid
②39076	39076-7001	1	Limiter
②49121A	49121-7016	1	Nozzle-Main
②59076A	59076-7017	1	Manifold-Intake
②92009	92009-2083	2	Screw

Ref	Part No.	Qty.	Description
②92009A	92009-2349	1	Screw
②92063C	92063-7066	1	Jet-Main, No. 108
②92063D	92063-7090	1	Jet-Main, No.106 (2380Ft)
②92063E	92063-7091	1	Jet-Main, No.104 (6560Ft)
②92081	92081-2234	1	Spring
②92093	92093-2100	1	Seal
②92093A	92093-7003	1	Seal
②92145	92145-7015	1	Spring




Air Filter and Muffler Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
②461	461DA0800	4	Washer-Spring (8Mm)				
②11011	11011-7046	1	Case-Filter, Air				
②11013	11013-7025	1	Element-Filter, Air				
②11013A	11013-7031	1	Element-Filter, Air				
②11060	11060-7021	2	Gasket-Muffler				
②16060	16060-7016	1	Pipe-Intake				
②92015A	92015-1367	2	Nut				
②92055	92055-7015	1	O-Ring				
②92192	92192-7010	1	Tube				
②92210	92210-7004	2	Nut (M6)				
②92210A	92210-7019	1	Nut				
②92210B	92210-7027	4	Nut (M8)				



Fuel Tank and Valve Assembly Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
②130	130AA0620	2	Bolt-Flanged (6X20)				
②23062	23062-7019-9H	1	Bracket				
②42036	42036-7012	1	Sleeve				
②49019	49019-7001	1	Filter-Fuel				
②49040	49040-7001	1	Pump-Fuel				
②92170	92170-2009	4	Clamp				
②92191	92191-7002	1	Tube				
②92192	92192-7135	1	Tube (6.35X12.7X160)				
②92192A	92192-7136	1	Tube (6.35X12.7X180)				



Starter Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
2130	130AA0814	2	Bolt-Flanged (8X14)				
213101	13101-7010	1	Gear ASM				
216146	16146-7013	1	Cover ASM				
221039	21039-7002	1	Brush				
221080	21080-7007	1	Armature				
221163	21163-7031	1	Starter-Electric				
239184	39184-7009	1	Bracket ASM				
292153	92153-7034	2	Bolt				
292200	92200-7023	1	Washer				
292200A	92200-7024	1	Washer				
292210	92210-7037	2	Nut				

56033



56070



56080



Label Assembly

Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
●56033	56033-7001	1	Label-Manual
●56070	56070-7001	1	Label-Warning
●56080	56080-7055	1	Label-Brand

Attachments and Accessories

For 79558 - GrandStand Mower, With 48in TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Hi Flow, 16.5 Inch (6 Pack)	110-0414
Blade-Lo Flow, 16.5 Inch (6 Pack)	110-0415
Blade-Recycler, 16.5 Inch (6 Pack)	110-0416
Blade-Atomic, 16.5 Inch (6 Pack)	110-0417
Blade-Mid Flow, 16.5 Inch (6 Pack)	110-0418
Light Kit	114-3505
Trash Bag Kit	117-0448
Recycler Kit	117-0540
Operator-Controlled Discharge Chute Kit	117-3600
Weight Kit	117-3620
Soft Bag (3 Bushel)	30104

NOTES

