



GrandStand[®] Mower With 122cm TURBO FORCE[®] Cutting Unit

Model No. 74567TE - 290000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Deck Assembly	 3	Fuel Tank Assembly	 28
Deck Assembly No. 117-3633	 4	Engine Assembly	 29
Lever Assembly No. 107-1664	 5	Cylinder and Crankcase Assembly Kawasaki FH580V-FS30	 30
Spring Idler Assembly No. 117-0445	 6	Piston and Crankshaft Assembly Kawasaki FH580V-FS30	 31
Idler Adjust Assembly No. 117-0446	 7	Valve and Camshaft Assembly Kawasaki FH580V-FS30	 32
Spindle Assembly No. 107-8504	 8	Lubrication Equipment Assembly Kawasaki FH580V-FS30	 33
Deflector Assembly No. 114-1910	 9	Cooling Equipment Assembly Kawasaki FH580V-FS30	 34
Left Hand Belt Cover Assembly No. 114-1980	 10	Electric Equipment Assembly Kawasaki FH580V-FS30	 35
Right Hand Belt Cover Assembly No. 114-1981	 11	Control Equipment Assembly Kawasaki FH580V-FS30	 36
Wheel Assembly	 12	Carburetor Assembly Kawasaki FH580V-FS30	 37
Frame and Muffler Guard Assembly	 13	Air Filter and Muffler Assembly Kawasaki FH580V-FS30	 38
Deck Lift Assembly	 14	Fuel Tank and Valve Assembly Kawasaki FH580V-FS30	 39
Upper Control and Tower Assembly	 15	Starter Assembly Kawasaki FH580V-FS30	 40
Control Tower Assembly No. 117-5757	 16	Label Assembly Kawasaki FH580V-FS30	 41
Lower Control Assembly	 17	Attachments and Accessories List	 42
Hydraulic Assembly	 18		
Hydraulic Motor Assembly No. 114-0549	 20		
Hydraulic Pump Assembly No. 117-3597	 21		
Hydraulic Belt Drive Assembly	 22		
Platform Assembly	 23		
Cushion Assembly No. 114-1917	 24		
Platform Assembly No. 117-0431	 25		
Parking Brake Assembly	 26		
Electrical Assembly	 27		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HWHTF. hex washer head thread forming
ASM. assembly	HYD. hydraulic
BBC. blade brake clutch	LH. left hand
CARR. carriage	NI. nylon insert
CCW. counter clock wise	NPTF. national pipe thread fine
CW. clockwise	PFH. phillips flat head
DEG. degrees	PPH. phillips pan head
ECM. electronic control module	PPHTF. phillips pan head thread forming
EXT. external	PRH. phillips round head
FH. flat head	PTH. phillips truss head
GA. gauge	PTO. power-take-off
HD. heavy-duty	RH. right hand
HF. hex flange	ROPS. roll-over protection system
HH. hex head	SFH. slotted fillister head
HHF. hex head flange	SHH. slotted hex head
HHFTF. hex head flange thread forming	SHWH. slotted hex washer head
HJ. hex jam	SPH. slotted pan head
HLH. hex lag head	SQH. square head
HOC. height-of-cut	SRH. slotted round head
HSBH. hex socket button head	STD. standard
HSFH. hex socket flat head	TAP. self tapping
HSH. hex socket head	TTH. torx truss head
HWH. hex washer head	


Footnotes

- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain parts from www.kawpowerepc.com




Deck Assembly

Ref	Part No.	Qty.	Description				
1	117-3633	1	Deck ASM				
2	107-3192-03	3	Blade-16.5 Inch (High Flow)				
3	103-0865	3	Washer-Blade Bolt, Heavy				
4	103-0862	3	Screw-Cap				
5	114-1908-01	1	Skid				
6	107-8541-01	1	Baffle-Discharge				
7	105-7755-01	1	Baffle ASM				
8	117-0410-01	1	48 Inch Baffle ASM				
9	107-1664	1	Lever ASM				
10	108-2177-01	2	Bracket-Cover, Tall				
11	115-7440	3	Pulley				
12	117-0445	1	Spring Idler ASM				
13	117-0446	1	Idler Adjust ASM				
14	114-0453	1	Belt-V				
15	107-8504	3	Spindle ASM				
16	32144-70	2	Screw-HWHTF				
17	92-1624	14	Screw-HWH				
18	3290-357	9	Nut-HHF, Whiz				
19	3231-1	4	Screw-CARR				
22	114-1910	1	Deflector ASM				
23	33115-025	18	Screw-HH				
24	33025-00	18	Nut-Lock				
28	114-1980	1	LH Belt Cover ASM				
29	114-1981	1	RH Belt Cover ASM				




Deck Assembly No. 117-3633

Ref	Part No.	Qty.	Description				
2	93-7010	2	Decal-Danger				
3	98-1977	2	Decal-Warning				
4	58-6520	3	Decal-Grease				
5	93-7818	1	Decal-Torque, Blade Bolt				
6	117-3628	1	Decal-Belt Routing, Ce				
7	107-1690	1	Decal				
8	110-2067	1	Decal-Setting, Baffle				
9	110-2068	1	Decal-Adjustment, Baffle				




Spring Idler Assembly No. 117-0445

Ref	Part No.	Qty.	Description				
1	114-1992	1	Plate-Idler				
2	114-0463	2	Washer-Friction, Composite				
3	110-9981	2	Washer-Plain				
4	3231-5	2	Screw-CARR				
5	3256-24	3	Washer-Flat				
6	93-1622	1	Pulley-Idler				
7	117-0447-01	1	Bracket-Anchor, Spring				
8	108-4056	1	Spring-Extension				
9	3296-39	2	Nut-Lock, NI				
10	1-413088	1	Bushing-Lever, Lift				




Idler Adjust Assembly No. 117-0446

Ref	Part No.	Qty.	Description				
1	114-1991	1	Plate-Idler				
2	3256-24	3	Washer-Flat				
3	93-1622	1	Pulley-Idler				
4	105-7788	2	Spacer				
5	3231-5	1	Screw-CARR				
6	3231-4	2	Screw-CARR				
7	98-5975	1	Washer-Belleville				
8	3296-39	3	Nut-Lock, NI				




Spindle Assembly No. 107-8504

Ref	Part No.	Qty.	Description				
1	10-8040	1	Key-Square				
2	106-3277	1	Hub-Pulley				
3	103-0865	1	Washer-Blade Bolt, Heavy				
4	106-3204	2	Shield-Bearing				
5		1	Spindle Bearing ASM				
5:1	106-3211	1	Housing-Spindle				
5:2	113514	2	Bearing-Ball				
5:3	107-8502	1	Spacer-Bearing				
5:4	302-5	1	Fitting-Grease				
6	3-8514	2	Washer-Thrust				
7	107-8501	1	Spindle ASM				
8	3219-6	1	Nut-Hex				




Deflector Assembly No. 114-1910

Ref	Part No.	Qty.	Description				
1	106-3248-03	1	Strap-Discharge				
2	110-0759	1	Deflector-Rubber				
3	108-7766-03	1	Bracket-Hinge, Front				
4	108-7767-03	1	Bracket-Hinge, Rear				
5	3231-25	4	Screw-CARR				
6	3296-39	4	Nut-Lock, NI				
7	105-4622	1	Spacer				
8	322-50	1	Screw-HH				
9	3296-29	1	Nut-Lock, NI				
10	108-4052	1	Spring-Torsion				




Left Hand Belt Cover Assembly No. 114-1980

Ref	Part No.	Qty.	Description				
2	237-84	3	Grommet				
3	106-6777	1	Handle-Latch, Swell				
4	99-3058	1	Washer				
5	106-6778	1	Bushing-Latch, Swell				
6	1-804254	1	Nut				
7	109-5667	1	Ring-Retaining, Bolt				
8	32144-70	1	Screw-HWHTF				




Right Hand Belt Cover Assembly No. 114-1981

Ref	Part No.	Qty.	Description				
2	237-84	3	Grommet				
3	106-6777	1	Handle-Latch, Swell				
4	99-3058	1	Washer				
5	106-6778	1	Bushing-Latch, Swell				
6	1-804254	1	Nut				
7	109-5667	1	Ring-Retaining, Bolt				
8	32144-70	1	Screw-HWHTF				




Wheel Assembly

Ref	Part No.	Qty.	Description				
1	112-3810	2	Wheel And Bearing ASM				
2		1	Wheel Bearing ASM				
1:1:1	1-633585	2	Bearing-Cone, Taper				
1:1:2	103-0063	2	Seal-Caster				
1:1:3	103-3051	2	Spacer-Nut				
1:1:4	103-3157	1	Axle-Caster				
1:1:5	110-9965	1	Wheel And Tire ASM				
1:2	103-2768	2	Guard-Seal				
1:3	3296-45	1	Nut-Lock, NI				
1:4	325-20	1	Screw-HH				
2	117-0429	2	Wheel ASM				
2:1	232-27	1	Stem-Valve				
2:2	117-0428	1	Tire				
2:3	106-8133	1	Rim-8 Inch				
3	242-50	8	Nut-Lug				



Frame and Muffler Guard Assembly


Ref	Part No.	Qty.	Description				
1	117-0520	1	Front Frame ASM				
1:2	302-5	2	Fitting-Grease				
1:3	1-543508	4	Cup-Bearing				
1:4	1-811010	2	Plug				
2	103-8618-01	2	Fork-Caster				
3	1-543511	2	Seal-Grease				
4	1-543509	4	Bearing-Roller, Tapered				
5	1-633508	6	Washer-Bellville				
6	3296-51	2	Nut-Lock, NI				
7	103-4882	2	Cap-Grease				
8	92-1624	4	Screw-HWH				
9	117-0434	1	Muffler Guard ASM				
9:2	106-5517	1	Decal-Surface, Hot				
10	117-0427-01	2	Bracket-Mounting, Guard				
11	3231-31	4	Screw-CARR				
12	104-8301	4	Nut-Flange, NI				
13	2412-87	3	Clamp-Cable				
14	3296-42	3	Nut-Lock, NI				
15	321-4	3	Screw-HH				
16	117-3591	2	Decal-Commercial				
17	68-3640	1	Decal				
18	3290-357	4	Nut-HHF, Whiz				



Deck Lift Assembly

Ref	Part No.	Qty.	Description
1	117-0505	1	Lift ASM
1:2	302-5	4	Fitting-Grease
2	117-0489-01	1	RH Lift ASM
3	117-0488-01	1	LH Lift ASM
4	114-5268	2	Lift Rod ASM
5	117-0498	2	Spacer
6	117-0513	2	Bracket-Rod, Lift
7	114-5274	1	Pin-HOC
8	117-3611	1	Bar-Lift
10	3256-29	8	Washer-Flat
11	32151-103	7	Ring-Retaining, EXT
12	324-10	2	Screw-HH
13	3217-9	3	Nut-HH
14	117-0519	2	Link-Lift
15	3256-25	2	Washer-Flat
16	3296-48	2	Nut-Lock, NI
17	117-0506	2	Gas Spring ASM
17:2	88-6770	2	Stud-Ball
17:3	3296-47	2	Nut-Lock, NI
18	109-9840	4	Screw-Shoulder, HHF
19	117-3575	2	Cover-Spring
20	114-3512	1	HOC Handle ASM
21	3256-22	1	Washer-Flat
22	302-5	1	Fitting-Grease


Ref	Part No.	Qty.	Description
23	114-5305-03	1	Lever-HOC
24	1-633268	1	Grip-Lever, Brake
25	3231-24	1	Screw-CARR
26	32128-21	4	Nut-HF
27	111044	2	Spacer
28	3256-26	1	Washer-Flat
29	66-0561	1	Screw-Shoulder
30	65-9940	1	Spring
31	3231-22	1	Screw-CARR
32	3296-59	3	Nut-Lock, NI
33	114-5307	1	Bracket-HOC
34	3296-23	3	Nut-Lock, NI
35	323-7	1	Screw-HH
36	117-3645	1	Hub-Pivot
37	32151-47	1	Ring-Retaining
38	40-1940	4	Washer



Upper Control and Tower Assembly


Ref	Part No.	Qty.	Description
1	117-5757	1	Control Tower ASM
2	114-5194	1	LH Lever ASM
3	114-5195	1	RH Lever ASM
4	114-0260	1	Shaft-Pivot
5	114-1904	1	Shaft-Pivot, Motion Control
6	114-5302	1	Motion Control ASM
7	103-9928	6	Bearing
8	3234-4	3	Screw-HHF
9	114-0239	1	Screw-HSH
10	3296-47	1	Nut-Lock, NI
11	114-0268	1	Cam-Lever, Handle Stop
12	3256-22	1	Washer-Flat
13	3296-42	1	Nut-Lock, NI
14	114-0249	1	Spring-Extension
15	1-633181	1	Plate-Tapped
16	32105-13	2	Screw-HWH
17	117-0484	1	Plate-Control, Limiter
18	106-9962	1	Control-Choke, Push / Pull
19	110-5547	2	Control Lever ASM
20	1-603175	1	Knob-Ball
21	99-7981	1	Knob-Grip, Soft
22	114-0241	2	Grip-Lever
23	2411-38	2	Joint-Ball
24	3296-27	2	Nut-Lock, NI

Ref	Part No.	Qty.	Description
25	93-2279	2	Clamp-Cable
26	32144-70	6	Screw-HWHTF
27	114-1966	1	Cable-Control
28	114-1950	1	Cable-Speed
29	1-807533	6	Bolt-CARR
30	3290-148	6	Nut-HF
31	114-1921-01	1	Bar-Cable
32	114-0409	1	HOC Pin ASM
33	2412-87	1	Clamp-Cable
34	2412-120	2	R-Clamp
35	32144-1	2	Screw-Taptite
36	104-7048	1	Cap-Housing
37	104-7050	1	Tube-Manual
38	92-1624	4	Screw-HWH
39	3290-357	3	Nut-HHF, Whiz
40	3256-23	2	Washer-Flat
41	2412-138	1	R-Clamp
42	3296-39	1	Nut-Lock, NI



Control Tower Assembly No. 117-5757


Ref	Part No.	Qty.	Description				
21		1	Control Tower ASM				
1:2	117-0453	1	Decal-Panel, Control				
1:3	117-0454	1	Decal-Opc				
1:4	117-3626	1	Decal-Warning				
1:5	117-0456	1	Decal-HOC				
1:6	117-0485	1	Decal-Service Aid				
2	114-3598	1	Decal-Stability				



Lower Control Assembly

Ref	Part No.	Qty.	Description
1	114-5304-01	1	Mount-Linkage, Drive
2	114-1993	1	Lever-Switch
3	114-1999	1	Lever-Switch
4	114-1956	2	Control Fork ASM
5	114-1955	2	Hub-Shoulder
6	114-3547	2	Arm-Control
7	321-15	2	Screw-HH
8	3256-22	8	Washer-Flat
9	65-8270	1	Washer
10	114-5155-03	1	Arm-Switch, Stop
11	32128-14	2	Nut-Hex, Flange
12	114-5295	2	Rod-Link, Shifter
13	3290-307	6	Pin-Hair
14	322-4	4	Screw-HH
15	3296-29	4	Nut-Lock, NI
16	114-3534	4	Roller
17	114-1912-03	1	Bracket-Shifter
18	106-7297	1	Clamp-Cable
19	49-2040	1	Screw-HWHTF
20	32144-70	5	Screw-HWHTF
21	3256-23	2	Washer-Flat
22	106-2584	1	Spring-Torsion
23	114-1978	1	Pin-Hinge
24	114-5347	1	Arm-Dual, Shifter


Ref	Part No.	Qty.	Description
25	2411-38	2	Joint-Ball
26	3296-27	2	Nut-Lock, NI
27	114-0433	1	Clip-Spring
28	117-0474	2	Cable-Control, Traction
29	1-633181	1	Plate-Tapped
30	32105-13	2	Screw-HWH
31	3290-378	1	Tie-Cable
32	114-3576	2	Bushing-Guide, Drill



Hydraulic Assembly


Ref	Part No.	Qty.	Description
1	105-0800	2	Wheel Hub / Stud ASM
1:2	10-6830	4	Stud-Type, Drive
2	114-0549	2	Motor-Wheel
3	3257-8	2	Key-Woodruff
4	85-7310	2	Nut-Motor, Wheel
5	325-8	8	Screw-HH
6	117-3572-01	1	LH Motor Mount ASM
7	117-3571-01	1	RH Motor Mount ASM
8	114-5168-01	1	Mount-Motor, Center
9	114-5166-01	1	Base-Engine
10	3232-3	4	Screw-CARR
11	3296-48	4	Nut-Lock, NI
12	3256-25	4	Washer-Flat
13	117-3597	2	Pump-Hydraulic
15	3231-22	12	Screw-CARR
16	3290-357	17	Nut-HHF, Whiz
17	114-5345-01	2	Plate-Lift
18	92-1624	5	Screw-HWH
20	107-8433	1	HYD Reservoir ASM
20:1		1	Reservoir-HYD
20:1:1	103-1948	1	Cap-Reservoir, HYD
20:1:2	103-1949	1	Gasket-Cap
20:2	115-4212	1	Decal-Warning
21	321-4	4	Screw-HH

Ref	Part No.	Qty.	Description
22	32128-33	2	Nut-HF
23	104-7836	1	Head-Filter
24	1-633750	1	Filter-Oil, HYD
26	3256-22	2	Washer-Flat
27	340-89	4	Fitting-HYD, 45 DEG
27:1	237-30	1	O-Ring
27:2	237-80	1	O-Ring
28	340-101	4	Fitting-HYD, 45 DEG
28:1	237-30	1	O-Ring
28:2	237-79	1	O-Ring
29	100-4887	5	Fitting-Barb
29:1	237-42	1	O-Ring
30	103-1807	3	Elbow-45 DEG
30:1	237-42	1	O-Ring
32	103-1988	2	Clamp-Hose
33	117-0442	2	HYD Hose ASM
34	117-0449	2	HYD Hose ASM
36	117-0459	1	Hose-Hydraulic
37	117-3569	1	Filter Hose ASM
37:1	117-0460	1	Hose-Hydraulic
37:2	117-0458	2	Hose-Hydraulic
37:3	1-603721	2	Fitting-Tee, Hose
37:4	103-1988	6	Clamp-Hose
38	117-3570	1	Tank Hose ASM




Hydraulic Motor Assembly No. 114-0549

Ref	Part No.	Qty.	Description				
1	1-000119	1	Seal Kit				
21:1		1	Ring-Back Up				
21:2		1	Seal-Commutator				
21:3		1	Seal-Shaft (Viton)				
21:4		1	Washer-Back Up, Steel				
21:5		5	Ring-Seal (Viton)				
21:7		1	Seal-Dirt And Water				
2	3257-8	1	Key-Woodruff				
3	85-7310	1	Nut-Motor, Wheel				
4	106-5549	6	Bolt-Special				
5	106-8764	1	Shaft-Coupling				




Hydraulic Pump Assembly No. 117-3597

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	115-4464	1	Housing Kit	44	106-8760	1	Charge Relief Valve Kit
2	106-8752	1	End Cap Kit (W/Poppets)	49	114-8155	1	Trunnion Seal Kit
3	106-8753	2	Pin-Headless, Straight	56	106-8762	1	Plug-HSH
4	106-8754	4	Bolt-HF	66	106-8763	1	Plug-HSH
5	106-8755	1	O-Ring	98	117-3629	1	Kit-Return
6	106-8756	1	Charge Pump Kit	99	105-6184	1	Seal Overhaul Kit
7	104-2122	1	Gerotor ASM				
8	106-8757	1	O-Ring				
10	104-2111	2	Capscrew				
15	106-8759	1	Bypass Valve Kit				
18	103-2664	1	Input Shaft Kit				
19	104-5311	1	Bearing-Ball				
20	104-5310	1	Seal-Lip				
21	104-5308	1	Spacer				
22	104-5309	1	Ring-Retaining				
25	103-2666	1	Cylinder Block Kit				
29	94-1936	1	Spring-Block				
30	94-1937	1	Washer-Thrust, Block				
31	105-6185	1	Plate-Valve				
32	94-1907	1	Swashplate-Variable				
34	94-6922	1	Bearing-Thrust				
37	115-4458	1	Arm-Trunnion, Tapered Square				
38	94-1910	1	Guide-Slot				
42	98-3252	2	Valve-Check (W/Poppet)				




Hydraulic Belt Drive Assembly

Ref	Part No.	Qty.	Description				
1		1	Pump Idler Assembly				
1:1	117-3568	1	Hub-Idler				
1:2	1-413088	1	Bushing-Lever, Lift				
1:3	114-0463	2	Washer-Friction, Composite				
1:4	117-3622	1	Plate-Idler				
1:5	110-9981	1	Washer-Plain				
1:6	323-13	1	Screw-HH				
1:7	3296-39	2	Nut-Lock, NI				
1:8	3256-24	1	Washer-Flat				
1:9	93-1622	1	Pulley-Idler				
1:10	323-9	1	Screw-HH				
1:11	108-4056	1	Spring-Extension				
2	1-807272	2	Key				
3	3241-5	4	Screw-Set				
4	114567	1	Belt-V Lower PTO				
5	105-5648	2	Pulley-Pump				




Cushion Assembly No. 114-1917

Ref	Part No.	Qty.	Description				
1	114-0463	4	Washer-Friction, Composite				
2	114-1915-01	2	Link-Pad				
3	114-1918-03	2	Hinge-Pad				
4	114-1919	1	Shield-Rear				
5	114-5314	1	Cushion-Pad				
6	322-5	4	Screw-HH				
7	3231-2	2	Screw-CARR				
8	3256-23	4	Washer-Flat				
9	3256-4	8	Washer-Flat				
10	3296-59	4	Nut-Lock, NI				
11	111044	4	Spacer				
12	93-2891	2	Bushing-Plastic				
13	3290-355	2	Pin-Hair				
14	3231-27	2	Screw-CARR				




Platform Assembly No. 117-0431

Ref	Part No.	Qty.	Description				
1	114-1998-01	1	Platform ASM				
2	114-1925	2	Bumper-Rubber				
3	114-1926	2	Bumper-Rubber				
4	3296-47	4	Nut-Lock, NI				
5	111044	2	Spacer				
6	3256-4	4	Washer-Flat				
7	3231-25	2	Screw-CARR				
8	3296-59	2	Nut-Lock, NI				
9	1-603175	1	Knob-Ball				
10	114-5288	1	Pin-Latch				
11	114-5348	1	Spring				
12	114-1920-03	1	Clamp-Shield				
13	114-5349	1	Mat-Foot				
14	32144-70	2	Screw-HWHTF				
15	67-1300	1	Decal				



Parking Brake Assembly


Ref	Part No.	Qty.	Description				
1	114-5187-03	1	Brake ASM				
2	114-5186-01	2	Support-Brake				
3	1-633131	1	Yoke-Linkage, Brake				
4	114-5196	1	Rod-Brake				
5	3220-3	1	Nut-HJ				
6	283-2	1	Pin-Clevis				
7	3290-307	2	Pin-Hair				
8	614672	2	Bolt-Shoulder				
9	5-0652	2	Spacer				
10	3296-39	3	Nut-Lock, NI				
11	114-5258-03	1	Lever-Brake				
12	117-0452-03	1	Plate-Switch, Brake				
13	106-3214	1	Mount-Pulley				
14	63-7400	2	Washer-Rebound				
15	3231-44	1	Screw-CARR				
16	1-633268	1	Grip-Lever, Brake				
17	32105-13	2	Screw-HWH				
18	1-633181	1	Plate-Tapped				
19	114-0463	1	Washer-Friction, Composite				
20	3256-7	1	Washer-Flat				



Electrical Assembly


Ref	Part No.	Qty.	Description
1	114-3536	1	Harness-Wire
1:1	109103	1	Fuse-30 Amp
1:2	109102	1	Fuse-25 Amp
1:3	218-578	1	Fuse-10 Amp
1:4	116-0053	1	Cap-Plug
2	110-6764	1	Switch-Ignition
3	1-513152	3	Switch-Closed, Normally
4	114-0279	1	Switch-PTO
5	115-4180	1	Module-Meter, Hour
6	1-513075	1	Switch-Solenoid
7	3220-2	2	Nut-Jam
8	3253-4	2	Washer-Lock
9	104-2491	1	Battery
10	117-0543-01	1	Cover-Battery
11	1-633651	2	Bolt-Holddown
12	1-543792	2	Wingnut
13	114-9404	1	Cable-Battery, Positive
14	105-0836	1	Cable-Battery, Black
15	106-8268	1	Cable-Battery, Red
16	3256-23	2	Washer-Flat
17	109-5715	2	Nut-HHF, Smooth
18	322-3	2	Screw-HH
19	32144-4	2	Screw-HWH
20	68-3640	1	Decal

Ref	Part No.	Qty.	Description
21	3256-22	1	Washer-Flat
22	32128-33	1	Nut-HF
23	3290-378	1	Tie-Cable
24	63-8360	1	Key-Ignition




Fuel Tank Assembly

Ref	Part No.	Qty.	Description
1	117-9672	1	Tank ASM
1:1	1-643172	2	Elbow-90 DEG
1:2	95-8972	1	Grommet
1:3	46-6560	3	Bushing
1:4	109-9619	1	Cap-Fuel
1:5	114-1928	1	Fitting-Fuel, Screen Tube
1:7	99-7262	1	Gauge-Fuel
2	114-1952-01	1	Support-Tank
3	3231-2	1	Screw-CARR
4	3296-39	1	Nut-Lock, NI
5	109-0294	2	Hose-Fuel
6	71-9280	2	Filter-Fuel
7	2412-98	4	Clamp
8	1-603770	1	Valve-Fuel
9	109-3491	1	Hose-Fuel
10	109-0678	1	Hose-Fuel
11	112-7069	1	Grommet
12	3290-378	1	Tie-Cable



Engine Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	114-3590	1	Engine-Kawasaki, FH580V-Fs30	26	103-1966	1	Adapter
2	117-0430	1	Muffler-Engine	27	92-6877	1	Valve-Drain, Oil
3	112-7067	1	Pulley	28	112-7069	1	Grommet
4	608006	1	Key-Square	29	33094-00	1	Washer-Plain
5	105-2635	1	Clutch / Brake	30	2412-87	1	Clamp-Cable
6	107-4136	1	Washer	31	46-8090	1	Screw-Plastite
7	1-603610	1	Washer-Spring	99	103-1964	1	Hose-Drain, Oil
8	3212-9	1	Screw-HH				
9	3256-23	6	Washer-Flat				
10	322-7	5	Screw-HH				
11	1-613235	1	Washer				
12	1-633545	2	Spacer				
13	1-633630	2	Grommet-Brake				
14	1-633543-03	1	Strap-Clutch, Brake				
15	32128-20	8	Nut-HF				
16	109-3476-03	1	Bracket-Muffler, LH				
17	109-3477-03	1	Bracket-Muffler, RH				
18	322-3	2	Screw-HH				
19	3256-3	2	Washer-Flat				
20	33113-016	3	Screw-HH				
21	33114-016	2	Screw-HH				
22	3256-22	3	Washer-Flat				
24	322-11	1	Screw-HH				
25	104-6373	1	Tube-Retainer				




Cylinder and Crankcase Assembly

Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description
❶130	130AA0640	4	Bolt-Flanged (6X40)
❶130A	130CA0875	2	Bolt-Flanged (8X75)
❶172	172BA0818	4	Bolt-Stud (8X18)
❶11004	11004-7016	2	Gasket-Head
❶11008	11008-6043	1	Head-Cylinder, No. 1
❶11008A	11008-7020	1	Head-Cylinder, No. 2
❶11022	11022-7018	2	Case-Rocker
❶11060	11060-7001	2	Gasket-Case, Rocker
❶11060A	11060-7008	1	Gasket-Cover, Crankcase
❶11061	11061-7001	1	Gasket-Breather
❶13271	13271-7016	1	Plate
❶14091	14091-7006	1	Cover
❶49015	49015-6253	1	Cover-Crankcase
❶49109	49109-7002	1	Element-Breather
❶49120	49120-7113	1	Crankcase
❶59071	59071-2079	1	Joint
❶92033	92033-7003	2	Ring-Snap
❶92043	92043-7001	6	Pin
❶92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)
❶92049A	92049-7015	1	Seal-Oil, S D (35X62X8 L HSH)
❶92049B	92049-7016	1	Seal-Oil, S D (35X48X8 R HSH)
❶92049C	92049-7019	1	Seal-Oil, S O (8X14X5 HSH)
❶92066	92066-7026	1	Plug
❶92153	92153-7043	4	Bolt (6X12)

Ref	Part No.	Qty.	Description
❶92153A	92153-7054	17	Bolt (8X50)




Piston and Crankshaft Assembly Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
③13001	13001-7010	2	Piston-Engine				
③13002	13002-7001	2	Pin-Piston				
③13008	13008-6060	2	Piston Ring Set				
③13031	13031-7073	1	Crankshaft				
③13251	13251-7010	2	Connecting Rod ASM				
③92033	92033-7002	4	Ring-Snap				
③92151	92151-7017	4	Bolt (6X35)				




Valve and Camshaft Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
❶12004	12004-7003	2	Valve-Intake				
❶12005	12005-7003	2	Valve-Exhaust				
❶12009	12009-7001	4	Retainer-Spring, Valve				
❶12011	12011-2056	8	Collet				
❶12016	12016-7008	4	Arm-Rocker				
❶12032	12032-7001	4	Tappet				
❶13070	13070-7001	2	Guide				
❶13070A	13070-7004	1	Guide				
❶13116	13116-2057	4	Rod-Push				
❶13271	13271-7007	1	Plate				
❶13271A	13271-7021	1	Plate-Governor				
❶42036	42036-7010	1	Sleeve				
❶49078	49078-7001	4	Spring-Valve, Engine				
❶49118	49118-7004	1	Camshaft				
❶92009	92009-2341	4	Screw				
❶92015	92015-2253	4	Nut				
❶92033	92033-7001	2	Ring-Snap				
❶92140	92140-7005	6	Ball				
❶92145	92145-7001	1	Spring				
❶92153	92153-7019	4	Bolt				
❶92200	92200-7001	1	Washer				



Lubrication Equipment Assembly
Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
③670	670D2016	3	O-Ring (16Mm)				
③13107	13107-7009	1	Shaft				
③13271	13271-7017	1	Plate				
③14075	14075-7009	1	Cap ASM				
③16154	16154-2053	1	Rotor-Pump (In)				
③16154A	16154-2054	1	Rotor-Pump (Out)				
③49065	49065-2078	1	Filter-Oil (Part Can Be Used As Substitute On Product And Is Supplied Until Stock Exhausted)				
③49065A	49065-7004	1	Filter-Oil				
③49065B	49065-7010	1	Filter-Oil				
③59051	59051-7011	1	Gear-Spur				
③59231	59231-7005	1	Filler				
③92043	92043-7003	2	Pin				
③92066	92066-7003	2	Plug				
③92140	92140-7003	1	Ball				
③92145	92145-7002	1	Spring				
③92153	92153-7043	3	Bolt (6X12)				



Cooling Equipment Assembly


Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
❶ 130	130AA0616	2	Bolt-Flanged (6X16)				
❶ 130A	130AA0625	2	Bolt-Flanged (6X25)				
❶ 130B	130AA0816	1	Bolt-Flanged (8X16)				
❶ 311	311AA0600	2	Nut-Hex (6Mm)				
❶ 13270	13270-7007	1	Plate				
❶ 14037	14037-7020-9H	1	Screen				
❶ 23062	23062-7010	1	Bracket				
❶ 49089	49089-7032	1	Shroud-Engine				
❶ 49089A	49089-7042	1	Shroud-Engine				
❶ 49089B	49089-7043	1	Shroud-Engine				
❶ 55020	55020-7004	1	Guard				
❶ 59041	59041-7012	1	Fan				
❶ 59066	59066-7037	1	Housing-Fan				
❶ 92004	92004-7006	2	Stud				
❶ 92026	92026-7007	1	Spacer				
❶ 92151	92151-7012	3	Bolt (6X12)				
❶ 92153	92153-7007	3	Bolt				
❶ 92153A	92153-7008	1	Bolt				
❶ 92153B	92153-7043	2	Bolt (6X12)				
❶ 92210	92210-0003	4	Nut				



Electric Equipment Assembly Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
③130	130AA0620	2	Bolt-Flanged (6X20)				
③311	311AA0600	2	Nut-Hex (6Mm)				
③510	510A5100	1	Key-Woodruff				
③21066	21066-7011	1	Regulator-Voltage				
③21171	21171-7034	2	Ignition Coil ASM				
③21193	21193-7032	1	Flywheel ASM				
③26030	26030-7001	1	Harness				
③26031	26031-7012	1	Harness				
③27010	27010-7001	1	Switch				
③59031A	59031-7014	1	Coil-Charging				
③92004	92004-7009	2	Stud				
③92009	92009-2308	1	Screw				
③92070	92070-7003	2	Spark Plug (R C J 8 Y, Solid)				
③92072	92072-7003	3	Band				
③92151	92151-2097	1	Bolt (12X30)				
③92172	92172-7018	4	Screw (5X20)				
③92200	92200-7002	1	Washer				



Control Equipment Assembly

Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
❶214	214AA0408	2	Screw-Pan +- (4X8)				
❸311	311AA0600	1	Nut-Hex (6Mm)				
❹411	411AA0600	1	Washer-Plain (6Mm)				
❶13107	13107-7010	1	Shaft				
❶13271	13271-7032	1	Plate				
❶16169	16169-7010	1	Link-Choke				
❶16171	16171-7001	1	Link				
❶39129	39129-7003	1	Spring-Governor				
❶49103	49103-7004	1	Arm-Governor				
❶49113A	49113-7052	1	Panel-Comp-Control				
❶92009	92009-7007	1	Screw (4X35)				
❶92145	92145-7003	1	Spring				
❶92145A	92145-7004	1	Spring				
❶92145B	92145-7005	1	Spring				
❶92150	92150-2182	2	Bolt (5X18)				
❶92153	92153-7033	1	Bolt (6X35)				
❶92153A	92153-7043	2	Bolt (6X12)				
❶92170	92170-7001	2	Clamp				



Carburetor Assembly Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
①130	130AA0635	4	Bolt-Flanged (6X35)
①172	172BA0690	2	Bolt-Stud (6X90)
①214	214AA0510	1	Screw-Pan +- (5X10)
①11061	11061-7004	2	Gasket-Insulator
①11061A	11061-7009	1	Gasket-Chamber
①11061B	11061-7010	1	Gasket-Screw
①11061C	11061-7018	1	Gasket-Cleaner, Air
①11061D	11061-7019	2	Gasket
①13107	13107-7018	1	Shaft
①15004	15004-7060	1	Carburetor ASM
①16014	16014-7005	1	Screw-Air, Pilot
①16020	16020-7003	1	Chamber-Float
①16025	16025-7006	1	Valve-Throttle
①16030	16030-7003	1	Valve-Float
①16031	16031-7002	1	Float
①16041	16041-7016	1	Shaft-Choke, Carburetor
①16041A	16041-7018	1	Shaft-Throttle, Carburetor
①16073	16073-7007	1	Insulator
①16186	16186-7001	1	Choke Valve ASM
①21188	21188-7002	1	Solenoid
①39076	39076-7001	1	Limiter
①49121A	49121-7016	1	Nozzle-Main
①59076A	59076-7017	1	Manifold-Intake
①92009	92009-2083	2	Screw


Ref	Part No.	Qty.	Description
①92009A	92009-2349	1	Screw
①92063C	92063-7066	1	Jet-Main, No. 108
①92063D	92063-7090	1	Jet-Main, No.106 (2380Ft)
①92063E	92063-7091	1	Jet-Main, No.104 (6560Ft)
①92081	92081-2234	1	Spring
①92093	92093-2100	1	Seal
①92093A	92093-7003	1	Seal
①92145	92145-7015	1	Spring



Air Filter and Muffler Assembly


Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
③ 461	461DA0800	4	Washer-Spring (8Mm)				
③ 11011	11011-7046	1	Case-Filter, Air				
③ 11013	11013-7025	1	Element-Filter, Air				
③ 11013A	11013-7031	1	Element-Filter, Air				
③ 11060	11060-7021	2	Gasket-Muffler				
③ 16060	16060-7016	1	Pipe-Intake				
③ 92015A	92015-1367	2	Nut				
③ 92055	92055-7015	1	O-Ring				
③ 92192	92192-7010	1	Tube				
③ 92210	92210-7004	2	Nut (M6)				
③ 92210A	92210-7019	1	Nut				
③ 92210B	92210-7027	4	Nut (M8)				



Fuel Tank and Valve Assembly Kawasaki FH580V-FS30


Ref	Part No.	Qty.	Description				
③130	130AA0620	2	Bolt-Flanged (6X20)				
③23062	23062-7019-9H	1	Bracket				
③42036	42036-7012	1	Sleeve				
③49019	49019-7001	1	Filter-Fuel				
③49040	49040-7001	1	Pump-Fuel				
③92170	92170-2009	4	Clamp				
③92191	92191-7002	1	Tube				
③92192	92192-7135	1	Tube (6.35X12.7X160)				
③92192A	92192-7136	1	Tube (6.35X12.7X180)				



Starter Assembly
Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description				
❶ 130	130AA0814	2	Bolt-Flanged (8X14)				
❶ 13101	13101-7010	1	Gear ASM				
❶ 16146	16146-7013	1	Cover ASM				
❶ 21039	21039-7002	1	Brush				
❶ 21080	21080-7007	1	Armature				
❶ 21163	21163-7031	1	Starter-Electric				
❶ 39184	39184-7009	1	Bracket ASM				
❶ 92153	92153-7034	2	Bolt				
❶ 92200	92200-7023	1	Washer				
❶ 92200A	92200-7024	1	Washer				
❶ 92210	92210-7037	2	Nut				

56033



56070



56080



Label Assembly

Kawasaki FH580V-FS30

Ref	Part No.	Qty.	Description
56033	56033-7001	1	Label-Manual
56070	56070-7001	1	Label-Warning
56080	56080-7055	1	Label-Brand

Attachments and Accessories

For 74567TE - GrandStand Mower, With 122cm TURBO FORCE Cutting Unit

Product Name	Model/Part
Blade-Hi Flow, 16.5 Inch (6 Pack)	110-0414
Blade-Lo Flow, 16.5 Inch (6 Pack)	110-0415
Blade-Recycler, 16.5 Inch (6 Pack)	110-0416
Blade-Atomic, 16.5 Inch (6 Pack)	110-0417
Blade-Mid Flow, 16.5 Inch (6 Pack)	110-0418
Light Kit	114-3505
Trash Bag Kit	117-0448
Recycler Kit	117-0540
Operator-Controlled Discharge Chute Kit	117-3600
Weight Kit	117-3620

NOTES

