




MODEL NO. 20441-5900001 & UP
MODEL NO. 20443-5900001 & UP

PARTS CATALOG

21" RECYCLER®
Mower




C-2288

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	16-9269	Cover - Recycling (Incl. Ref. #4)	1
2	93-0242	Grommet	4
3	32144-4	Screw - Tapping	4
4	85-7060	Decal - Danger	1
5	93-0236	Bracket - Handle R.H.	1
6	93-0262	Decal - Warning	1
7	93-0248	Decal - Warning	1
8	92-2915	Decal - HOC L.H.	1
9	92-2914	Decal - HOC R.H.	1
10	93-0235	Bracket - Handle L.H.	1
11	92-1005	Spring Arm Assembly	2
12	92-9592	Wheel Assembly	2
13	614650	Bolt - Shoulder	4
14	92-8647	Shield - Trailing	1
15	40-1940	Washer	4

Ref. No.	Part No.	Description	No. Used
16	92-1008	Knob - Height Adjust	4
17	614687	Spring Arm Assembly	2
18	614672	Bolt - Shoulder	4
19	92-9591	Wheel Assembly	2
20	614637	Bracket - Wheel Height Adj.	4
21	92-4890	Washer	4
22	3296-39	Nut - Lock	4
23	93-0231	Screw - Plastite	2
24	93-0222	Baffle - Front	1
25	93-0216	Kicker - Front	1
26	92-4881	Plate - Height Adjust	2
27	16-9259	Deck Assembly (Incl. Ref. #6 & 7 pg. 1) (Incl. Ref. #14 pg. 2)	1
28	3296-2	Nut - Lock	1
29	32105-27	Screw - Hex Washer Hd.	1




C-2289

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-6396	Shroud - Engine (Model No. 20441 Only)	1
2	93-4302	Screw - Sems (Model No. 20441 Only)	3
3	93-0246	Decal - Engine (Model No. 20441 Only)	1
4	93-1200	Cover - Strap (Model No. 20441 Only)	1
5	92-1701	Rope - Stop (Model No. 20441 Only)	1
6	55-3578	Gas Cap Assembly (Model No. 20441 Only)	1

Ref. No.	Part No.	Description	No. Used
7	32104-118	Screw - Phillips Hd. (Model No. 20441 Only)	2
8	68-3632	Line - Fuel (Model No. 20441 Only)	1
9		Engine (Model No. 20441 Only)	1
12	52-7320	Retainer - Blade (Model No. 20441 Only)	1
13	93-0245	Decal - Deck	1
14	39-5770	Decal - Danger	1
15	66-5370	Spring - Compression (Model No. 20441 Only)	1




C-2244

SHROUD & BLOCK ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used
1	614699	Screw	3
2	93-1231	Cover - Air Filter	1
3	609493	Element - Air Filter	1
4	93-4320	Plug	1
5	44-3175	Hose - Primer	1
6	93-1227	Shield - Carburetor	1
7	92-4948	Gasket - Carburetor	2
9	609482	Screw	2
10	92-9695	Carburetor Assembly	1
12	93-1215	Short Block Assembly	1
13	607199	Key	1

Ref. No.	Part No.	Description	No. Used
14	614702	Screw	4
15	93-1216	Base - Shroud	1
16	684743	Flywheel Assembly	1
17	614640	Hub - Starter	1
18	316959	Washer - Lock	1
19	130743	Nut	1
20	93-1248	Shroud	1
21	44-2750	Body - Primer	1
22	66-7460	Bulb - Primer	1
23	93-4304	Rope	1




C-1899

BRAKE & MUFFLER ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used
1	3290-459	Rivet	2
2	60-9010	Strap - Ground	1
3	92-2925	Strap - Insulation	1
4	12-5450	Screw - Thread Forming	1
5	53-4690	Stop - Ground Strap	1
6	92-1156	Wire - Brake Switch Lead	1
7	614654	Plate - Muffler	1
8	607601	Screw	4
9	93-1217	Baffle	1
10	609471	Screw	3
11	93-1108	Cover - Muffler	1

Ref. No.	Part No.	Description	No. Used
12	93-1233	Gasket - Exhaust	1
13	614009	Plug - Spark	1
14	684049	Ignition Assembly (Incl. Ref. #20)	1
15	84-7820	Plate - Brake Mount	1
16	613208	Screw - Hex Washer Hd.	2
17	614702	Screw	1
18	66-5380	Plate - Brake Assembly	1
19	92-9698	Screw - Shoulder	1
20	681678	Lead & Cover Assembly	1
21	66-5370	Spring - Compression	1




C-2292

BLOCK ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	681737	Set – Rings, Piston	1	12	683911	Bearing – Needle	1
3	92-4923	Piston & Ring Set	1	13	611393	Screw – Hex. Hd.	2
*	92-4925	Piston & Connecting Rod (Incl. Ref. #1, 3-7 & 13)	1	14	614636	Screw – Hex. Washer Hd.	3
4	606608	Pin – Wrist	1	15	93-4311	Cylinder & Crankcase Cover (Incl. Ref. #14, 16, 17, 18, 20, & 21)	1
5	303712	Ring – Retaining	2	16	602588	Reed – Carburetor	1
6	92-4921	Connecting Rod Assembly (Incl. Ref. #8, 12 & 13)	1	17	602587	Reed – Backup Plate	1
7	92-4927	Bearing	1	18	612872	Screw	2
8	677982	Liner – Split (Set of 2)	1	19	681831	Bearing – Needle	1
9	92-6379	Crankshaft	1	20	609629	Dowel	1
10	681830	Bearing – Upper Main	1	21	609123	Plug – Core	4
11	611396	Seal – Oil	2				

*Not Illustrated




C-2130B

CARBURETOR ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6376	Air Vane & Shaft	1	13	602850	Gasket	1
2	610165	Retainer - Speed Control	1	14	92-6371	Nozzle	1
3	93-1225	Lever - Speed Adjust	1	15	611071	Filter - Fuel	1
4	610834	Collar - Air Vane	1	16	678113	Float & Arm Assembly	1
5	92-4944	Spring - Governor	1	17	92-6389	Pin	1
6	92-6373	Disc - Throttle	1	18	92-9691	Float Chamber	1
7	92-4949	Bracket - Throttle Control	1	19	608850	Screw	4
8	613269	Screw	2	20	612383	Washer	1
9	92-6377	Carburetor Body	1	21	92-6370	Main Jet	1
10	92-9697	Kit - Float Valve, Body & Seat (Incl. Ref. #12)	1	22	93-4320	Shield - Fuel	1
12	603145	Spring	1	*	92-6385	Jet - High Altitude	1
				*	92-9695	Carburetor Assembly	1


*Not Illustrated



C-2290

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	32144-111	Screw - Phillips Pan Hd.	2	11	32144-73	Screw - Hex Washer Hd., Thread Forming (Model No. 20443 Only)	3
2	93-8470	Screw - Clamp (P/W Eng.) (Model No. 20443 Only)	1	12	322-3	Screw - Hex Hd. Cap	4
3	2210-249	Clamp - Casing (P/W Eng.) (Model No. 20443 Only)	1	13	3296-29	Nut - Lock	4
4		Engine - Quantum 4HP (Model No. 20443 Only)	1	14	93-0217	Kicker - Rear	1
5	93-0243	Shroud - Qt Wedge (Model No. 20443 Only)	1	15	93-0223	Baffle - Rear	1
6	2210-316	Stop - Rope (P/W Eng.) (Model No. 20443 Only)	1	16	62-7540	Retainer - Blade (Model No. 20443 Only)	1
7	93-0247	Decal - Engine (Model No. 20443 Only)	1	17	93-0241	Blade - Steel Deck	1
8	32144-121	Screw (Model No. 20443 Only)	2	18	93-0219	Accelerator	1
9	92-2289	Plate - Logo	1	19	3253-22	Washer - Lock	1
10	82-8550	Shield - Muffler (Model No. 20443 Only)	1	20	26-0670	Bolt - Blade	1
				21	93-0218	Kicker - Side	1
				22	92-1624	Screw - Engine	3




C-2291

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296-73	Nut - Lock	2
2	93-7383	Guide - Rope	1
3	321-51	Screw - Hex Hd. Cap	1
4	612825	Handle - Starter (Model No. 20441 Only)	1
5	612824	Clip - Rope Insert (Model No. 20441 Only)	1
6	93-0237	Handle - Upper	1
7	92-3134	Bar - Control	1
8	92-5412	Stop - Pivot	1
9	93-0253	Cable - Brake (Model No. 20443 Only)	1
10	93-0257	Cable - Brake (Model No. 20441 Only)	1

Ref. No.	Part No.	Description	No. Used
11	93-0252	Cable - Throttle (Model No. 20443 Only)	1
12	93-0256	Cable - Throttle (Model No. 20441 Only)	1
13	92-2269	Screw - Handle	1
14	92-2260	Screw - Handle	2
15	19-4050	Knob	2
16	93-0238	Handle - Lower	1
17	3290-378	Tie - Cable (Model No. 20443 Only)	1
17	3290-378	Tie - Cable (Model No. 20441 Only)	2



★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

1058 OWNER'S MANUAL


Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
1	493260	Cylinder Assembly	1
2	293708	Bushing - Cylinder	1
★3	299819	Seal - Oil	1
5	214349	Head - Cylinder	1
★7	272916	Gasket - Cylinder Head	1
8	495786	Breather - Valve Chamber	1
★9	272481	Gasket - Valve Cover	1
★9A	272238	Gasket - Baffle Plate	1
10	94650	Screw - Breather Mtg.	1
11	231933	Tube - Breather	1
13	94547	Screw - Cylinder Head	1
★52	272199	Gasket - Intake Elbow	1
54	94526	Screw - Intake Elbow Mounting	1
227	492349	Lever Assembly - Gov.	1
230	67072	Washer - Gov. Crank	1
284	94511	Screw - Hex. Head	1
306	224324	Shield - Cylinder	1
307	94515	Screw - Hex. Head	1
337	802592	Plug - Spark	1
383	89838	Wrench - Spark Plug	1

Ref. No.	Part No.	Description	No. Used
523	495264	Cap With Dipstick - Oil Filler	1
★524	280393	Seal - Filler Tube	1
525	495265	Tube - Oil Filler	1
562	92613	Bolt - Governor Lever	1
572	224328	Baffle - Cylinder	1
592	231082	Nut - Hex.	1
615	94474	Fastener	1
616	262578	Crank - Governor	1
625	281085	Tube - Fuel Intake	1
635	66538	Elbow - Spark Plug	1
★842	280966	Seal - O-Ring	1
847	495263	Oil Fill Tube Assy.	1
869	213512	Seat - Intake Valve	1
870	213513	Seat - Exhaust Valve	1
871	262001	Guide - Exhaust Valve	1
1019	494256	Label Kit	1
1058	272262	Owner's Manual	1

★ Included in Gasket Set - Part No. 496117.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
★12	272198	Gasket – Crankcase	1
15	94720	Plug – Oil Drain	1
16	494546	Crankshaft	1
		Note: Order 94388 For Timing Gear Key.	
18	493279	Sump – Engine	1
★20	399781	Seal – Oil	1
22	94220	Screw – Hex. Head	1
		Note: 94612 Screw – Hex. Head (One (1) Used in Hole Nearest Breather.)	
24	222698	Key – Flywheel	1
25	493262	Piston Assy. (Standard)	1
	493385	Piston Assy. (.010" O.S.)	1
	493386	Piston Assy. (.020" O.S.)	1
	493387	Piston Assy. (.030" O.S.)	1
26	493261	Ring Set (Standard)	1
	493388	Ring Set (.010" O.S.)	1
	493389	Ring Set (.020" O.S.)	1
	493390	Ring Set (.030" O.S.)	1

Ref. No.	Part No.	Description	No. Used
27	26026	Lock – Piston Pin	1
28	298909	Pin – Piston (Standard)	1
	298908	Pin – Piston (.005" O.S.)	1
29	490566	Rod Assembly – Conn.	1
		Note: For Conn. Rod With .020" Undersize Crankpin Bearing – Order No. 490743.	
32	94699	Screw – Conn. Rod	1
33	262651	Valve – Exhaust	1
34	262652	Valve – Intake	1
35	262224	Spring – Valve	1
40	93312	Retainer – Valve Spring	1
45	262204	Tappet – Valve	1
46	492828	Gear – Cam	1
47	493737	Slinger – Oil	1
741	262598	Gear – Timing	1

★ Included in Gasket Set – Part No. 496117.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
95	94098	Screw – Throttle Valve Mounting	1
●104	231371	Pin – Float Hinge	1
●◆116		Gasket – Sealing (Sold in Kit Only).	1
124	94525	Screw – Carburetor Mtg.	1
125	497314	Carburetor	1
●127		Plug – Welch (Sold in Kit Only).	1
130	224908	Valve – Throttle	1
131	493267	Shaft – Throttle	1
133	398187	Float Assy. – Carburetor	1

Ref. No.	Part No.	Description	No. Used
●134	398188	Valve – Inlet (Includes Seat)	1
●◆137		Gasket – Bowl (Sold in Kit Only).	1
●◆617	270344	Seal – Fuel Intake Tube	1
●◆634		Washer – Shaft (Sold in Kit Only).	1
955	497315	Screw – Bowl Mtg. (Std.)	1
		Note: 496495 Screw – Bowl Mtg. (High Altitude)	1
975	493640	Bowl Assy. – Carburetor	1

● Included in Carburetor Kit – Part No. 493762.
 ◆ Included in Carburetor Gasket Set – Part No. 490937.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
188A	94644	Screw - Hex. Head	1
188B	94602	Screw - Hex. Head	1
201	262579	Link - Governor	1
209	262661	Spring - Governor	1
618	262749	Spring - Return	1

Ref. No.	Part No.	Description	No. Used
620	497203	Bracket - Carburetor	1
620A	225152	Bracket - Control	1
621	396847	Switch - Stop	1
670A	493823	Spacer - Bracket	1




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
163	272653	Gasket – Air Cleaner	1
529	281299	Grommet – Breather	1
606	224815	Strap – Bracket	1
966	496116	Base – Air Cleaner	1
967	491588	Filter – Air	1

Ref. No.	Part No.	Description	No. Used
968	281340	Cover – Air Cleaner	1
969	94120	Screw – Cover Mtg.	1
971	94121	Screw – Air Cleaner	1
971A	94749	Screw – Hex. Head	1

★ Included in Gasket Set – Part No. 496117.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
55	492831	Housing – Rewind Starter	1
56	493824	Pulley – Rewind Starter	1
57	262594	Spring – Rewind Starter	1
58	280399	Rope – Rewind Starter	1
59	396892	Insert – Handle	1
60	393152	Handle – Rewind Starter	1
69	280973	Washer – Rewind Starter	1
69A	224322	Washer – Rewind Starter	1
456	224321	Retainer – Rewind Starter	1

Ref. No.	Part No.	Description	No. Used
459	492833	Pawl – Starter	1
461	262626	Pin – Starter	1
515	262625	Spring – Torsion	1
608	493295	Starter Assy. – Rewind	1
		Includes:	
		94128 Screw – Hex. Hd.	1
		92987 Nut – Hex.	1
1016	224278	Cover – Rewind Starter	1







Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
23	492177	Flywheel	1
37	224511	Guard - Flywheel	1
38	94786	Screw - Hex. Head	1
304	493294	Housing - Blower	1
305	94786	Screw - Sem	1
332	92284	Nut - Flywheel	1

Ref. No.	Part No.	Description	No. Used
333	802574	Armature - Magneto	1
334	94731	Screw - Sem	1
356	398808	Wire - Ground	1
363	19069	Puller - Flywheel	1
455	224250	Cup - Starter	1
851	493880	Terminal - Ignition Cable	1






Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
81	223664	Lock – Muffer Screw	1
187	492790	Hose – Fuel	1
188	398540	Screw – Tank Mounting	1
284	94511	Screw – Hex. Head	1
300	490547	Muffer – Exhaust	1
346	93705	Screw – Hex. Head	1
601	93807	Clamp – Hose	1

Ref. No.	Part No.	Description	No. Used
613	94231	Screw – Muffer Mtg.	1
670	280512	Spacer – Fuel Tank	1
676	493871	Deflector – Muffer	1
★883	272253	Gasket – Exhaust	1
957	397974	Cap Assy. – Fuel	1
972	495224	Tank Assembly – Fuel	1



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
★3	299819	Seal – Oil	1
★7	272916	Gasket – Cylinder Hd.	1
★9	272481	Gasket – Valve Cover	1
★9A	272238	Gasket – Baffle Plate	1
★12	272198	Gasket – Crankcase	1
★20	399781	Seal – Oil	1
★52	272199	Gasket – Intake Elbow	1
●104	231371	Pin – Float Hinge	1
●◆116		Gasket – Sealing (Sold in Kit Only).	1
121	493762	Carburetor Kit	1
●127		Plug – Welch (Sold in Kit Only).	1

Ref. No.	Part No.	Description	No. Used
●134	398188	Valve – Inlet (Includes Seat)	1
●◆137		Gasket – Bowl (Sold in Kit Only).	1
★163	272653	Gasket – Air Cleaner	1
358	497316	Gasket Set	1
★524	280393	Seal – Filler Tube	1
●◆617	270344	Seal – Fuel Intake Tube	1
●◆634		Washer – Shaft (Sold in Kit Only).	1
★842	280966	Seal – O-Ring	1
★883	272253	Gasket – Exhaust	1
977	490937	Gasket Set – Carburetor	1

- Included in Carburetor Kit – Part No. 493762.
- ◆ Included in Carburetor Gasket Set – Part No. 490937.

★ Included in Gasket Set – Part No. 496117.

TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
	Engine	2 9 1	66-5370	Spring - Compression	4 21 1
	Engine - Quantum 4HP	7 4 1	66-5380	Plate - Brake Assembly	4 18 1
130743	Nut	3 19 1	66-7460	Bulb - Primer	3 22 1
303712	Ring - Retaining	5 5 2	68-3632	Line - Fuel	2 8 1
316959	Washer - Lock	3 18 1	82-8550	Shield - Muffler	7 10 1
602587	Reed - Backup Plate	5 17 1	84-7820	Plate - Brake Mount	4 15 1
602588	Reed - Carburetor	5 16 1	85-7060	Decal - Danger	1 4 1
602850	Gasket	6 13 1	92-1005	Spring Arm Assembly	1 11 2
603145	Spring	6 12 1	92-1008	Knob - Height Adjust	1 16 4
606608	Pin - Wrist	5 4 1	92-1156	Wire - Brake Switch Lead	4 6 1
607199	Key	3 13 1	92-1624	Screw - Engine	7 22 3
607601	Screw	4 8 4	92-1701	Rope - Stop	2 5 1
608850	Screw	6 19 4	92-2260	Screw - Handle	8 14 2
609123	Plug - Core	5 21 4	92-2269	Screw - Handle	8 13 1
609471	Screw	4 10 3	92-2289	Plate - Logo	7 9 1
609482	Screw	3 9 2	92-2914	Decal - HOC R.H.	1 9 1
609493	Element - Air Filter	3 3 1	92-2915	Decal - HOC L.H.	1 8 1
609629	Dowel	5 20 1	92-2925	Strap - Insulation	4 3 1
610165	Retainer - Speed Control	6 2 1	92-3134	Bar - Control	8 7 1
610834	Collar - Air Vane	6 4 1	92-4881	Plate - Height Adjust	1 26 2
611071	Filter - Fuel	6 15 1	92-4890	Washer	1 21 4
611393	Screw - Hex. Hd.	5 13 2	92-4921	Connecting Rod Assembly	5 6 1
611396	Seal - Oil	5 11 2	92-4923	Piston & Ring Set	5 3 1
612383	Washer	6 20 1	92-4925	Piston & Connecting Rod	5 * 1
612824	Clip - Rope Insert	8 5 1	92-4927	Bearing	5 7 1
612825	Handle - Starter	8 4 1	92-4944	Spring - Governor	6 5 1
612872	Screw	5 18 2	92-4948	Gasket - Carburetor	3 7 2
613208	Screw - Hex Washer Hd.	4 16 2	92-4949	Bracket - Throttle Control	6 7 1
613269	Screw	6 8 2	92-5412	Stop - Pivot	8 8 1
614009	Plug - Spark	4 13 1	92-6370	Main Jet	6 21 1
614636	Screw - Hex. Washer Hd.	5 14 3	92-6371	Nozzle	6 14 1
614637	Bracket - Wheel Height Adj.	1 20 4	92-6373	Disc - Throttle	6 6 1
614640	Hub - Starter	3 17 1	92-6376	Air Vane & Shaft	6 1 1
614650	Bolt - Shoulder	1 13 4	92-6377	Carburetor Body	6 9 1
614654	Plate - Muffler	4 7 1	92-6379	Crankshaft	5 9 1
614672	Bolt - Shoulder	1 18 4	92-6385	Jet - High Altitude	6 * 1
614687	Spring Arm Assembly	1 17 2	92-6389	Pin	6 17 1
614699	Screw	3 1 3	92-6396	Shroud - Engine	2 1 1
614702	Screw	3 14 4	92-8647	Shield - Trailing	1 14 1
614702	Screw	4 17 1	92-9591	Wheel Assembly	1 19 2
677982	Liner - Split (Set of 2)	5 8 1	92-9592	Wheel Assembly	1 12 2
678113	Float & Arm Assembly	6 16 1	92-9691	Float Chamber	6 18 1
681678	Lead & Cover Assembly	4 20 1	92-9695	Carburetor Assembly	6 * 1
681737	Set - Rings, Piston	5 1 1	92-9695	Carburetor Assembly	3 10 1
681830	Bearing - Upper Main	5 10 1	92-9697	Kit - Float Valve, Body	6 10 1
681831	Bearing - Needle	5 19 1	92-9698	Screw - Shoulder	4 19 1
683911	Bearing - Needle	5 12 1	93-0216	Kicker - Front	1 25 1
684049	Ignition Assembly	4 14 1	93-0217	Kicker - Rear	7 14 1
684743	Flywheel Assembly	3 16 1	93-0218	Kicker - Side	7 21 1
12-5450	Screw - Thread Forming	4 4 1	93-0219	Accelerator	7 18 1
16-9259	Deck Assembly	1 27 1	93-0222	Baffle - Front	1 24 1
16-9269	Cover - Recycling	1 1 1	93-0223	Baffle - Rear	7 15 1
19-4050	Knob	8 15 2	93-0231	Screw - Plastite	1 23 2
26-0670	Bolt - Blade	7 20 1	93-0235	Bracket - Handle L.H.	1 10 1
39-5770	Decal - Danger	2 14 1	93-0236	Bracket - Handle R.H.	1 5 1
40-1940	Washer	1 15 4	93-0237	Handle - Upper	8 6 1
44-2750	Body - Primer	3 21 1	93-0238	Handle - Lower	8 16 1
44-3175	Hose - Primer	3 5 1	93-0241	Blade - Steel Deck	7 17 1
52-7320	Retainer - Blade	2 12 1	93-0242	Grommet	1 2 4
53-4690	Stop - Ground Strap	4 5 1	93-0243	Shroud - Qt Wedge	7 5 1
55-3578	Gas Cap Assembly	2 6 1	93-0245	Decal - Deck	2 13 1
60-9010	Strap - Ground	4 2 1	93-0246	Decal - Engine	2 3 1
62-7540	Retainer - Blade	7 16 1	93-0247	Decal - Engine	7 7 1
66-5370	Spring - Compression	2 15 1	93-0248	Decal - Warning	1 7 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3317-152A

Part No.	Description	Pg. Ref.		Part No.	Description	Pg. Ref.	
		No.	Qty.			No.	Qty.
93-0252	Cable - Throttle	8	11	2210-316	Stop - Rope (P/W Eng.)	7	6
93-0253	Cable - Brake	8	9	321-51	Screw - Hex Hd. Cap	8	3
93-0256	Cable - Throttle	8	12	322-3	Screw - Hex Hd. Cap	7	12
93-0257	Cable - Brake	8	10	3253-22	Washer - Lock	7	19
93-0262	Decal - Warning	1	6	3290-378	Tie - Cable	8	17
93-1108	Cover - Muffler	4	11	3290-378	Tie - Cable	8	17
93-1200	Cover - Strap	2	4	3290-459	Rivet	4	1
93-1215	Short Block Assembly	3	12	3296-2	Nut - Lock	1	28
93-1216	Base - Shroud	3	15	3296-29	Nut - Lock	7	13
93-1217	Baffle	4	9	3296-39	Nut - Lock	1	22
93-1225	Lever - Speed Adjust	6	3	3296-73	Nut - Lock	8	1
93-1227	Shield - Carburetor	3	6	32104-118	Screw - Phillips Hd.	2	7
93-1231	Cover - Air Filter	3	2	32105-27	Screw - Hex Washer Hd.	1	29
93-1233	Gasket - Exhaust	4	12	32144-4	Screw - Tapping	1	3
93-1248	Shroud	3	20	32144-73	Screw - Hex Washer Hd.	7	11
93-4302	Screw - Sems	2	2	32144-111	Screw - Phillips Pan Hd.	7	1
93-4304	Rope	3	23	32144-121	Screw	7	8
93-4311	Cylinder & Crankcase Cover	5	15				
93-4320	Plug	3	4				
93-4320	Shield - Fuel	6	22				
93-7383	Guide - Rope	8	2				
93-8470	Screw - Clamp (P/W Eng.)	7	2				
2210-249	Clamp - Casing (P/W Eng.)	7	3				

OPTIONAL EQUIPMENT

- Recycler Side Discharge Kit Model No. 59291
- Recycler Bagging Kit Model No. 59290

*Not Illustrated

