


TORO®

MODEL NO. 38180-5900001 Thru
6900001 & UP
MODEL NO. 38181-5900001 Thru
6900001 & UP

**PARTS
CATALOG**

CCR 2000® SNOWTHROWER




**ONLY COPY
DO NOT REMOVE**
Tech. Publications

HOUSING ASSEMBLY

C-2121

Ref. No.	Part No.	Description	No. Used
1	321-6	Screw - Hex. Hd.	3
2	3256-22	Washer	9
3	321-4	Screw - Hex. Hd.	3
4	3296-42	Nut - Lock	16
5	55-9430	Bracket - Housing	1
6	56-2610	Bracket - Lower Housing	1
7	38-7820	Bearing - Ball	2
8	32149-2	Nut - Keps	3
9	3229-11	Screw - Carriage	3
10	3256-67	Washer	2
11	52-7280	Washer - Thrust	2
12	38-8620	Retainer - Bearing	1
13	55-8760	Scraper	1
14	32128-10	Nut - Flange Lock	2

Ref. No.	Part No.	Description	No. Used
15	55-9512	Cover - Bottom	1
16	55-9220	Housing - Lower	1
17	52-9110	Flange - Bearing	1
18	32105-15	Screw - Hex. Hd.	5
19	3234-25	Screw - Hex. Flange Hd.	1
20	52-7290	Retainer - Bearing	1
21	3256-24	Washer	1
22	52-7270	Washer - Rubber	1
23	55-8700	Housing	1
24	322-43	Screw - Hex. Hd.	1
25	55-8840	Sideplate - R.H.	1
26	38-8211	Pin	1
27	3296-2	Nut - Lock	3




C-2122

DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296-29	Nut - Lock	3
2	3241-7	Screw - Set, Sq. Hd.	1
3	55-9300	Belt - Drive	1
4	55-9180	Pulley - Engine	1
5	12-8279	Idler Arm Assembly (Incl. Ref. #17 & 18)	1
6	25-5640	Washer	1
7	55-9530	Guide - Drive Belt	1
8	27-0410	Screw - Shoulder	1
9	321-13	Screw - Hex. Hd.	1
10	60-9480	Decal - Belt Routing	1
11	36-3860	Screw - Special	1
12	55-9010	Cover - Drive	1
13	12-3270	Screw - Self Tapping	2
14	32105-15	Screw - Hex Head	2
15	323-29	Screw - Hex. Hd.	1
16	55-9290	Pulley - Idler	1
17	32112-11	Pushnut	1

Ref. No.	Part No.	Description	No. Used
18	55-9520	Roller - Brake	1
19	3296-42	Nut - Lock	6
20	55-9570	Pivot Plate Assembly	1
21	60-9320	Pulley - Rotor	1
22	321-30	Screw - Hex. Hd.	1
23	3290-456	Washer - Belleville	1
24	32105-8	Screw - Hex. Hd.	3
25	55-8851	Sideplate - L.H.	1
26	55-9620	Spacer	3
27	3274-31	Screw - Button Hd.	1
28	321-4	Screw - Hex Head	2
29	322-3	Screw - Hex. Hd.	2
30	55-9550	Arm - Brake	1
31	32152-2	Nut - Lock	1
32	55-9280	Spring - Extension	1
33	5-4460	Washer	2
34	3245-41	Screw - Set	1




C-0014

DISCHARGE CHUTE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	94-2900	Decal - Discharge (Model No. 38180)	1	10	55-8730	Gear - Worm/Spur	1
*	94-2901	Decal - Discharge (Model No. 38181)	1	11	84-5650	Bracket - Chute Gears	1
2	55-8950	Plate - Friction	2	12	55-9150	Shaft - Gear	1
3	94-2790	Chute - Discharge (Model No. 38180) (Incl. Ref. #1)	1	13	32112-11	Pushnut	2
*	94-2791	Chute - Discharge (Model No. 38181) (Incl. Ref. #1)	1	14	3256-22	Washer	6
4	32149-1	Nut - Keps	3	15	3296-42	Nut - Lock	6
5	3230-18	Screw - Carriage	3	16	3256-22	Washer	2
6	55-8720	Gear Ring - Chute	1	17	46-8092	Screw - Special	2
7	321-4	Screw - Hex. Hd.	6	18	55-8750	Spacer/Spur Gear	1
8	55-8910	Retainer - Chute Ring	2	19	55-8921	Ring - Chute Support	1
9	55-8740	Gear - Face	1	20	20-4320	Washer - Rubber	2
				21	3230-22	Bolt - Carriage	2
				22	3296-29	Nut - Lock	2
				23	3290-456	Washer - Belleville	2
				24	3256-68	Washer	2
				25	56-2680	Deflector	1

*Not Illustrated




C-1755

ROTOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	55-9202	Rotor Shaft Assembly	1
2	66-6600	Rotor Half	2
3	3296-56	Nut - Lock	13
4	55-9370	Spacer	4

Ref. No.	Part No.	Description	No. Used
5	84-1971	Screw - Countersunk	8
6	321-4	Screw - Hex. Hd.	4
7	321-8	Screw - Hex. Hd.	1
8	88-0771	Blade - Rotor	2




C-0016

ENGINE & MAIN FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3256-22	Washer	2
2	3296-42	Nut - Lock	4
3	2412-98	Clamp - Fuel Line	4
4	49-2481	Line - Fuel	2
5	56-6360	Filter - Fuel	1
7	250-4	Cable Tie	1
8	321-4	Screw - Hex. Hd.	4
10	12-2489	Engine Assembly	1
11	322-3	Screw - Hex. Hd.	2
12	3290-456	Washer - Belleville	5
13	55-9460	Mount - Rebound	2
14	55-9470	Tube - Spacer	2
15	66-6510	Wheel	2
16	32112-14	Pushnut	2

Ref. No.	Part No.	Description	No. Used
17	66-6501	Spacer - Wheel	1
18	81-0570	Bolt - Engine Mount	4
19	3296-29	Nut - Lock	5
20	55-9450	Mount - Load	2
21	55-9070	Support - Recoil	1
22	66-6500	Spacer - Wheel	1
23	81-0300	Nut - Lock	1
24	63-3750	Frame Assembly	1
25	237-89	Grommet	1
26	3256-23	Washer	1
27	32152-8	Nut - Lock	1
28	13-2459	Tank - Fuel (Incl. Ref. #25)	1
29	55-9310	Seal - Tank	1




C-0017

CONTROL PANEL & SHROUDING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	55-3573	Gas Cap Assembly	1
2	72-9970	Decal - CCR-2000	1
3	12-4659	Control Panel Assembly (Incl. Ref. #6-8 & 11)	1
4	55-9350	Nameplate - Control (Model No. 38180)	1
*	94-2570	Nameplate - Control (Model No. 38181)	1
5	32144-112	Screw - Hex Flange Hd.	3
6	55-9410	Guide - Starter Rope	1
7	44-2750	Body - Primer	1
8	66-7460	Bulb - Primer	1
9	40-5940	Switch - Key	1
10	63-8360	Key	1
11	55-8820	Fitting - Choke Control	1
12	55-8810	Control - Choke (Model No. 38180)	1
*	55-8811	Control - Choke (Model No. 38181)	1

Ref. No.	Part No.	Description	No. Used
13	61-4651	Linkage - Choke	1
14	3256-49	Washer	1
15	32144-111	Screw - Hex. Hd.	1
16	55-9210	Shield - Heat	1
17	32105-8	Screw - Hex. Hd.	4
18	218-532	Connector Body	1
19	44-3171	Hose - Primer	1
20	55-9660	Washer - Rubber	4
21	3256-14	Washer	4
22	3296-12	Nut - Lock	4
23	55-8791	Shroud - Lower	1
24	3290-474	Pushnut	8
25	55-9540	Retainer - Chute Seal	1
26	55-9260	Seal - Chute	1
27	94-2796	Upper Shroud Assembly (Incl. Ref. #2 & 24-26)	1
28	3256-22	Washer	2
29	3250-32	Screw - Phillips	2

*Not Illustrated




C-0018

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	66-6870	Decal - Rotor Drive (Model No. 38180)	1
*	94-2577	Decal - Rotor Drive (Model No. 38181)	1
2	3290-320	Pushnut	1
3	40-8230	Grip - Crank Handle	1
4	12-5939	Upper Handle Assembly (Incl. Ref. #1, Model 38180)	1
*	94-2794	Upper Handle Assembly (Incl. Ref. #1, Model 38181)	1
5	55-9100	Arm - Clutch Cable	1
6	3274-31	Screw - Button Hd.	1
7	55-9340	Spacer - Control Bar	2
8	32111-8	Nut - Flange Lock	2
9	3296-42	Nut - Lock	3
10	256-249	Nyliner	1
11	321-13	Screw - Hex. Hd.	2
12	55-9090	Support - Chute Crank	1
13	3-7501	Washer - Curved	2

Ref. No.	Part No.	Description	No. Used
14	61-8640	Screw - Hex. Hd.	2
15	17-9424	Screw - Handle	5
16	55-9390	Cover - Spring	1
17	55-9321	Cable - Clutch	1
18	55-9380	Adjuster - Clutch Cable	1
19	55-9270	Spring - Extension	1
20	55-9420	Bolt - Eye	1
21	322-9	Screw - Hex. Hd.	2
22	322-3	Screw - Hex. Hd.	2
23	3296-29	Nut - Lock	6
24	55-9121	Handle - Lower (Model 38180)	1
*	55-9120	Handle - Lower (Model 38181)	1
25	55-9140	Rod - Chute Crank	1
26	55-9440	Spring - Compression	1
27	55-9670	Washer - Rubber	1
28	55-9130	Bar - Control	1

*Not Illustrated



C-0019


SHORT BLOCK ASSEMBLY

MODEL NO. 47PS5-4

Ref. No.	Part No.	Description	No. Used
1	81-0350	Cylinders//Crankcase Asm	1
2	81-0590	Ring Set	1
3	81-0620	Circlip	2
4	81-0600	Pin - Wrist	1
5	81-2140	Piston	1
6	81-0720	Oil Seal	1
7	81-0710	Washer - Thrust	1
8	81-0690	Bearing - Upper	1
9	81-5700	Crankshaft	1
10	81-0540	Bolt	5
11	81-0770	Collar - Governor	1

Ref. No.	Part No.	Description	No. Used
12	81-0750	Centrifugal Bracket - Governor	1
13	81-0700	Bearing - Lower	1
14	81-0730	Washer - Thrust	1
15	81-0740	Oil Seal	1
16	81-0760	Pin - Governor	1
17	81-0610	Wrist Pin	1
18	81-0520	Dowel Pin - Crankcase	2
19	81-0570	Bolt	4
*	12-2479	Short Block (Incl. Ref. #1-19)	1

*Not Illustrated




C-0020A

FLYWHEEL & MAGNETO ASSEMBLY

MODEL NO. 47PS5-4

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	81-5710	Socket Hd. Capscrew	2	7	53-1340	Bolt	1
2	81-1330	Nut - Hex. Flange	1	8	81-2860	Wire - Ground	1
3	81-0320	Flywheel	1	9	50-1170	Spark Plug	1
4	81-2370	Woodruff Key	1	10	81-1500	Cover - Spark Plug	1
5	94-8890	Coil - Magneto	1	*	41-7650	Puller - Flywheel	1
6	81-1480	Clamp	1				

*Not Illustrated



C-0021


CARBURETOR ASSEMBLY

MODEL NO. 47PS5-4

Ref. No.	Part No.	Description	No. Used
1	81-0450	Screw	2
2	81-2700	Spitcup	1
3	81-2710	Screw	2
4	81-2720	Valve - Choke	1
5		Body - Carburetor	1
6	81-5510	Shaft - Choke (Incl. Ref. #30 & 31)	1
7	81-2920	Shaft - Throttle	1
8	81-2930	Jet - Pilot	1
9	81-2940	Valve - Throttle	1
10	81-2570	Gasket - Carburetor	3
11	81-0460	Insulator - Carburetor	1
12	50-6350	Bolt	2
13	81-0470	Manifold - Intake	1
14	50-2360	Screw - Pilot	1
15	81-2580	Spring - Pilot Screw	1
16	81-2590	Spring - Choke Detent	2
17	81-2600	Pin - Hinge	1
18	81-2610	Spring - Torsion	1
19	81-2740	Nozzle - Main	1
20	81-4920	Float	1

Ref. No.	Part No.	Description	No. Used
21	81-2630	Gasket - Float Bowl	1
22	81-2640	Bowl - Float	1
23	81-2650	Gasket - Bowl Screen	1
24	81-2660	Screw - Float Bowl	1
25	81-2670	Screw - Drain	1
26	81-2680	Gasket - Drain Screw	1
27	81-4930	Spacer - Float	1
28	81-1040	Jet - Main (#80)	1
*	81-1940	Jet - Main (#76.3)	1
29	81-4700	Needle	1
30	81-5520	Ring - Upper Choke	1
31	81-5530	Ring - Lower Choke	1
*	81-4690	Carburetor Assembly Complete	1
*	81-2910	Choke Shaft Ass'y (Incl. Ref. #6, 30, & 31)	1
*	81-5820	Needle Valve Seat Kit	1
*	92-6002	Carburetor Kit (Incl. Ref. #10, 18, 21, 26, 31, & Part No. 81-5820)	1

*Not Illustrated




C-0022

GOVERNOR ASSEMBLY

MODEL NO. 47PS5-4

Ref. No.	Part No.	Description	No. Used
1	81-0440	Spring - Carburetor	1
2	81-0430	Rod - Carburetor	1
3	81-0410	Arm - Governor	1
4	81-2880	Shaft - Governor	1
5	81-2890	Screw	1
6	81-0540	Bolt	1
7	81-2900	Spring - Compression	1

Ref. No.	Part No.	Description	No. Used
8	81-0370	Bracket - Governor	1
		Spring	1
9	81-0850	Oil Seal	1
10	81-0860	Washer	1
11	81-0870	E-Ring	1
12	81-0900	Nut - Hex.	1
13	81-0360	Spring - Governor	1




C-0023

MUFFLER ASSEMBLY
MODEL NO. 47PS5-4

Ref. No.	Part No.	Description	No. Used
1	81-1080	Gasket - Muffler	1
2	81-0490	Muffler	1
3	81-0500	Stud - Muffler	2

Ref. No.	Part No.	Description	No. Used
4	81-1120	Washer - Lock	2
5	81-1110	Nut - Hex.	2



C-0024

RECOIL STARTER ASSEMBLY

MODEL NO. 47PS5-4

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	53-1340	Bolt	3	14	81-1630	Handle - Recoil	1
2	81-0310	Shroud - Blower	1	15	81-1220	Spring - Dog	1
3	81-1290	Cup - Starter	1	16	81-1230	Dog - Starter	1
4	82-1300	Bolt	3	17	81-1260	Bolt	1
5	81-1250	Retainer - Dog	1	19	55-9620	Spacer	1
6	81-1240	Spring - Compression	1	*	81-0280	Recoil Assembly (Incl. Ref. No. 5-9, & 12-17)	1
7	81-1210	Reel - Rope Pulley	1				
8		Retainer - Recoil Spring	1				
9	81-0290	Case - Recoil	1	*	81-2300	Recoil Spring & Retainer Assembly (Incl. Ref. #8 & 12)	1
10	81-0390	Bolt	4				
11	81-0300	Nut - Lock	1				
12		Spring - Recoil	1				
13	81-1270	Rope	1				

*Not Illustrated

TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3-7501	Washer - Curved	7 13 2	55-9270	Spring - Extension	7 19 1
5-4460	Washer	2 33 2	55-9280	Spring - Extension	2 32 1
12-2479	Short Block	8 * 1	55-9290	Pulley - Idler	2 16 1
12-2489	Engine Assembly	5 10 1	55-9300	Belt - Drive	2 3 1
12-3270	Screw - Self Tapping	2 13 2	55-9310	Seal - Tank	5 29 1
12-4659	Control Panel Assembly	6 3 1	55-9321	Cable - Clutch	7 17 1
12-5939	Upper Handle Assembly	7 4 1	55-9340	Spacer - Control Bar	7 7 2
12-8279	Idler Arm Assembly	2 5 1	55-9350	Nameplate - Control	6 4 1
13-2459	Tank - Fuel	5 28 1	55-9370	Spacer	4 4 4
17-9424	Screw - Handle	7 15 5	55-9380	Adjuster - Clutch Cable	7 18 1
20-4320	Washer - Rubber	3 20 2	55-9390	Cover - Spring	7 16 1
25-5640	Washer	2 6 1	55-9410	Guide - Starter Rope	6 6 1
27-0410	Screw - Shoulder	2 8 1	55-9420	Bolt - Eye	7 20 1
36-3860	Screw - Special	2 11 1	55-9430	Bracket - Housing	1 5 1
38-7820	Bearing - Ball	1 7 2	55-9440	Spring - Compression	7 26 1
38-8211	Pin	1 26 1	55-9450	Mount - Load	5 20 2
38-8620	Retainer - Bearing	1 12 1	55-9460	Mount - Rebound	5 13 2
40-5940	Switch - Key	6 9 1	55-9470	Tube - Spacer	5 14 2
40-8230	Grip - Crank Handle	7 3 1	55-9512	Cover - Bottom	1 15 1
41-7650	Puller - Flywheel	9 * 1	55-9520	Roller - Brake	2 18 1
44-2750	Body - Primer	6 7 1	55-9530	Guide - Drive Belt	2 7 1
44-3171	Hose - Primer	6 19 1	55-9540	Retainer - Chute Seal	6 25 1
46-8092	Screw - Special	3 17 2	55-9550	Arm - Brake	2 30 1
49-2481	Line - Fuel	5 4 2	55-9570	Pivot Plate Assembly	2 20 1
50-1170	Spark Plug	9 9 1	55-9620	Spacer	13 19 1
50-2360	Screw - Pilot	10 14 1	55-9620	Spacer	2 26 3
50-6350	Bolt	10 12 2	55-9660	Washer - Rubber	6 20 4
52-7270	Washer - Rubber	1 22 1	55-9670	Washer - Rubber	7 27 1
52-7280	Washer - Thrust	1 11 2	56-2610	Bracket - Lower Housing	1 6 1
52-7290	Retainer - Bearing	1 20 1	56-2680	Deflector	3 25 1
52-9110	Flange - Bearing	1 17 1	56-6360	Filter - Fuel	5 5 1
53-1340	Bolt	13 1 3	60-9320	Pulley - Rotor	2 21 1
53-1340	Bolt	9 7 1	60-9480	Decal - Belt Routing	2 10 1
55-3573	Gas Cap Assembly	6 1 1	61-4651	Linkage - Choke	6 13 1
55-8700	Housing	1 23 1	61-8640	Screw - Hex. Hd.	7 14 2
55-8720	Gear Ring - Chute	3 6 1	63-3750	Frame Assembly	5 24 1
55-8730	Gear - Worm/Spur	3 10 1	63-8360	Key	6 10 1
55-8740	Gear - Face	3 9 1	66-6500	Spacer - Wheel	5 22 1
55-8750	Spacer/Spur Gear	3 18 1	66-6501	Spacer - Wheel	5 17 1
55-8760	Scraper	1 13 1	66-6510	Wheel	5 15 2
55-8791	Shroud - Lower	6 23 1	66-6600	Rotor Half	4 2 2
55-8810	Control - Choke	6 12 1	66-6870	Decal - Rotor Drive	7 1 1
55-8811	Control - Choke	6 * 1	66-7460	Bulb - Primer	6 8 1
55-8820	Fitting - Choke Control	6 11 1	72-9970	Decal - CCR-2000	6 2 1
55-8840	Sideplate - R.H.	1 25 1	81-0280	Recoil Assembly	13 * 1
55-8851	Sideplate - L.H.	2 25 1	81-0290	Case - Recoil	13 9 1
55-8910	Retainer - Chute Ring	3 8 2	81-0300	Nut - Lock	13 11 1
55-8921	Ring - Chute Support	3 19 1	81-0300	Nut - Lock	5 23 1
55-8950	Plate - Friction	3 2 2	81-0310	Shroud - Blower	13 2 1
55-9010	Cover - Drive	2 12 1	81-0320	Flywheel	9 3 1
55-9070	Support - Recoil	5 21 1	81-0350	Cylinders//Crankcase Asm	8 1 1
55-9090	Support - Chute Crank	7 12 1	81-0360	Spring - Governor	11 13 1
55-9100	Arm - Clutch Cable	7 5 1	81-0370	Bracket - Governor	11 8 1
55-9120	Handle - Lower	7 1	81-0390	Bolt	13 10 4
55-9121	Handle - Lower	7 24	81-0410	Arm - Governor	11 3 1
55-9130	Bar - Control	7 28 1	81-0430	Rod - Carburetor	11 2 1
55-9140	Rod - Chute Crank	7 25 1	81-0440	Spring - Carburetor	11 1 1
55-9150	Shaft - Gear	3 12 1	81-0450	Screw	10 1 2
55-9180	Pulley - Engine	2 4 1	81-0460	Insulator - Carburetor	10 11 1
55-9202	Rotor Shaft Assembly	4 1 1	81-0470	Manifold - Intake	10 13 1
55-9210	Shield - Heat	6 16 1	81-0490	Muffler	12 2 1
55-9220	Housing - Lower	1 16 1	81-0500	Stud - Muffler	12 3 2
55-9260	Seal - Chute	6 26 1	81-0520	Dowel Pin - Crankcase	8 18 2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3317-184B

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
81-0540	Bolt	11 6 1	81-2940	Valve - Throttle	10 9 1
81-0540	Bolt	8 10 5	81-4690	Carburetor Assembly	10 * 1
81-0570	Bolt	8 19 4	81-4700	Needle	10 29 1
81-0570	Bolt - Engine Mount	5 18 4	81-4920	Float	10 20 1
81-0590	Ring Set	8 2 1	81-4930	Spacer-Float	10 27 1
81-0600	Pin - Wrist	8 4 1	81-5510	Shaft - Choke	10 6 1
81-0610	Wrist Pin	8 17 1	81-5520	Ring - Upper Choke	10 30 1
81-0620	Circlip	8 3 2	81-5530	Ring - Lower Choke	10 31 1
81-0690	Bearing - Upper	8 8 1	81-5700	Crankshaft	8 9 1
81-0700	Bearing - Lower	8 13 1	81-5710	Socket Hd. Capscrew	9 1 2
81-0710	Washer - Thrust	8 7 1	81-5820	Needle Valve Seat Kit	10 * 1
81-0720	Oil Seal	8 6 1	82-1300	Bolt	13 4 3
81-0730	Washer - Thrust	8 14 1	84-1971	Screw - Countersunk	4 5 8
81-0740	Oil Seal	8 15 1	84-5650	Bracket - Chute Gears	3 11 1
81-0750	Centrifugal Bracket	8 12 1	88-0771	Blade - Rotor	4 8 2
81-0760	Pin - Governor	8 16 1	92-6002	Carburetor Kit	10 * 1
81-0770	Collar - Governor	8 11 1	94-2570	Nameplate - Control	6 * 1
81-0850	Oil Seal	11 9 1	94-2577	Decal - Rotor Drive	7 * 1
81-0860	Washer	11 10 1	94-2790	Chute - Discharge	3 3 1
81-0870	E-Ring	11 11 1	94-2791	Chute - Discharge	3 * 1
81-0900	Nut - Hex.	11 12 1	94-2794	Upper Handle Assembly	7 * 1
81-1040	Jet - Main (#80)	10 28 1	94-2796	Upper Shroud Assembly	6 27 1
81-1080	Gasket - Muffler	12 1 1	94-2900	Decal - Discharge	3 1 1
81-1110	Nut - Hex.	12 5 2	94-2901	Decal - Discharge	3 * 1
81-1120	Washer - Lock	12 4 2	94-8890	Coil - Magneto	9 5 1
81-1210	Reel - Rope Pulley	13 7 1	218-532	Connector Body	6 18 1
81-1220	Spring - Dog	13 15 1	237-89	Grommet	5 25 1
81-1230	Dog - Starter	13 16 1	2412-98	Clamp - Fuel Line	5 3 4
81-1240	Spring - Compression	13 6 1	250-4	Cable Tie	5 7 1
81-1250	Retainer - Dog	13 5 1	256-249	Nyliner	7 10 1
81-1260	Bolt	13 17 1	321-4	Screw - Hex. Hd.	2 28 2
81-1270	Rope	13 13 1	321-4	Screw - Hex. Hd.	1 3 3
81-1290	Cup - Starter	13 3 1	321-4	Screw - Hex. Hd.	4 6 4
81-1330	Nut - Hex. Flange	9 2 1	321-4	Screw - Hex. Hd.	3 7 6
81-1480	Clamp	9 6 1	321-4	Screw - Hex. Hd.	5 8 4
81-1500	Cover - Spark Plug	9 10 1	321-6	Screw - Hex. Hd.	1 1 3
81-1630	Handle - Recoil	13 14 1	321-8	Screw - Hex. Hd.	4 7 1
81-1940	Jet - Main (#76.3)	10 * 1	321-13	Screw - Hex. Hd.	2 9 1
81-2140	Piston	8 5 1	321-13	Screw - Hex. Hd.	7 11 2
81-2300	Recoil Spring & Retainer	13 * 1	321-30	Screw - Hex. Hd.	2 22 1
81-2370	Woodruff Key	9 4 1	322-3	Screw - Hex. Hd.	5 11 2
81-2570	Gasket - Carburetor	10 10 3	322-3	Screw - Hex. Hd.	7 22 2
81-2580	Spring - Pilot Screw	10 15 1	322-3	Screw - Hex. Hd.	2 29 2
81-2590	Spring - Choke Detent	10 16 2	322-9	Screw - Hex. Hd.	7 21 2
81-2600	Pin - Hinge	10 17 1	322-43	Screw - Hex. Hd.	1 24 1
81-2610	Spring - Torsion	10 18 1	323-29	Screw - Hex. Hd.	2 15 1
81-2630	Gasket - Float Bowl	10 21 1	3229-11	Screw - Carriage	1 9 3
81-2640	Bowl - Float	10 22 1	3230-18	Screw - Carriage	3 5 3
81-2650	Gasket - Bowl Screen	10 23 1	3230-22	Bolt - Carriage	3 21 2
81-2660	Screw - Float Bowl	10 24 1	3234-25	Screw - Hex. Flange Hd.	1 19 1
81-2670	Screw - Drain	10 25 1	3241-7	Screw - Set, Sq. Hd.	2 2 1
81-2680	Gasket - Drain Screw	10 26 1	3245-41	Screw - Set	2 34 1
81-2700	Spitcup	10 2 1	3250-32	Screw - Phillips	6 29 2
81-2710	Screw	10 3 2	3256-14	Washer	6 21 4
81-2720	Valve - Choke	10 4 1	3256-22	Washer	5 1 2
81-2740	Nozzle - Main	10 19 1	3256-22	Washer	1 2 9
81-2860	Wire - Ground	9 8 1	3256-22	Washer	3 14 6
81-2880	Shaft - Governor	11 4 1	3256-22	Washer	3 16 2
81-2890	Screw	11 5 1	3256-22	Washer	6 28 2
81-2900	Spring - Compression	11 7 1	3256-23	Washer	5 26 1
81-2910	Choke Shaft Ass'y	10 * 1	3256-24	Washer	1 21 1
81-2920	Shaft - Throttle	10 7 1	3256-49	Washer	6 14 1
81-2930	Jet - Pilot	10 8 1	3256-67	Washer	1 10 2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3256-68	Washer	3 24 2	32105-8	Screw - Hex. Hd.	6 17 4
3274-31	Screw - Button Hd.	7 6 1	32105-8	Screw - Hex. Hd.	2 24 3
3274-31	Screw - Button Hd.	2 27 1	32105-15	Screw - Hex Head	2 14 2
3290-320	Pushnut	7 2 1	32105-15	Screw - Hex. Hd.	1 18 5
3290-456	Washer - Belleville	5 12 5	32111-8	Nut - Flange Lock	7 8 2
3290-456	Washer - Belleville	2 23 1	32112-11	Pushnut	3 13 2
3290-456	Washer - Belleville	3 23 2	32112-11	Pushnut	2 17 1
3290-474	Pushnut	6 24 8	32112-14	Pushnut	5 16 2
3296-2	Nut - Lock	1 27 3	32128-10	Nut - Flange Lock	1 14 2
3296-12	Nut - Lock	6 22 4	32144-111	Screw - Hex. Hd.	6 15 1
3296-29	Nut - Lock	5 19 5	32144-112	Screw - Hex Flange Hd.	6 5 3
3296-29	Nut - Lock	3 22 2	32149-1	Nut - Keps	3 4 3
3296-29	Nut - Lock	7 23 6	32149-2	Nut - Keps	1 8 3
3296-42	Nut - Lock	5 2 4	32152-2	Nut - Lock	2 31 1
3296-42	Nut - Lock	1 4 16	32152-8	Nut - Lock	5 27 1
3296-42	Nut - Lock	7 9 3			
3296-42	Nut - Lock	3 15 6			
3296-42	Nut - Lock	2 19 6			
3296-56	Nut - Lock	4 3 13			

OPTIONAL EQUIPMENT

Snow Cab Kit Part No. 88-0600