
FORM NO. 3317−229 Rev. A

TORO®

MODEL NO. 07344−40001 & UP

PARTS CATALOG

1/3 PLATFORM LIFT
FOR WORKMAN VEHICLE




T−1937

DECK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3712	Push Button Sta. w/Cord	1
2	92−9145	Key & Switch	1
3	93−3705	Decal − Danger	1
4	74−0720	Tube − Manual	1
5	3230−18	Bolt − Carriage	2
6	2412−133	R−Clamp	2
7	93−3707	Decal − Danger	2
8	93−3706	Decal − Danger	2
9	93−3701	Decal − Danger	1

Ref. No.	Part No.	Description	No. Used
10	3296−2	Nut − Lock	4
11		Decal − Danger	2
12		Decal − Danger	1
13	3250−12	Screw − Pan Phillips Head	4
14	93−3738	Plate − Kit, Decals (Incl. Ref. #10−15)	1
15		Decal − Danger	1
16	32128−20	Nut − Flange Head	2

© The TORO Company − 1995
All Rights Reserved




T−1938

ARM AND CYLINDER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3746	Adaptor − Fitting	1
2	93−3735	Assembly − Hose	1
3	93−3733	Control − Flow, Fixed	1
4	93−3747	Fitting − Reducer, Hex.	1
5	93−3749	Adaptor − Fitting	1
6	93−3706	Decal − Danger	2
7		Breather (w/Ref. #9)	1
8	250−5	Tie − Cable	7

Ref. No.	Part No.	Description	No. Used
9	93−3734	Cylinder − Hydraulic (Incl. Ref. #7)	1
10	93−3713	Limit Switch w/Lever	1
11	93−3711	Decal − Important	1
12	93−3708	Decal − Danger	1
13	93−3736	Pin − Quick Release	1
14		Block − Wood (1−1/2 x 1−7/8 x 7”)	2




T−1939

BRAKE SWITCH AND COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3709	Decal − No Step	2
2		Channel − Base	2
3	93−3737	Cover − Base	1
4	323−6	Screw − Cap Hex. Head	4
5	3253−5	Washer − Lock	4
6		Plate − Reinforcing	2
7	32128−29	Nut − Flange Head	2
8	3234−29	Screw − Flange, Hex. Head	4
9	32128−35	Nut − Flange Head	4
10	93−3722	Switch − Brake, Parking	1

Ref. No.	Part No.	Description	No. Used
11	3256−77	Washer − Flat	2
12	32105−14	Screw − Pan Phillips Head	2
14		Spacer − Short	1
15	3296−12	Nut − Lock	2
16	93−3710	Decal − Warning	1
17	93−3726	Level − Circular w/Adhesive	1
18		Spacer − Long	1
*	93−3727	Kit − Brake, Parking (Incl. Ref. #10−15, & 18)	1
*	250−5	Tie − Cable	2

*Not Illustrated



T−1940


POWER PACK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	323−3	Screw − Cap Hex. Head	2
2	3253−5	Washer − Lock	2
3	93−3732	Power Unit − DC Hydraulic	1
4	3296−12	Nut − Lock	4
5	93−3724	Switch − Mercury	2
6	93−3723	Kit − Switch, Leveling (Incl. Ref. #4−11)	1
7		Bracket − Switch, Level	1
8	3250−12	Screw − Pan Phillips Head	4
9	93−3725	Cable − Positive, w/Boot	1


Ref. No.	Part No.	Description	No. Used
*	93−3745	Cable − Negative, Battery	1
10	92−9144	Valve − Solenoid W/O Ride	1
11	93−3748	Adaptor − Fitting	1
12	94−2864	Relay Switch Kit	1
*	93−3718	Kit − Wire Harness, Front	1
*	63−7590	Relay	1
*	93−3721	Relay	1
*	93−7315	Horn − Warning	1
*	250−5	Tie − Cable	3

*Not Illustrated

ELECTRICAL SCHEMATIC



HYDRAULIC SCHEMATIC



T−1941

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.